


CONTROLS – 12 Tact Switches

Active-low with 10k pull-up + 100nF debounce per button


D-PAD

UP (GPIO40)




FACE BUTTONS (ABXY)

A (GPIO2)




SYSTEM + SHOULDER


START (GPIO18)




DOWN (GPIO41)




B (GPIO48)




SELECT (GPIO00)




LEFT (GPIO42)




X (GPIO47)




L (GPIO45)




RIGHT (GPIO1)




Y (GPIO21)



R (GPIO3)



MENU BUTTON



Generated by scripts/generate_schematics
ESP32 Emu Turbo – Handheld Retro Console

Sheet: /

File: 06-controls.kicad_sch

Title: Controls – 12 Buttons (SNES Layout)

Size: A3

Date:

KiCad E.D.A. 10.0.0-rc1.1-513-g294bfe097a

Rev:

Id: 6/1

BUTTON CIRCUIT (repeated 12x):