


CONTROLS – 12 Tact Switches


Active-low with 10k pull-up + 100nF debounce per button

D-PAD


UP (GPIO40)




DOWN (GPIO41)



LEFT (GPIO42)




RIGHT (GPIO1)




FACE BUTTONS (ABXY)


A (GPIO2)




B (GPIO48)



X (GPIO47)




Y (GPIO21)




SYSTEM + SHOULDER


START (GPIO18)




SELECT (GPIO00)




L (GPIO45)



R (GPIO3)



MENU BUTTON



BUTTON CIRCUIT (repeated 12x):