


CONTROLS – 12 Tact Switches


Active-low with 10k pull-up + 100nF debounce per button

D-PAD


UP (GPIO40)




DOWN (GPIO41)



LEFT (GPIO42)




RIGHT (GPIO1)




FACE BUTTONS (ABXY)


A (GPIO2)




B (GPIO48)



X (GPIO47)




Y (GPIO21)




SYSTEM + SHOULDER


START (GPIO18)



SELECT (GPIO0)




L (GPIO45)



R (GPIO3)

MENU BUTTON



Generated by scripts/generate_schematics
ESP32 Emu Turbo – Handheld Retro Console

Sheet: /

File: 06-controls.kicad_sch

Title: Controls – 12 Buttons (SNES Layout)

Size: A3

Date:

KiCad E.D.A. 10.0.0-rc1.1-513-4294bfe097a

Rev:

Id: 6/1

BUTTON CIRCUIT (repeated 12x):