Displaying joint coordinates							
POSITION							
	Joint	Too	l: 1				
	J1:	90.045 J2	: 42.19	5 J3:	29.336		
	J4:	40.000 J5	: 10.00	0 J6:	20.000		
	E1:	11.942 E2	: ****	* E3:	****		
	J2/J3	Interaction	on: 71	1.531			
(J7) G1 / J7			11.942				
(J8) G2 / J1				3.780			
			1	1	1	1	
	[TYPE]	JNT	USER	WORLD			
Displaying would accordingto eveters							
Displaying world coordinate system							
POSITION							
		_					
	World	To	ol: 1				
	World						
	World Config	uration: 1	N U T, 0,				
	World Config		N U T, 0,		956.895		
	World Config X: 1 W:	uration: 1 380.000 40.000	N U T, 0, y: -380. P: -12.	992 z: 676 r:	20.000		
	World Config X: 1 W:	uration: 1	N U T, 0, y: -380. P: -12.	992 z: 676 r:	20.000		
	World Config X: 1 W:	uration: 1 380.000 40.000	N U T, 0, y: -380. P: -12.	992 z: 676 r:	20.000		
	World Config X: 1 W:	uration: 1 380.000 40.000	N U T, 0, y: -380. P: -12.	992 z: 676 r:	20.000		
	World Config X: 1 W:	uration: 1 380.000 40.000 11.942 E	N U T, 0, y: -380. P: -12.	992 z: 676 r:	20.000		
	World Config X: 1 W: E1:	uration: 1 380.000 40.000 11.942 E	N U T, 0, y: -380. P: -12.	992 z: 676 r: *** E3:	20.000 *****		
	World Config X: 1 W: E1: (J7) G	uration: 1 380.000 40.000 11.942 E	N U T, 0, y: -380. P: -12.	.992 z: .676 r: **** E3:	20.000 *****		