



This document describes the firmware update procedure for MADC-32. The latest firmware file can be found at http://mesytec.com/downloads/firmwareupdates/firmware VME.html

Requirements

- XILINX Platform Cable USB II
- XILINX Lab Tools 14.7 Utilities
- The latest MADC-32 firmware file
- These steps are for Windows

Table of Contents

Download and License Start and Configuration Connection


Cable Setup
Programming
Project saving

Download and License

Download the "Lab Tools – 14.7 Utilities" from the following link. In order to download the software, it is necessary to register on the XILINX homepage.

 $\underline{https://www.xilinx.com/support/download/index.html/content/xilinx/en/downloadNav/design-tools.html}\\$

- After the download is complete, unzip the zip-file.
- Open the directory, click on "xsetup.exe" and follow the installer's instructions.
- When the installation is complete, the "Xilinx License Configuration Manager" window opens.
- Follow the pictures.




• Fill in the "Product Licensing - Name and Address Verification" form, then click next.

 $\underset{\scriptscriptstyle{V1.0}}{\text{MADC-32}}$

• Download your License.








Start and Configuration

- Connect the "XILINX Programming Device" with the USB-Cable to your PC.
- The USB driver is automatically installed by Windows. Wait until the installation is complete.
- The Status-LED should be yellow.
- Connect the "XILINX Adapter Plate with the coloured cables" to the Programming Device.


• Start the program from the Start menu. Be sure to start the 32 bit or 64 bit version depending on

the operating system version you are using.











- Double Click on "Boundary Scan"
- Then right click into the right window and "Add Xilinx Device..."




- In the next window load the "MADC-32 Firmware File" and click open.
- In the Window "Select Device Part Name" choose xcf02s and click OK.








• You can see the XILINX Device Icon with the MADC-32 Firmware on the right window in the programmer tool.



Connection

- Connect the Cables to the MADC-32 and power on the MADC-32.
- The Status-LED should turn green.









Cable Setup


These settings must be performed only once.






Programming

• Right click on the XILINX Device and click Program.





The MADC-32 Firmware is now updated

Project saving

• All settings can be stored to update other MADC-32 at a later time.

