Enable WIFI on Pi 3 using Command Line

1. Scan WIFI networks

To scan WIFI networks use following command

sudo iwlist wlan0 scan

Locate your SSID (Your WIFI Name)

2. Adding the network details to the raspberry pi

Open file /etc/wpa_supplicant/wpa_supplicant.conf with some editor of your own choice

Append following lines at the end of the file

```
network={
    ssid="Your WIFI network name"
    psk="Your_wifi_password"
}
```

3. Save the file and reboot your raspberry pi

*** Your Raspberry Pi has been connected ***