

ID1-ID5 servos: the yellow wire of the servo is connected to "S", the red wire to "+", the brown wire to "-".

ID6 servo: the white line of the servo connects to "S", the red wire to "+", the black wire to "-".

