Public Lab | Wiki documentation




Infragram Point & Shoot -

« Back to Infragram

The Infragram Point & Shoot is a handheld, battery powered mini camera (a modified Mobius Action Cam) for doing plant analysis. It has been modified at the factory to replace its infrared-blocking filter with a red filter, effectively exchanging its blue light channel for infrared light. This is based on a great deal of research by Public Lab contributors (http://publiclab.org/tag/infragram) and was initially pioneered in our community by [@nedhorning](/profile/nedhorning) and [@cfastie] (/profile/cfastie). See especially these (http://publiclab.org/notes/cfastie/04-22-2014/mobius-ir-conversion) two (http://publiclab.org/notes/cfastie/04-18-2014/mobius-filter-o-matic) research notes.

Vineyards, large farms, and NASA all use near-infrared photography (http://publiclab.org/wiki/near-infrared-camera) for assessing plant health, usually by mounting expensive sensors on airplanes and satellites. At Public Lab (http://publiclab.org), we've developed a Do-It-Yourself way to take these kinds of photos, enabling us to monitor our environment through quantifiable data.



(http://i.publiclab.org/system/images/photos/000/005/386/original/5412520298_93873f36d0_o.pnc

Our technique uses a modified digital camera to capture near-infrared and red light in the same image, but in different color channels. We then post-process the image to attempt to infer how much it is photosynthesizing. This allows us to better understand and quantify how much of the available light plants are metabolizing into sugar via photosynthesis.

Basics

Before you begin, to take useful plant analysis photos, you'll have to modify your camera's white balance, so that vegetation looks "bluish" but there is not an overall red tinge to the images. You can achieve this with a custom config file, as described below.

Some cameras may require a firmware upgrade to v1.20. If you've gotten your Infragram Point & Shoot from Public Lab's Kits initiative (through Kickstarter

(http://kickstarter.com/projects/publiclab/infragram-the-infrared-photography-project) or the Public Lab store (http://store.publiclab.org)), both the config file and the v1.20 firmware should be on the SD card provided (in addition to this documentation!). However, you'll still have to load up the white balance file as described in "Installing config file" below.

Troubleshooting

If you have trouble, please post on this site (/post?tags=question:infragram&template:question) or join the infrared discussion list (/lists).


For any information, support, or troubleshooting not covered here, please look to this epic thread about the Mobius Action Cam at RCGroups.com

(http://www.rcgroups.com/forums/showthread.php?t=1904559) which contains a great deal of

information about using and modifying the camera. An official manual for the Mobius Action Cam can also be found here: http://mobius-actioncam.com/softwareuser-guide/ (http://mobius-actioncam.com/softwareuser-guide/)

Using the camera

There are three basic modes to the camera, which you can switch through with the **M** button, and each shows a different color on the main LED.



(http://i.publiclab.org/system/images/photos/000/005/381/original/modes.png)

(Artwork based on: http://publiclab.org/notes/mathew/05-10-2014/illustrating-infragram-point-shoot-instructions (http://publiclab.org/notes/mathew/05-10-2014/illustrating-infragram-point-shoot-instructions)) Once you've loaded the custom white balance in the config file (see below) and charged up the camera, you're ready to use it -- just turn it on, press **M** twice, until you see a RED light. Then you can use the "Shutter" button which looks like: , to take photos. The red light will blink.

Images should look roughly like this:



(http://i.publiclab.org/system/images/photos/000/005/383/original/good-bad.png)

Installing config file

If your camera did not ship with a config file or you are using a new SD card, **follow these steps to get your Infragram Point & Shoot to take properly white-balanced images**, necessary for post processing at Infragram.org (http://infragram.org). This is also relevant for anyone who has a Mobius Action Cam and wants to script or customize its settings.

The config file may also be used to set up **Timelapse Mode** -- see below at the Timelapse section (#Timelapse).

Note: The WB setting in the config file should be "7" but occasionally we've found that some cameras require an "8" -- if you have trouble, please post to the plots-infrared list (/lists).

- 1. turn the camera on with the "Power" button *while* also pressing "Mode" until the red light blinks 3 times (5-6 secons) to generate a config
- 2. plug it in via USB and wait for the disk to appear
- 3. replace the generated config file with this one in the home directory: \(\Delta\) SYSCFG.TXT (http://i.publiclab.org/system/images/photos/000/005/385/original/SYSCFG.TXT) or \(\Delta\) SYSCFG.TXT (http://i.publiclab.org/system/images/photos/000/005/225/original/SYSCFG.TXT) for a 2-second timelapse mode.
- 4. repeat turn on pressing mode.

Timelapse


To set the camera to Timelapse mode, you'll need to follow the above instructions for uploading a custom config file; you can use this one to have a 2-second timelapse, or tweak the

Set Time Lapse Shooting line for an interval you prefer: SYSCFG.TXT

(http://i.publiclab.org/system/images/photos/000/005/225/original/SYSCFG.TXT)

To start timelapse mode:

- 1. Turn on the camera
- 2. Press M twice to enter Photo Mode
- 3. Press the shutter button () to start the timer, and look for the blinking red light:



(http://i.publiclab.org/system/images/photos/000/005/384/original/timelapse.png)

(Artwork based on: http://publiclab.org/notes/mathew/05-10-2014/illustrating-infragram-point-shoot-instructions (http://publiclab.org/notes/mathew/05-10-2014/illustrating-infragram-point-shoot-instructions))

Updating firmware

v1.20 firmware:

Excerpted from RCGroups.com (http://www.rcgroups.com/forums/showthread.php?t=1904559):

- 1. Download the firmware .zip archive file and un-zip it. Copy the actual firmware fil e (always named FWTLCAM.BIN as noted above) from it's identifying folder into the came ra's flash card root directory (the one that opens when the camera connects as a remov able drive). This can be done with the card in the camera connected to the computer as a Removable Drive, or externally in a card reader. But do NOT rename the file. If you do, the camera will not install it!
- 2. Disconnect the camera and turn it off.
- 3. Insert the flash card containing the new firmware file into the camera (if not alre ady in the camera).
- 4. Press the Power button until the BLUE LED turns on and begins to flash. RELEASE THE POWER BUTTON AS SOON AS LED FLASHING BEGINS! If you keep pressing it longer, you may turn off the camera before the update process is done. DO NOT PRESS ANY BUTTONS WHILE THE INSTALLATION IS IN PROGRESS (about 20 sec. to complete)
- 5. To confirm the firmware is being loaded into the camera, the BLUE LED will continue to blink during the upload process.
- 6. When the FW installation is complete, the BLUE LED will turn off for about 2 sec. a nd the YELLOW LED will then turn on solid, indicating the FW file is has been automatically deleted from the memory card.
- 7. You're done! The camera will be in the normal start-up standby mode ready for use.`

Resources

Kit insert: infragram-ps-insert.pdf

(http://i.publiclab.org/system/images/photos/000/005/388/original/infragram-ps-insert.pdf)

This work is licensed under a Creative Commons Attribution-ShareAlike 3.0 Unported License. Hardware designs on this site are released under the CERN Open Hardware License 1.1. Read more about Public Laboratory's open source licensing here.