



1. Connect the pump to the motor driver black --> OUTC
2. Connect the pump to the motor driver red --> OUTD
3. Load blink and disconnect from computer
4. Arduino Pin 13 --> ind
5. Arduino GND --> inc
6. Arduino red pin V --> red female pin on the motor driver
7. Arduino black pin G --> black female pin on the motor driver
8. Insert Batteries MATCH POLARITY!!!
9. Battery Black --> Black male pin on the motor driver
10. Battery Red --> Red male pin on the motor driver