Strength of Materials

Practical Problem:

In the professional field, a Designer faces one of the two following problems:

- (i) For a given lexternal load voysem, designer has to economically design the member (i.e. shape 4 Size) so that it can wafely withstand the external load without being shructurally damaged or functionally unserviceable.
- (ii) To find out the maximum external load which can be safely applied on a given load carrying member beyond which it will be structurally of functionally unserviceable.


Strength of Materials

- A load carrying member may be called whuchurally damaged or functionally Unserviceable if:


 (a) the internal force created due to applied external load is more than the limiting resistance capacity of the member Strength
 - (b) the elastic deformation exceeds certain limiting value } Stiffness
- (e) the initial Configuration of the member becomes unstable } Stability
- The term External load is used in a generalized Sense. It may be Force, Moment, Torque
- The term Deformation is used in generalized Some. It may be elongation from pression, Deflector Angle of Twist, change of shape

Strength of Materials

Topics		
Properties of Materials		
Stress & Strain		
Shear force & Bending moment in Beams		
Flexural or Bending Stress in Straight Beams (Theory of pure bending)	Strength (S)	Rigidity (R)
Shear stress in Straight Beams	Strength (S)	
Torsion of circular shafts	Strength (S)	Rigidity (R)
Combined loading (Mohr's circle for stress)	Strength (S)	
Deflection of beams		Rigidity (R)
Columns	Stability (S)	



Fundamentals of Stress





When total force or total load (gradually applied) carried by the body is uniformly distributed over its cross section, the **average stress** (**uniformly distributed stress**) induced in the body is:




In order to fulfill this assumption of uniform stress distribution, the following conditions must be satisfied


- The bar/member must be straight & made of homogeneous & isotropic material.
- The line of action of the resultant force contains the centroid of the section.
- That portion of the member being considered must have a uniform c/s & remote from discontinuity or abrupt change in c/s.
- The stress must be computed for section well remote from the section on which the load is applied since the stresses in the vicinity of the contact areas are highly concentrated.







S.no	Types of Support	Representation by	Reaction Force	Resisting Load
1.	Roller Support		Vertical	Vertical loads
2.	Pinned Support	A	Horizontal and vertical	Vertical and horizontal loads
3.	Fixed Support	1	Horizontal, vertical and moments	All types of loads Horizontal, vertical and Moments
4.	Simple Support		Vertical	Vertical loads







Flexural or Bending Stress in Straight Beams




Concept of pure bending

Elastic Flexure formula: Bernoulli-Euler Flexure Formula

$$\frac{M}{I} = \frac{\sigma}{y} = \frac{E}{R}$$


$$\sigma_{\text{max}} = \frac{M}{I} y_{\text{max}} = \frac{M}{Z}$$


Section Modulus Z=I/y_{max}




The following assumptions must be satisfied

- The beam is subjected to pure bending (shear force=0, no torsion, no axial loads).
- The beam is initially straight with a c/s that is constant throughout the length.
- The beam has an axis of symmetry in the plane of bending.
- Plane c/s of the beam remain plane during bending.
- Couples are assumed to be loaded in the plane of symmetry.
- The beam material is homogeneous, isotropic & obeys Hooke's law.






Calculation of MoI of the cross section about NA



Dia.: 33.85 mm




Inner Dia.: 30 mm Outer Dia.: 45 mm


	Solid Circular	Hollow circular
Area (A)	sq. mm	sq. mm
MoI (I)		
Section Modulus (Z)		
Remarks		

Example A beam 240 mm \times 400 mm weighing 500 N/m is simply supported over a span of 4 m. It carries a concentrated load of 20,000 N at a distance 1 m from the left support. Determine (i) maximum stress in the beam (ii) maximum stress at the mid span (iii) stress at 50 mm below the top fibre at the section of maximum bending moment (iv) percentage of bending moment resisted by the central and outer half of the cross-section (v) nature of variation of maximum stress at a section along the length of beam (vi) nature of variation of curvature along the length of the beam and its maximum value. Given

 $E = 1 \times 10^4 \text{ N/mm}^2$

- 1. Determination of maximum bending moment or the bending moment at the required section by drawing S.F.D. and B.M.D.
- 2. Determination of centroid of the cross-section and thus fix up the position of neutral axis.
- 3. Calculate the moment of inertia of the cross-section about neutral axis.
- 4. Determine y_1 and y_2 i.e., the distance of the extreme fibres from neutral axis.
- 5. Apply the "Flexure Formula".





Transverse shearing stresses due to bending

In addition to normal stresses induced by bending of a beam, transverse shearing stresses are induced between the elements, provided the bending moment varies along the length of the beam.

 $\tau = \frac{V}{Ib} \int_{z}^{c} y dA = \frac{VQ}{Ib}$


I: MOI of c/s about NA

V: Shear force at beam section under consideration

b: Beam width at section

Q: Moment of area of element about NA

z: Location where shear stress is desired





12 January 2023

MACHINE DESIGN

Maximum Values of Transverse Shear Stress

Beam Shape	Formula	Beam Shape	Formula
$\tau_{\rm avc} = \frac{V}{A}$ Rectangular	$\tau_{\text{max}} = \frac{3V}{2A}$	$\tau_{\rm avc} = \frac{V}{A}$ Hollow, thin-walled round	$ \tau_{\text{max}} = \frac{2V}{A} $
$\tau_{\rm avc} = \frac{V}{A}$ Circular	$\tau_{\text{max}} = \frac{4V}{3A}$	Structural I beam (thin-walled)	$ au_{ ext{max}} \doteq rac{V}{A_{ ext{web}}}$





Difference between Bending Moment and Twisting Moment

Bending Moment (BM)

- 1. In bending, moment or couple acts about transverse axis
- 2. In bending, the plane of cross-section rotates about NA
- Due to bending, normal stresses are produced which vary from zero at NA to maximum at top and bottom surface i.e., at extreme fibres.

Twisting Moment (TM)


- 1. In twisting, couple acts about longitudinal axis or polar axis.
- 2. In twisting, plane of cross-section rotates about polar axis. Hence, radii rotate about polar axis.
- Due to twisting, only shear stresses are produced which acts in two mutually perpendicular planes and vary from zero at polar axis to maximum at the surface in circumferential directions.

Transverse Axis: Y-axis & Z-axis

Moment about transverse axis causes Bending Moment.

Longitudinal Axis: X-axis

Moment about longitudinal axis causes rotation about that axis. This moment is called twisting moment or torsional moment or Torsion



 \mbox{My} & \mbox{Mz} causes rotations about transverse axis. Hence \mbox{My} & \mbox{Mz} are Bending moments

Mx causes rotations about longitudinal axis or polar axis. Hence Mx is twisting moment or torsional moment or Torsion

A circular prismatic bar or circular shaft

Difference between Bending Moment and Twisting Moment

Bending Moment (BM)


- 1. In bending, moment or couple acts about transverse axis
- 2. In bending, the plane of cross-section rotates about NA
- Due to bending, normal stresses are produced which vary from zero at NA to maximum at top and bottom surface i.e., at extreme fibres.

Twisting Moment (TM)

- 1. In twisting, couple acts about longitudinal axis or polar axis.
- 2. In twisting, plane of cross-section rotates about polar axis. Hence, radii rotate about polar axis.
- Due to twisting, only shear stresses are produced which acts in two mutually perpendicular planes and vary from zero at polar axis to maximum at the surface in circumferential directions.

Torsion of circular shafts


Torsion formula:



here, J = Polar moment of inertiaG = Modulus of rigidity

 θ = Angle of twist in radian

L = Length of shaftR = Radius of shaft




Assumptions

- The bar/member must be straight & circular.
- The sections under consideration are remote from the point of application of the load.
- That portion of the member being considered must be free from abrupt change in c/s.
- Adjacent c/s originally plane & parallel remain plane & parallel after twisting.
- The material is homogeneous, isotropic & obeys Hooke's law.

12 January 2023 MACHINE DESIGN





Rigidity Criteria

$$\tau = \frac{T\rho}{J}$$

$$\tau_{\text{max}} = \frac{T}{J/\rho_{\text{max}}} = \frac{T}{Z_p}$$

Z_p=Polar modulus =Torsional Section Modulus

Where, $J = \int_A \rho^2 dA = Poller Moment Of Inertia = \frac{\pi d^4}{32}$ For Dia. d.


So, $T = G\theta \frac{\pi d^4}{32}$ & $\theta = \frac{32}{\pi} \frac{T}{Gd^4}$ And Total Angle Of Twist Is, $\varphi = \theta I = \frac{TL}{GJ}$. **GJ=Torsional Rigidity**


The τ_{max} Of A Solid Shaft In Twist Is, $~\tau_{max}=\frac{Tr}{J}=\frac{16T}{\pi d^3}.$

The Shaft Diameter Is, $d = \sqrt[3]{\frac{16T}{\pi\tau}}$.


And τ At Any Point At A Distance ρ From Center Is, $\tau = \frac{T\rho}{J}$.


For Hollow Shaft, J Is Replaced By The Value, $J = \frac{\pi}{32} (d_0^4 - d_1^4)$.








Example 6.1: A steel shaft circular in cross-section has to withstand a torque of 12×10^3 N.m. If the shearing stress is not to exceed 45 MPa and angle of twist has to remain within one degree per 5 m length of the shaft, find (a) the minimum diameter of the solid shaft, (b) minimum diameter of hollow shaft if external diameter is twice the internal diameter, (c) percentage of material saved in case of the above hollow shaft. Given $G = 8 \times 10^4$ MPa.














Deflection of beams

Deflection due to bending:

Methods • Double-integration method.

Governing equation

$$\frac{M}{EI} = \frac{d^2y}{dx^2}$$

$$y = \iint \frac{M}{EI} dx + C_1 x + C_2$$

Where, y is the lateral deflection of the beam at any point x along its length

12 January 2023

37

	Beam Deflection Formulas				
Beam Type	Slope, θ	Equation Of <i>Elastic Line</i> , y = 1	$f(x)$ δ_{max}		
a P X	$\theta = \frac{Pa^2}{2EI}$	$y = \frac{Px^{2}}{6EI}(3a - x), [0 < x < a]$ $y = \frac{Pa^{2}}{6EI}(3x - a), [a < x < l]$	$\delta_{\max} = \frac{Pa^2}{6EI} (3l - a)$		
y 1	$\theta = \frac{\text{wl}^3}{6\text{EI}}$	$y = \frac{wx^2}{24EI}(x^2 + 61^2 - 4Ix)$	$\delta_{\max} = \frac{wl^4}{8EI}$		
W x	$\theta = \frac{Wl^3}{24EI}$	$y = \frac{Wx^2}{120EI} (10 l^3 - 10 l^2 x + 5 lx^2 - 10 l^2 x + 5 lx$	$\delta_{\max} = \frac{Wt}{30EI}$		
y M	$\theta = \frac{Ml}{El}$	$\mathbf{y} = \frac{\mathbf{M}\mathbf{x}^2}{2\mathbf{E}\mathbf{I}}$	$\delta_{max} = \frac{Ml^2}{2EI}$		
After the Control of Management and Control of	$\theta_1 = \frac{\frac{Pb (l^2 - b^2)}{61EI}}{61EI}$ $\theta_2 = \frac{\frac{Pab (21 - b)}{61EI}}$	$\begin{split} y &= \frac{Pbx}{61E1} (l^2 - x^2 - b^2), [0 < x < a] \\ y &= \frac{Pb}{61E1} \left[\frac{1}{b} (x - a)^3 + (l^2 - b^2)x - x^2 \right], \\ [a < x < l] \end{split}$	$\delta_{\max} = \frac{\frac{Pb(1^2 - b^2)^{3/2}}{9\sqrt{3} 1EI}}{9\sqrt{3} 1EI}$ At $x = \sqrt{\frac{1^2 - b^2}{3}}$ $\frac{Pb}{48EI}(31^2 - 4b^2), [a > b]$		
1 w/Unit 2	$\theta_1 = \theta_2 = \frac{\mathrm{wl}^3}{24\mathrm{EI}}$	$y = \frac{wx}{24EI} (l^3 - 2lx^2 + x^3)$	$\delta_{\max} = \frac{5wl^4}{384EI}$		
Mary 2	$\theta_1 = \frac{M1}{6EI} = \frac{1}{2}\theta_2$	$y = \frac{Mlx}{6EI} \left(1 - \frac{x^2}{1^2} \right)$	$\delta_{\text{max}} = \frac{Ml^2}{9\sqrt{3}El} \text{ At } \mathbf{x} = \frac{1}{\sqrt{3}}$ $\delta_{l/2} = \frac{Ml^2}{16El}$		
ly 1 2	$\theta_1 = \frac{7W1^3}{360 \text{ EI}}$ $\theta_2 = \frac{W1^3}{45 \text{ EI}}$	$y = \frac{Wx}{360EI} (71^4 - 101^2x^2 + 3x^4)$ δ_{m}	$\begin{aligned} & a_x \! = \! 0.00652 \frac{w_1^{**}}{11} \; \text{At } x \! = \! 0.5191 \\ & \delta_{1/2} = \! 0.00651 \frac{w_1^{**}}{11} \end{aligned}$		