Solid Mechanics (ME 301)

Dr. Nirmal Baran Hui

Department of Mechanical Engineering NIT Durgapur - 713209, West Bengal India Email: nirmal.hui@me.nitdgp.ac.in

Books:


- 1. Strength of Materials: Part I, II, S. Timoshenko, CBS Publishers, 1985.
- 2. Engineering Mechanics of Solids, E. P. Popov, PHI, 1993.
- 3. Introduction to Solid Mechanics, I. H. Shames and J. M. Pittariesi, PHI, 2003.
- 4. Strength of Materials, F. L. Singer and A. Pytel, HarperCollins Publishers, 1991

Deflection of Beams

Assumptions:


- Stress is proportional to strain i.e. hooks law applies. Thus, the equation is valid only for beams that are not stressed beyond the elastic limit.
- The curvature is always small.
- Any deflection resulting from the shear deformation of the material or shear stresses is neglected.

Consider a beam AB which is initially straight and horizontal when unloaded. If under the action of loads the beam deflect to a position A'B' under load or in-fact we say that the axis of the beam bends to a shape A'B'. It is customary to call A'B' the curved axis of the beam as the elastic line or deflection curve.



To express the deflected shape of the beam in rectangular co-ordinates let us take two axes x and y, x-axis coincide with the original straight axis of the beam and the y axis shows the deflection.

Futher, let us consider an element ds of the deflected beam. At the ends of this element let us construct the normal which intersect at point O denoting the angle between these two normal be di



tani =
$$\frac{dy}{dx}$$
(1) or i = $\frac{dy}{dx}$ Assuming tani = i

Futher

ds = Rdi

however,

ds = dx [usually for small curvature]

Hence

or
$$\frac{di}{dx} = \frac{1}{R}$$

substitutingthevalueofi, one get

$$\frac{d}{dx}\left(\frac{dy}{dx}\right) = \frac{1}{R} \text{ or } \frac{d^2y}{dx^2} = \frac{1}{R}$$

Fromthe simple bending theory

$$\frac{M}{I} = \frac{E}{R} \text{ or } M = \frac{E}{R}$$

so the basic differential equation governing the deflection of beams is

$$M=EI\frac{d^2y}{dx^2}$$

Relationship between shear force, bending moment and deflection

i.e w =
$$-\frac{dF}{dx}$$

w = $-EI\frac{d^4y}{dx^4}$

Therefore if 'y'isthe deflection of the loadedbeam, then the following import an trelation scan bearrived at

$$slope = \frac{dy}{dx}$$

$$B.M = EI \frac{d^2y}{dx^2}$$

Shearforce =
$$El \frac{d^3 y}{dx^3}$$

$$|loaddistribution = El \frac{d^4y}{dx^4}$$

Methods for finding the deflection

Direct integration method: The governing differential equation is defined as

$$M = EI \frac{d^2y}{dx^2}$$
 or $\frac{M}{EI} = \frac{d^2y}{dx^2}$

on integrating one get,

$$\frac{dy}{dx} = \int \frac{M}{EI} dx + A - - - \text{ this equation gives the slope}$$


of the loaded beam.

Integrate once again to get the deflection.

$$y = \iint \frac{M}{FI} dx + Ax + B$$

Where A and B are constants of integration to be evaluated from the known conditions of slope and deflections for the particular value of x.

Case 1: Cantilever Beam with Concentrated Load at the end



End Criteria / Boundary Conditions:

i.e at
$$x = L$$
; $y = 0$ -----(1)

at
$$x = L$$
; $dy/dx = 0$ -----(2)

$$S.F|_{x=x} = -W$$

$$BM|_{\mathbf{x}=\mathbf{x}} = -W.\mathbf{x}$$

Therefore $M|_{x=x} = -W.x$

the governing equation
$$\frac{M}{EI} = \frac{d^2y}{dx^2}$$

substituting the value of M interms of x then integrating the equation one get

$$\frac{M}{EI} = \frac{d^2y}{dx^2}$$

$$\frac{d^2y}{dx^2} = -\frac{VVx}{FI}$$

$$\int \frac{d^2 y}{dx^2} = \int -\frac{Wx}{EI} dx$$

$$\frac{dy}{dx} = -\frac{Wx^2}{2EI} + A$$

Integrating once more,

$$\int \frac{dy}{dx} = \int -\frac{Wx^2}{2EI} dx + \int A dx$$
$$y = -\frac{Wx^3}{6EI} + Ax + B$$

$$A = \frac{W^2}{2EI}$$

While employing the first condition yields

$$y = -\frac{WL^3}{6EL} + AL + B$$

$$B = \frac{WL^3}{6EL} - AL$$

$$=\frac{WL^3}{6EI}-\frac{WL^3}{2EI}$$

$$= \frac{WL^3 - 3WL^3}{6EL} = -\frac{2WL^3}{6EL}$$

$$B = -\frac{WL^3}{3EI}$$

Substituting the values of A and B we get


$$y = \frac{1}{EI} \left[-\frac{VVx^3}{6EI} + \frac{VVL^2x}{2EI} - \frac{VVL^3}{3EI} \right]$$

The slope as well as the deflection would be maximum at the free end hence putting x≠0 we get,

$$y_{max} = -\frac{VVL^3}{3EI}$$

$$(Slope)_{m.ax}m = + \frac{WL^2}{2EI}$$

Case 2: A Cantilever with Uniformly distributed Loads



$$S.F|_{x-x} = -w$$

$$BM|_{x-x} = -w.x. \frac{x}{2} = w \left(\frac{x^2}{2}\right)$$

$$\frac{M}{EI} = \frac{d^2y}{dx^2}$$

$$\frac{d^2y}{dx^2} = -\frac{wx^2}{2EI}$$

$$\int \frac{d^2y}{dx^2} = \int -\frac{wx^2}{2EI} dx$$

$$\frac{dy}{dx} = -\frac{wx^3}{6EI} + A$$

$$\int \frac{dy}{dx} = \int -\frac{wx^3}{6EI} dx + \int A dx$$

$$y = -\frac{wx^4}{24EI} + Ax + B$$


End Criteria / Boundary Conditions: i.e at x = L; y = 0 ----- (1) at x = L; dy/dx = 0 ---- (2)

$$A = + \frac{wx^3}{6EI}$$
whereas the first boundary conditions yields
$$B = \frac{wL^4}{24EI} - \frac{wL^4}{6EI}$$

$$B = - \frac{wL^4}{8EI}$$
Thus,
$$y = \frac{1}{EI} \left[- \frac{wx^4}{24} + \frac{wL^3x}{6} - \frac{wL^4}{8EI} \right]$$
So
$$y_{max} = - \frac{wL^4}{8EI}$$

$$\left(\frac{dy}{dx}\right)_{max} = \frac{wL^3}{6EI}$$

Case 3: Simply Supported beam with uniformly distributed Loads



End Criteria / Boundary Conditions:

i.e at
$$x = 0$$
; $y = 0$ ----- (1)
at $x = L$; $y = 0$ ---- (2)

$$S.F|_{X-X} = w\left(\frac{1}{2}\right) - w.x$$

$$B.M|_{X-X} = w.\left(\frac{1}{2}\right) \cdot x - w.x.\left(\frac{x}{2}\right)$$

$$= \frac{wl.x}{2} - \frac{wx^2}{2}$$

The differential equation which gives the elastic curve for the deflected beam is:

$$\frac{d^2y}{dx^2} = \frac{M}{EI} = \frac{1}{EI} \left[\frac{wl.x}{2} - \frac{wx^2}{2} \right]$$
$$\frac{dy}{dx} = \int \frac{wlx}{2EI} dx - \int \frac{wx^2}{2EI} dx + A$$
$$= \frac{wlx^2}{4EI} - \frac{wx^3}{6EI} + A$$

Integrating, once more one gets

$$y = \frac{wIx^3}{12FI} - \frac{wx^4}{24FI} + A.x + B$$
 ----(1)


$$0 = \frac{wl^4}{12El} - \frac{wl^4}{24El} + A.1$$
$$A = -\frac{wl^3}{24El}$$

So the equation which gives the deflection curve is


$$y = \frac{1}{EI} \left[\frac{wLx^3}{12} - \frac{wx^4}{24} - \frac{wL^3x}{24} \right]$$

Then
$$y_{\text{max}^{\text{m}}} = \frac{1}{\text{EI}} \left[\frac{\text{wL}}{12} \left(\frac{\text{L}^3}{8} \right) - \frac{\text{w}}{24} \left(\frac{\text{L}^4}{16} \right) - \frac{\text{wL}^3}{24} \left(\frac{\text{L}}{2} \right) \right]$$

$$y_{\text{max}^{\text{m}}} = -\frac{5\text{wL}^4}{384\text{EI}}$$



Case 4: Simply Supported beam with Concentrated Load



$$R_1 = \frac{Wb}{a+b}$$

Hence,

$$EI\frac{d^2y}{dx^2} = \frac{Wb}{(a+b)}x$$

$$0 \le x \le a - - - - - - - (1)$$

$$EI\frac{d^2y}{dx^2} = \frac{Wb}{(a+b)} \times -W(x-a) \qquad a \le x \le I - - - - - - (2)$$

integrating (1) and (2) we get,

$$EI\frac{dy}{dx} = \frac{Wb}{2(a+b)}x^2 + k_1 \qquad 0 \le x \le a - \cdots (3)$$

$$EI\frac{dy}{dx} = \frac{VVb}{2(a+b)}x^2 - \frac{VV(x-a)^2}{2} + k_2$$
 $a \le x \le 1 - \cdots - (4)$

B.M for the portion AB

$$M|_{\Delta B} = R_1.x \ 0 \le x \le a$$

B.M for the portion BC

$$M|_{BC} = R_1 \cdot x - W(x - a) \ a \le x \le I$$

so the differential equation for the two cases would be,

$$EI\frac{d^2y}{dx^2} = R_1x$$

$$EI\frac{d^2y}{dx^2} = R_1 \times W(x - a)$$

Boundary Conditions:

at x = 0; y = 0 in the portion AB i.e. $0 \le x \le a$

at x = 1; y = 0 in the portion BC i.e. $a \le x \le 1$

at x = a; dy/dx, the slope is same for both portion at x = a; y, the deflection is same for both portion

Using Condition (c)

$$EI\frac{dy}{dx} = \frac{VVb}{2(a+b)}x^2 + k$$

$$0 \le x \le a - - - - - (3)$$

$$EI\frac{dy}{dx} = \frac{VVb}{2(a+b)}x^2 - \frac{VV(x-a)^2}{2} + k \qquad a \le x \le 1 - \dots$$
 (4)

Integrating agian equation (3) and (4) we get

Ely =
$$\frac{VVb}{6(a+b)} x^3 + kx + k_3$$
 $0 \le x \le a - - - - - (5)$

Ely =
$$\frac{\text{VVb}}{6(a+b)} x^3 - \frac{\text{VV}(x-a)^3}{6} + kx + k_4$$
 $a \le x \le 1 - \cdots - (6)$

Utilizing condition (a) in equation (5) yields

$$k_3 = 0$$

Utilizing condition (b) in equation (6) yields

$$0 = \frac{VVb}{6(a+b)}l^3 - \frac{VV(l-a)^3}{6} + kl + k_4$$

$$k_4 = -\frac{Wb}{6(a+b)}I^3 + \frac{W(I-a)^3}{6} - kI$$

Buta+b=l,

Thus,

$$k_4 = -\frac{VVb(a+b)^2}{6} + \frac{VVb^3}{6} - k(a+b)$$

Using Condition (d)

Therefore
$$y|_{\text{from equation }5} = y|_{\text{from equation }6}$$
 or
$$\frac{Wb}{6(a+b)}x^3 + kx + k_3 = \frac{Wb}{6(a+b)}x^3 - \frac{W(x-a)^3}{6} + kx + k_4$$

$$\frac{Wb}{6(a+b)}a^3 + ka + k_3 = \frac{Wb}{6(a+b)}a^3 - \frac{W(a-a)^3}{6} + ka + k_4$$
 Thus, $k_4 = 0$; OR
$$k_4 = -\frac{Wb(a+b)^2}{6} + \frac{Wb^3}{6} - k(a+b) = 0$$

$$k(a+b) = -\frac{Wb(a+b)^2}{6} + \frac{Wb^3}{6}$$

$$k(a+b) = -\frac{Wb(a+b)^{2}}{6} + \frac{Wb^{3}}{6}$$
$$k = -\frac{Wb(a+b)}{6} + \frac{Wb^{3}}{6(a+b)}$$

so the deflection equations for each portion of the beam are

Ely =
$$\frac{Wb}{6(a+b)}x^3 + kx + k_3$$

Ely = $\frac{Wbx^3}{6(a+b)} - \frac{Wb(a+b)x}{6} + \frac{Wb^3x}{6(a+b)}$ ---- for $0 \le x \le a$ ----- (7)

and for other portion

Ely =
$$\frac{\text{Wb}}{6(a+b)} x^3 - \frac{\text{W}(x-a)^3}{6} + kx + k_4$$


Substituting the value of 'k' in the above equation


Ely =
$$\frac{Wbx^3}{6(a+b)} - \frac{W(x-a)^3}{6} - \frac{Wb(a+b)x}{6} + \frac{Wb^3x}{6(a+b)}$$
 For **for** $a \le x \le 1 - \cdots (8)$


so either of the equation (7) or (8) may be used to find the deflection at x = ahence substituting x = a in either of the equation we get

$$Y|_{x=a} = -\frac{VVa^2b^2}{3EI(a+b)}$$


$$Y_{\text{max}^{\text{m}}} = -\frac{WL^3}{48E}$$







THE AREA-MOMENT / MOMENT-AREA METHODS



$$\frac{d\theta}{ds} = \frac{1}{R} = \frac{M}{EI}$$


$$\frac{d\theta}{ds} = \frac{N}{E}$$

But for small curvature[but θ is the angle, slope is $\tan \theta = \frac{dy}{dx}$ for small

angles tan8 $\approx \theta$, hence $\theta \cong \frac{dy}{dx}$ so we get $\frac{d^2y}{dx^2} = \frac{M}{El}$ by putting ds $\approx dx$]


Hence,

$$\frac{d\theta}{dx} = \frac{M}{EI} \text{ or } d\theta = \frac{M.dx}{EI} - - - - - (1)$$




Theorem I: The angle θ between tangents at any two points A and B on the elastic line is equal to the total area of corresponding portion of the bending moment diagram, divided by EI.

$$\delta = \int_{A}^{B} x d\theta = \frac{1}{EI} \times \begin{cases} \text{first moment of area with respect} \\ \text{to point B, of the total B.M diagram} \end{cases}$$




Theorem II: The deflection of B away from the tangent at A is equal to the statical moment, with respect to B, of the bending moment area between A and B, divided by EI.



slope at
$$A = \frac{1}{EI}$$
 [Area of B.M diagram between the points A and B]
$$= \frac{1}{EI} \left[\frac{1}{2} L.WL \right]$$

$$= \frac{WL^2}{2EI}$$

Thus, $\delta = \frac{1}{EI} [\text{first moment of area of B. M diagram between A and B about A}]$ $= \frac{1}{EI} [A\overline{y}]$ $= \frac{1}{EI} \left[\left(\frac{1}{2} \text{L.WL} \right) \frac{2}{3} \text{L} \right]$ $= \frac{WL^3}{3EI}$



slope at
$$A = \frac{1}{FI} [Area of B. M diagram between A and C]$$

$$= \frac{1}{EI} \left[\left(\frac{1}{2} \right) \left(\frac{L}{2} \right) \left(\frac{WL}{4} \right) \right]$$

 $= \frac{1}{EI} \left[\left(\frac{1}{2} \right) \left(\frac{L}{2} \right) \left(\frac{VVL}{4} \right) \right]$ we are taking half area of the B.M because we

have to work out this relative to a zero slope


$$=\frac{WL^2}{16E}$$

Deflection of A relative to C = central deflection of C

or

$$\delta_{\rm C} = \frac{1}{\rm FI} [\text{Moment of B.M diagram between points A and C about A}]$$

$$= \frac{1}{EI} \left[\left(\frac{1}{2} \right) \left(\frac{L}{2} \right) \left(\frac{WL}{4} \right) \frac{2}{3} L \right]$$



Slope at point C w.r.t point A = $\frac{1}{EI}$ [Area of B.M diagram between point A and C]

$$= \frac{1}{EI} \left[\left(\frac{2}{3} \right) \left(\frac{WL^2}{8} \right) \left(\frac{L}{2} \right) \right]$$
$$= \frac{WL^3}{24EI}$$


$$=\frac{WL^3}{24EI}$$

Deflection at point C

$$=\frac{1}{EI}[A \overline{y}]$$

re lative to A

$$= \frac{1}{EI} \left[\left(\frac{\text{WL}^3}{24} \right) \left(\frac{5}{8} \right) \left(\frac{L}{2} \right) \right]$$
$$= \frac{5}{8} \text{WL}^4$$



BEAM TYPE	SLOPE AT FREE END	Deflection at any section in terms of x: y is positive downward	MAXIMUM DEFLECTION
1. Cantilever Beam — Concentrated load P at the free end			
6, P x	$\theta = \frac{Pl^2}{2EI}$	$y = \frac{Px^2}{6EI} (3l - x)$	$\delta_{\max} = \frac{Pl^3}{3EI}$
2. Cantilever Beam — Concentrated load P at any point			
0 P b X X 18 max	$\theta = \frac{Pa^2}{2EI}$	$y = \frac{Px^{2}}{6EI} (3a - x) \text{ for } 0 < x < a$ $y = \frac{Pa^{2}}{6EI} (3x - a) \text{ for } a < x < l$	$\delta_{\max} = \frac{Pa^2}{6EI}(3l - a)$
3. Cantilever Beam — Uniformly distributed load of wkg per unit length			
w kg per u.l. 8 max	$\theta = \frac{wl^3}{6EI}$	$y = \frac{wx^2}{24EI} (x^2 + 6l^2 - 4lx)$	$\delta_{\max} = \frac{wl^4}{8EI}$
4. Cantilever Beam — Uniformly varying load; maximum intensity wkg per unit length			
L Ta max	$\theta = \frac{wl^3}{24EI}$	$y = \frac{wx^2}{120lEI} \left(10l^3 - 10l^2x + 5lx^2 - x^3 \right)$	$\delta_{\max} = \frac{wl^4}{30EI}$
5. Cantilever Beam — Couple M applied at the free end			
A Tamax	$\theta = \frac{Ml}{E\bar{I}}$	$y = \frac{Mx^2}{2EI}$	$\delta_{\max} = \frac{Ml^2}{2EI}$
6. Beam Freely Supported at Ends — Concentrated load P at the center			
By P P2	$\theta_1 = \theta_2 = \frac{Pl^2}{16EI}$	$y = \frac{Px}{12EI} \left(\frac{3l^2}{4} - x^2 \right) \text{ for } 0 < x < \frac{l}{2}$	$\delta_{\max} = \frac{Pl^3}{48EI}$


BEAM TYPE

SLOPE AT ENDS

DEFLECTION AT ANY SECTOIN IN TERMS OF x: y IS POSITIVE DOWNWARD

MAXIMUM AND CENTER DEFLECTION

7. Beam Freely Supported at Ends Concentrated load at any point



Left End.

$$\theta_1 = \frac{Pb(l^2 - b^2)}{6lEI}$$
Right End.

$$\theta_2 = \frac{Pab(2l - b)}{6lEI}$$

Left End.

$$\theta_{1} = \frac{Pb(l^{2} - b^{2})}{6lEI}$$

$$Right End.$$

$$\theta_{2} = \frac{Pab(2l - b)}{6lEI}$$

$$y = \frac{Pb}{6lEI} (l^{2} - x^{2} - b^{2})[0 < x < a]$$

$$y = \frac{Pb}{6lEI} \left[\frac{l}{b} (x - a)^{3} + (l^{2} - b^{2})x - x^{3} \right] [a < x < l]$$

$$\delta_{\text{max}} = \frac{Pb(l^2 - b^2)^{3/2}}{9\sqrt{3} \, l \, EI}$$

$$at \, x = \sqrt{\frac{l^2 - b^2}{3}}$$
At center, if $a > b$

$$\delta = \frac{Pb}{48EI}(3l^2 - 4b^2)$$

8. Beam Freely Supported at Ends — Uniformly distributed load of wkg per unit length




$$\theta_1 = \theta_2 = \frac{wl^3}{24EI}$$

$$y = \frac{wx}{24EI} (l^3 - 2lx^2 + x^3)$$

$$\delta_{\max} = \frac{5wl^4}{384EI}$$

9. Beam Freely Supported at Ends — Couple M at the right end



$$\theta_1 = \frac{Ml}{6EI}$$


$$\theta_2 = \frac{Ml}{2EI}$$

$$y = \frac{Mlx}{6EI} \left(1 - \frac{x^2}{l^2} \right)$$

$$\delta_{\text{max}} = \frac{Ml^2}{9\sqrt{3} EI}$$

$$at \, x = l/\sqrt{3}$$
At center
$$\delta = \frac{Ml^2}{16EI}$$

Uniformly varying load: max. intensity w 10. Beam Freely Supported at Ends



$$\theta_1 = \frac{7wl^3}{360EI}$$


$$\theta_2 = \frac{wl^3}{45EI}$$

$$y = \frac{wx}{360lEI} \left(7l^4 - 10l^2x^2 + 3x^4\right)$$

$$\delta_{\text{max}} = .00652 \frac{wl^4}{EI}$$

$$at \, x = 0.519l$$
At center
$$\delta = .00651 \frac{wl^4}{EI}$$

DETERMINE THE SLOPE AT POINTS B AND C OF THE BEAM SHOWN BELOW. TAKE E = 200 GPa AND I = 360 x 10⁶ mm⁴



$$\theta_B = \theta_{B/A}; \quad \theta_C = \theta_{C/A}$$

 Applying Theorem 1, is equal to the area under the M/EI diagram between points A & B

$$\theta_{B} = \theta_{B/A} = -\left(\frac{50kNm}{EI}\right)(5m) - \frac{1}{2}\left(\frac{100kNm}{EI} - \frac{50kNm}{EI}\right)(5m)$$
$$= -\frac{375kNm^{2}}{EI}$$

Substituting numerical data for E & I


$$-\frac{375kNm^2}{[200(10^6)kN/m^2][360(10^6)(10^{-12})m^4]} = -0.00521rad$$


$$\theta_C = \theta_{C/A} = \frac{1}{2} \left(-\frac{100 \, kNm}{EI} \right) (10m) = -\frac{500 \, kNm^2}{EI}$$

Substituti ng numerical values of EI, we have :

$$\frac{-500 \, kNm^2}{[200(10^6)kN/m^2][360(10^6)(10^{-12})m^4]} = -0.00694 \, rad$$

Determine the deflection at C of the beam shown as below. Take E = 200GPa and I=360E6 mm4.





$$\frac{\Delta'}{3} = \frac{t_{A/B}}{6}$$

$$\Delta' = \frac{t_{A/B}}{2}$$

$$\Delta_C = \frac{t_{A/B}}{2} - t_{C/B}$$

 $t_{\rm C/D}$ is the moment of the M/EI diagram between C and B about the point C

$$t_{C/B} = \left[\frac{1}{3}(3m)\right] \left[\frac{1}{2}(3m)\left(\frac{2.5kN.m}{EI}\right)\right]$$

$$t_{C/B} = \frac{3.75kN.m^3}{EI}$$

 $t_{\text{A/B}}$ is the moment of the M/EI diagram between A and B about point A

$$t_{A/B} = \left[\frac{1}{3}(6m)\right] \left[\frac{1}{2}(6m)\left(\frac{5kN.m}{EI}\right)\right]$$


$$t_{A/B} = \frac{30kN.m^3}{EI}$$


$$\Delta_C = \frac{1}{2} \left(\frac{30kN.m^3}{EI} \right) - \frac{3.75kN.m^3}{EI}$$


$$\Delta_C = \frac{11.25kN.m^3}{EI}$$

$$\Delta_C = 0.0141m = 14.1mm$$

USE THE MOMENT AREA THEOREM TO DETERMINE THE DEFLECTION AT C. EI IS CONSTANT.







From elastic curve,
$$\frac{\Delta'}{15} = \frac{t_{B/A}}{10}$$


$$\Delta' = \frac{15}{10} t_{B/A}$$

$$\Delta_C = t_{C/A} - \Delta'$$

$$\Delta_C = t_{C/A} - \frac{15}{10} t_{B/A}$$

$$t_{C/A} = \left[\frac{1}{2} \left(\frac{-300}{EI}\right) (5)(3.33)\right] + \left[\frac{1}{2} \left(\frac{-300}{EI}\right) (10)(8.33)\right] \qquad t_{B/A} = \left[\frac{1}{2} \left(\frac{-300}{EI}\right) (10)(3.33)\right]$$

$$t_{C/A} = \frac{-15000kN.m^3}{EI}$$



$$t_{B/A} = \left[\frac{1}{2} \left(\frac{-300}{EI} \right) (10)(3.33) \right]$$


$$t_{C/A} = \frac{-5000kN.m^3}{EI}$$


$$\Delta_C = \frac{-15000}{EI} - \frac{15}{10} \left(\frac{-5000}{EI} \right)$$

$$\Delta_C = \frac{7500kN.m^3}{EI}$$


Bending Moment Diagrams by Parts


- Application of the moment-area theorems is practically only if the area under the bending moment diagrams and its first moment can be calculated without difficulty.
- The key to simplifying the computation is to divide the BMD into simple geometric shape (rectangles, triangles and parabolas) that have known areas and centroidal coordinates.
- Sometimes the conventional BMD lends itself to such division, but often it is
 preferable to draw the BMD by parts, with each part of the diagrams representing
 the effect of one load.
- Calculate the support reactions
- introduce a FIX SUPPORT as a convenient location. A simply support by the original beam is usually a good choice, but sometimes another point is more convenient. The beam is now cantilevered from this support.
- Draw a BMD for each loading (including the support reactions of the original beam. If all the diagrams can be fitted on a single plot, do so. Draw the positive moment above the x-axis and negative moment below the x-axis






USE THE MOMENT AREA THEOREM TO DETERMINE THE DEFLECTION AT C.EI IS CONSTANT. 60kN








From the elastic curve... refer to the previous example


$$\Delta_C = t_{C/A} - \frac{15}{10} t_{B/A}$$



$$t_{C/A} = \frac{1}{2}(900)(10)(11.67)$$

$$+\frac{1}{2}(-900)(15)(\frac{2}{3})(15)$$

$$t_{C/A} = 52500 - 67500$$
$$= -15000$$



$$\Delta_C = \frac{-15000}{EI} - \frac{15}{10} \left(\frac{-5000}{EI} \right)$$

$$\Delta_C = \frac{7500kN.m^3}{EI}$$