



PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
FALPIX. ANY REPRODUCTION IN
PART OR AS A WHOLE WITHOUT THE
WRITTEN PERMISSION OF FALPIX IS
PROHIBITED.



DRAWING NOTES: UNLESS OTHERWISE SPECIFIED

1. TO ATTACH ASSEMBLY A2 (ARM) TO ASSEMBLY A1 (FRAME), PUSH AMP CONNECTORS TOGETHER AND THEN FASTEN THREADED COLLET.

	NAME	DATE
DRAWN	P. Maroli	3/9/17
CHECKED	Jake K.	3/9/17
CALL (925)-963-2273 WITH ANY QUESTIONS REGARDING THIS DWG.		
INTERPRET GEOMETRIC TOLERANCING PER: ANSI Y14.5		
UNLESS OTHERWISE SPECIFIED:		
DIMENSIONS ARE IN INCHES TOLERANCES:		
ANGULAR $\pm 20'$ TWO PLACE DECIMAL ± 0.01 THREE PLACE DECIMAL ± 0.003		
MATERIAL		
FINISH		
DO NOT SCALE DRAWING		
SIZE	DWG. NO.	REV
B	A1000	B
SCALE: 2:5	WEIGHT:	SHEET 1 OF 2

DRAWN BY: P. Maroli
DATE: 3/9/17
REV: B



ENGINEERING PARTS LIST

A1000, UAV ASSEMBLY

ITEM NO.	QTY.	NUMBER	DESCRIPTION
A1	1	A1002	FRAME ASSEMBLY
A2	4	A1001	ARM ASSEMBLY