

Light Release User Manual:

Before turning on:

- Plug into microcontroller with python IDE such as Thonny
- Insure main.py and light_release_final.py are installed on the breadboard
- Delete any pre-existing “deployment.csv” files
- Set deployment time equal to how long you want the sensor to be underwater for
- Double check that all connections are plugged in correctly
- Make sure switch on breadboard is in the on position

Pre-deployment:

- Turn on battery pack
- Put internal assembly into the housing
- Put electromagnet at the bottom of the housing
- Screw bottom cap into place **tightly**

Deployment:

- Place package onto mooring, securing the magnet in place
- Gently lower mooring to seabed
- Set reminder for surfacing time

Retrieval:

- After package has surfaced, collect it and dry it off
- Unscrew bottom cap
- Take out electromagnet and circuit
- Switch off battery
- Plug into microcontroller and download “deployment.csv”