
Flashing firmware Windows 10

- 1. Download the Flash Download Tools and unzip.
- 2. Open flash_download_tool_3.8.5.exe
- 3. Select ESP32 and Developer Mode
- 4. Select and check the 3 binary file in the first 3 field and match the option as in screenshot.

Two types of build are now available: the SD card version as before (now named BlueRetro_universal_sd.bin) and also internal flash (SPIFFS). For each type I also provide the regular universal version with system auto detection. But in addition system hard-coded versions are available. A total of 24 variants are available.



- 5. Select proper COM port for your machine.
- 6. Press START (If the flash does not start hold the EN button to start the process)
- 7. Wait for status to change to FINISH.

Clearing Flash memory:

If the flash is failing or the firmware is corrupt and will not recover you can erase the flash memory.

- 1. Open Powershell
 - a. Make sure that python is installed
 - b. python –version
 - i. if python is not installed, go to the window store, search for python and install 3.91
 - c. Install esptool
 - i. pip install esptool
 - d. Clear Flash
 - i. esptool.py --chip esp32 --port comX erase_flash
 - 1. comX will be the com port on your machine
- 2. Once complete, retry ESP flash tool