

SLOKI ECU FLASHER TOOL

USER MANUAL

1. Launch the SLOKI ECU Flasher application.




Figure 1: Application Screen

2. Click the BROWSE button to select the location where the project file will be saved.




Figure 2: Application Screen

3. Enter a project name and click SAVE. **Note: Ensure the folder path does not contain spaces.**




Figure 3: Application Screen

4. Click the CREATE button. A new configuration tab will open.




Figure 4: Application Screen

5. Click the Add File button to add the required HEX files.




Figure 5: Application Screen

6. Select the appropriate file type from the drop-down list.




Figure 6: Application Screen

7. Click the BROWSE button and select the required HEX file.




Figure 7: Application Screen

8. Configure the CAN communication parameters as required and click the set button
It will change the windows tool and can analyzer baudrate




Figure 8: Application Screen

9. Click the Browse button to select the security (.dll) file.




Figure 9: Application Screen

10. Select the controller baud rate and click SEND. A confirmation message will appear upon success.




Figure 10: Application Screen

11. After adding all required files, click FLASH to open the flashing window.




Figure 11: Application Screen

12. Click FLASH to start the flashing process.




Figure 12: Application Screen

Once flashing is completed, a success message will be displayed. If flashing fails, an error message will be shown.

13. Use the Force Boot option if force flashing is required.




Figure 13: Application Screen

14. To load an existing project, open the Load Project tab and browse for the required .sproj file.




Figure 14: Application Screen

Flasher Template Installer – User Manual

15. Open the Flasher Template Installer application.




Figure 15: Installer Screen

16. Right-click the installer and select Run as Administrator.

17. Click the INSTALL button to begin the installation.




Figure 17: Installer Screen

18. After the installation is completed, click CLOSE to exit the installer.

Website: www.sloki.in