




REQUESTER ROLE

SI Work Order App Requester Guide

Reporting faults and following repairs



Contents

01 Getting started FOR EVERYONE

What SI does · Roles — who does what · Getting an account · Signing in · Choosing a new password · Finding your way around · Using SI on your phone · Notifications · How a work order moves · Priorities and SLA deadlines · Inside a work order

02 Requester guide ROLE GUIDE

At a glance · Your dashboard · Raising a work order · After you submit · Editing your work order · Comments and photos · Following progress · Finding work orders · Common situations

03 Quick reference APPENDIX

Who can do what · Words SI uses · Need help?

Note: How to use this guide. Chapter 1 covers what everybody needs: getting an account, signing in, finding your way around, and how work orders move. Chapter 2 is everything a Requester can do, step by step. Screenshots come from the SI test site with demo data, so names and numbers will differ from what you see. Buttons and labels are shown in **bold**.

01.

FOR EVERYONE

Getting started

What SI is, how to get an account, how to sign in, and how to find your way around. Read this first, whatever your role.

IN THIS CHAPTER

- 1.1** What SI does
 - 1.2** Roles — who does what
 - 1.3** Getting an account
 - 1.4** Signing in
 - 1.5** Choosing a new password
 - 1.6** Finding your way around
 - 1.7** Using SI on your phone
 - 1.8** Notifications
 - 1.9** How a work order moves
 - 1.10** Priorities and SLA deadlines
 - 1.11** Inside a work order
-

1.1 What SI does

SI (Service Inside) is PMW Group's maintenance work order app. When a machine or facility has a fault, somebody **raises a work order**. An HOD or Administrator assigns it to a technician, the technician **carries out the repair**, and the app keeps a full record of who did what and when.

It runs in any web browser — on a PC, a tablet or a phone — so there is nothing to install. You can also add it to your phone's home screen so it opens like an app (see *Using SI on your phone* below).

1.2 Roles — who does what

Every account has one or more roles. Your role decides which screens you see and which buttons you get. This guide covers the three most common roles:

Role	What they do in SI
Requester	Reports faults by raising work orders, adds photos and comments, and follows the repair until it is finished.
Technician	Receives jobs, accepts or declines them, carries out the repair step by step, and marks the work completed.
Administrator	Oversees all work in the plant, assigns technicians, manages user accounts, and maintains the settings (departments, equipment, priorities and SLA targets).

Note: SI also has **Supervisor**, **HOD** and **Manager** roles. HODs assign technicians and sign off closed work orders, and Supervisors and Managers oversee the work. One person can hold more than one role — for example Requester + Technician — and then gets everything both roles allow.

1.3 Getting an account

There is **no self sign-up** in SI. Accounts are created by your Administrator, so the app always knows who everybody is and what they are allowed to do.

- 1 Contact your **Administrator** (or the IT / maintenance office) and ask for an SI account.
- 2 Give them your **full name**, **company email address**, **phone number**, your **employee ID** (if you have one) and your **department**, and tell them which **role** you need.
- 3 The Administrator creates the account and gives you a **temporary password**.
- 4 Sign in with it (see below). The first time you sign in, SI asks you to **choose your own password** before you can do anything else.

1.4 Signing in

Figure 1.1 — The sign-in screen.

- 1 Open SI in your browser (or tap the SI icon on your home screen).
- 2 In **Company email or employee ID**, type either your company email address **or** your employee ID. Both work — capital letters and spaces in an employee ID do not matter.
- 3 Type your **Password**. Tap the eye icon to show what you typed.
- 4 Tick **Remember me** on your own phone or PC so you stay signed in. Leave it unticked on a shared computer.
- 5 Press **Sign in**. SI opens the dashboard for your role.

Tip: If sign-in fails, SI shows the same message whether the email/ID or the password was wrong — this protects your account. Check both, and after a few failed tries wait a moment before trying again.

Important: Forgot your password? Contact your **Administrator**. They will set a temporary password for you, which you replace the next time you sign in.

1.5 Choosing a new password

Change your password
Choose a new password for your account.

New password *

Confirm new password *

At least 8 characters. Nobody else can see it, your administrator included — if you forget it, it has to be reset.

✓ **Change password**

Figure 1.2 — The Change password screen appears on your first sign-in, and after an Administrator resets your password.

- Enter the new password twice. It must be **at least 8 characters**.
- Nobody else can see your password — not even your Administrator.
- Until you set your own password you cannot reach any other screen. This is on purpose: the temporary password was chosen by somebody else.

1.6 Finding your way around

My Work Orders
Everything you've raised, and what's happening with it.

Waiting for a technician **6** | Closed today **0**

Open 31 still in flight

Of these — a job can appear in a stage and in an SLA figure both:

Open 6 | Assigned 1 | Accepted 5 | Repairing 5 | Waiting Spare Part 3 | Testing 3 | On The Way 4 | On Site 4

SLA at risk 0 | Overdue 9

Waiting for a technician 6
You raised these and nobody has been assigned yet.

WO-2026-000017 Floodlight	P4	Unassigned	Breached - Acknowledge	Open →
WO-2026-000018 Batching Plant	P1	Unassigned	Breached - Acknowledge	Open →
WO-2026-000028 Batching Plant	P3	Unassigned	Breached - Acknowledge	Open →
WO-2026-000029 Floodlight	P4	Unassigned	Breached - Acknowledge	Open →

Ravi Kumar
Requester

Sign out

Figure 1.3 — The screen layout (Requester shown). On a PC the menu is on the left.

Part of the screen	What it is for
Dashboard	Your starting page: counts and lists of the work that needs your attention.
Work Orders	The full list of work orders you can see, with search, filters, sorting and Excel export.
Notifications	Everything SI has told you about, grouped by category.
Users / Settings	Administrators only — accounts and system settings.
Bell icon (top right)	Opens your latest notifications. A red dot means something is unread.
Role badge (top right)	Shows the role you are working as. If you hold several roles, use it to switch dashboards.
Your name / Sign out	Bottom of the menu. Always sign out on a shared computer.

1.7 Using SI on your phone




Figure 1.4 — Dashboard on a phone




Figure 1.5 — Tap ≡ to open the menu




Figure 1.6 — A work order on a phone

SI adapts to small screens. The menu hides behind the ≡ button at the top left, and wide tables turn into cards you can scroll.

- **iPhone:** open SI in **Safari**, tap the **Share** button, then **Add to Home Screen**. Pop-up alerts on iPhone only work once SI is added this way.
- **Android:** open SI in **Chrome**, tap the : menu, then **Install app** or **Add to Home screen**.

1.8 Notifications




Figure 1.7 — The bell opens your latest notifications without leaving the page.

- SI notifies you when something happens that concerns you — for example a job assigned to you, or your work order completed.
- Each notification shows **how long ago** it happened and the exact date and time, plus **tags** for who caused it and which stage the job was at.
- Tap a notification to open that work order. **Mark all read** clears the red dot.
- On the **Notifications** page, filter by category and use **Clear read** to delete notifications you have already read. Unread ones are never deleted.
- To get alerts on your phone or PC while SI is in the background, press **Turn on alerts with sound** in the bell panel and allow notifications when the browser asks. Alerts only arrive while SI is open somewhere (a tab or the home-screen app) — not after it has been fully closed.

1.9 How a work order moves

Every work order goes through the same stages, in order. No stage can be skipped, and every move is recorded on the **Status Timeline** with the person's name and the time.



Status	Meaning
Open	Raised and waiting for somebody to assign a technician.
Assigned	A technician has been chosen and must accept or decline. A decline sends it back to Open.
Accepted	The technician has taken the job but not started yet.
Repairing	Work is in progress.
Waiting Spare Part	Paused because a part is needed. Returns to Repairing when the part arrives.
Testing	The fix is being tested. A failed test sends it back to Repairing.
Completed → Closed	The technician marks the repair completed, and SI closes it automatically at the same moment.

1.10 Priorities and SLA deadlines

You never choose a priority — SI works it out from the **production impact** picked when the work order is raised, and raises it further if a **safety** or **environmental** risk is flagged. Each priority has an SLA (service-level agreement): a time limit for each of three stages.

Priority	Production impact	1. Acknowledge	2. Response	3. Resolution
P1 Critical	Full production stoppage	5 min	10 min	3 hrs 45 min
P2 High	Running at reduced capacity	15 min	45 min	7 hrs
P3 Medium	Auxiliary equipment, no line impact	30 min	3 hrs 30 min	20 hrs
P4 Low	No production impact (cosmetic/routine)	2 hrs	22 hrs	4 days
P7 Long-term	Long-term task (planned)	5 days	3 days	7 days
P8 Scheduled	Scheduled work (month-scale)	5 days	5 days	20 days

- **Acknowledge** — from raising the work order until a technician is assigned.
- **Response** — from assignment until the technician starts work.
- **Resolution** — from starting work until the repair is completed.
- Each stage's clock starts when the previous stage finishes. The header of every work order shows the current stage and the time left, for example **14m left, At risk** (in the last quarter of its time) or **Breached** (late).
- These are the current settings. Administrators can change them, so the times shown in the app are always the ones that apply.

1.11 Inside a work order

The screenshot shows the 'Air Compressor 1000 K/P' work order page. The left sidebar contains 'Dashboard', 'Work Orders' (selected), and 'Notifications'. The top right has a 'Requester' button. The main header includes a 'Back to Work Orders' link, the work order ID 'WO-2026-000049', a 'P2' priority badge, and an 'Open' status. An 'Edit' button is visible. The 'Raised' date is '25/09/2026 11:24 AM' by 'Ravi Kumar'. The 'Acknowledge SLA' is '14m left'. Below the header are six tabs: 'Overview' (selected), 'Assignment', 'Conversation', 'Photos', 'Status Timeline', and 'Workflow'.

Overview Tab Content:

Department	Maintenance
Plant	F1 — PMW Industries
Equipment	Air Compressor 1000 K/P
Area	Compressor room, Bay 2
Type	Breakdown
Production impact	Running at reduced capacity
Requested by	Ravi Kumar
Requester phone	98450 11223
Safety risk	No
Environmental risk	No
Permit / LOTO required	No

Complaint: DEMO (user manual) — Oil leaking from the compressor base, pressure drops to 5 bar after 10 minutes of running. Loud knocking sound on start-up.

SLA targets (P2)

	target	actual
Acknowledge	15 min	Running
Response	45 min after assignment	...
Resolution	7 hrs after work starts	...

Measured in stages, not from when it was raised: each window starts when the one before it is met.

Figure 1.8 — Every work order has the same header and six tabs.

Tab	What you find there
Overview	All the details — department, plant, equipment, complaint, risks — plus the SLA targets and how long each stage actually took.
Assignment	Who the job is assigned to. HODs and Administrators assign and reassign here, until the job is completed. After that the Assign buttons are greyed out.
Conversation	Comments and photos in one chat-style thread. A red number shows how many new messages you have not read.
Photos	Every photo, grouped by the stage it was taken at (before work, during repair, testing...).
Status Timeline	The full history: every move, who made it, when, and any reason given.
Workflow	Tells you whose move it is, and holds the action buttons when it is yours.

Tip: If your session expires while you are typing a work order, SI keeps what you typed and offers to restore it after you sign back in. Photos cannot be kept, so re-attach them.

02.

ROLE GUIDE

Requester guide

You report faults and follow them until they are fixed. This chapter covers everything a Requester can do in SI.

IN THIS CHAPTER

- 2.1** At a glance
 - 2.2** Your dashboard
 - 2.3** Raising a work order
 - 2.4** After you submit
 - 2.5** Editing your work order
 - 2.6** Comments and photos
 - 2.7** Following progress
 - 2.8** Finding work orders
 - 2.9** Common situations
-

2.1 At a glance

You can	You cannot
Raise a work order, with photos	See work orders raised by other people
Edit your work order while it is still Open	Edit it once a technician is assigned
Comment and add photos on your own work orders	Assign a technician or choose who does the job
Replace a photo you uploaded (while the job is live)	Do the technician's steps (accept, repair, test, complete)
Follow progress on the timeline and get notified	Delete a work order, or anyone else's comment or photo
Search, filter and export your work orders to Excel	Reach the Users or Settings screens

2.2 Your dashboard




Figure 2.1 — My Work Orders — the Requester dashboard.

- **Waiting for a technician** — work orders you raised that nobody has been assigned to yet.
- **Closed today** — your work orders finished and signed off today.
- **Open ... still in flight** — everything not yet finished, broken down by stage and by SLA (at risk / overdue). Tap any figure to see the work orders behind it.
- **Recent activity** — your work orders with the latest changes first. Press **See all** for the full list.

2.3 Raising a work order

Go to **Work Orders** and press **Raise Work Order**. Fields marked * are required.

← Back to Work Orders

Raise Work Order

Priority is set from the production impact, and escalates for safety or environmental risk.

Department *

Maintenance

Who should handle this. Change it if someone else should take it.

Plant *

F1 — BMW Industries

Where the machine is. This is what decides the equipment list below — changing it clears the equipment, because each plant keeps its own machines.

Equipment *

Air Compressor 1000 K/P

Showing F1 — BMW Industries's machines. Not listed? Choose "Other (specify)" at the bottom and say what it is.

Area

Compressor room, Bay 2

Criticality: **medium** · Machine code: AC2 · Model: PK 75-250

Work order type

Breakdown

Inspection

Project

Repairing

Unplanned failure needing corrective work.

Complaint *

DEMO (user manual) — Oil leaking from the compressor base, pressure drops to 5 bar after 10 minutes of running. Loud knocking sound on start-up.

Production impact *

☐ Full production stoppage

P1

☒ Running at reduced capacity

P2

☐ Auxiliary equipment, no line impact

P3

☐ No production impact (cosmetic/routine)

P4

☐ Long-term task (planned, no immediate impact)

P7

☐ Scheduled work (month-scale)

P8

Priority

P2

Set from the production impact. Not editable.

Upload Photo

Upload Photo

Resized and compressed on this device before it uploads, so a photo straight off a phone camera goes up in a fraction of the time.

Safety risk

No

Yes

Environmental risk

No

Yes

Requester *

Ravi Kumar

Phone number *

98450 11223

SLA preview

From production impact

Acknowledge

15 min

Response

45 min after assignment

Resolution

7 hrs after work starts

Each window starts when the one before it is met, not when the job is raised — so the time to repair is measured from when the repair begins.

Submit

Cancel

Figure 2.2 — A completed Raise Work Order form, with the SLA preview on the right.

- 1 Department** — the department that should handle the job. Pick the right one; it decides who is told about it.

- 2 **Plant** — where the machine is: F1, F2, F3 or Facility. The equipment list only shows machines at the plant you pick.
- 3 **Equipment** — click the box and type part of the machine name or machine code, then pick it from the list. The machine's criticality, code and model appear underneath.
- 4 **Area** (optional) — where exactly: line, bay, floor, room.
- 5 **Work order type** — **Breakdown** (unplanned failure), **Inspection** (routine check), **Project** (improvement or installation) or **Repairing** (repair of a known fault).
- 6 **Complaint** — describe the problem: what happened, symptoms, sounds, error codes, and when it started.
- 7 **Production impact** — how badly production is affected. This sets the priority, shown in the **Priority** box underneath.
- 8 **Upload Photo** — add one or more photos of the fault. They are shrunk automatically before upload, so a phone photo goes up quickly.
- 9 **Safety risk / Environmental risk** — choose **Yes** if there is one (see below).
- 10 **Requester** and **Phone number** — filled in from your account. Correct them if needed.
- 11 Check the **SLA preview** on the right, then press **Submit**.

The screenshot shows the 'Raise Work Order' interface. On the left is a dark blue sidebar with 'SI SERVICE INSIDE' at the top, followed by 'Dashboard', 'Work Orders' (highlighted), and 'Notifications'. At the bottom of the sidebar is the user profile for 'Ravi Kumar' (Requester) with a 'Sign out' button. The main content area has a 'Back to Work Orders' link and the title 'Raise Work Order'. Below the title is a note: 'Priority is set from the production impact, and escalates for safety or environmental risk.' The form consists of three main sections: 'Department' (a dropdown menu set to 'Maintenance'), 'Plant' (a dropdown menu set to 'F1 — PMW Industries'), and 'Equipment' (a search bar with a list of equipment items below it). The equipment list includes 'Air Compressor 1000 K/P', 'Air Compressor 1130.7 K/P', 'Air Receiver Tank 1034 K/P', 'Bandsaw No 3', and 'Brass Socket (Stamping) No 1'. To the right of the form is a blue box labeled 'SLA preview' with the text 'Fill in the form to see the priority and SLA targets here.' Below this box are two buttons: 'Submit' (orange) and 'Cancel' (grey).

Figure 2.3 — Type to search. Only machines at the chosen plant are listed.

Machine not in the list?

SI SERVICE INSIDE

Dashboard

Work Orders

Notifications

Users

Settings

Anita Desai Administrator

Sign out

Back to Work Orders

Raise Work Order

Priority is set from the production impact, and escalates for safety or environmental risk.

Department *

Maintenance

Who should handle this. Change it if someone else should take it.

Plant *

Facility

Where the machine is. This is what decides the equipment list below — changing it clears the equipment, because each plant keeps its own machines.

Equipment *

Other (specify)

Showing Facility's machines. Not listed? Choose "Other (specify)" at the bottom and say what it is.

Which equipment *

Name the machine, tool or fixture

Recorded on this work order only — it is not added to the equipment list.

Area

Where in the plant — line, bay, floor

Work order type

Breakdown Inspection Project Repairing

Unplanned failure needing corrective work.

Complaint *

What happened? Include symptoms, sounds, error codes...

SLA preview

Fill in the form to see the priority and SLA targets here.

Submit Cancel

Figure 2.4 — Choose "Other (specify)" at the bottom of the list, then say which equipment it is.

Scroll to the bottom of the equipment list (or type "other") and choose **Other (specify)**. A **Which equipment** box appears — type the name of the machine. It is recorded on this work order only. Ask your Administrator to add the machine to the list if it will come up again.

Flagging a safety or environmental risk

Safety risk

No Yes

High Medium Low

Raises the priority to at least P2.

Environmental risk

No Yes

Figure 2.5 — Choosing Yes for Safety risk asks for its severity and can raise the priority.

- Choose **Yes** under **Safety risk**, then pick the severity: **High** (immediate danger to people), **Medium** (hazardous if left) or **Low** (minor, controlled).
- A line such as "Raises the priority to at least P2" shows what it does to the priority. A High safety risk always makes the job **P1**.

- An **Environmental risk** raises the priority to at least **P2**.

Important: SI is not an emergency alarm. For immediate danger to people, follow the plant's emergency procedure first — then raise the work order.

2.4 After you submit

The screenshot shows the SI Service Inside app interface. On the left is a dark blue sidebar with navigation options: Dashboard, Work Orders (selected), and Notifications. At the bottom of the sidebar is the user profile for Ravi Kumar, Requester, with a 'Sign out' button. The main content area shows a work order titled 'Air Compressor 1000 K/P' with ID 'WO-2026-000049' and priority 'P2'. It is marked as 'Open'. Above the title are buttons for 'Edit', 'Raised 25/09/2026 11:24 AM by Ravi Kumar', and 'Acknowledge SLA 14m left'. Below the title are tabs for Overview, Assignment, Conversation, Photos, Status Timeline, and Workflow. The 'Overview' tab is active, displaying a table of details:

Department	Maintenance
Plant	F1 — PMW Industries
Equipment	Air Compressor 1000 K/P
Area	Compressor room, Bay 2
Type	Breakdown
Production impact	Running at reduced capacity
Requested by	Ravi Kumar
Requester phone	98450 11223
Safety risk	No
Environmental risk	No
Permit / LOTO required	No

To the right of the table is a 'Complaint' section with the text: 'DEMO (user manual) — Oil leaking from the compressor base, pressure drops to 5 bar after 10 minutes of running. Loud knocking sound on start-up.' Below this is an 'SLA targets (P2)' section with a table:

	target	actual
Acknowledge	15 min	Running
Response	45 min after assignment	
Resolution	7 hrs after work starts	

A note below the SLA targets states: 'Measured in stages, not from when it was raised: each window starts when the one before it is met.'

Figure 2.6 — Your new work order opens straight away with its WO number.

- SI gives the work order a number such as **WO-2026-000049** — quote it when you talk to maintenance.
- You receive a **Work order submitted** notification as your receipt.
- Everyone who can assign work (HODs and Administrators) is told about it, and the **Acknowledge** clock starts.
- The **Workflow** tab tells you who the job is waiting on.

← Back to Work Orders

WO-2026-000049 **P2** • Open

Air Compressor 1000 K/P [Edit](#)

Raised 25/09/2026 11:24 AM by Ravi Kumar

Acknowledge SLA 14m left

Overview Assignment Conversation Photos Status Timeline **Workflow**

Waiting on a Supervisor: Assign technician.

Waiting for a Supervisor to assign a technician.

Figure 2.7 — Workflow tab: while it is Open you are waiting for a technician to be assigned.

2.5 Editing your work order

SI SERVICE INSIDE

Dashboard Work Orders Notifications

← Back to Work Order

Edit WO-2026-000049

Core details can be corrected while this work order is still Open — before a technician is assigned.

Department *
Maintenance

Who should handle this. Change it if someone else should take it.

Plant *
F1 — PMW Industries

Where the machine is. This is what decides the equipment list below — changing it clears the equipment, because each plant keeps its own machines.

Equipment *
Air Compressor 1000 K/P

Showing F1 — PMW Industries's machines. Not listed? Choose "Other (specify)" at the bottom and say what it is.

Area
Compressor room, Bay 2

Criticality: medium · Machine code: AC2 · Model: PK 75-250

Work order type
Breakdown Inspection Project Repairing

Unplanned failure needing corrective work.

Complaint *
DEMO (user manual) — Oil leaking from the compressor base, pressure drops to 5 bar after 10 minutes of running. Loud knocking sound on start-up.

SLA preview

P2 From production impact

Acknowledge 15 min

Response 45 min after assignment

Resolution 7 hrs after work starts

Each window starts when the one before it is met, not when the job is raised — so the time to repair is measured from when the repair begins.

Changing the impact re-derives the priority, but SLA deadlines already set at creation are not changed retroactively.

Save Changes Cancel

Ravi Kumar Requester

Sign out

Figure 2.8 — Edit WO — available only while the work order is Open.

- While the status is **Open**, press **Edit** at the top of the work order to correct any detail — department, plant, equipment, complaint, impact and so on — then press **Save Changes**.
- Once a technician is assigned the **Edit** button disappears. From then on details only change through the workflow, so the record cannot be quietly rewritten. To add information, post a **comment** instead.

2.6 Comments and photos




Figure 2.9 — The Conversation tab: your messages on the right, everyone else's on the left.

- 1 Open the work order and go to **Conversation**.
 - 2 Type in the **Message...** box and press **Post**.
 - 3 To add a picture, press **Photo** and take or choose one. It appears in the thread and on the **Photos** tab.
- Use comments to add details the technician needs, answer their questions, or report that things have got worse.
 - You can edit or delete your own comments. You cannot delete other people's comments or any photo.
 - On the **Photos** tab, open one of **your** photos and press **Replace** to swap it for a better one while the job is still live. A replaced photo is marked as replaced, and the original is kept in the audit record.

[← Back to Work Orders](#)

WO-2026-000049 P2 • [Open](#)

[Edit](#)

Raised
25/09/2026 11:24 AM
by Ravi Kumar

Acknowledge SLA
14m left

Overview

Assignment

Conversation

Photos

Status Timeline

Workflow

Photos (1)

[Upload](#)

Before work (1)
Taken while the fault was reported and waiting — nobody had started on it yet.



Ravi Kumar
Requester
25/09/2026 11:24 AM

Figure 2.10 — The Photos tab groups photos by the stage they were taken at.

2.7 Following progress




Figure 2.11 — The Status Timeline of a finished work order, including a spare-part wait and a failed test.

- The **Status Timeline** lists every step with the person and the time. Amber sub-entries show steps that went back — for example a failed test sent back to Repairing, with the reason.
- SI notifies you when your job is **accepted**, when it is **waiting for a spare part** (and when work resumes), when it is **completed**, and if its **priority or deadline** is changed.
- When the technician marks the job completed it closes automatically. The completion notes on the **Overview** tab say what was done.

2.8 Finding work orders

My Work Orders
Showing 1-9 of 46 work orders · All dates

Search WO#, equipment or area | Sort: Newest first | Filters | Export

Priority: All | Status: All | Date raised: All dates | Department: All
Plant: All | Machine: All | Assigned technician: All | SLA: All

WORK ORDER	DEPARTMENT	PRIORITY	STATUS	RAISED	ASSIGNED	SLA
WO-2026-000049 Air Compressor 1000 K/P	Maintenance	P2	Open	25/09/2026 11:24 AM	Unassigned	12m left Acknowledge
WO-2026-000048 Batching Plant	Maintenance	P1	Assigned	19/09/2026 9:06 PM	Meera Iyer	Breached Response
WO-2026-000047 Air Compressor 1000 K/P	Production F1	P2	Closed	19/09/2026 9:03 PM	Arun Kumar	-
WO-2026-000046 Steelpole Cutting Machine No 1	Production F1	P1	Closed	08/09/2026 9:14 AM	Arun Kumar	-
WO-2026-000086 Batching Plant	Production F3	P7	Closed	01/09/2026 3:53 AM	Arun Kumar	-
WO-2026-000087 Floodlight	QC F3	P2	Closed	30/08/2026 3:53 PM	Meera Iyer	-
WO-2026-000088 Batching Plant	Production F3	P7	Closed	29/08/2026 3:53 AM	Arun Kumar	-
WO-2026-000089 Floodlight	QC F3	P4	Accepted	27/08/2026 3:53 PM	Meera Iyer	- Response

Left sidebar: Dashboard, Work Orders, Notifications. User: Ravi Kumar, Requester. Sign out.

Figure 2.12 — Work Orders list with the Filters panel open.

- **Search** by WO number, equipment or description.
- **Sort** by newest, oldest, priority, SLA (soonest due) or WO number.
- **Filters** — priority, status, date raised (today, this week, this month, a custom range...), department, plant, machine, technician and SLA state.
- **Export** — downloads the work orders currently listed to an Excel workbook, with their history and comments on separate sheets.
- Tap any row to open that work order.

2.9 Common situations

Q I picked the wrong department or machine.

If the work order is still **Open**, press **Edit** and correct it. If a technician is already assigned, post a comment explaining the mistake, or ask your HOD.

Q The machine is not in the equipment list.

Check you chose the right **Plant** first. If it is still missing, choose **Other (specify)** and type its name.

Q Nobody has picked up my urgent job.

Check the **Workflow** tab and the SLA in the header. For a true emergency, phone the maintenance team as well.

Q The problem came back after the job was closed.

Contact your HOD or Supervisor. They can send a finished job back to repair, or you can raise a new work order that mentions the old WO number.

Q I raised the same fault twice.

Comment on the duplicate saying which WO number it repeats. Only an Administrator can delete a work order.

Q I can't see a colleague's work order.

Requesters only see work orders they raised. Ask the person who raised it, or a Supervisor.

03.

APPENDIX

Quick reference

Who can do what at a glance, and the words SI uses.

IN THIS CHAPTER

- 3.1** Who can do what
 - 3.2** Words SI uses
 - 3.3** Need help?
-

3.1 Who can do what

Action	Requester	Technician	Admin
Sign in with email or employee ID	✓	✓	✓
Change your own password	✓	✓	✓
See work orders you raised	✓	—	✓ all
See work orders assigned to you	—	✓	✓ all
Raise a work order	✓	X ¹	✓
Raise one on somebody's behalf	X	X	✓
Edit details while Open	Own	X	✓
Assign / reassign a technician	X	X	✓
Accept, decline, start, test, complete	X	Own jobs	—
Pause for a spare part / resume	X	Own jobs	—
Comment and add photos	✓	✓	✓
Replace a photo you uploaded	✓	✓	✓
Change a priority / extend an SLA	X	X	✓
Delete a work order	X	X	✓
Export the list to Excel	✓	✓	✓
Manage users	X	X	✓ ²
Change settings	X	X	✓ ²

¹ Unless the account also holds the Requester role. ² Some actions are for the app developer only — see the Administrator guide.

3.2 Words SI uses

Term	Meaning
Work order (WO)	A record of one fault or job, numbered like WO-2026-000049.
Requester	The person who reported the fault.
Assign	Choosing which technician does the job.
Handover	Reassigning a job that is already under way. It keeps its stage.
Production impact	How badly the fault affects production. It decides the priority.
Priority (P1–P8)	How urgent a job is. P1 is the most urgent.
SLA	The time allowed for each stage: acknowledge, response and resolution.
At risk / Breached	A stage in its last quarter of time / a stage that ran out of time.

Term	Meaning
Sign-off	A HOD's check that a closed job was done properly. Only then does it count on the dashboards.
Retire	Take a setting out of use without breaking old records.
App developer	The team that builds and maintains SI. They carry out the actions marked ★.

3.3 Need help?

For account problems — cannot sign in, forgotten password, wrong role — contact your **Administrator**. For questions about a particular job, comment on the work order so everyone involved can see it.