


ALL ROLES

SI Work Order App User Guide

Complete manual — all roles



Contents

01 Getting started FOR EVERYONE

What SI does · Roles — who does what · Getting an account · Signing in · Choosing a new password · Finding your way around · Using SI on your phone · Notifications · How a work order moves · Priorities and SLA deadlines · Inside a work order

02 Requester guide ROLE GUIDE

At a glance · Your dashboard · Raising a work order · After you submit · Editing your work order · Comments and photos · Following progress · Finding work orders · Common situations

03 Technician guide ROLE GUIDE

At a glance · Your dashboard — My Tasks · The job workflow · Comments and photos · Keeping an eye on the SLA · Notifications you receive · Common situations

04 Administrator guide ROLE GUIDE

At a glance · The Administrator dashboard · Assigning a technician · Raising a work order for somebody · Changing a priority · Extending an SLA · Deleting a work order · Managing users · Settings · Common situations

05 Quick reference APPENDIX

Who can do what · Words SI uses · Need help?

Note: How to use this guide. Chapter 1 covers what everybody needs: getting an account, signing in, finding your way around, and how work orders move. Chapters 2–4 are one per role — read the one for your role. Screenshots come from the SI test site with demo data, so names and numbers will differ from what you see. Buttons and labels are shown in **bold**.

01.

FOR EVERYONE

Getting started

What SI is, how to get an account, how to sign in, and how to find your way around. Read this first, whatever your role.

IN THIS CHAPTER

- 1.1** What SI does
 - 1.2** Roles — who does what
 - 1.3** Getting an account
 - 1.4** Signing in
 - 1.5** Choosing a new password
 - 1.6** Finding your way around
 - 1.7** Using SI on your phone
 - 1.8** Notifications
 - 1.9** How a work order moves
 - 1.10** Priorities and SLA deadlines
 - 1.11** Inside a work order
-

1.1 What SI does

SI (Service Inside) is PMW Group's maintenance work order app. When a machine or facility has a fault, somebody **raises a work order**. An HOD or Administrator assigns it to a technician, the technician **carries out the repair**, and the app keeps a full record of who did what and when.

It runs in any web browser — on a PC, a tablet or a phone — so there is nothing to install. You can also add it to your phone's home screen so it opens like an app (see *Using SI on your phone* below).

1.2 Roles — who does what

Every account has one or more roles. Your role decides which screens you see and which buttons you get. This guide covers the three most common roles:

Role	What they do in SI
Requester	Reports faults by raising work orders, adds photos and comments, and follows the repair until it is finished.
Technician	Receives jobs, accepts or declines them, carries out the repair step by step, and marks the work completed.
Administrator	Oversees all work in the plant, assigns technicians, manages user accounts, and maintains the settings (departments, equipment, priorities and SLA targets).

Note: SI also has **Supervisor**, **HOD** and **Manager** roles. HODs assign technicians and sign off closed work orders, and Supervisors and Managers oversee the work. One person can hold more than one role — for example Requester + Technician — and then gets everything both roles allow.

1.3 Getting an account

There is **no self sign-up** in SI. Accounts are created by your Administrator, so the app always knows who everybody is and what they are allowed to do.

- 1 Contact your **Administrator** (or the IT / maintenance office) and ask for an SI account.
- 2 Give them your **full name**, **company email address**, **phone number**, your **employee ID** (if you have one) and your **department**, and tell them which **role** you need.
- 3 The Administrator creates the account and gives you a **temporary password**.
- 4 Sign in with it (see below). The first time you sign in, SI asks you to **choose your own password** before you can do anything else.

1.4 Signing in

Figure 1.1 — The sign-in screen.

- 1 Open SI in your browser (or tap the SI icon on your home screen).
- 2 In **Company email or employee ID**, type either your company email address **or** your employee ID. Both work — capital letters and spaces in an employee ID do not matter.
- 3 Type your **Password**. Tap the eye icon to show what you typed.
- 4 Tick **Remember me** on your own phone or PC so you stay signed in. Leave it unticked on a shared computer.
- 5 Press **Sign in**. SI opens the dashboard for your role.

Tip: If sign-in fails, SI shows the same message whether the email/ID or the password was wrong — this protects your account. Check both, and after a few failed tries wait a moment before trying again.

Important: Forgot your password? Contact your **Administrator**. They will set a temporary password for you, which you replace the next time you sign in.

1.5 Choosing a new password

Change your password
Choose a new password for your account.

New password *

Confirm new password *

At least 8 characters. Nobody else can see it, your administrator included — if you forget it, it has to be reset.

✓ **Change password**

Figure 1.2 — The Change password screen appears on your first sign-in, and after an Administrator resets your password.

- Enter the new password twice. It must be **at least 8 characters**.
- Nobody else can see your password — not even your Administrator.
- Until you set your own password you cannot reach any other screen. This is on purpose: the temporary password was chosen by somebody else.

1.6 Finding your way around

My Work Orders
Everything you've raised, and what's happening with it.

Waiting for a technician **6** | Closed today **0**

Open 31 still in flight

Of these — a job can appear in a stage and in an SLA figure both:

Open 6 | Assigned 1 | Accepted 5 | Repairing 5 | Waiting Spare Part 3 | Testing 3 | On The Way 4 | On Site 4

SLA at risk 0 | Overdue 9

Waiting for a technician 6
You raised these and nobody has been assigned yet.

WO-ID	Title	Priority	Status	Actions
WO-2026-000017	Floodlight	P4	Unassigned	Breached - Acknowledge Open →
WO-2026-000018	Batching Plant	P1	Unassigned	Breached - Acknowledge Open →
WO-2026-000028	Batching Plant	P3	Unassigned	Breached - Acknowledge Open →
WO-2026-000029	Floodlight	P4	Unassigned	Breached - Acknowledge Open →

Ravi Kumar
Requester

Sign out

Figure 1.3 — The screen layout (Requester shown). On a PC the menu is on the left.

Part of the screen	What it is for
Dashboard	Your starting page: counts and lists of the work that needs your attention.
Work Orders	The full list of work orders you can see, with search, filters, sorting and Excel export.
Notifications	Everything SI has told you about, grouped by category.
Users / Settings	Administrators only — accounts and system settings.
Bell icon (top right)	Opens your latest notifications. A red dot means something is unread.
Role badge (top right)	Shows the role you are working as. If you hold several roles, use it to switch dashboards.
Your name / Sign out	Bottom of the menu. Always sign out on a shared computer.

1.7 Using SI on your phone




Figure 1.4 — Dashboard on a phone




Figure 1.5 — Tap ≡ to open the menu




Figure 1.6 — A work order on a phone

SI adapts to small screens. The menu hides behind the ≡ button at the top left, and wide tables turn into cards you can scroll.

- **iPhone:** open SI in **Safari**, tap the **Share** button, then **Add to Home Screen**. Pop-up alerts on iPhone only work once SI is added this way.
- **Android:** open SI in **Chrome**, tap the : menu, then **Install app** or **Add to Home screen**.

1.8 Notifications




Figure 1.7 — The bell opens your latest notifications without leaving the page.

- SI notifies you when something happens that concerns you — for example a job assigned to you, or your work order completed.
- Each notification shows **how long ago** it happened and the exact date and time, plus **tags** for who caused it and which stage the job was at.
- Tap a notification to open that work order. **Mark all read** clears the red dot.
- On the **Notifications** page, filter by category and use **Clear read** to delete notifications you have already read. Unread ones are never deleted.
- To get alerts on your phone or PC while SI is in the background, press **Turn on alerts with sound** in the bell panel and allow notifications when the browser asks. Alerts only arrive while SI is open somewhere (a tab or the home-screen app) — not after it has been fully closed.

1.9 How a work order moves

Every work order goes through the same stages, in order. No stage can be skipped, and every move is recorded on the **Status Timeline** with the person's name and the time.



Status	Meaning
Open	Raised and waiting for somebody to assign a technician.
Assigned	A technician has been chosen and must accept or decline. A decline sends it back to Open.
Accepted	The technician has taken the job but not started yet.
Repairing	Work is in progress.
Waiting Spare Part	Paused because a part is needed. Returns to Repairing when the part arrives.
Testing	The fix is being tested. A failed test sends it back to Repairing.
Completed → Closed	The technician marks the repair completed, and SI closes it automatically at the same moment.

1.10 Priorities and SLA deadlines

You never choose a priority — SI works it out from the **production impact** picked when the work order is raised, and raises it further if a **safety** or **environmental** risk is flagged. Each priority has an SLA (service-level agreement): a time limit for each of three stages.

Priority	Production impact	1. Acknowledge	2. Response	3. Resolution
P1 Critical	Full production stoppage	5 min	10 min	3 hrs 45 min
P2 High	Running at reduced capacity	15 min	45 min	7 hrs
P3 Medium	Auxiliary equipment, no line impact	30 min	3 hrs 30 min	20 hrs
P4 Low	No production impact (cosmetic/routine)	2 hrs	22 hrs	4 days
P7 Long-term	Long-term task (planned)	5 days	3 days	7 days
P8 Scheduled	Scheduled work (month-scale)	5 days	5 days	20 days

- **Acknowledge** — from raising the work order until a technician is assigned.
- **Response** — from assignment until the technician starts work.
- **Resolution** — from starting work until the repair is completed.
- Each stage's clock starts when the previous stage finishes. The header of every work order shows the current stage and the time left, for example **14m left, At risk** (in the last quarter of its time) or **Breached** (late).
- These are the current settings. Administrators can change them, so the times shown in the app are always the ones that apply.

1.11 Inside a work order

The screenshot shows the 'Air Compressor 1000 K/P' work order interface. On the left is a dark blue sidebar with the SI logo and navigation links: Dashboard, Work Orders (selected), and Notifications. The main content area has a header with a 'Back to Work Orders' link, the work order ID 'WO-2026-000049', a 'P2' priority badge, and an 'Open' status. An 'Edit' button is visible. The right side of the header shows the date '25/09/2026 11:24 AM', the requester 'Ravi Kumar', and an 'Acknowledge SLA 14m left' timer. Below the header are six tabs: Overview (selected), Assignment, Conversation, Photos, Status Timeline, and Workflow. The 'Overview' tab displays a detailed form with the following information:

Department	Maintenance
Plant	F1 — PMW Industries
Equipment	Air Compressor 1000 K/P
Area	Compressor room, Bay 2
Type	Breakdown
Production impact	Running at reduced capacity
Requested by	Ravi Kumar
Requester phone	98450 11223
Safety risk	No
Environmental risk	No
Permit / LOTO required	No

Complaint
DEMO (user manual) — Oil leaking from the compressor base, pressure drops to 5 bar after 10 minutes of running. Loud knocking sound on start-up.

SLA targets (P2)

	target	actual
Acknowledge	15 min	Running
Response	45 min after assignment	
Resolution	7 hrs after work starts	

Measured in stages, not from when it was raised: each window starts when the one before it is met.

Figure 1.8 — Every work order has the same header and six tabs.

Tab	What you find there
Overview	All the details — department, plant, equipment, complaint, risks — plus the SLA targets and how long each stage actually took.
Assignment	Who the job is assigned to. HODs and Administrators assign and reassign here, until the job is completed. After that the Assign buttons are greyed out.
Conversation	Comments and photos in one chat-style thread. A red number shows how many new messages you have not read.
Photos	Every photo, grouped by the stage it was taken at (before work, during repair, testing...).
Status Timeline	The full history: every move, who made it, when, and any reason given.
Workflow	Tells you whose move it is, and holds the action buttons when it is yours.

Tip: If your session expires while you are typing a work order, SI keeps what you typed and offers to restore it after you sign back in. Photos cannot be kept, so re-attach them.

02.

ROLE GUIDE

Requester guide

You report faults and follow them until they are fixed. This chapter covers everything a Requester can do in SI.

IN THIS CHAPTER

- 2.1** At a glance
 - 2.2** Your dashboard
 - 2.3** Raising a work order
 - 2.4** After you submit
 - 2.5** Editing your work order
 - 2.6** Comments and photos
 - 2.7** Following progress
 - 2.8** Finding work orders
 - 2.9** Common situations
-

2.1 At a glance

You can	You cannot
Raise a work order, with photos	See work orders raised by other people
Edit your work order while it is still Open	Edit it once a technician is assigned
Comment and add photos on your own work orders	Assign a technician or choose who does the job
Replace a photo you uploaded (while the job is live)	Do the technician's steps (accept, repair, test, complete)
Follow progress on the timeline and get notified	Delete a work order, or anyone else's comment or photo
Search, filter and export your work orders to Excel	Reach the Users or Settings screens

2.2 Your dashboard




Figure 2.1 — My Work Orders — the Requester dashboard.

- **Waiting for a technician** — work orders you raised that nobody has been assigned to yet.
- **Closed today** — your work orders finished and signed off today.
- **Open ... still in flight** — everything not yet finished, broken down by stage and by SLA (at risk / overdue). Tap any figure to see the work orders behind it.
- **Recent activity** — your work orders with the latest changes first. Press **See all** for the full list.

2.3 Raising a work order

Go to **Work Orders** and press **Raise Work Order**. Fields marked * are required.

← Back to Work Orders

Raise Work Order

Priority is set from the production impact, and escalates for safety or environmental risk.

Department *

Maintenance

Who should handle this. Change it if someone else should take it.

Plant *

F1 — BMW Industries

Where the machine is. This is what decides the equipment list below — changing it clears the equipment, because each plant keeps its own machines.

Equipment *

Air Compressor 1000 K/P

Showing F1 — BMW Industries's machines. Not listed? Choose "Other (specify)" at the bottom and say what it is.

Area

Compressor room, Bay 2

Criticality: **medium** · Machine code: AC2 · Model: PK 75-250

Work order type

Breakdown Inspection Project Repairing

Unplanned failure needing corrective work.

Complaint *

DEMO (user manual) — Oil leaking from the compressor base, pressure drops to 5 bar after 10 minutes of running. Loud knocking sound on start-up.

Production impact *

☐ Full production stoppage (P1)

☒ Running at reduced capacity (P2)

☐ Auxiliary equipment, no line impact (P3)

☐ No production impact (cosmetic/routine) (P4)

☐ Long-term task (planned, no immediate impact) (P7)

☐ Scheduled work (month-scale) (P8)

Priority

P2 Set from the production impact. Not editable.

Upload Photo

Upload Photo

Resized and compressed on this device before it uploads, so a photo straight off a phone camera goes up in a fraction of the time.

Safety risk

No Yes

Environmental risk

No Yes

Requester *

Ravi Kumar

Phone number *

98450 11223

SLA preview

From production impact

Acknowledge 15 min

Response 45 min after assignment

Resolution 7 hrs after work starts

Each window starts when the one before it is met, not when the job is raised — so the time to repair is measured from when the repair begins.

Submit Cancel

Figure 2.2 — A completed Raise Work Order form, with the SLA preview on the right.

- 1 Department** — the department that should handle the job. Pick the right one; it decides who is told about it.

- 2 **Plant** — where the machine is: F1, F2, F3 or Facility. The equipment list only shows machines at the plant you pick.
- 3 **Equipment** — click the box and type part of the machine name or machine code, then pick it from the list. The machine's criticality, code and model appear underneath.
- 4 **Area** (optional) — where exactly: line, bay, floor, room.
- 5 **Work order type** — **Breakdown** (unplanned failure), **Inspection** (routine check), **Project** (improvement or installation) or **Repairing** (repair of a known fault).
- 6 **Complaint** — describe the problem: what happened, symptoms, sounds, error codes, and when it started.
- 7 **Production impact** — how badly production is affected. This sets the priority, shown in the **Priority** box underneath.
- 8 **Upload Photo** — add one or more photos of the fault. They are shrunk automatically before upload, so a phone photo goes up quickly.
- 9 **Safety risk / Environmental risk** — choose **Yes** if there is one (see below).
- 10 **Requester** and **Phone number** — filled in from your account. Correct them if needed.
- 11 Check the **SLA preview** on the right, then press **Submit**.

The screenshot shows the 'Raise Work Order' interface. On the left is a dark blue sidebar with navigation links: Dashboard, Work Orders (selected), and Notifications. Below these is a user profile for Ravi Kumar (Requester) and a Sign out button. The main content area has a header with a 'Back to Work Orders' link and the title 'Raise Work Order'. Below the title is a note: 'Priority is set from the production impact, and escalates for safety or environmental risk.' The form consists of three main sections: 'Department' (a dropdown menu set to 'Maintenance'), 'Plant' (a dropdown menu set to 'F1 - PMW Industries'), and 'Equipment' (a search bar with a list of equipment items below it). To the right of the form is a blue box labeled 'SLA preview' with the text 'Fill in the form to see the priority and SLA targets here.' Below this box are two buttons: 'Submit' (orange) and 'Cancel' (grey). At the bottom of the equipment list, there is a text input field with the placeholder 'What happened? Include symptoms, sounds, error codes...'.

Figure 2.3 — Type to search. Only machines at the chosen plant are listed.

Machine not in the list?

SI SERVICE INSIDE

Dashboard

Work Orders

Notifications

Users

Settings

Anita Desai Administrator

Sign out

Back to Work Orders

Raise Work Order

Priority is set from the production impact, and escalates for safety or environmental risk.

Department *

Maintenance

Who should handle this. Change it if someone else should take it.

Plant *

Facility

Where the machine is. This is what decides the equipment list below — changing it clears the equipment, because each plant keeps its own machines.

Equipment *

Other (specify)

Showing Facility's machines. Not listed? Choose "Other (specify)" at the bottom and say what it is.

Which equipment *

Name the machine, tool or fixture

Recorded on this work order only — it is not added to the equipment list.

Area

Where in the plant — line, bay, floor

Work order type

Breakdown Inspection Project Repairing

Unplanned failure needing corrective work.

Complaint *

What happened? Include symptoms, sounds, error codes...

SLA preview

Fill in the form to see the priority and SLA targets here.

Submit Cancel

Figure 2.4 — Choose "Other (specify)" at the bottom of the list, then say which equipment it is.

Scroll to the bottom of the equipment list (or type "other") and choose **Other (specify)**. A **Which equipment** box appears — type the name of the machine. It is recorded on this work order only. Ask your Administrator to add the machine to the list if it will come up again.

Flagging a safety or environmental risk

Safety risk

No Yes

High Medium Low

Raises the priority to at least P2.

Environmental risk

No Yes

Figure 2.5 — Choosing Yes for Safety risk asks for its severity and can raise the priority.

- Choose **Yes** under **Safety risk**, then pick the severity: **High** (immediate danger to people), **Medium** (hazardous if left) or **Low** (minor, controlled).
- A line such as "Raises the priority to at least P2" shows what it does to the priority. A High safety risk always makes the job **P1**.

- An **Environmental risk** raises the priority to at least **P2**.

Important: SI is not an emergency alarm. For immediate danger to people, follow the plant's emergency procedure first — then raise the work order.

2.4 After you submit

The screenshot shows the SI Service Inside app interface. On the left is a dark blue sidebar with the SI logo and navigation links: Dashboard, Work Orders (selected), and Notifications. Below these is a user profile for Ravi Kumar, labeled as the Requester, with a 'Sign out' button. The main content area is light blue and shows the details of a new work order. At the top, it says 'Back to Work Orders' and displays the work order number 'WO-2026-000049' with a 'P2' priority tag and an 'Open' status. The title of the work order is 'Air Compressor 1000 K/P'. There is an 'Edit' button and information about when it was raised (25/09/2026 11:24 AM by Ravi Kumar) and the remaining Acknowledge SLA (14m left). Below this is a tabbed interface with 'Overview' selected. The Overview tab shows a table of details: Department (Maintenance), Plant (F1—PMW Industries), Equipment (Air Compressor 1000 K/P), Area (Compressor room, Bay 2), Type (Breakdown), Production impact (Running at reduced capacity), Requested by (Ravi Kumar), Requester phone (98450 11223), Safety risk (No), Environmental risk (No), and Permit / LOTO required (No). To the right of this table is a 'Complaint' section with the text: 'DEMO (user manual) — Oil leaking from the compressor base, pressure drops to 5 bar after 10 minutes of running. Loud knocking sound on start-up.' Below the complaint is an 'SLA targets (P2)' section with a table showing targets for Acknowledge (15 min), Response (45 min after assignment), and Resolution (7 hrs after work starts). A note at the bottom of the SLA section states: 'Measured in stages, not from when it was raised: each window starts when the one before it is met.'

Figure 2.6 — Your new work order opens straight away with its WO number.

- SI gives the work order a number such as **WO-2026-000049** — quote it when you talk to maintenance.
- You receive a **Work order submitted** notification as your receipt.
- Everyone who can assign work (HODs and Administrators) is told about it, and the **Acknowledge** clock starts.
- The **Workflow** tab tells you who the job is waiting on.




Figure 2.7 — Workflow tab: while it is Open you are waiting for a technician to be assigned.

2.5 Editing your work order




Figure 2.8 — Edit WO — available only while the work order is Open.

- While the status is **Open**, press **Edit** at the top of the work order to correct any detail — department, plant, equipment, complaint, impact and so on — then press **Save Changes**.
- Once a technician is assigned the **Edit** button disappears. From then on details only change through the workflow, so the record cannot be quietly rewritten. To add information, post a **comment** instead.

2.6 Comments and photos




Figure 2.9 — The Conversation tab: your messages on the right, everyone else's on the left.

- 1 Open the work order and go to **Conversation**.
 - 2 Type in the **Message...** box and press **Post**.
 - 3 To add a picture, press **Photo** and take or choose one. It appears in the thread and on the **Photos** tab.
- Use comments to add details the technician needs, answer their questions, or report that things have got worse.
 - You can edit or delete your own comments. You cannot delete other people's comments or any photo.
 - On the **Photos** tab, open one of **your** photos and press **Replace** to swap it for a better one while the job is still live. A replaced photo is marked as replaced, and the original is kept in the audit record.

[← Back to Work Orders](#)

WO-2026-000049 P2 • [Open](#)

[Edit](#)

Raised

25/09/2026 11:24 AM

by Ravi Kumar

Acknowledge SLA

14m left

Overview

Assignment

Conversation

Photos

Status Timeline

Workflow

Photos (1)

[Upload](#)

Before work (1)
Taken while the fault was reported and waiting — nobody had started on it yet.



Ravi Kumar
Requester
25/09/2026 11:24 AM

Figure 2.10 — The Photos tab groups photos by the stage they were taken at.

2.7 Following progress




Figure 2.11 — The Status Timeline of a finished work order, including a spare-part wait and a failed test.

- The **Status Timeline** lists every step with the person and the time. Amber sub-entries show steps that went back — for example a failed test sent back to Repairing, with the reason.
- SI notifies you when your job is **accepted**, when it is **waiting for a spare part** (and when work resumes), when it is **completed**, and if its **priority or deadline** is changed.
- When the technician marks the job completed it closes automatically. The completion notes on the **Overview** tab say what was done.

2.8 Finding work orders

My Work Orders
Showing 1-9 of 46 work orders · All dates

Search WO#, equipment or area | Sort: Newest first | Filters | Export

Priority: All | Status: All | Date raised: All dates | Department: All
Plant: All | Machine: All | Assigned technician: All | SLA: All

WORK ORDER	DEPARTMENT	PRIORITY	STATUS	RAISED	ASSIGNED	SLA
WO-2026-000049 Air Compressor 1000 K/P	Maintenance	P2	Open	25/09/2026 11:24 AM	Unassigned	12m left Acknowledge
WO-2026-000048 Batching Plant	Maintenance	P1	Assigned	19/09/2026 9:06 PM	Meera Iyer	Breached Response
WO-2026-000047 Air Compressor 1000 K/P	Production F1	P2	Closed	19/09/2026 9:03 PM	Arun Kumar	-
WO-2026-000046 Steelpole Cutting Machine No 1	Production F1	P1	Closed	08/09/2026 9:14 AM	Arun Kumar	-
WO-2026-000086 Batching Plant	Production F3	P7	Closed	01/09/2026 3:53 AM	Arun Kumar	-
WO-2026-000087 Floodlight	QC F3	P2	Closed	30/08/2026 3:53 PM	Meera Iyer	-
WO-2026-000088 Batching Plant	Production F3	P7	Closed	29/08/2026 3:53 AM	Arun Kumar	-
WO-2026-000089 Floodlight	QC F3	P4	Accepted	27/08/2026 3:53 PM	Meera Iyer	- Response

SI SERVICE INSIDE
Dashboard
Work Orders
Notifications
Ravi Kumar Requester
Sign out

Figure 2.12 — Work Orders list with the Filters panel open.

- **Search** by WO number, equipment or description.
- **Sort** by newest, oldest, priority, SLA (soonest due) or WO number.
- **Filters** — priority, status, date raised (today, this week, this month, a custom range...), department, plant, machine, technician and SLA state.
- **Export** — downloads the work orders currently listed to an Excel workbook, with their history and comments on separate sheets.
- Tap any row to open that work order.

2.9 Common situations

Q I picked the wrong department or machine.

If the work order is still **Open**, press **Edit** and correct it. If a technician is already assigned, post a comment explaining the mistake, or ask your HOD.

Q The machine is not in the equipment list.

Check you chose the right **Plant** first. If it is still missing, choose **Other (specify)** and type its name.

Q Nobody has picked up my urgent job.

Check the **Workflow** tab and the SLA in the header. For a true emergency, phone the maintenance team as well.

Q The problem came back after the job was closed.

Contact your HOD or Supervisor. They can send a finished job back to repair, or you can raise a new work order that mentions the old WO number.

Q I raised the same fault twice.

Comment on the duplicate saying which WO number it repeats. Only an Administrator can delete a work order.

Q I can't see a colleague's work order.

Requesters only see work orders they raised. Ask the person who raised it, or a Supervisor.

03.

ROLE GUIDE

Technician guide

You carry out the repairs. This chapter walks through a job from the moment it is assigned to you until it is closed, including every alternative path.

IN THIS CHAPTER

- 3.1** At a glance
 - 3.2** Your dashboard — My Tasks
 - 3.3** The job workflow
 - 3.4** Comments and photos
 - 3.5** Keeping an eye on the SLA
 - 3.6** Notifications you receive
 - 3.7** Common situations
-

3.1 At a glance

You can	You cannot
See every job assigned to you, with its SLA clock	See jobs that are not assigned to you, including unassigned ones
Accept a job, or decline it with a reason	Assign or reassign a job — to yourself or to anybody else
Start work, pause for a spare part, resume	Skip a step — the order is fixed
Test the fix, record a failed test, mark it completed	Reopen a job once it is closed
Comment and add before/after photos	Delete a work order, another person's comment, or a photo
Search, filter and export your jobs	Raise a work order (unless you also hold the Requester role)

3.2 Your dashboard — My Tasks

My Tasks
Jobs assigned to you, and where each one stands.

Waiting for you to accept **1** | Closed today **0**

Open 13 still in flight

Of these — a job can appear in a stage and in an SLA figure both:

- Assigned **1** | Accepted **3** | Repairing **3** | Waiting Spare Part **1** | Testing **1** | On The Way **2** | On Site **2** | SLA at risk **0** | Overdue **1**

Waiting for you to accept 1
Accept to start, or decline with a reason so the Supervisor can reassign.

WO-2026-000049
Air Compressor 1000 K/P **P2** Arun Kumar 48m left - Response **Open**

Recent activity
Most recently updated first. [See all](#)

WORK ORDER	PRIORITY	STATUS	LAST ACTIVITY	RAISED	SLA
WO-2026-000049 Air Compressor 1000 K/P	P2	Assigned	25/09/2026 2:22 PM	25/09/2026 11:24 AM	48m left - Response
WO-2026-000047 Air Compressor 1000 K/P	P2	Closed	19/09/2026 9:05 PM	19/09/2026 9:03 PM	—
WO-2026-000046 Steelpole Cutting Machine No 1	P1	Closed	19/09/2026 2:53 AM	08/09/2026 9:14 AM	—
WO-2026-000066			19/09/2026 2:52 AM	03/09/2026 2:52 AM	

Figure 3.1 — My Tasks — the Technician dashboard.

- **Waiting for you to accept** — new jobs assigned to you. These need your answer first.
- **Closed today** — jobs you finished that have been signed off today.
- **Open ... still in flight** — your jobs by stage, plus how many are **at risk** or **overdue** on their SLA.
- The list underneath shows each waiting job with its priority and the time left.




Figure 3.2 — My Tasks on a phone

3.3 The job workflow

Everything you do to a job happens on its **Workflow** tab. The yellow bar always says "**Your move: ...**" and names the buttons you can press next. Some steps need a short note — the button stays greyed out until you type one.



Step 1 — Accept or decline

← Back to Work Orders

WO-2026-000049 **P2** • Assigned

Air Compressor 1000 K/P

Raised 25/09/2026 11:24 AM by Ravi Kumar

Response SLA 39m left

Overview Assignment Conversation **2** Photos Status Timeline **Workflow**

Your move: Accept or Decline.

You've been assigned this work order. Accept it to start, or decline with a reason so the Supervisor can reassign.

Accept this job

Can't take this one

Reason for declining...

Confirm decline

Figure 3.3 — A new assignment: accept it, or decline with a reason.

- You get a notification when a job is assigned to you. Open it, go to **Workflow**, and read the **Overview** and **Conversation** first.
- Accept this job** — the job becomes yours and moves to **Accepted**. The Requester and the people who assign work are told.
- Can't take this one** — type a reason (for example "on leave this afternoon") and press **Confirm decline**. SI shows your reason again before sending. The job goes back to Open to be reassigned, and it **disappears from your list**.

Step 2 — Start work

← Back to Work Orders

WO-2026-000049 **P2** • Accepted

Air Compressor 1000 K/P

Raised 25/09/2026 11:24 AM by Ravi Kumar

Response SLA 39m left

Overview Assignment Conversation **2** Photos Status Timeline **Workflow**

Your move: Start work.

Accepted. Start work once you're at the equipment.

Start Work

Figure 3.4 — Accepted: press Start Work when you begin the repair.

When you actually begin, press **Start Work**. The job moves to **Repairing** and the **Resolution** clock starts. Press it when you start, not before — the time it takes to repair is measured from this moment.

Step 3 — Repairing (and waiting for a spare part)

The screenshot shows the 'Workflow' tab for work order WO-2026-000049, which is in the 'Repairing' state. The title is 'Air Compressor 1000 K/P'. The 'Raised' date and time are 25/09/2026 11:24 AM by Ravi Kumar. The 'Resolution SLA' is 6h 58m left. The 'Conversation' tab has 2 messages. The 'Workflow' tab is active, showing a yellow bar with the text 'Your move: Start testing or Waiting for spare part.' Below this is a light blue box with the instruction: 'Log progress in Comments as you work. If you need a part, mark it — otherwise move to testing once you believe it's fixed.' There are two buttons: 'Waiting Spare Part' (with a pause icon) and 'Start Testing' (with a play icon). Below these is a text input field containing 'Base gasket kit (PK 75-250) ordered from store — ETA 2 days.' and a 'Confirm' button.

Figure 3.5 — Repairing: go to testing, or pause for a spare part with a reason.

- Post progress in **Conversation** as you work — findings, part numbers, meter readings, photos.
- If you need a part, press **Waiting Spare Part**, type **which part and why** (for example "Base gasket kit ordered from store — ETA 2 days"), then press **Confirm**. The Requester and the people who assign work are told the job is paused.
- When the part arrives, press **Part Received — Resume Repair**. The job returns to **Repairing**.

The screenshot shows the 'Workflow' tab for work order WO-2026-000049, which is in the 'Waiting Spare Part' state. The title is 'Air Compressor 1000 K/P'. The 'Raised' date and time are 25/09/2026 11:24 AM by Ravi Kumar. The 'Resolution SLA' is 6h 58m left. The 'Conversation' tab has 2 messages. The 'Workflow' tab is active, showing a yellow bar with the text 'Your move: Resume repair.' Below this is a light blue box with the text 'Paused — waiting on a spare part.' There is one button: 'Part Received — Resume Repair' (with a play icon).

Figure 3.6 — Paused — waiting on a spare part.

Step 4 — Testing

← Back to Work Orders

WO-2026-000049 **P2** • Testing

Air Compressor 1000 K/P

Raised 25/09/2026 11:24 AM by Ravi Kumar

Resolution SLA 6h 58m left

Overview Assignment Conversation **2** Photos Status Timeline **Workflow**

Your move: Mark completed or Test failed.

Testing the fix. If it holds, mark completed; if not, send it back to repair.

Test Failed Mark Completed

Still losing pressure after 15 minutes — second seal also worn. Back to Repair

Figure 3.7 — Testing: mark it completed, or record a failed test.

- When you believe it is fixed, press **Start Testing**.
- If the test **fails**, press **Test Failed**, describe **what failed**, and press **Back to Repair**. The job returns to **Repairing** and the reason is recorded on the timeline. Fix it and test again.

Step 5 — Mark completed

← Back to Work Orders

WO-2026-000049 **P2** • Testing

Air Compressor 1000 K/P

Raised 25/09/2026 11:24 AM by Ravi Kumar

Resolution SLA 6h 57m left

Overview Assignment Conversation Photos Status Timeline **Workflow**

Your move: Mark completed or Test failed.

Testing the fix. If it holds, mark completed; if not, send it back to repair.

Test Failed Mark Completed

Replaced base gasket and both shaft seals (kit PK 75-250). Pressure held at 8 bar for 30 minutes, no leak, knocking gone.

Mark completed

Figure 3.8 — Describe what you did to fix it. The Requester can read this.

1 Press **Mark Completed**.

- 2 In **What did you do to fix it?** describe the repair — parts replaced, adjustments made, test results. The Requester will read this.
- 3 Press **Mark completed** to confirm. The job becomes **Completed** and is **closed automatically** at the same moment.




Figure 3.9 — Finished — nothing further to do.

Tip: Before completing, add an "after" photo in Conversation. It is filed under the Testing stage on the Photos tab, next to the "before" photo the Requester took.

3.4 Comments and photos




Figure 3.10 — The Conversation thread: your messages on the right in navy.

- Type in **Message...** and press **Post**. Press **Photo** to attach a picture from your camera or gallery.
- Photos are shrunk automatically before upload, so they go up quickly even on mobile data.
- Each photo is filed under the stage the job was at when you took it, so **Before work**, **Repairing** and **Testing** photos stay separate on the Photos tab.
- You can replace a photo **you** uploaded while the job is live: open it on the **Photos** tab and press **Replace**.




Figure 3.11 — Photos grouped by stage — the Requester's "before" photo and your testing photo.

3.5 Keeping an eye on the SLA

- The top right of every job shows the stage that is running and the time left — **Response SLA** before you start work, **Resolution SLA** after.
- SI warns you when a job assigned to you is **at risk** (in the last quarter of its time) and again if it is **breached**.
- A late stage stays marked as missed on the record, even if the job is finished afterwards. Only an Administrator can give a job more time (Extend SLA).

3.6 Notifications you receive

The screenshot displays the 'Notifications' section of the SI Service Inside app. The left sidebar contains navigation options: Dashboard, Work Orders, and Notifications (highlighted). The top right corner shows a bell icon and a 'Technician' label. The main content area is titled 'Notifications' and shows '7 unread of 8'. It includes filters for 'All', 'Assignment 5', 'Requester 2', and 'System 1'. The notifications list shows five items: two assignments, two verifications, and a priority change. Each notification includes a timestamp, a status indicator, and a close button. The bottom of the list shows 'Showing 1-5 of 8 notifications' and a pagination control with '1' selected.

Figure 3.12 — Notifications for a technician.

- A job is **assigned** to you, or **handed over** to you from another technician. A handover keeps the job at its current stage — there is nothing to accept, just carry on.
- A job you finished is **sent back for rework** by a HOD, Manager or Administrator.
- A job of yours is **at risk** or has **breached** its SLA.
- An Administrator **changed the priority** of, or **extended**, one of your jobs.

3.7 Common situations

Q I accepted by mistake / I can't continue this job.

Tell your HOD in the job's Conversation. Only an HOD or Administrator can reassign it to somebody else.

Q A job I declined has disappeared.

That is expected. It went back to the queue with your reason.

Q The Confirm button is greyed out.

That step needs a note — a decline reason, which spare part, what failed, or what you did. Type it and the button turns on.

Q I don't see a Raise Work Order button.

Technician-only accounts don't raise work orders. Ask your Administrator to add the Requester role if you need to.

Q The job is waiting on a part for a long time.

Leave it in Waiting Spare Part and post updates in Conversation. Press Resume Repair only when the part is actually here.

Q My new role or job isn't showing.

Role changes take up to an hour to take effect. Sign out and back in to see them straight away.

04.

ROLE GUIDE

Administrator guide

You oversee all work in the plant, assign technicians, manage accounts and maintain the settings. This chapter covers every Administrator screen.

IN THIS CHAPTER

- 4.1** At a glance
 - 4.2** The Administrator dashboard
 - 4.3** Assigning a technician
 - 4.4** Raising a work order for somebody
 - 4.5** Changing a priority
 - 4.6** Extending an SLA
 - 4.7** Deleting a work order
 - 4.8** Managing users
 - 4.9** Settings
 - 4.10** Common situations
-

4.1 At a glance

You can	Rules to know
See and search every work order in every plant	You cannot assign a job to yourself
Raise work orders, including on somebody's behalf	Details can only be edited while a job is Open
Assign and reassign technicians	Priority changes need a written reason
Change a priority, extend an SLA, delete a work order	Deleting a work order cannot be undone
Create accounts, change roles, activate / deactivate	You can only manage accounts ranked below you
Maintain departments, equipment, labels and SLA targets	Some actions are for the app developer only (marked ★)

Note: Actions marked ★ in this chapter are done by the app developer, who also looks after the Administrator accounts, because Administrators cannot edit each other. Ask them when you need one.

4.2 The Administrator dashboard




Figure 4.1 — The plant-wide dashboard with its cards and charts.

- **Cards** — Total open work orders, a count for each priority, Completed today, Overdue, Average response time, Average repair time and Active technicians. **Tap any card** to see the work orders behind the number.
- **Refresh now** recalculates the figures (they also refresh by themselves every 15 minutes).
- **Trends and breakdowns** — work orders raised over time, by department, by machine (top 10), and technician performance. Use the quiet **plant · period** line above the charts to choose a plant and a period (today, this week, this month, last 12 months or a custom range).
- Figures count work that has been **signed off**. A job that has closed but not yet been checked by a HOD is not counted yet.

4.3 Assigning a technician




Figure 4.2 — The Assignment tab lists technicians with their skills and how many open jobs they have.

- 1 Open the work order (the dashboard's unassigned list, or **Work Orders** filtered by status **Open**).
- 2 Go to the **Assignment** tab.
- 3 Check each technician's skills and **open jobs** count, then press **Assign** next to the right person.
- 4 A confirmation names the technician and explains what happens next. Press **Done**.




Figure 4.3 — The confirmation after assigning.

- The technician is notified and must **accept** or **decline**. If they decline, the job comes back **unassigned** and you are notified, with their reason.
- **Reassign** — on the Assignment or Workflow tab, choose a different technician at any stage until the job is completed. Before they accept, the new person must accept. After that it is a **handover**: the job keeps its stage, and the new technician simply carries on.

- Nobody can assign a job to themselves — not even an Administrator. By default HODs and Administrators can assign, and Administrators always can. The ★ app developer can let other roles assign in Settings → Permissions.
- Once a job is completed or closed its technician is fixed, and the Assign buttons are greyed out for everybody — so nobody can hand a finished job to someone by mistake. If it really needs another technician, press **Not done properly** and **Send back for rework** first. The job goes back to Repairing, and you can then reassign it.




Figure 4.4 — The Workflow tab shows who the job is waiting on, with a Reassign button.

4.4 Raising a work order for somebody

Raise a work order exactly as a Requester does (see the Requester guide). As an Administrator you can change the **Requester** and **Phone number** fields to the person who reported the fault — for example after a phone call. That person then gets the "Work order submitted" receipt and can follow the job.

4.5 Changing a priority

Change priority ✕

WO-2026-000049 is **High (P2)** — derived from its production impact.

New priority

- ☐ **Back to the derived priority (P2)**
Follows the production impact again, including any later edit of it.
- ☐ **P1** Critical
- ☒ **P2** High
- ☐ **P3** Medium
- ☐ **P4** Low
- ☐ **P7** Long-term
- ☐ **P8** Scheduled

Reason *

Why this priority — the technician and the requester both see this.

At least 10 characters (0 so far).

Cancel ↕ Change priority

Figure 4.5 — Change priority — a reason of at least 10 characters is required.

- 1** Open the work order and press **Change priority** at the top.
 - 2** Choose the new priority — or **Back to the derived priority** to let the production impact decide again.
 - 3** Type the **Reason** (at least 10 characters), for example "Reclassified — this overhaul turned out to be urgent".
 - 4** Press **Change priority**.
- Only possible while the job is still live (not once it is closed).
 - The SLA deadlines are recalculated from when the job was raised. The technician and the requester are notified, and the change and your reason are recorded on the timeline.
 - The assigned technician and the stage do not change.

4.6 Extending an SLA

Extend SLA ✕

W0-2026-000048 is **Critical (P1)**, and its **response** stage was due **19/09/2026 9:17 PM** — 5d 17h ago.

Every option below still leaves this work order past its deadline. Extending it will give it more time, but it will stay overdue.

Give it more time

- ☐ **Another 10m, still Critical (P1)**
Response due 19/09/2026 9:27 PM · +10m · still overdue
- ☐ **Re-grade to High (P2)**
Response due 19/09/2026 9:52 PM · +35m · still overdue
- ☐ **Re-grade to Medium (P3)**
Response due 20/09/2026 12:37 AM · +3h 20m · still overdue
- ☐ **Re-grade to Low (P4)**
Response due 20/09/2026 7:07 PM · +21h 50m · still overdue
- ☐ **Re-grade to Long-term (P7)**
Response due 22/09/2026 9:07 PM · +2d 23h · still overdue
- ☒ **Re-grade to Scheduled (P8)** Suggested
Response due 24/09/2026 9:07 PM · +4d 23h · still overdue

ⓘ This is recorded on the work order's timeline with your name and the time, and the assigned technician and the person who raised it are both notified. The stages this work order has already missed stay on its record — extending gives it more time from here, it does not erase what happened.

No, leave it **Yes, extend to P8**

Figure 4.6 — Extend SLA offers more time at the same priority, or a re-grade to a less urgent one.

The **Extend SLA** button appears when the stage a job is in is **at risk or overdue**.

- **Give it more time** — adds another full stage window at the **same** priority. Use this when the job is correctly graded but genuinely needs longer. You can do it more than once — SI warns you, in red, how many times it has already been extended.
- **Re-grade** — moves the job to a less urgent priority, which gives the current stage that priority's longer window. **Suggested** marks the option that best fits.
- Options marked **still overdue** would still leave the job late.
- Press **Yes, extend...** to confirm. It is recorded with your name, and the technician and requester are notified. Stages already missed stay recorded as missed — extending gives time from now on, it does not erase history.

4.7 Deleting a work order




Figure 4.7 — Deleting needs the WO number typed exactly.

Important: Deleting removes the work order together with its comments, photos, notifications and history. It **cannot be undone** (a record of the deletion is kept). For duplicates or mistakes, deleting is fine — for real work, keep the record.

Press **Delete** on the work order, type the WO number (for example WO-2026-000049) and press **Delete permanently**. By default only Administrators can delete. The ★ app developer can allow other roles in **Settings** → **Permissions**.

4.8 Managing users

Users
Accounts, roles and passwords. 7 total.

Q Name, email, employee ID or depart Role: All

USER	ROLE	DEPARTMENT	STATUS	ACTIONS
Anita Desai · you admin@example.com	Administrator	DEPT-ENGINEERING	Active	Protected — administered only from Supabase
Arun Kumar tech.arun@example.com	Technician	DEPT-ENGINEERING	Active	Password Role Edit Deactivate Delete
Meera Iyer tech.meera@example.com	Technician	DEPT-ENGINEERING	Active	Password Role Edit Deactivate Delete
Priya Nair supervisor@example.com	Supervisor	DEPT-ENGINEERING	Active	Password Role Edit Deactivate Delete
Rajesh Menon hod@example.com	HOD Requester	DEPT-ENGINEERING	Active	Password Role Edit Deactivate Delete

Showing 1-5 of 7 users


Figure 4.8 — Admin → Users.

Go to **Users** in the menu. Search by name, email, employee ID or department, and filter by role. Each row shows the person's roles, department and status, with action buttons on the right.

Button	What it does
Add user	Create a new account.
Password ★	Set a temporary password for somebody (for example when they have forgotten theirs).
Role	Change the person's roles and department.
Edit	Change name, phone and employee ID. Changing somebody else's sign-in email is ★.
Deactivate / Activate (power icon)	Remove or restore the person's access. Their history stays.
Delete (bin icon) ★	Permanently remove an account that has never been used on a work order.

Note: Who you can manage: you can act on your own account, or on accounts ranked **below** yours (Requester → Technician → Supervisor → HOD → Manager → Administrator). Administrators cannot edit other Administrators, and only the app developer can create one. Accounts the app developer manages show "administered only from Supabase" and have no buttons.

Adding a new user



Add a user ×

They can sign in as soon as this is saved.

Name *

Email *

Phone

Employee ID

Roles *

- ☒ Requester
- ☐ Technician
- ☐ Supervisor
- ☐ HOD
- ☐ Manager
- ☐ Administrator

Department

No department ▼


Initial password *

A starting password — pass it on yourself. They will be asked to choose their own the first time they sign in, and until they do, they can reach nothing else.

Figure 4.9 — Add a user.

- 1 Press **Add user**.
- 2 Enter **Name** and **Email** (their company email — used to sign in). Add **Phone** and **Employee ID** if they have one; the employee ID becomes a second way to sign in.
- 3 Tick one or more **Roles**, and choose their **Department**.
- 4 Type an **Initial password** and press **Create user**.
- 5 Give the person their email/employee ID and the initial password yourself. SI makes them choose their own password the first time they sign in.

Changing roles



The image shows a 'Change roles' dialog box for a user named Arun Kumar with email tech.arun@example.com. It features a list of roles: Requester, Technician (checked), Supervisor, HOD, Manager, and Administrator. Below the roles is a 'Department' dropdown menu currently set to 'Engineering'. A note at the bottom explains that roles are tied to the user's access token and Supabase reissues it every hour, so changes take effect after a sign-out and sign-in. At the bottom right are 'Cancel' and 'Save roles' buttons.

Change roles ×

Arun Kumar · tech.arun@example.com

Roles *

- ☐ Requester
- ☒ Technician
- ☐ Supervisor
- ☐ HOD
- ☐ Manager
- ☐ Administrator

Department

Engineering ▼

A role lives in the user's access token, which Supabase reissues about once an hour. To make this take effect immediately, have them sign out and back in.

Cancel ✓ Save roles

Figure 4.10 — Change roles — tick every role the person should hold.

- Tick every role they need — a person can hold several, and they get everything all of them allow.
- Press **Save roles**. The change reaches the person the next time their sign-in refreshes — **up to an hour**. To make it take effect immediately, ask them to sign out and back in.
- You can only give roles that are below your own. Nobody can change their own roles.

Editing a profile

Edit profile ✕

tech.arun@example.com

Name *

Arun Kumar

Phone

98450 77003

Employee ID

Their existing HR or payroll number. Optional, and it becomes a second way for them to sign in — case and spaces do not matter. Leave it blank if they do not have one.

Email *

tech.arun@example.com


This is how they sign in. Changing it takes effect immediately; the new address is marked confirmed, so there is no email to click.

Cancel **✓ Save**

Figure 4.11 — Edit profile.

Correct the name, phone or employee ID and press **Save**. Changing the sign-in **Email** takes effect immediately — only the ★ app developer can do this for other people.

Resetting a password ★



Set a new password ✕

Arun Kumar · tech.arun@example.com

New password *

Confirm new password *


They are not told automatically — pass the new password on yourself. They will have to replace it the first time they sign in, and until they do they can reach nothing else in the app. Their existing sessions stay signed in until the token expires.

Cancel ✓ Set password

Figure 4.12 — Set a new password.

When somebody has forgotten their password, ask the ★ app developer. They press Password and set a temporary password. Pass it on to the person yourself — SI does not send it. They must replace it the next time they sign in, and can do nothing else until they do.

Deactivating and reactivating



Users
Accounts, roles and passwords. 7 total.

Q Name, email, employee ID or depart Role: All

USER	ROLE	DEPARTMENT	STATUS	ACTIONS
Anita Desai · you admin@example.com	Administrator	DEPT-ENGINEERING	Active	Protected — administered only from Supabase
Arun Kumar tech.arun@example.com	Technician	DEPT-ENGINEERING	Inactive	🔗 Password 🛡️ Role ✎ Edit 🔌 🗑️
Meera Iyer tech.meera@example.com	Technician	DEPT-ENGINEERING	Active	🔗 Password 🛡️ Role ✎ Edit 🔌 🗑️
Priya Nair supervisor@example.com	Supervisor	DEPT-ENGINEERING	Active	🔗 Password 🛡️ Role ✎ Edit 🔌 🗑️
Rajesh Menon hod@example.com	HOD Requester	DEPT-ENGINEERING	Active	🔗 Password 🛡️ Role ✎ Edit 🔌 🗑️

Showing 1–5 of 7 users

Navigation: < 1 2 >

Figure 4.13 — A deactivated account shows Inactive. Press the same button again to reactivate.




Figure 4.14 — Deactivating asks first, and names the person so you can check it is the right account.

- 1 Find the person in **Users** and press the red **power** button on their row.
- 2 SI asks **Deactivate this account?** and names the person, so you can check it is the right one.
- 3 Press **Deactivate** to confirm, or **Cancel** to leave the account as it is.

To **reactivate**, press the same button (now green) on an Inactive account. This happens straight away, with no confirmation, so a mistaken deactivation is quick to undo.

- Use deactivation when somebody leaves or should no longer have access. Everything they did stays on the record.
- It can take up to an hour to lock out a person who is already signed in.
- Nobody can deactivate their own account.

Deleting an account ★




Figure 4.15 — Delete an account — type the person's name to confirm.

Only for accounts that were never used — for example one created by mistake. If the person has raised, worked on, commented on or photographed anything, SI refuses and tells you what it found. **Deactivate** them instead.

4.9 Settings

Settings
Labels, colours, SLA targets and the equipment register. Changes apply everywhere immediately.

Statuses | Priorities | SLA targets | Impact levels | Work order types | Safety severities | Departments | Equipment | Permissions | Plant assignment | Storage

ⓘ The statuses are fixed by the workflow. Rename or recolour them; the order controls the status timeline. Two are marked retired — migration 0039 removed On The Way and On Site from the flow, so no new work order can reach them. They stay here because work orders closed before that change still show those steps on their timeline.

CODE	LABEL	COLOUR	ORDER	EDIT
open	Open	● #0F3D91	1	
assigned	Assigned	● #0F3D91	2	
accepted	Accepted	● #F59E08	3	
on_the_way (retired)	On The Way	● #F59E08	4	
on_site (retired)	On Site	● #F59E08	5	

Showing 1–5 of 11 rows

Figure 4.16 — Admin → Settings, with its eleven tabs.

Go to **Settings** in the menu. Changes apply everywhere in the app straight away. Use the pencil icon on a row to edit it.

Tab	What you can do there
Statuses	Rename and recolour statuses and set their order on the timeline. The statuses themselves are fixed by the workflow.
Priorities	Rename, recolour and describe P1–P8. The colours are used on every badge.
SLA targets	The acknowledge, response and resolution minutes for each priority, plus the labels shown to users. Keep the minutes and the labels matching.
Impact levels	The production-impact choices on the raise form and the priority each one gives.
Work order types	Rename and describe Breakdown, Inspection, Project and Repairing.
Safety severities	The safety severities and the priority each one raises a job to.
Departments	Add, rename and retire departments.
Equipment	Add and edit machines. Plant is required — a machine without one cannot be picked on the raise form. Department and criticality are optional.
Permissions ★	Which roles may assign technicians, and which may delete work orders.

Tab	What you can do there
Plant assignment ★	Move old work orders raised before plants existed ("Main Plant") to the plant they really happened at.
Storage	How full the database and photo storage are, against the plan limits.




Figure 4.17 — SLA targets




Figure 4.18 — Equipment register

- **Retire instead of delete.** When a value is no longer used (an old department, a scrapped machine, a priority), retire it: it disappears from the pickers but old work orders keep showing it correctly. Retiring and restoring is ★. A value can only be deleted outright if nothing has ever used it.
- Anyone raising a work order can add a missing **department**; only Administrators can add **equipment**. When somebody reports "Other (specify)" machines often, add them in **Equipment**.

4.10 Common situations

Q A new employee joins.

Users → **Add user**, with their company email, employee ID, roles and department and an initial password. Give them the details yourself.

Q Somebody forgot their password.

Ask the ★ app developer to set a temporary password with **Password**, and pass it on. They choose a new one when they sign in.

Q Somebody leaves the company.

Deactivate their account. Don't delete it — their work history must stay.

Q A role change isn't showing for the person.

It takes up to an hour. Ask them to sign out and back in.

Q A technician declined a job.

You are notified and the job is Open again. Read the reason on the timeline and **Assign** someone else.

Q A job is stuck because the technician is away.

Reassign it on the Assignment tab. The new technician carries on from the same stage.

Q A job was graded wrongly.

Change priority with a reason. If it just needs more time at the same priority, use **Extend SLA** → **Give it more time**.

Q A machine is missing from the raise form.

Settings → **Equipment** → **Add equipment**, and set its **plant**.

Q A duplicate work order was raised.

Check it really is a duplicate, then **Delete** it (type the WO number to confirm).

Q A closed job wasn't really fixed.

Managers, HODs and Administrators can send a completed or closed job back to Repairing from its Workflow tab.

05.

APPENDIX

Quick reference

Who can do what at a glance, and the words SI uses.

IN THIS CHAPTER

- 5.1** Who can do what
 - 5.2** Words SI uses
 - 5.3** Need help?
-

5.1 Who can do what

Action	Requester	Technician	Admin
Sign in with email or employee ID	✓	✓	✓
Change your own password	✓	✓	✓
See work orders you raised	✓	—	✓ all
See work orders assigned to you	—	✓	✓ all
Raise a work order	✓	X ¹	✓
Raise one on somebody's behalf	X	X	✓
Edit details while Open	Own	X	✓
Assign / reassign a technician	X	X	✓
Accept, decline, start, test, complete	X	Own jobs	—
Pause for a spare part / resume	X	Own jobs	—
Comment and add photos	✓	✓	✓
Replace a photo you uploaded	✓	✓	✓
Change a priority / extend an SLA	X	X	✓
Delete a work order	X	X	✓
Export the list to Excel	✓	✓	✓
Manage users	X	X	✓ ²
Change settings	X	X	✓ ²

¹ Unless the account also holds the Requester role. ² Some actions are for the app developer only — see the Administrator guide.

5.2 Words SI uses

Term	Meaning
Work order (WO)	A record of one fault or job, numbered like WO-2026-000049.
Requester	The person who reported the fault.
Assign	Choosing which technician does the job.
Handover	Reassigning a job that is already under way. It keeps its stage.
Production impact	How badly the fault affects production. It decides the priority.
Priority (P1–P8)	How urgent a job is. P1 is the most urgent.
SLA	The time allowed for each stage: acknowledge, response and resolution.
At risk / Breached	A stage in its last quarter of time / a stage that ran out of time.

Term	Meaning
Sign-off	A HOD's check that a closed job was done properly. Only then does it count on the dashboards.
Retire	Take a setting out of use without breaking old records.
App developer	The team that builds and maintains SI. They carry out the actions marked ★.

5.3 Need help?

For account problems — cannot sign in, forgotten password, wrong role — contact your **Administrator**. For questions about a particular job, comment on the work order so everyone involved can see it.