

ADMINISTRATOR ROLE

SI Work Order App Administrator Guide

Assigning work, managing users and settings

The image shows the SI Work Order App Administrator Dashboard and a mobile app view. The dashboard includes a sidebar with navigation options: Dashboard, Work Orders, Notifications, Users, and Settings. The main content area displays a 'Dashboard' with various metrics and a 'Trends and breakdowns' section.

Dashboard Metrics:

- Total Open Work Orders: 25
- P1 Critical: 7
- P7 Long-term: 0
- P8 Scheduled: 1
- Avg. Repair Time: 287.9 hrs
- Active Technicians: 2

Trends and breakdowns:

Work Orders Raised
Raised - per month - 01/10/2025 - 30/09/2026 - verified only

Legend

Mobile App View:

The mobile app view shows a detailed view of a work order for 'Air Compressor 1000 K/P'. The work order is raised on 25/09/2026 at 11:24 AM by Ravi Kumar. The app includes tabs for Overview, Assignment, and Conversation. The Overview tab shows details such as Department (Maintenance), Plant (F1— PMW Industries), Equipment (Air Compressor 1000 K/P), Area (Compressor room, Bay 2), Type (Breakdown), Production impact (Running at reduced capacity), Requested by (Ravi Kumar), Requester phone (98450 11223), and Safety risk (No).

Contents

01 Getting started FOR EVERYONE

What SI does · Roles — who does what · Getting an account · Signing in · Choosing a new password · Finding your way around · Using SI on your phone · Notifications · How a work order moves · Priorities and SLA deadlines · Inside a work order

02 Administrator guide ROLE GUIDE

At a glance · The Administrator dashboard · Assigning a technician · Raising a work order for somebody · Changing a priority · Extending an SLA · Deleting a work order · Managing users · Settings · Common situations

03 Quick reference APPENDIX

Who can do what · Words SI uses · Need help?

Note: How to use this guide. Chapter 1 covers what everybody needs: getting an account, signing in, finding your way around, and how work orders move. Chapter 2 is everything a Administrator can do, step by step. Screenshots come from the SI test site with demo data, so names and numbers will differ from what you see. Buttons and labels are shown in **bold**.

01.

FOR EVERYONE

Getting started

What SI is, how to get an account, how to sign in, and how to find your way around. Read this first, whatever your role.

IN THIS CHAPTER

- 1.1** What SI does
 - 1.2** Roles — who does what
 - 1.3** Getting an account
 - 1.4** Signing in
 - 1.5** Choosing a new password
 - 1.6** Finding your way around
 - 1.7** Using SI on your phone
 - 1.8** Notifications
 - 1.9** How a work order moves
 - 1.10** Priorities and SLA deadlines
 - 1.11** Inside a work order
-

1.1 What SI does

SI (Service Inside) is PMW Group's maintenance work order app. When a machine or facility has a fault, somebody **raises a work order**. A Supervisor or Administrator **assigns** it to a technician, the technician **carries out the repair**, and the app keeps a full record of who did what and when.

It runs in any web browser — on a PC, a tablet or a phone — so there is nothing to install. You can also add it to your phone's home screen so it opens like an app (see *Using SI on your phone* below).

1.2 Roles — who does what

Every account has one or more roles. Your role decides which screens you see and which buttons you get. This guide covers the three most common roles:

Role	What they do in SI
Requester	Reports faults by raising work orders, adds photos and comments, and follows the repair until it is finished.
Technician	Receives jobs, accepts or declines them, carries out the repair step by step, and marks the work completed.
Administrator	Oversees all work in the plant, assigns technicians, manages user accounts, and maintains the settings (departments, equipment, priorities and SLA targets).

Note: SI also has **Supervisor**, **HOD** and **Manager** roles. Supervisors assign work, Managers oversee it, and HODs sign off closed work orders. One person can hold more than one role — for example Requester + Technician — and then gets everything both roles allow.

1.3 Getting an account

There is **no self sign-up** in SI. Accounts are created by your Administrator, so the app always knows who everybody is and what they are allowed to do.

- 1 Contact your **Administrator** (or the IT / maintenance office) and ask for an SI account.
- 2 Give them your **full name**, **company email address**, **phone number**, your **employee ID** (if you have one) and your **department**, and tell them which **role** you need.
- 3 The Administrator creates the account and gives you a **temporary password**.
- 4 Sign in with it (see below). The first time you sign in, SI asks you to **choose your own password** before you can do anything else.

1.4 Signing in

Figure 1.1 — The sign-in screen.

- 1 Open SI in your browser (or tap the SI icon on your home screen).
- 2 In **Company email or employee ID**, type either your company email address **or** your employee ID. Both work — capital letters and spaces in an employee ID do not matter.
- 3 Type your **Password**. Tap the eye icon to show what you typed.
- 4 Tick **Remember me** on your own phone or PC so you stay signed in. Leave it unticked on a shared computer.
- 5 Press **Sign in**. SI opens the dashboard for your role.

Tip: If sign-in fails, SI shows the same message whether the email/ID or the password was wrong — this protects your account. Check both, and after a few failed tries wait a moment before trying again.

Important: Forgot your password? Contact your **Administrator**. They will set a temporary password for you, which you replace the next time you sign in.

1.5 Choosing a new password

Change your password
Choose a new password for your account.

New password *

Confirm new password *

At least 8 characters. Nobody else can see it, your administrator included — if you forget it, it has to be reset.

✓ **Change password**

Figure 1.2 — The Change password screen appears on your first sign-in, and after an Administrator resets your password.

- Enter the new password twice. It must be **at least 8 characters**.
- Nobody else can see your password — not even your Administrator.
- Until you set your own password you cannot reach any other screen. This is on purpose: the temporary password was chosen by somebody else.

1.6 Finding your way around

SI SERVICE INSIDE

Dashboard
Work Orders
Notifications

My Work Orders
Everything you've raised, and what's happening with it.

Waiting for a technician **6** Closed today **0**

Open 31 still in flight

Of these — a job can appear in a stage and in an SLA figure both:

Open 6 Assigned 1 Accepted 5 Repairing 5 Waiting Spare Part 3 Testing 3 On The Way 4 On Site 4

SLA at risk 0 Overdue 9

Waiting for a technician 6
You raised these and nobody has been assigned yet.

WO-2026-000017 Floodlight	P4	Unassigned	Breached - Acknowledge	Open →
WO-2026-000018 Batching Plant	P1	Unassigned	Breached - Acknowledge	Open →
WO-2026-000028 Batching Plant	P3	Unassigned	Breached - Acknowledge	Open →
WO-2026-000029 Floodlight	P4	Unassigned	Breached - Acknowledge	Open →

Ravi Kumar
Requester
Sign out

Figure 1.3 — The screen layout (Requester shown). On a PC the menu is on the left.

Part of the screen	What it is for
Dashboard	Your starting page: counts and lists of the work that needs your attention.
Work Orders	The full list of work orders you can see, with search, filters, sorting and Excel export.
Notifications	Everything SI has told you about, grouped by category.
Users / Settings	Administrators only — accounts and system settings.
Bell icon (top right)	Opens your latest notifications. A red dot means something is unread.
Role badge (top right)	Shows the role you are working as. If you hold several roles, use it to switch dashboards.
Your name / Sign out	Bottom of the menu. Always sign out on a shared computer.

1.7 Using SI on your phone




Figure 1.4 — Dashboard on a phone




Figure 1.5 — Tap ≡ to open the menu




Figure 1.6 — A work order on a phone

SI adapts to small screens. The menu hides behind the ≡ button at the top left, and wide tables turn into cards you can scroll.

- **iPhone:** open SI in **Safari**, tap the **Share** button, then **Add to Home Screen**. Pop-up alerts on iPhone only work once SI is added this way.
- **Android:** open SI in **Chrome**, tap the : menu, then **Install app** or **Add to Home screen**.

1.8 Notifications




Figure 1.7 — The bell opens your latest notifications without leaving the page.

- SI notifies you when something happens that concerns you — for example a job assigned to you, or your work order completed.
- Each notification shows **how long ago** it happened and the exact date and time, plus **tags** for who caused it and which stage the job was at.
- Tap a notification to open that work order. **Mark all read** clears the red dot.
- On the **Notifications** page, filter by category and use **Clear read** to delete notifications you have already read. Unread ones are never deleted.
- To get alerts on your phone or PC while SI is in the background, press **Turn on alerts with sound** in the bell panel and allow notifications when the browser asks. Alerts only arrive while SI is open somewhere (a tab or the home-screen app) — not after it has been fully closed.

1.9 How a work order moves

Every work order goes through the same stages, in order. No stage can be skipped, and every move is recorded on the **Status Timeline** with the person's name and the time.



Status	Meaning
Open	Raised and waiting for somebody to assign a technician.
Assigned	A technician has been chosen and must accept or decline. A decline sends it back to Open.
Accepted	The technician has taken the job but not started yet.
Repairing	Work is in progress.
Waiting Spare Part	Paused because a part is needed. Returns to Repairing when the part arrives.
Testing	The fix is being tested. A failed test sends it back to Repairing.
Completed → Closed	The technician marks the repair completed, and SI closes it automatically at the same moment.

1.10 Priorities and SLA deadlines

You never choose a priority — SI works it out from the **production impact** picked when the work order is raised, and raises it further if a **safety** or **environmental** risk is flagged. Each priority has an SLA (service-level agreement): a time limit for each of three stages.

Priority	Production impact	1. Acknowledge	2. Response	3. Resolution
P1 Critical	Full production stoppage	5 min	10 min	3 hrs 45 min
P2 High	Running at reduced capacity	15 min	45 min	7 hrs
P3 Medium	Auxiliary equipment, no line impact	30 min	3 hrs 30 min	20 hrs
P4 Low	No production impact (cosmetic/routine)	2 hrs	22 hrs	4 days
P7 Long-term	Long-term task (planned)	5 days	3 days	7 days
P8 Scheduled	Scheduled work (month-scale)	5 days	5 days	20 days

- **Acknowledge** — from raising the work order until a technician is assigned.
- **Response** — from assignment until the technician starts work.
- **Resolution** — from starting work until the repair is completed.
- Each stage's clock starts when the previous stage finishes. The header of every work order shows the current stage and the time left, for example **14m left, At risk** (in the last quarter of its time) or **Breached** (late).
- These are the current settings. Administrators can change them, so the times shown in the app are always the ones that apply.

1.11 Inside a work order

The screenshot shows the 'Air Compressor 1000 K/P' work order page. The left sidebar contains 'Dashboard', 'Work Orders' (selected), and 'Notifications'. The top right has a 'Requester' button. The main header includes a 'Back to Work Orders' link, the work order ID 'WO-2026-000049', a 'P2' priority badge, and an 'Open' status. An 'Edit' button is visible. The 'Raised' date is '25/09/2026 11:24 AM' by Ravi Kumar, and the 'Acknowledge SLA' is '14m left'. Below the header are six tabs: Overview, Assignment, Conversation, Photos, Status Timeline, and Workflow. The 'Overview' tab is active, displaying a table of details and a 'Complaint' section.

Field	Value
Department	Maintenance
Plant	F1 — PMW Industries
Equipment	Air Compressor 1000 K/P
Area	Compressor room, Bay 2
Type	Breakdown
Production impact	Running at reduced capacity
Requested by	Ravi Kumar
Requester phone	98450 11223
Safety risk	No
Environmental risk	No
Permit / LOTO required	No

Complaint
DEMO (user manual) — Oil leaking from the compressor base, pressure drops to 5 bar after 10 minutes of running. Loud knocking sound on start-up.

SLA targets (P2)

Stage	Target	Actual
Acknowledge	15 min	Running
Response	45 min after assignment	
Resolution	7 hrs after work starts	

Measured in stages, not from when it was raised: each window starts when the one before it is met.

Figure 1.8 — Every work order has the same header and six tabs.

Tab	What you find there
Overview	All the details — department, plant, equipment, complaint, risks — plus the SLA targets and how long each stage actually took.
Assignment	Who the job is assigned to. Supervisors and Administrators assign and reassign here, until the job is completed. After that the Assign buttons are greyed out.
Conversation	Comments and photos in one chat-style thread. A red number shows how many new messages you have not read.
Photos	Every photo, grouped by the stage it was taken at (before work, during repair, testing...).
Status Timeline	The full history: every move, who made it, when, and any reason given.
Workflow	Tells you whose move it is, and holds the action buttons when it is yours.

Tip: If your session expires while you are typing a work order, SI keeps what you typed and offers to restore it after you sign back in. Photos cannot be kept, so re-attach them.

02.

ROLE GUIDE

Administrator guide

You oversee all work in the plant, assign technicians, manage accounts and maintain the settings. This chapter covers every Administrator screen.

IN THIS CHAPTER

- 2.1** At a glance
 - 2.2** The Administrator dashboard
 - 2.3** Assigning a technician
 - 2.4** Raising a work order for somebody
 - 2.5** Changing a priority
 - 2.6** Extending an SLA
 - 2.7** Deleting a work order
 - 2.8** Managing users
 - 2.9** Settings
 - 2.10** Common situations
-

2.1 At a glance

You can	Rules to know
See and search every work order in every plant	You cannot assign a job to yourself
Raise work orders, including on somebody's behalf	Details can only be edited while a job is Open
Assign and reassign technicians	Priority changes need a written reason
Change a priority, extend an SLA, delete a work order	Deleting a work order cannot be undone
Create accounts, change roles, activate / deactivate	You can only manage accounts ranked below you
Maintain departments, equipment, labels and SLA targets	Some actions are for the Superuser only (marked ★)

Note: ★ **Superuser** is one specially protected Administrator account held by IT. It exists so there is always somebody who can manage Administrators, because Administrators cannot edit each other. Actions marked ★ in this chapter need the Superuser.

2.2 The Administrator dashboard




Figure 2.1 — The plant-wide dashboard with its cards and charts.

- **Cards** — Total open work orders, a count for each priority, Completed today, Overdue, Average response time, Average repair time and Active technicians. **Tap any card** to see the work orders behind the number.
- **Refresh now** recalculates the figures (they also refresh by themselves every 15 minutes).
- **Trends and breakdowns** — work orders raised over time, by department, by machine (top 10), and technician performance. Use the quiet **plant · period** line above the charts to choose a plant and a period (today, this week, this month, last 12 months or a custom range).
- Figures count work that has been **signed off**. A job that has closed but not yet been checked by a HOD is not counted yet.

2.3 Assigning a technician




Figure 2.2 — The Assignment tab lists technicians with their skills and how many open jobs they have.

- 1 Open the work order (the dashboard's unassigned list, or **Work Orders** filtered by status **Open**).
- 2 Go to the **Assignment** tab.
- 3 Check each technician's skills and **open jobs** count, then press **Assign** next to the right person.
- 4 A confirmation names the technician and explains what happens next. Press **Done**.




Figure 2.3 — The confirmation after assigning.

- The technician is notified and must **accept** or **decline**. If they decline, the job comes back **unassigned** and you are notified, with their reason.
- **Reassign** — on the Assignment or Workflow tab, choose a different technician at any stage until the job is completed. Before they accept, the new person must accept. After that it is a **handover**: the job keeps its stage, and the new technician simply carries on.
- Nobody can assign a job to themselves — not even an Administrator.

- Once a job is completed or closed its technician is fixed, and the Assign buttons are greyed out for everybody — so nobody can hand a finished job to someone by mistake. If it really needs another technician, press **Not done properly** and **Send back for rework** first. The job goes back to Repairing, and you can then reassign it.




Figure 2.4 — The Workflow tab shows who the job is waiting on, with a Reassign button.

2.4 Raising a work order for somebody

Raise a work order exactly as a Requester does (see the Requester guide). As an Administrator you can change the **Requester** and **Phone number** fields to the person who reported the fault — for example after a phone call. That person then gets the "Work order submitted" receipt and can follow the job.

2.5 Changing a priority

Change priority ✕

WO-2026-000049 is **High (P2)** — derived from its production impact.

New priority

- ☐ **Back to the derived priority (P2)**
Follows the production impact again, including any later edit of it.
- ☐ **P1** Critical
- ☒ **P2** High
- ☐ **P3** Medium
- ☐ **P4** Low
- ☐ **P7** Long-term
- ☐ **P8** Scheduled

Reason *

Why this priority — the technician and the requester both see this.

At least 10 characters (0 so far).

Cancel ↕ Change priority

Figure 2.5 — Change priority — a reason of at least 10 characters is required.

- 1** Open the work order and press **Change priority** at the top.
 - 2** Choose the new priority — or **Back to the derived priority** to let the production impact decide again.
 - 3** Type the **Reason** (at least 10 characters), for example "Reclassified — this overhaul turned out to be urgent".
 - 4** Press **Change priority**.
- Only possible while the job is still live (not once it is closed).
 - The SLA deadlines are recalculated from when the job was raised. The technician and the requester are notified, and the change and your reason are recorded on the timeline.
 - The assigned technician and the stage do not change.

2.6 Extending an SLA

Extend SLA

W0-2026-000048 is **Critical (P1)**, and its **response** stage was due **19/09/2026 9:17 PM** — 5d 17h ago.

Every option below still leaves this work order past its deadline. Extending it will give it more time, but it will stay overdue.

Give it more time

- ☐ **Another 10m, still Critical (P1)**
Response due 19/09/2026 9:27 PM · +10m · still overdue
- ☐ **Re-grade to High (P2)**
Response due 19/09/2026 9:52 PM · +35m · still overdue
- ☐ **Re-grade to Medium (P3)**
Response due 20/09/2026 12:37 AM · +3h 20m · still overdue
- ☐ **Re-grade to Low (P4)**
Response due 20/09/2026 7:07 PM · +21h 50m · still overdue
- ☐ **Re-grade to Long-term (P7)**
Response due 22/09/2026 9:07 PM · +2d 23h · still overdue
- ☒ **Re-grade to Scheduled (P8)** **Suggested**
Response due 24/09/2026 9:07 PM · +4d 23h · still overdue

ⓘ This is recorded on the work order's timeline with your name and the time, and the assigned technician and the person who raised it are both notified. The stages this work order has already missed stay on its record — extending gives it more time from here, it does not erase what happened.

No, leave it **Yes, extend to P8**

Figure 2.6 — Extend SLA offers more time at the same priority, or a re-grade to a less urgent one.

The **Extend SLA** button appears when the stage a job is in is **at risk or overdue**.

- **Give it more time** — adds another full stage window at the **same** priority. Use this when the job is correctly graded but genuinely needs longer. You can do it more than once — SI warns you, in red, how many times it has already been extended.
- **Re-grade** — moves the job to a less urgent priority, which gives the current stage that priority's longer window. **Suggested** marks the option that best fits.
- Options marked **still overdue** would still leave the job late.
- Press **Yes, extend...** to confirm. It is recorded with your name, and the technician and requester are notified. Stages already missed stay recorded as missed — extending gives time from now on, it does not erase history.

2.7 Deleting a work order




Figure 2.7 — Deleting needs the WO number typed exactly.

Important: Deleting removes the work order together with its comments, photos, notifications and history. It **cannot be undone** (a record of the deletion is kept). For duplicates or mistakes, deleting is fine — for real work, keep the record.

Press **Delete** on the work order, type the WO number (for example WO-2026-000049) and press **Delete permanently**. By default only Administrators can delete. The ★ Superuser can allow other roles in **Settings** → **Permissions**.

2.8 Managing users

Users
Accounts, roles and passwords. 7 total.

Q Name, email, employee ID or depart Role: All

USER	ROLE	DEPARTMENT	STATUS	ACTIONS
Anita Desai · you admin@example.com	Administrator	DEPT-ENGINEERING	Active	Protected — administered only from Supabase
Arun Kumar tech.arun@example.com	Technician	DEPT-ENGINEERING	Active	Password Role Edit Deactivate Delete
Meera Iyer tech.meera@example.com	Technician	DEPT-ENGINEERING	Active	Password Role Edit Deactivate Delete
Priya Nair supervisor@example.com	Supervisor	DEPT-ENGINEERING	Active	Password Role Edit Deactivate Delete
Rajesh Menon hod@example.com	HOD Requester	DEPT-ENGINEERING	Active	Password Role Edit Deactivate Delete

Showing 1–5 of 7 users


Figure 2.8 — Admin → Users.

Go to **Users** in the menu. Search by name, email, employee ID or department, and filter by role. Each row shows the person's roles, department and status, with action buttons on the right.

Button	What it does
Add user	Create a new account.
Password ★	Set a temporary password for somebody (for example when they have forgotten theirs).
Role	Change the person's roles and department.
Edit	Change name, phone and employee ID. Changing somebody else's sign-in email is ★.
Deactivate / Activate (power icon)	Remove or restore the person's access. Their history stays.
Delete (bin icon) ★	Permanently remove an account that has never been used on a work order.

Note: Who you can manage: you can act on your own account, or on accounts ranked **below** yours (Requester → Technician → Supervisor → Manager → Administrator → Superuser). Administrators cannot edit other Administrators, and only the Superuser can create one. Protected accounts show "administered only from Supabase" and have no buttons.

Adding a new user



Add a user ✕

They can sign in as soon as this is saved.

Name *

Email *

Phone

Employee ID

Roles *

- ☒ Requester
- ☐ Technician
- ☐ Supervisor
- ☐ HOD
- ☐ Manager
- ☐ Administrator

Department

No department ▼


Initial password *

A starting password — pass it on yourself. They will be asked to choose their own the first time they sign in, and until they do, they can reach nothing else.

Figure 2.9 — Add a user.

- 1 Press **Add user**.
- 2 Enter **Name** and **Email** (their company email — used to sign in). Add **Phone** and **Employee ID** if they have one; the employee ID becomes a second way to sign in.
- 3 Tick one or more **Roles**, and choose their **Department**.
- 4 Type an **Initial password** and press **Create user**.
- 5 Give the person their email/employee ID and the initial password yourself. SI makes them choose their own password the first time they sign in.

Changing roles



The screenshot shows a modal dialog titled "Change roles" with a close button (X) in the top right corner. Below the title, the user's name and email are displayed: "Arun Kumar · tech.arun@example.com". The dialog contains two main sections: "Roles *" and "Department". The "Roles *" section lists six roles with checkboxes: "Requester" (unchecked), "Technician" (checked), "Supervisor" (unchecked), "HOD" (unchecked), "Manager" (unchecked), and "Administrator" (unchecked). The "Department" section features a dropdown menu currently set to "Engineering". Below these sections, a note states: "A role lives in the user's access token, which Supabase reissues about once an hour. To make this take effect immediately, have them sign out and back in." At the bottom right, there are two buttons: "Cancel" and "Save roles" (which is highlighted in dark blue with a white checkmark icon).

Figure 2.10 — Change roles — tick every role the person should hold.

- Tick every role they need — a person can hold several, and they get everything all of them allow.
- Press **Save roles**. The change reaches the person the next time their sign-in refreshes — **up to an hour**. To make it take effect immediately, ask them to sign out and back in.
- You can only give roles that are below your own. Nobody can change their own roles.

Editing a profile

Edit profile ✕

tech.arun@example.com

Name *

Arun Kumar

Phone

98450 77003

Employee ID

Their existing HR or payroll number. Optional, and it becomes a second way for them to sign in — case and spaces do not matter. Leave it blank if they do not have one.

Email *

tech.arun@example.com


This is how they sign in. Changing it takes effect immediately; the new address is marked confirmed, so there is no email to click.

Cancel ✓ Save

Figure 2.11 — Edit profile.

Correct the name, phone or employee ID and press **Save**. Changing the sign-in **Email** takes effect immediately — only the ★ Superuser can do this for other people.

Resetting a password ★



Set a new password ✕

Arun Kumar · tech.arun@example.com

New password *

Confirm new password *


They are not told automatically — pass the new password on yourself. They will have to replace it the first time they sign in, and until they do they can reach nothing else in the app. Their existing sessions stay signed in until the token expires.

Cancel ✓ Set password

Figure 2.12 — Set a new password.

When somebody has forgotten their password, the Superuser presses **Password**, types a temporary password twice and presses **Set password**. Pass it on to the person yourself — SI does not send it. They must replace it the next time they sign in, and can do nothing else until they do.

Deactivating and reactivating



Users
Accounts, roles and passwords. 7 total.

Q Name, email, employee ID or depart Role: All

USER	ROLE	DEPARTMENT	STATUS	ACTIONS
Anita Desai · you admin@example.com	Administrator	DEPT-ENGINEERING	Active	Protected — administered only from Supabase
Arun Kumar tech.arun@example.com	Technician	DEPT-ENGINEERING	Inactive	Password Role Edit 🔌 🗑️
Meera Iyer tech.meera@example.com	Technician	DEPT-ENGINEERING	Active	Password Role Edit 🔌 🗑️
Priya Nair supervisor@example.com	Supervisor	DEPT-ENGINEERING	Active	Password Role Edit 🔌 🗑️
Rajesh Menon hod@example.com	HOD Requester	DEPT-ENGINEERING	Active	Password Role Edit 🔌 🗑️

Showing 1–5 of 7 users

1 2 >

Figure 2.13 — A deactivated account shows Inactive. Press the same button again to reactivate.




Figure 2.14 — Deactivating asks first, and names the person so you can check it is the right account.

- 1 Find the person in **Users** and press the red **power** button on their row.
- 2 SI asks **Deactivate this account?** and names the person, so you can check it is the right one.
- 3 Press **Deactivate** to confirm, or **Cancel** to leave the account as it is.

To **reactivate**, press the same button (now green) on an Inactive account. This happens straight away, with no confirmation, so a mistaken deactivation is quick to undo.

- Use deactivation when somebody leaves or should no longer have access. Everything they did stays on the record.
- It can take up to an hour to lock out a person who is already signed in.
- Nobody can deactivate their own account.

Deleting an account ★




Figure 2.15 — Delete an account — type the person's name to confirm.

Only for accounts that were never used — for example one created by mistake. If the person has raised, worked on, commented on or photographed anything, SI refuses and tells you what it found. **Deactivate** them instead.

2.9 Settings




Figure 2.16 — Admin → Settings, with its eleven tabs.

Go to **Settings** in the menu. Changes apply everywhere in the app straight away. Use the pencil icon on a row to edit it.

Tab	What you can do there
Statuses	Rename and recolour statuses and set their order on the timeline. The statuses themselves are fixed by the workflow.
Priorities	Rename, recolour and describe P1–P8. The colours are used on every badge.
SLA targets	The acknowledge, response and resolution minutes for each priority, plus the labels shown to users. Keep the minutes and the labels matching.
Impact levels	The production-impact choices on the raise form and the priority each one gives.
Work order types	Rename and describe Breakdown, Inspection, Project and Repairing.
Safety severities	The safety severities and the priority each one raises a job to.
Departments	Add, rename and retire departments.
Equipment	Add and edit machines. Plant is required — a machine without one cannot be picked on the raise form. Department and criticality are optional.
Permissions ★	Which roles may delete work orders.

Tab	What you can do there
Plant assignment ★	Move old work orders raised before plants existed ("Main Plant") to the plant they really happened at.
Storage	How full the database and photo storage are, against the plan limits.




Figure 2.17 — SLA targets




Figure 2.18 — Equipment register

- **Retire instead of delete.** When a value is no longer used (an old department, a scrapped machine, a priority), retire it: it disappears from the pickers but old work orders keep showing it correctly. Retiring and restoring is ★. A value can only be deleted outright if nothing has ever used it.
- Anyone raising a work order can add a missing **department**; only Administrators can add **equipment**. When somebody reports "Other (specify)" machines often, add them in **Equipment**.

2.10 Common situations

Q A new employee joins.

Users → **Add user**, with their company email, employee ID, roles and department and an initial password. Give them the details yourself.

Q Somebody forgot their password.

Ask the ★ Superuser to set a temporary password with **Password**, and pass it on. They choose a new one when they sign in.

Q Somebody leaves the company.

Deactivate their account. Don't delete it — their work history must stay.

Q A role change isn't showing for the person.

It takes up to an hour. Ask them to sign out and back in.

Q A technician declined a job.

You are notified and the job is Open again. Read the reason on the timeline and **Assign** someone else.

Q A job is stuck because the technician is away.

Reassign it on the Assignment tab. The new technician carries on from the same stage.

Q A job was graded wrongly.

Change priority with a reason. If it just needs more time at the same priority, use **Extend SLA** → **Give it more time**.

Q A machine is missing from the raise form.

Settings → **Equipment** → **Add equipment**, and set its **plant**.

Q A duplicate work order was raised.

Check it really is a duplicate, then **Delete** it (type the WO number to confirm).

Q A closed job wasn't really fixed.

Managers, HODs and Administrators can send a completed or closed job back to Repairing from its Workflow tab.

03.

APPENDIX

Quick reference

Who can do what at a glance, and the words SI uses.

IN THIS CHAPTER

- 3.1** Who can do what
 - 3.2** Words SI uses
 - 3.3** Need help?
-

3.1 Who can do what

Action	Requester	Technician	Admin
Sign in with email or employee ID	✓	✓	✓
Change your own password	✓	✓	✓
See work orders you raised	✓	—	✓ all
See work orders assigned to you	—	✓	✓ all
Raise a work order	✓	X ¹	✓
Raise one on somebody's behalf	X	X	✓
Edit details while Open	Own	X	✓
Assign / reassign a technician	X	X	✓
Accept, decline, start, test, complete	X	Own jobs	—
Pause for a spare part / resume	X	Own jobs	—
Comment and add photos	✓	✓	✓
Replace a photo you uploaded	✓	✓	✓
Change a priority / extend an SLA	X	X	✓
Delete a work order	X	X	✓
Export the list to Excel	✓	✓	✓
Manage users	X	X	✓ ²
Change settings	X	X	✓ ²

¹ Unless the account also holds the Requester role. ² Some actions are Superuser-only — see the Administrator guide.

3.2 Words SI uses

Term	Meaning
Work order (WO)	A record of one fault or job, numbered like WO-2026-000049.
Requester	The person who reported the fault.
Assign	Choosing which technician does the job.
Handover	Reassigning a job that is already under way. It keeps its stage.
Production impact	How badly the fault affects production. It decides the priority.
Priority (P1–P8)	How urgent a job is. P1 is the most urgent.
SLA	The time allowed for each stage: acknowledge, response and resolution.
At risk / Breached	A stage in its last quarter of time / a stage that ran out of time.

Term	Meaning
Sign-off	A HOD's check that a closed job was done properly. Only then does it count on the dashboards.
Retire	Take a setting out of use without breaking old records.
Superuser	The protected master Administrator account, held by IT.

3.3 Need help?

For account problems — cannot sign in, forgotten password, wrong role — contact your **Administrator**. For questions about a particular job, comment on the work order so everyone involved can see it.