




TECHNICIAN ROLE

SI Work Order App Technician Guide

Receiving, repairing and completing jobs



Contents

01 Getting started FOR EVERYONE

What SI does · Roles — who does what · Getting an account · Signing in · Choosing a new password · Finding your way around · Using SI on your phone · Notifications · How a work order moves · Priorities and SLA deadlines · Inside a work order

02 Technician guide ROLE GUIDE

At a glance · Your dashboard — My Tasks · The job workflow · Comments and photos · Keeping an eye on the SLA · Notifications you receive · Common situations

03 Quick reference APPENDIX

Who can do what · Words SI uses · Need help?

Note: How to use this guide. Chapter 1 covers what everybody needs: getting an account, signing in, finding your way around, and how work orders move. Chapter 2 is everything a Technician can do, step by step. Screenshots come from the SI test site with demo data, so names and numbers will differ from what you see. Buttons and labels are shown in **bold**.

01.

FOR EVERYONE

Getting started

What SI is, how to get an account, how to sign in, and how to find your way around. Read this first, whatever your role.

IN THIS CHAPTER

- 1.1** What SI does
 - 1.2** Roles — who does what
 - 1.3** Getting an account
 - 1.4** Signing in
 - 1.5** Choosing a new password
 - 1.6** Finding your way around
 - 1.7** Using SI on your phone
 - 1.8** Notifications
 - 1.9** How a work order moves
 - 1.10** Priorities and SLA deadlines
 - 1.11** Inside a work order
-

1.1 What SI does

SI (Service Inside) is PMW Group's maintenance work order app. When a machine or facility has a fault, somebody **raises a work order**. An HOD or Administrator assigns it to a technician, the technician **carries out the repair**, and the app keeps a full record of who did what and when.

It runs in any web browser — on a PC, a tablet or a phone — so there is nothing to install. You can also add it to your phone's home screen so it opens like an app (see *Using SI on your phone* below).

1.2 Roles — who does what

Every account has one or more roles. Your role decides which screens you see and which buttons you get. This guide covers the three most common roles:

Role	What they do in SI
Requester	Reports faults by raising work orders, adds photos and comments, and follows the repair until it is finished.
Technician	Receives jobs, accepts or declines them, carries out the repair step by step, and marks the work completed.
Administrator	Oversees all work in the plant, assigns technicians, manages user accounts, and maintains the settings (departments, equipment, priorities and SLA targets).

Note: SI also has **Supervisor**, **HOD** and **Manager** roles. HODs assign technicians and sign off closed work orders, and Supervisors and Managers oversee the work. One person can hold more than one role — for example Requester + Technician — and then gets everything both roles allow.

1.3 Getting an account

There is **no self sign-up** in SI. Accounts are created by your Administrator, so the app always knows who everybody is and what they are allowed to do.

- 1 Contact your **Administrator** (or the IT / maintenance office) and ask for an SI account.
- 2 Give them your **full name**, **company email address**, **phone number**, your **employee ID** (if you have one) and your **department**, and tell them which **role** you need.
- 3 The Administrator creates the account and gives you a **temporary password**.
- 4 Sign in with it (see below). The first time you sign in, SI asks you to **choose your own password** before you can do anything else.

1.4 Signing in

Figure 1.1 — The sign-in screen.

- 1 Open SI in your browser (or tap the SI icon on your home screen).
- 2 In **Company email or employee ID**, type either your company email address **or** your employee ID. Both work — capital letters and spaces in an employee ID do not matter.
- 3 Type your **Password**. Tap the eye icon to show what you typed.
- 4 Tick **Remember me** on your own phone or PC so you stay signed in. Leave it unticked on a shared computer.
- 5 Press **Sign in**. SI opens the dashboard for your role.

Tip: If sign-in fails, SI shows the same message whether the email/ID or the password was wrong — this protects your account. Check both, and after a few failed tries wait a moment before trying again.

Important: Forgot your password? Contact your **Administrator**. They will set a temporary password for you, which you replace the next time you sign in.

1.5 Choosing a new password

Change your password
Choose a new password for your account.

New password *

Confirm new password *

At least 8 characters. Nobody else can see it, your administrator included — if you forget it, it has to be reset.

✓ **Change password**

Figure 1.2 — The Change password screen appears on your first sign-in, and after an Administrator resets your password.

- Enter the new password twice. It must be **at least 8 characters**.
- Nobody else can see your password — not even your Administrator.
- Until you set your own password you cannot reach any other screen. This is on purpose: the temporary password was chosen by somebody else.

1.6 Finding your way around

My Work Orders
Everything you've raised, and what's happening with it.

Waiting for a technician **6** | Closed today **0**

Open 31 still in flight

Of these — a job can appear in a stage and in an SLA figure both:

Open 6 | Assigned 1 | Accepted 5 | Repairing 5 | Waiting Spare Part 3 | Testing 3 | On The Way 4 | On Site 4

SLA at risk 0 | Overdue 9

Waiting for a technician 6
You raised these and nobody has been assigned yet.

WO-2026-000017 Floodlight	P4	Unassigned	Breached - Acknowledge	Open →
WO-2026-000018 Batching Plant	P1	Unassigned	Breached - Acknowledge	Open →
WO-2026-000028 Batching Plant	P3	Unassigned	Breached - Acknowledge	Open →
WO-2026-000029 Floodlight	P4	Unassigned	Breached - Acknowledge	Open →

Ravi Kumar
Requester

Sign out

Figure 1.3 — The screen layout (Requester shown). On a PC the menu is on the left.

Part of the screen	What it is for
Dashboard	Your starting page: counts and lists of the work that needs your attention.
Work Orders	The full list of work orders you can see, with search, filters, sorting and Excel export.
Notifications	Everything SI has told you about, grouped by category.
Users / Settings	Administrators only — accounts and system settings.
Bell icon (top right)	Opens your latest notifications. A red dot means something is unread.
Role badge (top right)	Shows the role you are working as. If you hold several roles, use it to switch dashboards.
Your name / Sign out	Bottom of the menu. Always sign out on a shared computer.

1.7 Using SI on your phone




Figure 1.4 — Dashboard on a phone




Figure 1.5 — Tap ≡ to open the menu




Figure 1.6 — A work order on a phone

SI adapts to small screens. The menu hides behind the ≡ button at the top left, and wide tables turn into cards you can scroll.

- **iPhone:** open SI in **Safari**, tap the **Share** button, then **Add to Home Screen**. Pop-up alerts on iPhone only work once SI is added this way.
- **Android:** open SI in **Chrome**, tap the : menu, then **Install app** or **Add to Home screen**.

1.8 Notifications




Figure 1.7 — The bell opens your latest notifications without leaving the page.

- SI notifies you when something happens that concerns you — for example a job assigned to you, or your work order completed.
- Each notification shows **how long ago** it happened and the exact date and time, plus **tags** for who caused it and which stage the job was at.
- Tap a notification to open that work order. **Mark all read** clears the red dot.
- On the **Notifications** page, filter by category and use **Clear read** to delete notifications you have already read. Unread ones are never deleted.
- To get alerts on your phone or PC while SI is in the background, press **Turn on alerts with sound** in the bell panel and allow notifications when the browser asks. Alerts only arrive while SI is open somewhere (a tab or the home-screen app) — not after it has been fully closed.

1.9 How a work order moves

Every work order goes through the same stages, in order. No stage can be skipped, and every move is recorded on the **Status Timeline** with the person's name and the time.



Status	Meaning
Open	Raised and waiting for somebody to assign a technician.
Assigned	A technician has been chosen and must accept or decline. A decline sends it back to Open.
Accepted	The technician has taken the job but not started yet.
Repairing	Work is in progress.
Waiting Spare Part	Paused because a part is needed. Returns to Repairing when the part arrives.
Testing	The fix is being tested. A failed test sends it back to Repairing.
Completed → Closed	The technician marks the repair completed, and SI closes it automatically at the same moment.

1.10 Priorities and SLA deadlines

You never choose a priority — SI works it out from the **production impact** picked when the work order is raised, and raises it further if a **safety** or **environmental** risk is flagged. Each priority has an SLA (service-level agreement): a time limit for each of three stages.

Priority	Production impact	1. Acknowledge	2. Response	3. Resolution
P1 Critical	Full production stoppage	5 min	10 min	3 hrs 45 min
P2 High	Running at reduced capacity	15 min	45 min	7 hrs
P3 Medium	Auxiliary equipment, no line impact	30 min	3 hrs 30 min	20 hrs
P4 Low	No production impact (cosmetic/routine)	2 hrs	22 hrs	4 days
P7 Long-term	Long-term task (planned)	5 days	3 days	7 days
P8 Scheduled	Scheduled work (month-scale)	5 days	5 days	20 days

- **Acknowledge** — from raising the work order until a technician is assigned.
- **Response** — from assignment until the technician starts work.
- **Resolution** — from starting work until the repair is completed.
- Each stage's clock starts when the previous stage finishes. The header of every work order shows the current stage and the time left, for example **14m left, At risk** (in the last quarter of its time) or **Breached** (late).
- These are the current settings. Administrators can change them, so the times shown in the app are always the ones that apply.

1.11 Inside a work order

The screenshot shows the SI Service Inside interface for a work order titled "Air Compressor 1000 K/P". The interface includes a left sidebar with navigation options: Dashboard, Work Orders (selected), and Notifications. The main content area has a header with a "Back to Work Orders" link, the work order ID "WO-2026-000049", a "P2" priority indicator, and an "Open" status. There are buttons for "Edit" and "Requester". The work order details are organized into tabs: Overview (selected), Assignment, Conversation, Photos, Status Timeline, and Workflow. The Overview tab displays a table of details for Department (Maintenance), Plant (F1 — PMW Industries), Equipment (Air Compressor 1000 K/P), Area (Compressor room, Bay 2), Type (Breakdown), Production impact (Running at reduced capacity), Requested by (Ravi Kumar), Requester phone (98450 11223), Safety risk (No), Environmental risk (No), and Permit / LOTO required (No). A "Complaint" section describes the issue: "DEMO (user manual) — Oil leaking from the compressor base, pressure drops to 5 bar after 10 minutes of running. Loud knocking sound on start-up." An "SLA targets (P2)" section shows a table with targets for Acknowledge (15 min), Response (45 min after assignment), and Resolution (7 hrs after work starts). A note at the bottom states: "Measured in stages, not from when it was raised: each window starts when the one before it is met."

Figure 1.8 — Every work order has the same header and six tabs.

Tab	What you find there
Overview	All the details — department, plant, equipment, complaint, risks — plus the SLA targets and how long each stage actually took.
Assignment	Who the job is assigned to. HODs and Administrators assign and reassign here, until the job is completed. After that the Assign buttons are greyed out.
Conversation	Comments and photos in one chat-style thread. A red number shows how many new messages you have not read.
Photos	Every photo, grouped by the stage it was taken at (before work, during repair, testing...).
Status Timeline	The full history: every move, who made it, when, and any reason given.
Workflow	Tells you whose move it is, and holds the action buttons when it is yours.

Tip: If your session expires while you are typing a work order, SI keeps what you typed and offers to restore it after you sign back in. Photos cannot be kept, so re-attach them.

02.

ROLE GUIDE

Technician guide

You carry out the repairs. This chapter walks through a job from the moment it is assigned to you until it is closed, including every alternative path.

IN THIS CHAPTER

- 2.1** At a glance
 - 2.2** Your dashboard — My Tasks
 - 2.3** The job workflow
 - 2.4** Comments and photos
 - 2.5** Keeping an eye on the SLA
 - 2.6** Notifications you receive
 - 2.7** Common situations
-

2.1 At a glance

You can	You cannot
See every job assigned to you, with its SLA clock	See jobs that are not assigned to you, including unassigned ones
Accept a job, or decline it with a reason	Assign or reassign a job — to yourself or to anybody else
Start work, pause for a spare part, resume	Skip a step — the order is fixed
Test the fix, record a failed test, mark it completed	Reopen a job once it is closed
Comment and add before/after photos	Delete a work order, another person's comment, or a photo
Search, filter and export your jobs	Raise a work order (unless you also hold the Requester role)

2.2 Your dashboard — My Tasks

My Tasks
Jobs assigned to you, and where each one stands.

Waiting for you to accept: **1**

Closed today: **0**

Open 13 still in flight

Of these — a job can appear in a stage and in an SLA figure both:

- Assigned 1
- Accepted 3
- Repairing 3
- Waiting Spare Part 1
- Testing 1
- On The Way 2
- On Site 2
- SLA at risk 0
- Overdue 1

Waiting for you to accept 1
Accept to start, or decline with a reason so the Supervisor can reassign.

WO-2026-000049
Air Compressor 1000 K/P **P2** Arun Kumar 40m left - Response **Open** →

Recent activity
Most recently updated first. [See all →](#)

WORK ORDER	PRIORITY	STATUS	LAST ACTIVITY	RAISED	SLA
WO-2026-000049 Air Compressor 1000 K/P	P2	Assigned	25/09/2026 2:22 PM	25/09/2026 11:24 AM	40m left - Response
WO-2026-000047 Air Compressor 1000 K/P	P2	Closed	19/09/2026 9:05 PM	19/09/2026 9:03 PM	—
WO-2026-000046 Steelpole Cutting Machine No 1	P1	Closed	19/09/2026 2:53 AM	08/09/2026 9:14 AM	—
WO-2026-000066			10/09/2026 2:52 AM	01/09/2026 2:52 AM	

Figure 2.1 — My Tasks — the Technician dashboard.

- **Waiting for you to accept** — new jobs assigned to you. These need your answer first.
- **Closed today** — jobs you finished that have been signed off today.
- **Open ... still in flight** — your jobs by stage, plus how many are **at risk** or **overdue** on their SLA.
- The list underneath shows each waiting job with its priority and the time left.




Figure 2.2 — My Tasks on a phone

2.3 The job workflow

Everything you do to a job happens on its **Workflow** tab. The yellow bar always says "**Your move: ...**" and names the buttons you can press next. Some steps need a short note — the button stays greyed out until you type one.



Step 1 — Accept or decline

← Back to Work Orders

WO-2026-000049 **P2** • Assigned

Air Compressor 1000 K/P

Raised 25/09/2026 11:24 AM by Ravi Kumar

Response SLA 39m left

Overview Assignment Conversation **2** Photos Status Timeline **Workflow**

Your move: Accept or Decline.

You've been assigned this work order. Accept it to start, or decline with a reason so the Supervisor can reassign.

Accept this job

Can't take this one

Reason for declining...

Confirm decline

Figure 2.3 — A new assignment: accept it, or decline with a reason.

- You get a notification when a job is assigned to you. Open it, go to **Workflow**, and read the **Overview** and **Conversation** first.
- Accept this job** — the job becomes yours and moves to **Accepted**. The Requester and the people who assign work are told.
- Can't take this one** — type a reason (for example "on leave this afternoon") and press **Confirm decline**. SI shows your reason again before sending. The job goes back to Open to be reassigned, and it **disappears from your list**.

Step 2 — Start work

← Back to Work Orders

WO-2026-000049 **P2** • Accepted

Air Compressor 1000 K/P

Raised 25/09/2026 11:24 AM by Ravi Kumar

Response SLA 39m left

Overview Assignment Conversation **2** Photos Status Timeline **Workflow**

Your move: Start work.

Accepted. Start work once you're at the equipment.

Start Work

Figure 2.4 — Accepted: press Start Work when you begin the repair.

When you actually begin, press **Start Work**. The job moves to **Repairing** and the **Resolution** clock starts. Press it when you start, not before — the time it takes to repair is measured from this moment.

Step 3 — Repairing (and waiting for a spare part)

The screenshot shows the 'Repairing' state of a work order. At the top, there's a 'Back to Work Orders' link. Below it, the work order ID 'WO-2026-000049' is followed by a 'P2' priority badge and a 'Repairing' status badge. The title 'Air Compressor 1000 K/P' is prominently displayed. On the right, it shows the work order was 'Raised' on '25/09/2026 11:24 AM' by 'Ravi Kumar', and the 'Resolution SLA' is '6h 58m left'. A navigation bar includes 'Overview', 'Assignment', 'Conversation' (with a red badge '2'), 'Photos', 'Status Timeline', and 'Workflow' (which is selected). The main content area has a yellow bar stating 'Your move: Start testing or Waiting for spare part.' Below this is a light blue box with instructions: 'Log progress in Comments as you work. If you need a part, mark it — otherwise move to testing once you believe it's fixed.' There are two buttons: 'Waiting Spare Part' (with a pause icon) and 'Start Testing' (with a play icon). A text input field contains the text 'Base gasket kit (PK 75-250) ordered from store — ETA 2 days.', and a 'Confirm' button is to its right.

Figure 2.5 — Repairing: go to testing, or pause for a spare part with a reason.

- Post progress in **Conversation** as you work — findings, part numbers, meter readings, photos.
- If you need a part, press **Waiting Spare Part**, type **which part and why** (for example "Base gasket kit ordered from store — ETA 2 days"), then press **Confirm**. The Requester and the people who assign work are told the job is paused.
- When the part arrives, press **Part Received — Resume Repair**. The job returns to **Repairing**.

The screenshot shows the 'Waiting Spare Part' state of the same work order. The top header and navigation bar are identical to Figure 2.5, but the status badge now says 'Waiting Spare Part'. The main content area has a yellow bar stating 'Your move: Resume repair.' Below this is a light blue box with the text 'Paused — waiting on a spare part.' At the bottom, there is a single button labeled 'Part Received — Resume Repair' with a play icon.

Figure 2.6 — Paused — waiting on a spare part.

Step 4 — Testing

Figure 2.7 — Testing: mark it completed, or record a failed test.

- When you believe it is fixed, press **Start Testing**.
- If the test **fails**, press **Test Failed**, describe **what failed**, and press **Back to Repair**. The job returns to **Repairing** and the reason is recorded on the timeline. Fix it and test again.

Step 5 — Mark completed

Figure 2.8 — Describe what you did to fix it. The Requester can read this.

1 Press **Mark Completed**.

- 2 In **What did you do to fix it?** describe the repair — parts replaced, adjustments made, test results. The Requester will read this.
- 3 Press **Mark completed** to confirm. The job becomes **Completed** and is **closed automatically** at the same moment.




Figure 2.9 — Finished — nothing further to do.

Tip: Before completing, add an "after" photo in Conversation. It is filed under the Testing stage on the Photos tab, next to the "before" photo the Requester took.

2.4 Comments and photos




Figure 2.10 — The Conversation thread: your messages on the right in navy.

- Type in **Message...** and press **Post**. Press **Photo** to attach a picture from your camera or gallery.
- Photos are shrunk automatically before upload, so they go up quickly even on mobile data.
- Each photo is filed under the stage the job was at when you took it, so **Before work**, **Repairing** and **Testing** photos stay separate on the Photos tab.
- You can replace a photo **you** uploaded while the job is live: open it on the **Photos** tab and press **Replace**.




Figure 2.11 — Photos grouped by stage — the Requester's "before" photo and your testing photo.

2.5 Keeping an eye on the SLA

- The top right of every job shows the stage that is running and the time left — **Response SLA** before you start work, **Resolution SLA** after.
- SI warns you when a job assigned to you is **at risk** (in the last quarter of its time) and again if it is **breached**.
- A late stage stays marked as missed on the record, even if the job is finished afterwards. Only an Administrator can give a job more time (Extend SLA); if it then finishes within the new deadline, the stage shows as **Extended** instead.

2.6 Notifications you receive

The screenshot shows the SI Service Inside interface for a technician. On the left is a dark blue sidebar with navigation links: Dashboard, Work Orders, and Notifications (highlighted). Below the sidebar is the technician's profile: Arun Kumar, Technician, with a 'Sign out' button. The main area is titled 'Notifications' and shows '7 unread of 8'. There are buttons for 'Mark all read' and 'Clear read'. Below these are filters: 'All' (selected), 'Assignment 5', 'Requester 2', and 'System 1'. The notifications list includes:

- You've been assigned a work order** (8m ago, 25/09/2026 2:22 PM): WO-2026-000049 — Air Compressor 1000 K/P. Status: Assigned. Action: Assignment.
- Your repair was verified** (5d ago, 19/09/2026 9:05 PM): WO-2026-000047 — Air Compressor 1000 K/P has been signed off by Rajesh Menon. Status: Closed. Action: System.
- You've been assigned a work order** (5d ago, 19/09/2026 9:03 PM): WO-2026-000047 — Air Compressor 1000 K/P. Status: Assigned. Action: Assignment.
- Your repair was verified and closed** (08/09/2026 9:16 AM): Ravi Kumar has verified WO-2026-000046 — Steelpole Cutting Machine No 1 and closed it. Status: Closed. Action: Requester.
- Priority changed to P7** (02/09/2026 10:06 PM): WO-2026-000008 is now Long-term (P7), was Medium (P3). Action: Assignment.

At the bottom, it says 'Showing 1-5 of 8 notifications' with pagination controls (1, 2).

Figure 2.12 — Notifications for a technician.

- A job is **assigned** to you, or **handed over** to you from another technician. A handover keeps the job at its current stage — there is nothing to accept, just carry on.
- A job you finished is **sent back for rework** by a HOD, Manager or Administrator.
- A job of yours is **at risk** or has **breached** its SLA.
- An Administrator **changed the priority** of, or **extended**, one of your jobs.

2.7 Common situations

Q I accepted by mistake / I can't continue this job.

Tell your HOD in the job's Conversation. Only an HOD or Administrator can reassign it to somebody else.

Q A job I declined has disappeared.

That is expected. It went back to the queue with your reason.

Q The Confirm button is greyed out.

That step needs a note — a decline reason, which spare part, what failed, or what you did. Type it and the button turns on.

Q I don't see a Raise Work Order button.

Technician-only accounts don't raise work orders. Ask your Administrator to add the Requester role if you need to.

Q The job is waiting on a part for a long time.

Leave it in Waiting Spare Part and post updates in Conversation. Press Resume Repair only when the part is actually here.

Q My new role or job isn't showing.

Role changes take up to an hour to take effect. Sign out and back in to see them straight away.

03.

APPENDIX

Quick reference

Who can do what at a glance, and the words SI uses.

IN THIS CHAPTER

- 3.1** Who can do what
 - 3.2** Words SI uses
 - 3.3** Need help?
-

3.1 Who can do what

Action	Requester	Technician	Admin
Sign in with email or employee ID	✓	✓	✓
Change your own password	✓	✓	✓
See work orders you raised	✓	—	✓ all
See work orders assigned to you	—	✓	✓ all
Raise a work order	✓	X ¹	✓
Raise one on somebody's behalf	X	X	✓
Edit details while Open	Own	X	✓
Assign / reassign a technician	X	X	✓
Accept, decline, start, test, complete	X	Own jobs	—
Pause for a spare part / resume	X	Own jobs	—
Comment and add photos	✓	✓	✓
Replace a photo you uploaded	✓	✓	✓
Change a priority / extend an SLA	X	X	✓
Delete a work order	X	X	✓
Export the list to Excel	✓	✓	✓
Manage users	X	X	✓ ²
Change settings	X	X	✓ ²

¹ Unless the account also holds the Requester role. ² Some actions are for the app developer only — see the Administrator guide.

3.2 Words SI uses

Term	Meaning
Work order (WO)	A record of one fault or job, numbered like WO-2026-000049.
Requester	The person who reported the fault.
Assign	Choosing which technician does the job.
Handover	Reassigning a job that is already under way. It keeps its stage.
Production impact	How badly the fault affects production. It decides the priority.
Priority (P1–P8)	How urgent a job is. P1 is the most urgent.
SLA	The time allowed for each stage: acknowledge, response and resolution.
At risk / Breached / Extended	A stage in its last quarter of time / a stage that ran out of time / a stage an Administrator gave more time, while it is within its new deadline.

Term	Meaning
Sign-off	A HOD's check that a closed job was done properly. Only then does it count on the dashboards.
Retire	Take a setting out of use without breaking old records.
App developer	The team that builds and maintains SI. They carry out the actions marked ★.

3.3 Need help?

For account problems — cannot sign in, forgotten password, wrong role — contact your **Administrator**. For questions about a particular job, comment on the work order so everyone involved can see it.