# **GENII Version 2 NESHAPS**Users' Guide

B. A. Napier

June 2005

Prepared for U.S. Environmental Protection Agency under Contract DE-AC05-76RLO 1830

#### DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor Battelle Memorial Institute, nor any of their employees, makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof, or Battelle Memorial Institute. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

PACIFIC NORTHWEST NATIONAL LABORATORY

operated by

BATTELLE MEMORIAL INSTITUTE

for the

UNITED STATES DEPARTMENT OF ENERGY

under Contract DE-AC05-76RLO 1830

Printed in the United States of America

Available to DOE and DOE contractors from the Office of Scientific and Technical Information, P.O. Box 62, Oak Ridge, TN 37831; prices available from (615) 576-8401.

Available to the public from the National Technical Information Service, U.S. Department of Commerce, 5285 Port Royal Rd., Springfield, VA 22161

# GENII Version 2 NESHAPS User's Guide

# **Table of Contents**

1.0 Introduct	ion	1				
1.1	GENII V2 NESHAPS Capabilities and Limitations					
1.2	GENII V2 NESHAPS Pathways and Scenarios					
1.3	Hardware Requirements					
1.4	Component Programs	2				
1.5	Quality Assurance (QA) Issues					
1.6	Documentation and Availability					
1.7	References for Section 1	3				
2.0 Installation	on	4				
3.0 Using FR	AMES	7				
3.1	Conceptual Site Models					
3.2	Basic FRAMES Controls					
3.3	Navigating the FRAMES Window					
4.0 Using GI	ENII V2 NESHAPS					
4.1	Using the FRAMES Contaminant Selection/Database Editor					
4.2	Using the FRAMES User-Defined Source Module					
4.3	Using the GENII Chronic Plume Atmospheric Transport Module					
4.4	Formatting Meteorological Data for GENII					
	4.4.1 Standard GENII Meteorological Data Format					
	4.4.2 Converting Joint Frequency Data to GENII V2 Format					
	4.4.3 Converting CD144 Data to GENII V2 Format					
	4.4.4 Converting SAMSON and CEAM data to GENII V2 Format					
4.5	Using the GENII V2 NESHAPS Chronic Exposure Module					
	4.5.1 Main Control Screen					
	4.5.2 Soil Tab					
	4.5.3 Agriculture – General Screen					
	4.5.4 Agriculture – Food Crop Screen					
	4.5.5 Agriculture – Intake Delays Screen	39				
	4.5.6 Pathways Screen					
4.6	Using the GENII V2 NESHAPS Receptor Intake Module					
	4.6.1 Initial Entries					
	4.6.2 Pathway Parameters	43				
4.7	Using the GENII V2 NESHAPS Health Impacts Module					
	4.7.1 Method Selections	49				
4.8	Using Specialized Output Processors					
4.9	Additional Specialized FRAMES Input Modules	55				
	Problem					
6.0 Template	e Files	72				
	Meteorological Processor Technical Basis					
	Meteorological File Formats					
	Precipitation Probabilities for Select United States Stations					
Appendix D	Stability Distributions for Select United States Stations	123				

#### 1.0 INTRODUCTION

The GENII computer code was developed for the Environmental Protection Agency (EPA) at Pacific Northwest National Laboratory (PNNL) to incorporate the internal dosimetry models recommended by the International Commission on Radiological Protection (ICRP) and the radiological risk estimating procedures of Federal Guidance Report 13 into updated versions of existing environmental pathway analysis models. The resulting environmental dosimetry computer codes are compiled in the GENII Version 2 Environmental Dosimetry System, NESHAPS Edition. The GENII system was developed to provide a state-of-the-art, technically peer-reviewed, documented set of programs for calculating radiation dose and risk from radionuclides released to the environment. Although the codes were initially developed at the US Department of Energy's Hanford Site, they were designed with the flexibility to accommodate input parameters for a wide variety of generic sites. A new version of the codes, GENII Version 2 NESHAPS, is described in this report.

# 1.1 GENII V2 NESHAPS Capabilities and Limitations

The GENII V2 NESHAPS system includes the capabilities for calculating radiation doses following chronic atmospheric releases. Air transport is modeled using a chronic (annual average) plume model, which allows use of an effective stack height or calculation of plume rise from buoyant or momentum effects (or both). The code provides risk estimates for health effects to individuals or populations; these can be obtained using the code by applying appropriate risk factors to the effective dose, effective dose equivalent, or organ dose. In addition, GENII V2 NESHAPS uses cancer risk factors from Federal Guidance Report 13 to estimate risk to specific organs or tissues.

Data entry is accomplished via interactive, menu-driven user interfaces. Default exposure and consumption parameters are provided for both the maximum individual. Source term information may be entered as radionuclide release quantities for transport scenarios, or as basic radionuclide concentrations in environmental media (air, water, soil). For input of basic or derived concentrations, decay of parent radionuclides and ingrowth of radioactive decay products prior to the start of the exposure scenario may be considered. A single code run can accommodate unlimited numbers of radionuclides including the source term and any radionuclides that accumulate from decay of the parent, because the system works sequentially on individual decay chains.

The code package provides interfaces through the Framework for Risk Analysis in Multimedia Environmental Systems (FRAMES). Target populations are identified by direction and distance (radial grid in GENII V2 NESHAPS) for individuals and populations.

#### 1.2 GENII V2 NESHAPS Pathways and Scenarios

Available release scenarios include chronic releases to air (ground level or elevated sources). Exposure pathways include direct exposure via soil (surface sources), air (semi-infinite cloud and finite cloud geometries), inhalation and ingestion pathways. The tritium model also includes exposure via skin absorption.

GENII Version 1 implemented dosimetry models recommended by the ICRP in Publications 26, 30, and 48, and approved for use by DOE Order 5400.5. GENII V2 NESHAPS implements these models plus those of ICRP Publications 56 through 72, and the related risk factors published in Federal Guidance Report 13. Risk factors in the form of EPA developed "slope factors" are also included (these are a special subset of the FGR-13 values). These dosimetry and risk models are considered to be 'state of the art' by the international radiation protection community and have been adopted by most national and international organizations as their standard dosimetry methodology.

# 1.3 Hardware Requirements

GENII Version 2 requires Windows® 2000 or XP using Pentium processors, and disk storage in excess of 60 Mbytes. FRAMES and GENII make use of the memory-swapping capabilities of Windows®, so the programs should run on any Windows®-compatible computer. However, they will generally run fastest on machines with 256 Mbytes of memory or more.

# 1.4 Component Programs

GENII Version 2 consists of an atmospheric transport model, an environmental accumulation model, an exposure module, and a dose/risk module, each with a specific user interface code, as well as a dedicated report generator. The computer programs are of several types: user interfaces (i.e., interactive, menu-driven programs to assist the user with scenario generation and data input), internal and external dose factor libraries, the environmental dosimetry programs, and FRAMES-supplied file-viewing routines. For maximum flexibility, the code has been divided into several interrelated, but separate, exposure and dose calculations.

### 1.5 Quality Assurance (QA) Issues

All GENII versions were developed under QA plans based on the American National Standards Institute (ANSI) standard NQA-1 as implemented in the PNNL Quality Assurance Manual. All steps of the code development have been documented and tested, and hand calculations have verified the code's implementation of major transport and exposure pathways for a subset of the radionuclide library. A collection of hand calculations and other verification activities is available. A comprehensive test plan has been developed and testing is underway. The code has been reviewed by the EPA Science Advisory Board and a separate EPA-sponsored, independent peer review panel. The QA of both GENII Version 1.485 and Version 2 have been reviewed by the US Department of Energy (DOE 2003; 2004).

GENII Version 1 has been included in the International Atomic Energy Agency's VAMP project (VAlidation of Model Predictions - an acronym for the Coordinated Research Program on Validation of Models for the Transfer of Radionuclides in Terrestrial, Urban and Aquatic Environments), an international effort to compare environmental radionuclide transport models with measured environmental data. Results for test scenario CB (based on environmental measurements following the Chernobyl accident) indicated that dose estimates from GENII were comparable to, although slightly higher than, those of other

participating models, which is consistent with its primary function as a prospective analysis tool. The models included in the code have been validated to various degrees by additional studies; however these have not been compared directly to output from the code.

# 1.6 Documentation and Availability

The overall system design is documented in the GENII Version 2 NESHAPS Software Design Document (Napier et al. 2005). Specific instruction on the use of FRAMES and the SUM3 processor is available in electronic and print forms (Napier 2005). This report explains user interactions with the GENII modules. A series of example cases are available electronically; these are described in this report.

Electronic documentation of GENII V2 NESHAPS is available, and the code, documentation, and users' manuals have been made available through the Internet by the US Environmental Protection Agency.

#### 1.7 References for Section 1

DOE. 2003. Software Quality Assurance Plan and Criteria for the Safety Analysis Toolbox Codes, Defense Nuclear Facilities Safety Board Recommendation 2002-1 Software Quality Assurance Improvement Plan Commitment 4.2.1.2. U.S. Department of Energy, Washington, D.C.

DOE. 2004. Defense Nuclear Facilities Safety Board Recommendation 2002-1, Software Quality Assurance Improvement Plan, Commitment 4.2.1.3: Software Quality Assurance Improvement Plan: GENII Gap Analysis. DOE-EH-4.2.1.3-GENII-Gap Analysis. U.S. Department of Energy, Washington, D.C.

Napier, B. A., R. A. Peloquin, D. L. Strenge, and J. V. Ramsdell. 1988. GENII - The Hanford Environmental Radiation Dosimetry Software System. PNL-6584, Vols. 1-3. Pacific Northwest Laboratory, Richland, Washington.

Napier, B.A.. 2005. *Getting Started with GENII V2 NESHAPS*, Pacific Northwest National Laboratory, Richland, Washington.

Napier, B. A., D. L. Strenge, J. V. Ramsdell, Jr., P.W. Eslinger, and C. F. Fosmire. 2005. GENII Version 2 NESHAPS Software Design Document, Pacific Northwest National Laboratory, Richland, Washington.

#### 2.0 INSTALLATION

The GENII V2 NESHAPS environmental radiation dosimetry software package runs within the FRAMES Framework for Risk Analysis in Multimedia Environmental Systems. Therefore, both programs are required in order to run GENII V2 NESHAPS. FRAMES and GENII are provided together in a single installation package via either CD or the EPA's Internet website. The files in the installation package will perform all the necessary checking and program installation.

You may use the CD provided, or download the information from the Internet site. If using the Internet download, copy the file from the web site to the target computer in a temporary directory.

If you have an older version of FRAMES and GENII on the target computer, please remove them. By removing the older versions, you are assured that only the newer files are in place. This can be accomplished by using START/Settings/Control Panel/Add Remove Programs. First highlight the existing FRAMES installation, and hit the Add/Remove button. Repeat this step for the existing GENII installation, if it was installed separately from FRAMES.

Next install FRAMES and GENII. The GENII V2 NESHAPS installation consists of a single file that will automatically install all the necessary FRAMES and GENII routines and support files. The file is called GENIINSetup.exe for the NESHAPS Installation package. To install the package from the web site, copy the GENIINSetup.exe file onto the user's computer. It may be copied into any temporary directory. Then, run the GENIINSetup.exe routine. One way to do this is to use the Windows START – RUN commands, with \{user's directory}\ GENIINSetup.exe in the box, where {user's directory} is the location of the file that has been copied.

A series of options will be presented by the setup program. If the user selects the "Complete" setup, all installation steps are automatic – including the destination directory. If you want GENII to be installed in a directory other than C:\FRAMES, select "Custom". It is recommended that the installation occur in the FRAMES directory suggested by the program: \FRAMES\ – several of the example problems assume that this directory is in use and will not execute properly if another is selected. (In addition, the FRAMES program does not handle long file names in directory structures, so if a different directory is selected, its name should conform to the older DOS conventions.) If the user selects "Custom" installation, the target drive and directory may be selected first. You have a selection of features to install: FRAMES is mandatory, and it is suggested that all of the GENII V2 NESHAPS components be installed as well. The documentation and generic input templates may be omitted. A number of MEPAS modules (http://mepas.pnl.gov/earth/mepasmain.html) will supplement GENII; the MEPAS code is also available if desired.

The installation routine will install any required Windows drivers and controls, if they are not already present on your host computer. Upon completion of the installation, it may be necessary to reboot the computer to allow the operating system to update itself to these newer components.

The file originally copied from the web site may be deleted upon successful installation; however, if it is retained on the user's system, repairs may be made to the installation if any files are lost or corrupted.

When the FRAMES and GENII V2 NESHAPS programs have been successfully installed, the GENII V2 NESHAPS Users Guide (this document), the Getting Started with GENII V2 NESHAPS, and GENII Version 2 NESHAPS Software Design Document will be found in the \GENII DOCUMENTATION subdirectory. This is the complete technical documentation of the software algorithms. NOTE: These are Adobe Acrobat portable document (pdf) files, formatted for an HP® LaserJet 5 printer. They should print properly on other systems.

The installation package will place an icon for launching FRAMES on the desktop, as well as establish a FRAMES grouping on the Windows Start Menu.

FRAMES is invoked by double-clicking on the FRAMES 1.5 icon on the desktop, or from the same icon in the FRAMES group on the Start Menu. A simple way to test whether it is likely that the installation has been successful is to double-click the icon. A window similar to that shown in Figure 2.1 should appear. Left click on the *Customize* command. A menu of several items should appear; one item should be the word Logo followed by a small arrow indicating the availability of another submenu. Place the cursor over the word Logo, and a menu with the options Show and Select should appear. Left click on Select, and a list of available logos should be presented. Left click on the file geniilogo.jpg, and then hit the open button. The GENII V.2 logo should appear in the upper left portion of the FRAMES screen. This indicates that it is probable that the FRAMES and GENII components have all been loaded. The size of the FRAMES screen may be adjusted using the maximize/minimize buttons on the upper right, or by left clicking and dragging on the diagonal hash marks on the lower right.

If it is desired at a later time to uninstall GENII and FRAMES, this may be done from the Windows Control Panel Add/Remove Programs command. This can be accomplished by using START/Settings/Control Panel/Add Remove Programs. Highlight the existing combined FRAMES and GENII installation, and hit the Add/Remove button. This will uninstall all of the program files originally installed; any input, intermediate, or output files generated in the interim will not be removed. It may be necessary to manually delete any remaining files and the FRAMES directory.




Figure 2.1. Initial FRAMES display, without the GENII logo showing.

#### 3.0 USING FRAMES

The software platform from which different codes can be linked to communicate with each other is called the Framework for Risk Analysis in Multimedia Environmental Systems (FRAMES). FRAMES is an open-architecture, object-oriented system that provides an environmental database. This software platform aids the user in constructing a Conceptual Site Model that is real-world based. Further, the software allows the user to choose the most appropriate codes to solve simulation requirements and provides graphical packages for analyzing intermediate and final results. This section provides general information about using FRAMES.

## 3.1 Conceptual Site Models

The Conceptual Site Model is built by the user based on the conditions of the problem that is to be solved. The site is simulated on the screen by choosing icons to represent the various major environmental media or activities to be modeled and connecting lines that represent the real or potential flow of contamination.

Figure 3.1 illustrates the conceptual model for a specific modeling exercise as represented on the FRAMES main screen. For the hypothetical case represented in Figure 3.1, three major routes of contaminant transport are acting at a single location. Contamination is being released from a source into the atmosphere, and groundwater and surface water also are contributing contaminants to the environment at the location of interest. Contaminants are entering the food chain, individuals are being exposed, and, in this case, the effects of the contaminants on their health are being evaluated. Each icon on the Conceptual Site screen represents a real entity. For example, the River icon represents a local source of surface




Figure 3.1. A GENII Conceptual Site Model represented in the FRAMES window

water, and the Aquifer icon represents the groundwater at this location. (Note that aquatic transport models are not provided with GENII V2 NESHAPS; this description is generic and is provided to illustrate the reason that the FRAMES capabilities were selected for GENII implementation.) The dark lines connecting the icons on the screen visually show the paths that the contaminants follow. The lighter lines indicate that each icon is connected with, and has access to, information in the contaminant database. After the site model has been built and the case has been run, the user can view the results by running intermediate data viewers for each icon.

#### 3.2 Basic FRAMES Controls

There are five standard menu items on the FRAMES menu bar. These are File, Site, Customize, GO, and Help.

The File menu consists of five groupings, in standard Windows® format. The first grouping includes New, Open, and Close. These are the first options invoked in creating a new input Conceptual Site Model, in editing an existing Conceptual Model, or in finishing work with one. Upon first starting FRAMES, no new activities can be started without first selecting either **New** or **Open**; either of these options activates the FRAMES workspace. For a new case, the system will prompt for a file name before the user is allowed to enter data into the first module user interface. The Save and Save As options save the current contents of the workspace in global input data (GID) files of the user's choice. The Print command sends information about the case displayed in the workspace to the printer. There are numerous available sub-options for printing: the Conceptual Site Model picture may be printed along with a user-prepared summary description, and for each icon in the model, summary information about the model selected, the input data entered, and any usersupplied references may be optionally selected. The user has the option of adding references to model and data selection choices throughout FRAMES and GENII; the most generally accessible place to start these descriptive additions is with the **References** and **Project Description** menu selections. Each of these menu selections opens a window in which textual information may be entered for later retrieval; the information entered is saved in ASCII files associated with the project's GID file. Such entries are a useful method of documenting decisions and data sources used in establishing the basis for an analysis. FRAMES retains links to the four most-recently accessed GID files; clicking the mouse on one of these is equivalent to using the **Open** command. Finally, the **Exit** command shuts down all FRAMES operations, after first providing the option to save any changes or additions made during the work session.

FRAMES offers several ways to organize the Conceptual Site Model. If the user so desires, several Sites may be related and saved in the same Global Input Data file. This option is available using the **Site** menu. The Site currently active is shown in the FRAMES workspace; the name of this site is displayed in the second box on the bottom of the FRAMES window, as illustrated in Figure 3.1. In Figure 3.1, the default Site name of *Scenario 1* is used. Clicking on the **Site** menu allows access to options to create a **New** Site, **Rename** the active Site, and switch between Sites. Use of multiple Sites within a single GID file may be an advantage to users with complex problems in simplifying data organization, reporting, or records holding.

The **Customize** menu provides the FRAMES user with the ability to control the overall look of the FRAMES window. Every icon in a Conceptual Site Model has an internal identifier used by FRAMES to control data flow to and from the component models. The **Show Object ID** option allows the user to see the actual identifier assigned by FRAMES. This identifier is the default identifier used in the **General Info** command described below, and is stored in the project GID file. If the user will be reviewing the GID file for any reason, this is useful information; however, the display may be suppressed to simplify complex Conceptual Site Model displays. The **Show Icons** option may be used to simplify the display in the left-hand FRAMES window. Use of this option will remove the display icons from the selection window, leaving only the model type names displayed. The Font option allows the user to use any of the fonts available in Windows in the FRAMES display. (This option has been used throughout this Users Guide to make the reduced-size screen captures legible.) The **Colors** option gives the user the ability to change the display colors of the FRAMES background and various types of connecting lines. This capability may be used to make viewing easier under various conditions, to highlight specific features of a Conceptual Site Model, or to simplify complex diagrams in the FRAMES window. The **Logo** option, as illustrated in Section 2, allows the user to display a model logo in the box at the upper left of the FRAMES window. Generally, a FRAMES or GENII logo, or several stylized graphic depictions of contaminant transport in the environment, are available.

The **GO** command is a convenient way of running a computation after a Conceptual Site Model has been constructed. This single function starts FRAMES in completing all necessary steps in an analysis. All models are run in sequence; if data inputs are necessary, the data input is prompted before the models are run. This option will not run viewers or sensitivity/uncertainty modules. More is described about this below.

The **HELP** command will bring up a hypertext file summarizing the information in this Section of the Users Guide.

#### 3.3 Navigating the FRAMES Window

In order to build a Conceptual Site Model in the FRAMES workspace, the user must select the appropriate model icons, connect them in the desired order, and assign models and data to them.


Icons are selected from those available in the left-hand window. To select an icon, place the mouse cursor over the icon or icon label in the left window and double click the LEFT mouse button. This will add an icon of the selected type to the FRAMES workspace. Repeat until the desired icons are all selected. The only icon type required for all analyses is the Contaminant Database icon; only one of these is allowed per Conceptual Site Model.

Icons may be moved about the screen and arranged in any order. It is usually desirable to place the icons in an order that is logical from the physical description of the system and flow of data from beginning to end of the calculation, and that results in clear lines of communication. The icons are moved by placing the mouse cursor over them, clicking and holding the LEFT mouse button, and dragging the icon to the desired location.

The icons must be connected in the way that data and intermediate results will proceed. To connect icons, RIGHT-CLICK on the icon; from the menu that appears, place the cursor over the Connect-Disconnect selection, and a secondary menu listing the other available icons will appear; select the desired icon. Alternatively, the user may hold down the SHIFT key then LEFT-CLICK and drag the arrow from one Icon to the next. Note, in FRAMES 1.5, all model icons must be connected to the Contaminant Database icon; the connecting lines for database connections will generally appear in a different color than the contaminant flow lines. To remove connector lines, use the RIGHT-CLICK Connect-Disconnect procedure or repeat the SHIFT, LEFT-CLICK, and drag used to connect the icons, tracing the same path. Lines may be added and removed as often as necessary during the Conceptual Model construction.

To delete an icon from the workspace, place the mouse cursor over the icon, click the RIGHT mouse button, and select the Delete option from the menu that appears. Removing an icon will simultaneously remove any connecting lines attached to it.


All icons have an associated status indicator attached in the form of a "traffic light." The status indicator appears as an indicator on the left side of the icon. The indicator will change appearance as actions are taken during the case construction. When the icon is first placed in the workspace, and after it is first connected to other icons, it will appear all black. When a model has been selected and associated with the icon, it will display a red dot. When data entry for the model has been completed, the indicator will display a yellow dot. When the model has been successfully run, the indicator will display a green dot. The various appearances of the status indicator are illustrated in Figure 3.2.



**Figure 3.2**. Appearance of the FRAMES icon status indicators.

When the overall design of the Conceptual Site Model is completed, individual computational models may be associated with the icons. To select a specific model from a module type icon, first ensure that all module connections are complete, then RIGHT-CLICK on the icon and choose **General Info**. The model selection screen will appear as shown in Figure 3.3. This screen will display the models that are available for assignment to this icon. The type of icon and the way that the connecting lines have been drawn will determine the models available. Two windows are shown on the left of the model selection screen, applicable and non-applicable models. The total number of models shown in both windows will be all those of this icon type available on the computer; the ones applicable to the situation as diagrammed will be listed as available. If the model desired is listed as non-

available, it is usually because the connection lines have been drawn in such a way as to preclude its use, so the Conceptual Site Model may need to be reviewed or revised.



**Figure 3.3**. FRAMES Model Selection screen.

To select a particular model from the available list, highlight it with a LEFT click of the mouse cursor. This will place a summary description of the model in the large window on the right side of the screen. Note that default Object ID is listed on this screen and also used as the default for the User Label. This is the best time to name the icon in the User Label box if an identifier other than the default Object ID is desired to be shown on the FRAMES workspace. Other fields on this screen are associated with specific model inputs, and are described in their specific sections.

When the model has been selected, LEFT click on the OK button and the active window will return to the FRAMES workspace. If the model was selected correctly, the status light will be red.

The model selection activity should be repeated for all icons. This may be done manually for each, as described above, or the process may be speeded up using the **GO** menu.

Model selection must start with the first models in the connected string. Models available for the second, third, and subsequent icons in the chain may depend on those that have been selected earlier. Note that once a particular model has been selected, FRAMES then assumes that those further down the computational chain are dependent upon it. If, at a later time, changes are made to the **General Info** window, FRAMES will assume that subsequent modules also require review to ensure that the entire chain of calculations has not been altered. Thus, the sequence of status indicators will change from their prior state to solid black until the model selection and data entry have been reviewed.

Additional commands available with a RIGHT click of the cursor over an icon include **User Input** and **Run Model**. The User Input selection becomes available after a model has been

selected. Selecting User Input will start the user interface for the specific model assigned to the icon. When all data have been entered, the Run Model selection will become available. This selection actually causes the model to run with the data input, creating whatever intermediate data it provides. Upon running the model, the Print/View User Input and Print/View User Output options are activated. These selections start FRAMES data viewers that allow review of the input and output information for each module. These viewers are specific to the type of data being examined and are described in more detail in the specific sections for which they are applicable.

#### **4.0 USING GENII V2 NESHAPS**

The GENII V2 NESHAPS system includes the capabilities for calculating radiation doses following chronic atmospheric releases. Air transport is via the plume model, which allows use of an effective stack height or calculation of plume rise from buoyant or momentum effects (or both). The code provides radiation dose and/or risk estimates for health effects to individuals or populations; radiation dose may be reported as effective dose equivalent, equivalent dose and effective dose, or organ dose, and health risk may be reported as cancer incidence or fatalities. GENII Version 2 uses cancer risk factors from Federal Guidance Report 13 to estimate risk to specific organs or tissues.

Data entry is accomplished via interactive, window-driven user interfaces. Default exposure and consumption parameters are provided for the maximum individual. Source term information may be entered as radionuclide release quantities. Decay of parent radionuclides and ingrowth of radioactive decay products may be considered prior to the start of and during the exposure scenario. A single code run can accommodate unlimited numbers of radionuclides including the source term and any radionuclides that accumulate from decay of the parent, because the system works sequentially on individual decay chains.

Target populations are identified by direction and distance (radial grid for Version 2 NESHAPS) for individuals and populations.

GENII V2 NESHAPS is intended to be used as a general-purpose package for estimating the consequences of radionuclides released into the environment. Available release scenarios include chronic releases to air (ground level or elevated sources). Exposure pathways include direct exposure soil (surface sources), air (semi-infinite cloud and finite cloud geometries), inhalation, and ingestion pathways. Special models are included for tritium and carbon-14; the tritium model includes exposure via skin absorption, the carbon-14 model assumes carbon behaves primarily as CO<sub>2</sub>. An additional capability for releases of radon isotopes is included.

GENII Version 1 implemented dosimetry models recommended by the ICRP in Publications 26, 30, and 48, and approved for use by DOE Order 5400.5. GENII Version 2 implements these models plus those of ICRP Publications 56 through 72, and the related risk factors published in Federal Guidance Report 13. Risk factors in the form of EPA developed "slope factors" are also included. At the discretion of the user, different dose and risk approaches may be compared and contrasted. These dosimetry and risk models are considered to be 'state of the art' by the international radiation protection community and have been adopted by most national and international organizations as their standard dosimetry methodology.

The GENII Version 2 system consists of an atmospheric model, an environmental accumulation model, an exposure module, and a dose/risk module, each with a specific user interface code, as well as a dedicated report generator. The computer programs are of several types: user interfaces (i.e., interactive, window- driven programs to assist the user with scenario generation and data input), internal and external dose factor libraries, the environmental dosimetry programs, and FRAMES-supplied file-viewing routines. For maximum flexibility, the code has been divided into several interrelated, but separate,

exposure and dose calculations. The components of the system communicate with each other through a series of intermediate data files. Each of the intermediate files is accessible to the user through the FRAMES data-visualization utilities.

Various source input modules are provided by FRAMES. The chronic Gaussian-plume model can be run on either hourly or compiled joint-frequency data on wind speed, direction, and stability. Dry and wet deposition, for gases and various types of particles, is estimated. Utility programs are included to translate several types of available meteorological data into GENII input files. The terrestrial transport model is tailored for chronic accumulation. The human intake module allows customization of the exposure of individuals to the environmental contamination; up to 15 categories of pathways (with as many as 4 pathways per category) for up to 6 age groups are available. The dose and risk module includes the older ICRP models (for comparison with DOE and NRC regulations), the newer ICRP models, and risk estimation using EPA slope factors, dose-to-risk conversion factors, or the latest Federal Guidance Report 13 methods. The various impacts modules are provided by FRAMES to manipulate, summarize, and organize output as desired.

General instructions for entering data into each of the necessary FRAMES and GENII modules are provided here.

# 4.1 Using the FRAMES Contaminant Selection/ Database Editor

A FRAMES module that is needed in all GENII scenarios is that for the contaminant database. This icon is needed in all FRAMES applications of GENII. Once the icon has been established on the scenario screen, a database must be selected. This is done by right-clicking on the contaminant icon and selecting *General Info*. This selection will open a window similar to that in Figure 4.1. The GENII and FRAMES installation provides both a radionuclide-specific GENII database and a more general FRAMES radionuclide and chemical contaminant database. It is recommended that the user highlight the GENII Radionuclide Database and click the *OK* button. This will turn the indicator light to yellow on the contaminant database icon.

Next, right click a second time on the database icon and select the User Input option which will now be available. A screen similar to that in Figure 4.2 will open, allowing the selection of radionuclides for the case being evaluated. To select a radionuclide, the user may scroll through the list of available radionuclides in the lower left, or type the first few letters of the desired radionuclide in the *Search for* box at the bottom. When the desired radionuclide is visible, highlight it with a single left click. The radionuclide may be selected with either a double left click or by using the *Add* button. When all the desired radionuclides are selected, the user may either hit *File/Exit-Save Changes* or enquire about the nuclide properties.




Figure 4.1. FRAMES database selection screen

If the user wants to examine or modify the parameters in the database, the user should next hit the Constituent Properties tab. This will open a screen similar to that in Figure 4.3. On this screen are all of the default parameters used in the various calculations that are not accessible via the individual user interfaces. The parameters include a number of physical and chemical properties that are not used by GENII V2 NESHAPS (but may be used by other codes that are compatible with GENII). The database also includes radiation dosimetry parameters such as inhalation and ingestion dose and risk conversion factors (use of which are described in Section 4.7). Environmental transport parameters such as aquatic food bioaccumulation factors, soil-to-plant and feed-to-animal-product transfer parameters, and various environmental rate parameters are also shown (use of which are described in Section 4.5). The user may make TEMPORARY changes to the parameters for a single case using this screen from within FRAMES. PERMANENT changes to the database may only be made using the editor in stand-alone mode.




Figure 4.2. Database editor radionuclide selection screen

When the user has selected all radionuclides and modified all parameters required, the user should select the *File/Exit-Save Changes* tab and exit. This will set the indicator light to green on the Contaminant Database icon, and the user may proceed to the next set of inputs.

# 4.2 Using the FRAMES User-Defined Source Modules

FRAMES provides utility programs for inputting data on the quantities of radionuclides emitted to the environment, along with several other related parameters that may or may not be required for GENII operations. The General Info selection will show available options based on FRAMES file type: AFF is Air Flux File, WFF is Water Flux File, SCF is Soil Concentration File, etc. An example of the type of input required is shown in Figure 4.4. The **File** menu item allows input data to be saved, or existing data to be reviewed and retained unchanged. The **Options** menu item has only one function – to allow





Figure 4.3. Database editor constituent properties tab

input of decay progeny information if desired. This option may be used if the analyst wishes to set the emitted quantities of progeny to a non-zero value; the default is zero. Use of this option is illustrated in Figure 4.4 for a simple 2-member decay chain, <sup>131</sup>I.


The illustration in Figure 4.4 is for input of releases to the atmosphere. Input for an Area Source is illustrated; only the area of the source is required to describe the site conditions. If a point source (i.e., a stack release) were selected, the various descriptors of the source would also be required.



**Figure 4.4**. FRAMES Known Source screen for an atmospheric release, illustrating use of the **Show Progeny** Option.

Note that inputs proceed for one radionuclide decay chain at a time. All progeny for the parent radionuclide, if the Show Progeny option is selected, must be entered. FRAMES allows time-dependent releases to be entered – GENII V.2 uses annual average release rates. Thus, GENII will integrate the total release entered in the User-Defined Source module, divide by the total time, and use that as the annual average release rate. A quirk of this system is that FRAMES requires that a minimum of two time points be entered. An easy way to put in a known release over one year is to put it in as a square wave, as shown in Figure 4.4.


For releases to the atmosphere, there is a second required input screen in the FRAMES User-Defined Source module, accessed using the **Flux Types** button. This screen is illustrated in Figure 4.5. This screen must be accessed before the User-Defined Source module will allow input of the releases. It defines the number and type of particle sizes that the GENII atmospheric transport model will simulate. GENII will model particles, non-reactive gases (i.e., noble gases), and reactive gases such as iodine. If gases are to be simulated, the GAS 1 box must be checked. The fraction of the gases that are reactive must also be entered (this has no effect on the noble gases Ar, Kr, Xe, or Rn, or on elemental tritium). Up to three particle sizes can be modeled; information is supplied here for each particle size. When this information is entered, click on the **Done** button to return to the main input screen.



**Figure 4.5.** FRAMES User-Defined Source Flux Types options.

Nearly all non-control parameters have the ability to associate a reference. These references are intended to help document the selection of parameters and allow traceability of assumptions. To associate a reference with a data entry, place the focus (click the cursor in the box) on the parameter of interest, click on the **Reference** menu item, and select either Add or Select. A window like that shown in Figure 4.6 will appear. If the **Add** option was selected, a blank entry will appear allowing text entry of a new reference. The entries are free formatted, so any short and long descriptor may be added. If the **Select** option is chosen, the available entries may be scrolled using the arrow buttons, or a specific entry searched for using the appropriate boxes.

Notice that all parameters requiring a numeric value have units and ranges. The code will internally convert from one set of units to another if the units tabs are selected. The allowable ranges for numerical values scroll across the bottom of the screen – values outside of these ranges will not be accepted. Unacceptable or incomplete entries are displayed with a red background; acceptable completed entries are displayed with a light green background.



**Figure 4.6**. The Reference Editor window.

# 4.3 Using the GENII V2 NESHAPS Atmospheric Transport Module

One atmospheric transport model is provided in the GENII V2 NESHAPS package. This is the chronic plume (Straight-line Gaussian) model. The chronic plume model will run with joint frequency of occurrence data as well as hourly inputs. Utility programs are provided to transform available data formats into the form required by GENII V.2 models.

The FRAMES User-Defined Source Module is used to supply information to the GENII air transport models. The **General Info** model selection window (accessed by RIGHT clicking on the source and air transport icons) has two parameters that interact between the User-Defined Sources and the air transport model. These are the Easting Coordinate and the Northing Coordinate for each source and for each air transport model (see Figure 3.3). These coordinates are used to describe the location of the sources relative to the center of the atmospheric dispersion grid. Figure 4.7 illustrates the effect of these parameters. For the case analyzed for Figure 4.7, two identical sources are postulated, one is at position –20 km Easting, 0 km Northing, and one is at +20 km Easting, 0 km Northing. The center of the atmospheric grid is set at 0 km Easting, 0 km Northing. Thus, the two sources are equidistant from the center of the grid to the east and west. The resulting graph of contaminant deposition (created with the FRAMES Gnuplot utility) clearly indicates two peaks of concentration surrounding the two sources, spaced to either side of the center of the grid. This illustrates the joint use of the Easting Coordinate and Northing Coordinate in establishing release points.




Figure 4.7. Result calculated with 2 sources 20 km east and west of atmospheric grid center

The primary input screen for the chronic plume model is illustrated in Figure 4.8. The Chronic Plume model is useful for situations of moderate complexity over open, flat terrain, particularly when only averaged meteorological data are available.

The chronic plume model uses a radial grid. The number of radii is variable depending on the nature of the available data. If only compass point joint-frequency data are available, a 16-point compass can be used. If the data are available in 10s of degrees, a 36-point compass may be used. The downwind distances for calculations are user selectable. The defaults for the distances reflect 0.5, 1.5, 2.5, 3.5, 4.5, 75, 15, 25, 35, and 45 miles in meters.

Figure 4.9 illustrates the **Model Parameters** tab. These allow selection of the type of model desired for determining the magnitude of the Gaussian stability parameters. If the **Calm Wind Distribution** check box is invoked, additional information is required. In the NESHAPS Edition of GENII V2, selection of these parameters has been fixed to the EPA-approved values.




Figure 4.8. GENII Chronic Plume Model initial input screen




Figure 4.9. GENII Chronic Plume Model Parameters tab

The information provided on the Default Parameters tab is used inside the model. They are available here for code development and special implementation purposes. These parameters are discussed in the GENII Software Design Document; they are not typically changed by the user, and have been fixed to the EPA-approved values.

Figure 4.10 illustrates the **Meteorological Files** tab. This tab allows the user to direct the code to the appropriate meteorological data file for input. LEFT click on the Browse for Meteorological File button and a window to the file directory will be opened. If a file is available in the appropriate GENII format, simply select it here.

If a meteorological file in GENII V2 NESHAPS format is not directly available for the chronic plume model, one may be created from other sources of data. If joint frequency data are available, the **Use Joint Frequency Data file** button may be chosen to activate the model to process the information into the appropriate format. If hourly data are available, the **Use SAMSON or CD144 formatted file** button is used. The necessary data types, file formats, and other processing information are described in Section 4.4 and the Appendix.

The submersion dose cloud shine library is generally fixed and not altered by the user.




Figure 4.10. GENII Chronic Plume Meteorological Files tab




Figure 4.11. GENII Chronic Plume Source Information tab

The Source Information tab is illustrated in Figure 4.11. This tab allows selection of calculation of plume rise by the code. In addition, certain enhanced dispersion options, described in the GENII Version 2 NESHAPS Software Design Document, may be selected on this screen. These options require additional input describing the projected area of the buildings around the release point for building wake calculations. If multiple sources are being modeled, a separate tab is provided for each source point.

#### 4.4 Formatting Meteorological Data for GENII V2 NESHAPS

The GENII meteorological models run from files of hourly meteorological data in a specific format. If a meteorological file in GENII V2 NESHAPS format is not directly available, one may be created from other sources of data. If joint frequency data are available, the **Use Joint Frequency Data file** button may be chosen to activate the model to process the information into the appropriate format for the chronic plume model. If hourly data are available, the **Use SAMSON or CD144 formatted file** button is used for the chronic and acute plume and puff models. The necessary data types, file formats, and other processing information are described in the following Sections.

### 4.4.1 Standard GENII Meteorological Data Format

The first record of the meteorological file contains the surface roughness of the site (see Section A.2.3) and the height of the wind measurements. Following the first record are the records containing the meteorological data. Each record after the first contains the year,

month, day and hour of the record. Following the date and time are the stability class, the flow vector (wind direction plus 180 degrees, i.e., the direction the wind is blowing towards), the wind speed, the dry bulb temperature, the mixing height, the precipitation type (e.g, none, light rain, light snow), the precipitation rate, and a weighting factor. The format of the file is given in Appendix B.

# 4.4.2 Converting Joint Frequency Data to GENII V2 Format

Joint frequency data (JFD) may be used to simulate hourly data for the GENII chronic plume model. Two different formats of JFD are read by the GENII processing program, the format used by the EPA's Industrial Source Complex (ISC3) model (EPA 1995a) and the format used by the GENII 1.485 code (Napier et al. 1988).

The ISC3 format, also called the STAR summary, is described in EPA (1995a) and is summarized here. The JFD in the STAR format is normally constructed using 16 wind direction sectors, with the first 22.5-degree-wide sector centered on winds from the North (increasing clockwise), six wind speed classes, and six stability classes. Wind speed classes are usually grouped as 0-3, 3-6, 6-10, 10-16, 16-21, and greater than 21 knots. Stability classes are based on the Pasquill stability categories (A [very unstable] - F [very stable]). Thus, the JFD file in the ISC3 format normally consists of 96 records. Each record is for a specific stability class and wind direction sector. Within each record is the frequency for the six wind speed classes for the given stability class and wind direction sector. In a quasi-programming sense, the file would be read as follows

```
Loop On I = 1, Number of Stability Classes (normally 6)

Loop On K = 1, Number of Wind Direction Sectors (normally 16)

READ (JFDFILE,'(6F10.0)') (FREQ(I,J,K), J = 1 to Wind Speed Classes)

End Loop On K

End Loop on I
```

where FREQ(I,J,K) = Frequency of stability class I, wind speed class J, and wind direction sector K.

Thus, in a normal STAR summary the first 16 records are for sixteen direction sectors of stability class A (or 1), the next 16 are for stability class 2, and so forth. A selection of STAR files is provided with GENII – these are listed in Appendix D. The user provides the number of wind direction sectors, stability classes, and wind speed classes. So, as long as the JFD follows the above format (records containing the frequency by wind speed class; records ordered by wind direction sector then stability class), the number of stability classes, wind direction sectors, and wind speed classes can vary.

The GENII V2 NESHAPS format is different from the ISC3 format. A description of the format is given in Napier et al. (1988), and is summarized here. Unlike the ISC3 format, the GENII format contains the percentages (frequency times 100) rather than frequencies of a given stability class, wind speed class, and wind direction sector. The JFD is usually constructed based on 16 wind direction sectors like the ISC3 format, but a variable number of wind speed class and atmospheric stability classes may be used. Table 4.1 shows the format of the GENII JFD file.

Table 4.1. Format of Joint Frequency Distribution of Wind Speed, Wind Direction, and Atmospheric Stability for GENII V2 NESHAPS.

Record Number	Field Number	Data Type	Field Size	Description		
1	1	CHARACTER	80	Descriptive Title		
2	1	CHARACTER	80	Secondary Title		
3	1	INTEGER	5	Number of wind speed classes in file		
3	2	INTEGER	5	Number of atmospheric stability classes		
3	3	INTEGER	5	(Not Used always set to 1)		
3	4	INTEGER	5	(Not Used always set to 1)		
3	5	REAL	10	Height at which wind speed data was collected (m)		
4	1 - 10	REAL	7	Average Wind Speed for each wind speed class (m/s)		
Joint Frequency Data Set						
5 till end	1-16	REAL	5	Percent of time with wind from North, North-Northeast, Northeast, etc.) Each record has the 16 sectors. Data are grouped first by atmospheric stability class and then by wind speed group.		

The GENII 1.485 format JFD file has the first four records containing information about the joint frequency data set, and the rest of the records are the joint frequency data set. In the same pseudo-programming language, the joint frequency data set would be read as:

```
LOOP ON I = 1 TO Number of Wind Speed Classes

LOOP ON J = 1 TO Number of Stability Classes

READ( JFDFILE, '(16f5.0)') (PREC(I,J,K), K = 1 to Number of Direction Sectors)

END LOOP ON J

END LOOP ON I
```

As with the ISC3 format, the user provides the number of wind speed classes, wind direction sectors, and atmospheric stability classes.

In order to convert joint frequency data to the hourly format needed for the GENII chronic plume model, a utility program is provided. It is accessed from the **Use Joint Frequency Data file** button on the Chronic Plume model **Meteorological Parameters** tab (Figure 4.10). Left clicking on this button brings up the program screen illustrated in Figure 4.12.





Figure 4.12. Initial input screen for processing joint frequency information

The three **Browse** buttons on the upper right allow the user to define a file in which to store the processing requirements, identify the source of the joint frequency data, and save the resulting quasi-hourly data file. The first and third fields allow the user to either select an existing file name (in which existing data will be overridden) or type in a new name. The second field allows the user to find an existing file; when the existing file is selected, the user is prompted to identify it as containing either STAR or GENII formatted data. The three tabs on the lower portion of the window allow input of data needed in the expansion of the JFD to quasi-hourly data. The **Station Information** describes the location and nature of the meteorological station from which the data are derived. The Joint Frequency Info tab, Figure 4.13, provides information needed in the processing. The meteorological information in the JFD file does not include date/time information. The JJFDPROC program instead creates pseudo-hourly data where there is one record for each wind speed class, wind direction sector, and stability class found in the JFD. In addition, the number of records will be expanded based on variation of the temperature and precipitation type. GENII V2 NESHAPS provides representative precipitation information that may be combined with standard IFD files, via the **Precipitation** tab illustrated in Figure 4.14. How these variations expand the number of records is explained in Appendix Sections A.3.5 and A.3.6 for temperature and precipitation, respectively.



**Figure 4.13.** Joint Frequency Info tab inputs




Figure 4.14. Including representative precipitation data with JFD inputs

When all data have been input, LEFT click on the **Process Joint Frequency Distribution** button. The JJFDPROC processor will create a file in the appropriate GENII V2 NESHAPS hourly format. The output records have a weighting factor that is the number of

hours with the meteorological data contained in the record. As there is no date/time information, the year, month, day, and hour for each record is given as -1. The data will be stored in the file assigned in the second box. Exit from the processor program back to the **Meteorological Files** tab (Figure 4.10) and enter the newly created filename in the box for **Path and Name for Meteorological Data File**.

Joint frequency data have historically been the most common form of meteorological summaries available. Joint frequency data from the CAP-88 code for a large number of locations are available; these have been modified and are provided in a STAR subdirectory of data along with the GENII V2 NESHAPS installation. See Appendix B.

# 4.4.3 Converting CD144 Data to GENII V2 format

The CD-144 format refers to the "Card Deck 144 format" available from the National Climatic Data Center (NCDC). The file is composed of one record per hour, with all weather elements reported in an 80-column block. The format of these records is described in the Card Deck 144 WBAN Hourly Surface Observation Reference Manual (NOAA 1970), also available from NCDC. Data in this file includes the year, month, day, hour, cloud ceiling height, wind direction, wind speed, dry bulb temperature, and opaque cloud cover (see Appendix A). The following describes the variables found in the CD-144 format.

- Year, Month and Day identifies the year, month and day during which the meteorological data were observed.
- Hour identifies the hour of the meteorological data observation. Hour is based on the 24-hour clock and is recorded as 00 through 23. Times are Local Standard Time (LST).
- Ceiling Height the height of the cloud base above local terrain and is coded in hundreds of feet.
- Wind Direction the direction from which the wind is blowing, rounded to the nearest 10 degrees. Calm is given by 00.
- Wind Speed the wind speed measured in knots. Calm given by 00.
- Dry Bulb Temperature the ambient air temperature measured in whole degrees Fahrenheit.
- Cloud Cover There are two cloud cover parameters, opaque cloud cover and total cloud cover. Both parameters identify the amount of cloud covered measured in tens of percent, e.g. 0 = clear or less than 10%, 4 = 40 49%, '-' = Overcast of 100%. The model uses opaque cloud cover.

In order to convert CD144 data to the GENII V.2 hourly format, use the **Use SAMSON or CD144 formatted file** button on the chronic plume Meteorological Files tab. This will start a processing program with an input screen illustrated in Figure 4.15. The three **Browse** buttons on the upper right allow the user to define a file in which to store the processing requirements, identify the source of the CD144 data, and save the resulting hourly data file. The first and third fields allow the user to either select an existing file name (in which existing data will be overridden) or type in a new name. The second field allows the user to find an existing file; when the existing file is selected, the user is prompted to identify it as containing either CD144 or SAMSON formatted data. If hourly precipitation data are

available in the NCDC TD3240 format, checking the **Use TD3240 Data** box opens a fourth filename box, in which that filename may be entered. The inputs on the lower portion of the window allow input of data needed in the expansion, describing the location and nature of the meteorological station from which the data are derived.

When all data have been input, LEFT click on the **Process Data** button. The HRLYPROC processor will create a file in the appropriate GENII V.2 hourly format. The data will be stored in the file assigned in the second box. Exit from the processor program back to the **Meteorological Files** tab (Figure 4.14) and enter the newly created filename in the box for **Path and Name for Meteorological Data File**.

CD144 data may be purchased from the National Climatic Data Center. Alternatively, a large amount of CD144 data are available from the EPA Technology Transfer Network Support Center for Regulatory Air Models, located on the Internet at <a href="http://www.epa.gov/scram001/tt24.htm">http://www.epa.gov/scram001/tt24.htm</a>. Note that this data may require preliminary decompression and conversion to CD144 format before it can be successfully used in the GENII processing routine.




Figure 4.15. Input screen for processing CD144 or SAMSON data

# 4.4.4 Converting SAMSON and CEAM Data to GENII V2 Format

The National Climatic Data Center (NCDC) has made available solar and meteorological data from the first order stations in the United States for the period 1961 - 1990 on a set of three CD-ROMs, referred to as the SAMSON data. A second CD of data from 1991 through 1995 is also available. The GENII V2 NESHAPS processors can process data retrieved from these CD-ROMs. It cannot access the data directly from the SAMSON CD-ROM, but the user can run the software provided with the data to retrieve the station, period of time and variables from the site and period to be modeled. The software is a DOS-based, interactive graphical interface.

Multiple years of data can be extracted for a single station and saved to the same file. However, the GENII processor expects a maximum of one year of data in the data file. The reason for this restriction is explained below.

Retrieving the data from the CD-ROM is completely under the control of the user. When data are retrieved from the CD-ROMs, the user has the option to specify which variables to retrieve from a list of 21 variables for each station. At a minimum, the ceiling height, wind direction, wind speed, dry bulb temperature, opaque cloud cover, and present weather must be retrieved. In most cases, the hourly precipitation amount will also be retrieved, but it is not required.

When the data are retrieved from the CD-ROM, two records are written at the beginning of the file that identify the station (first record) and the variables retrieved (second record). GENII uses both records to obtain information about the station (e.g., latitude and longitude) and to determine how to process the data that follows. These two records begin with the tilde character (~). If more than one year of data are retrieved from the CD-ROM, these two records will appear before each year in the file. Thus, an error will occur when the program reads these second set of header records.

The second header record is used by the model to determine if enough variables have been retrieved from the CD-ROM. If there are insufficient variables retrieved, an error will occur during the model execution. The user should return to the CD-ROM and retrieve the data once again to make sure all the necessary variables are retrieved.

Data records follow the header records in the retrieved file. There is one record for each hour of time period selected by the user. Unlike the CD-144 format which reports the hour on the 00 - 23 clock, the hour in the retrieved file is reported on the 01 - 24 hour clock. Hour 24 of a day from the SAMSON data corresponds to hour 00 of the next day for the CD-144 data.

Data stored in the SAMSON format are in different units than found in the CD-144 data. The output using either format is the same, so the SAMSON and CD-144 data are converted to a specific set of units for each meteorological variable.

The process for converting the data is the same as that described above for CD144 data; only the selection of SAMSON is different. TD3240 data are not necessary with SAMSON.

Data from SAMSON have been extracted, combined with similar data, and made available by the EPA on the CEAM (Center for Exposure Assessment Modeling) website at <a href="http://www.epa.gov/ceampubl/tools/metdata/us\_met.htm">http://www.epa.gov/ceampubl/tools/metdata/us\_met.htm</a> The semi-processed data available on the CEAM site are in a formatted file that may be converted to GENII format using the same processor as SAMSON data. The file data format is provided in Appendix B. When the CEAM site is queried, the user may download data for a multiple-year period for a given location. Each selected location downloads a 7 Mbyte zip file which unloads into a directory with a name of the type C:\metdata\"state"\"city code"\files. The meteorological processor has been adapted so that the desired year of data may be extracted and used as described above.

# 4.5 Using the GENII V2 NESHAPS Chronic Exposure Module

This user interface controls input for the chronic terrestrial and aquatic models used to estimate the radionuclide exposure media concentration for soil, terrestrial, and aquatic exposure pathways. The deposition from prior years of deposition (from air) is evaluated using atmospheric deposition and water concentration data provided as a function of time.

The various GENII or other FRAMES-compatible atmospheric transport modules may be used to supply information to the GENII chronic exposure model. The **General Info** model selection window (accessed by RIGHT clicking on the exposure icon) has two parameters that interact between the air transport models and the GENII chronic exposure model. These are the Easting Coordinate and the Northing Coordinate for the GENII exposure model (see Figure 3.3). These coordinates are used to describe the location of the location of interest relative to the center of the atmospheric dispersion grid. If the defaults of (0,0) Easting and Northing are used, it is assumed that ALL points on the atmospheric grid are desired. If any other pair of values is used, the GENII model will determine the CLOSEST atmospheric grid point, and use the values appropriate to that location.

The **File** menu item allows input data to be saved, or existing data to be reviewed and retained unchanged. All parameters in this module are fixed to EPA-approved values – no changes are allowed to the user. Only the **Help** button is functional; it may be used to view a description of the parameters similar to what is described herein. If no individual parameter has the focus of the mouse cursor, selection of Help will bring up the general help, which describes the Near Field model inputs in general terms. If a parameter has the focus, the context specific help will describe the use of the particular parameter.

#### 4.5.1 Main Control Screen

The main control screen for the GENII chronic exposure user interface, Figure 4.16, allows the user to view the general selections on exposure pathways and some basic parameters for the exposure analysis that have been selected for EPA NESHAPS compliance analyses. As noted above, the user may not vary these selections in the GENII V2 NESHAPS codes.




Figure 4.16. GENII Chronic Exposure Module Main Controls screen

The general selections allow inclusion (control box checked) or exclusion of general classes of exposure pathways.

- Animal product ingestion
- Terrestrial food ingestion
- Aquatic food ingestion
- Recreational surface water exposures
- The debug option flag should not be used (checked) by the average user as large output files may be generated.

The parameters entered on the control screen are for description of the timing of the exposure scenario and other parameters that are general in nature to the overall analysis.

<u>Duration of exposure period</u> is the time period over which the individual is exposed. It is measured from the time given for the start of exposure. A minimum value of 1 year should be provided, and the value should be in increments of 1 year. The analysis will provide results (to the exposure media intermediate file (EPF extension) for each year in the duration of exposure. A longer exposure duration will result in a larger output file. The NESHAPS Edition has a 1-year exposure time, to correspond with the Clean Air Act requirements.

End of release period is the elapsed time measured from time zero to the end of the release (from air, surface water, or groundwater). Exposures may be evaluated beyond this time

period for exposure to residual activity. For the NESHAPS Edition, this is set to 100 years, which corresponds with the selection of 100 years total release.

<u>Time from start to exposure</u> is the time from zero to the beginning of the intake analysis. The duration of exposure begins at the end of the "time from start to exposure." For the NESHAPS Edition, this is set to 99 years, in order to simulate a long-term ongoing release.

Air deposition time prior to exposure is used when atmospheric releases are being evaluated. This time period is measured backwards from the "time from start to exposure" and must be less than or equal to that time parameter. This is also set to 99 years for the NESHAPS edition.

Other parameters on the control screen are as follows.

Absolute humidity is used in the special tritium models for food pathways.

<u>Fraction of plant roots in surface soil</u> is used in the food crop and animal feed analyses and represents the fraction of plant roots that are in the contaminated soil layer. The uptake by plants is assumed to be proportional to this fraction.

Average daily rain rate is used to estimate the interception fraction from rain when wet deposition rates are provided in the atmospheric transport output file (ATO), and the user has selected the option to allow the code to calculate the wet deposition interception fraction.

#### 4.5.2 Soil Screen

The soil tab has several sub-screens.

### 4.5.2.1 Soil - Leaching Screen

The soil leaching screen is fixed to use the GENII default transport factor data.

The type of leach rate constant option allows selection of the method for specifying the soil loss rate constant for the leaching model. The rate constant may be defined in three ways: use of values in the GENII transport factor data file, calculation of rate constants from user supplied parameters, or input of rate constants (for each radionuclide). The method is selected from the pull-down list. When use of the GENII transport factor data file is selected, no additional input is needed for this screen.

# 4.5.2.2 Soil - Resuspension Screen

This screen is similar to Figure 4.17. In the GENII V2 NESHAPS Edition, all values have been fixed; the Mass Loading option is selected, and only the Mass Loading Factor is pertinent.




Figure 4.17. Soil Resuspension screen.

The <u>type of model to run</u> selects the model to use to evaluate air concentration from calculated soil concentrations. Four options are available: none (no resuspended contamination), use mass loading model, use Anspaugh model, and user input of resuspension factor.

The <u>mass loading factor for resuspension model</u> parameter is entered when the mass loading option is selected. This parameter is the airborne particulate concentration at the exposure location.

The <u>depth of topsoil available for resuspension</u> parameter is entered when the Anspaugh model is selected. This parameter represents the thickness of soil in which the deposited activity has been mixed.

The <u>resuspension factor</u> is entered when that option has been selected. The value provided is used for all radionuclides in the analysis.

### 4.5.2.3 Soil - Surface Soil Screen

This screen, equivFigure 4.18, allows input of parameters describing the surface soil layer. These parameters are related. For the GENII V2 NESHAPS Edition, all values are set to EPA-approved values.




Figure 4.18. Chronic Exposure Module Surface Soil Tab.

The <u>surface soil areal density</u> is used to convert concentrations expressed per unit area to concentrations expressed per unit soil mass.

The <u>surface soil layer used for density</u> is the depth of soil used in calculation of the soil areal density.

The <u>surface soil density</u> is the soil mass density used to calculate the soil areal density.

# 4.5.3 Agriculture - General Screen

This screen, Figure 4.19, allows the user to describe harvest removal, deposition to plants, and resuspension to plant surfaces, and loss by weathering from plant surfaces. All NESHAPS values are fixed.

The <u>radionuclide removal due to harvesting</u> option allows the user to activate ("x" in box) the calculation of radionuclide loss due to harvest removal of each food crop and animal product feed. When activated, the soil concentration is depleted at the end of each year. The amount of loss is calculated from the plant concentration at harvest, the annual plant yield, the root penetration factors, and the soil concentrations at harvest.

The <u>user defined dry deposition retention fraction to plants</u> option allows the user to select the method for evaluating the dry deposition retention fraction. If this option is activated




Figure 4.19. Agriculture – General Screen

("x" in box), then the user is allowed to enter the dry deposition retention fraction to plants (next parameter). If not activated, the code uses the default method based on plant biomass.

The <u>dry deposition retention fraction to plants</u> is entered to define the fraction of dry deposition activity that is retained on plant surfaces during initial dry deposition from the air.

The <u>user defined wet deposition retention fraction to plants</u> option allows the user to select the method for evaluating the wet deposition retention fraction. If this option is activiated ("x" in box), then the user is allowed to enter the wet deposition retention fraction to plants (next parameter). If not activated, the code uses the default method based on biomass and rainfall rate.

The <u>wet deposition retention fraction to plants</u> is entered representing the fraction of wet deposition activity that is retained on plant surfaces during initial wet deposition.

The <u>resuspension factor from soil to plant surfaces</u> is used to evaluate the air concentration above the plants from resuspension of particulate activity.

The <u>deposition velocity from soil to plant surfaces</u> is used to estimate the amount of resuspended activity deposited onto plants.

The <u>weathering half life from plants</u> is used to evaluate the weathering loss rate constant for loss of activity between deposition (wet or dry) and harvest.

### 4.5.3.1 Agriculture - Animal Feed - Biomass Screen

The <u>standing biomass</u> for each animal feed type is the total above-ground plant mass (wet weight) used to estimate interception fractions for wet and dry deposition. All inputs are fixed to EPA-approved values.

### 4.5.3.2 Agriculture - Animal Feed - Consumption Screen

The <u>feed consumption rate</u> for each animal feed is entered. The value for each feed type represents the total intake of this type of feed. These values are multiplied by their respective contaminated fraction to determine the contaminated portion of the intake of each feed type. All inputs are fixed to EPA-approved values.

# 4.5.3.3 Agriculture - Animal Feed - Storage Time Screen

The <u>storage time</u> between harvest and feeding to the animal is used to evaluate radioactive decay during the storage period. All inputs are fixed to EPA-approved values.

### 4.5.3.4 Agriculture - Animal Feed - Diet Fraction Screen

The contaminated fraction of feed for each animal type is the fraction of the feed type eaten by the animal that is contaminated. This fraction is multiplied by the feed consumption rate to determine the total contaminated intake of each feed type. All inputs are fixed to EPA-approved values.

# 4.5.3.5 Agriculture - Animal Feed - Growing Period Screen

The growing period for each animal feed type defines the deposition period for irrigation and atmospheric deposition to plants. All inputs are fixed to EPA-approved values.

# 4.5.3.6 Agriculture - Animal Feed - Yield Screen

The <u>yield</u> of each animal feed type gives the total annual production of edible feed crops per unit area of farmland. The yield is used to calculate the harvest removal losses from the soil. All inputs are fixed to EPA-approved values.

### 4.5.3.7 Agriculture - Animal Feed - Dry/wet Ratio Screen

The <u>dry/wet ratio</u> for each animal feed type is used to convert between dry and wet weight bases. All inputs are fixed to EPA-approved values.

# 4.5.3.8 Agriculture - Animal Feed - Translocation Factor Screen

The <u>translocation factor</u> for each animal feed type is the fraction of activity reaching the plant surface that is transferred to the edible part of the plant. All inputs are fixed to EPA-approved values.

### 4.5.4 Agriculture – Food Crop

The Food Crop screen has several sub-screens used to input the parameters necessary to describe agricultural practices for foods consumed directly by people. All inputs are fixed to EPA-approved values.

### 4.5.4.1 Agriculture - Food Crop - Biomass Screen

The <u>standing biomass</u> for each food crop is used to estimate soil losses from harvest removal. All inputs are fixed to EPA-approved values.

### 4.5.4.2 Agriculture - Food Crop - Growing Period Screen

The growing period for each food crop defines the deposition period for irrigation and atmospheric deposition to plants. All inputs are fixed to EPA-approved values.

# 4.5.4.3 Agriculture - Food Crop - Yield Screen

The <u>yield</u> of each food crop gives the total annual production of edible food crops per unit area of farmland. All inputs are fixed to EPA-approved values.

# 4.5.4.4 Agriculture - Food Crop - Dry/wet Ratio Screen

The <u>dry/wet ratio</u> for each food crop is used to convert between dry and wet weight bases. All inputs are fixed to EPA-approved values.

### 4.5.4.5 Agriculture - Food Crop - Translocation Factor Screen

The <u>translocation factor</u> for each food crop is the fraction of activity reaching the plant surface that is transferred to the edible part of the plant. All inputs are fixed to EPA-approved values.

### 4.5.5 Agriculture - Intake Delays Screen

The <u>intake delay</u> for each food crop, animal product, and aquatic food is the average time between harvest and consumption of the food by the exposed individual. The time period is used to account for radioactive decay prior to consumption. All inputs are fixed to EPA-approved values.

### 4.5.6 Pathways Screen

The selection of exposure pathways is controlled on this screen, Figure 4.20. Each pathway may be selected for inclusion in the analysis for the current exposure location. All inputs are fixed to EPA-approved values. The following pathways may be selected.

• Animal product (meat, poultry, milk, eggs) ingestion




Figure 4.20. Pathways selection screen

- Food crop (leafy vegetables, root vegetables, fruit, grains) ingestion
- Aquatic food (fish, mollusks, crustacea, aquatic plants) ingestion
- Drinking water ingestion
- Inadvertent shower water ingestion
- Inadvertent swimming water ingestion
- Inadvertent soil ingestion
- Air inhalation from atmospheric transport or resuspension outdoors
- Indoor inhalation of contaminants released from domestic water during showering and other uses, and infiltration from outdoors
- Inhalation of suspended soil from prior air or irrigation deposition
- External exposure from waterborne activity while swimming
- External exposure from waterborne activity while boating
- External exposure from sediment activity while on shoreline
- External exposure from soil activity
- External exposure to airborne activity from atmospheric transport

The external exposure to air may be evaluated using the finite plume model or the semi-infinite plume model. When the finite plume model is checked, the external dose values are read directly from the atmospheric transport file (ATO) and no calculations are performed for this pathway in the GENII chronic exposure module. Otherwise, a semi-infinite plume is assumed and the dose is to be based on the air concentration.

# 4.6 Using the GENII Receptor Intake Module

This user interface allows the user to specify the number of age groups to be considered, and parameters necessary to estimate the intake or exposure to radionuclides. The single screen for this user interface (Figure 4.21) has three divisions: 1) number of age groups (upper left), 2) age group and exposure pathway selection (lower left), and 3) parameter value entry for the selected age group and exposure pathway (right). Only the number of age groups may accessed by the user of GENII V2 NESHAPS; this should be set to 1 to initiate calculations.

The various GENII or other FRAMES-compatible exposure modules may be used to supply information to the GENII receptor intake model. The two parameters in the **General Info** model selection window (accessed by RIGHT clicking on the exposure icon), Easting Coordinate and the Northing Coordinate for the GENII exposure model (see Figure 3.3), have *no impact* on the calculation – all locations transmitted by the EPF file are processed.

The **File** menu item allows input data to be saved, or existing data to be reviewed and retained unchanged. Note that the defaults are NOT age-specific, and are provided only for reference adults. This is because GENII cannot know beforehand how many, and of what structure, the age groups selected will be.

Three kinds of **Help** are available: **General, Context-**specific, or allowed **Ranges** of input values. If no individual parameter has the focus of the mouse cursor, selection of Help will bring up the general help, which describes the Near Field model inputs in general terms. If a parameter has the focus, the context specific help will describe the use of the particular parameter.

#### 4.6.1 Initial Entries

Some initial selections must be made to define the nature of the analysis desired before any of the other parameters will become available.




Figure 4.21. GENII Intake Module Screen

# 4.6.1.1 Number of Age Groups

The <u>number of age groups</u> is set to the number of age groups to be evaluated in the current intake assessment. Most parameters to be provided are a function of age. A maximum of 6 groups can be defined.

### 4.6.1.2 Age Group and Exposure Pathway Selection

The <u>age group selection</u> pull-down box is used to identify the age group associated with input parameters to be entered. Values for all parameters should be entered for all of the number of age groups defined.

The <u>age group lower bound</u> is the youngest age of individuals in the currently selected age group. The minimum value for this parameter is 0 years (birth).

The <u>age group upper bound</u> is the oldest age of individuals in the receptor population group for the current intake scenario. There is a practical upper bound of 100 years; the value must be greater than the lower bound selected.

The <u>exposure pathway selection</u> pull-down list allows the user to select the exposure pathway for which parameters are to be entered. A specific pathway is selected by clicking on the desired pathway, or by scrolling up or down using the arrow keys on the keyboard. The parameters are entered in the input area on the right side of the screen.

The right side of the screen is used for <u>parameter value entry</u>. The parameters displayed for entry correspond to the exposure pathway and age group selected. For the two swimming pathways (external and ingestion) all parameters are displayed when either of the pathways is selected. Changing them in one place changes them in the other.

# 4.6.2 Pathway Parameters

The parameters for each exposure pathway are described below in the order in which the pathways appear in the exposure pathway pull-down list.

# 4.6.2.1 External Exposure to Air

Parameters for external exposure to air define the time the individual is exposed to contaminated air during a day and the year.

The <u>daily plume immersion exposure time</u> is the average number of hours in a day that the individual is exposed during a year.

The <u>yearly plume immersion exposure time</u> is the number of days in a year that the individual is exposed to the contaminated airborne plume.

#### 4.6.2.2 External Ground Exposure

Parameters for external ground exposure allow definition of the time the individual is exposed to ground during a year, and shielding factors and time fractions for indoor and outdoor exposures.

The <u>indoor shielding factor</u> is the fractional reduction applied to the external dose rate factor for ground exposure for the time the individual is indoors.

The <u>outdoor shielding factor</u> is the fractional reduction applied to the external dose rate factor for ground exposure for the time the individual is outdoors.

The <u>daily external ground exposure time</u> is the total time (per day) that an individual is exposed to contaminated ground. This is an average value over the exposure duration.

The <u>yearly external ground exposure time</u> is the number of days in a year that the individual is exposed to contaminated ground.

The <u>fraction of time spent indoors</u> is the average time fraction during a typical day that the individual spends indoors.

The <u>fraction of time spent outdoors</u> is the average time fraction during a typical day that the individual spends outdoors.

# 4.6.2.3 External Exposure While Swimming

Parameters for swimming include the frequency of swimming, the duration of each swimming event, and the number of days in a year that the individual swims. Note that this set of pathways is not used in GENII V2 NESHAPS. These three parameter values are also used for the water ingestion while swimming pathway. If one of the parameters is changed during entry of values for the other pathway, the value for this pathway will also be changed.

The <u>frequency of swimming event</u> is the number of times the individual swims per day on the days in which swimming occurs.

The <u>duration of swimming event</u> is the time the individual spends swimming during each swimming event.

The <u>swimming days</u> is the number of days in a year that swimming occurs. On each of these days it is assumed that the individual swim the number of times specified by the frequency of swimming event and for the duration of swimming event for each of these event.

# 4.6.2.4 External Exposure While Boating

The <u>shielding factor</u> for boating is the reduction factor to be applied to the external dose rate while boating because of shielding by the boat. This is in addition to the geometry factor of 0.5.

The <u>frequency of boating event</u> is the number of times a day (during the days in which boating occurs) that the individual is involved in a boating event.

The <u>duration of boating event</u> is the length of time the individual is boating during the typical boating event.

The <u>boating days</u> are the number of days in a year that the individual is involved in boating. During each of these days, the individual is assumed to be involved in the number of events given by the frequency of boating events with each event lasting for the duration of boating events hours.

### 4.6.2.5 External Exposure to Shoreline

The <u>frequency of shoreline</u> use is the number of times a day the individual uses the shoreline.

The <u>duration of shoreline event</u> is the average time the individual spends on the shoreline during one visit to the shoreline.

The <u>shoreline days</u> are the number of days in a year during which the individual visits the shoreline exposure location.

The <u>shore width factor</u> is a factor for reduction of the external dose rate factor for exposure to the shoreline. The external dose rate factors are based on exposure to an infinite flat plane of contamination. Because most shorelines do not represent an infinite plane, a reduction is allowed to address this difference in geometry.

### 4.6.2.6 Food Crop Ingestion

This screen allows input of consumption rates and periods for each of the four food crops pathways (leafy vegetables, root vegetables, fruit, and grain). The root crops include all vegetable crops not considered to be leafy vegetables. The grain crops represent breads and cereals.

The <u>food crop consumption rate</u> is the average amount of food crop consumed in a day for those days in which the food crop is eaten by the exposed individual.

The <u>food crop consumption period</u> is the number of days in a year that the food crop is consumed at the average rate.

### 4.6.2.7 Animal Product Ingestion

This screen allows input of consumption rates and periods for each of the four animal product food pathways (meat, poultry meat, milk, and eggs).

The <u>animal product consumption rate</u> is the average amount of animal product consumed in a day for those days in which the animal product is eaten by the exposed individual.

The <u>animal product consumption period</u> is the number of days in a year that the animal product is consumed at the average rate.

# 4.6.2.8 Aquatic Food Ingestion

This screen allows input of consumption rates and periods for each of the four aquatic food product pathways (fish, mollusks, crustacea, and aquatic plants).

The <u>aquatic food product consumption rate</u> is the average amount of aquatic food product consumed in a day for those days in which the aquatic food product is eaten by the exposed individual.

The <u>aquatic food product consumption period</u> is the number of days in a year that the aquatic food product is consumed at the average rate.

### 4.6.2.9 Drinking Water Ingestion

The <u>drinking water ingestion rate</u> is the average daily consumption rate of water on those days that the contaminated water is consumed by the exposed individual.

The <u>drinking water ingestion period</u> is the number of days in a year that water is consumed at the average rate.

# 4.6.2.10 Water Ingestion While Swimming

The exposure parameters for this pathway include the three parameters for the external exposure while swimming pathway plus the ingestion rate of water while swimming. The three parameters common to all swimming pathways are the frequency of swimming events, the duration of swimming event, and the swimming days.

The <u>ingestion rate of water while swimming</u> is the amount of water inadvently swallowed by the exposed individual during an hour of swimming.

# 4.6.2.11 Water Ingestion While Showering

The <u>frequency of showering event</u> is the number of times a day (during the days in which showering occurs) that the individual is showers.

The <u>duration of showering event</u> is the length of time the individual is showers during one shower.

The <u>showering days</u> is the number of days in a year that the individual showers. During each of these days, the individual is assumed to be involved in the number of events given by the frequency of showering events.

The <u>ingestion rate of water while showering</u> is the rate of inadvertent water intake by the exposed individual during each hour of showering.

### 4.6.2.12 Inadvertent Soil Ingestion

The <u>soil contact days</u> is the number of days in a year that the exposed individual contacts soil.

The <u>inadvertent soil ingestion rate</u> is the average daily rate of ingestion of soil on the days in which soil is contacted.

#### 4.6.2.13 Air Inhalation

The <u>air inhalation rate</u> is the volume of air inhaled outdoors per day on those days in which the individual is exposed to contaminated air.

The <u>air inhalation period</u> is the number of days in a year that the individual is exposed to contaminated outdoor air.

# 4.6.2.14 Resuspended Soil Inhalation

Suspension of contaminants previously deposited to soil represents a possible pathway for inhalation exposure. The parameters for this pathway include the inhalation rate, inhalation

period (days per year) and the fraction of a day that the individual is exposed to the resuspended soil.

The <u>resuspended soil inhalation rate</u> is the daily inhalation rate during the exposure period to the resuspended contamination. This may be the same as the inhalation rate of air from section 4.6.2.13 above – only the resuspended portion is considered here.

The <u>resuspended soil inhalation period</u> is the number of days in a year that the individual is exposed to resuspended contamination.

The <u>fraction of a day inhalation occurs</u> is the fraction of time in an average day that the individual is exposed to the resuspended contamination.

#### 4.6.2.15 Indoor Inhalation

The <u>indoor inhalation rate</u> is the daily inhalation rate during the exposure period to the indoor air contamination. Total hours distributed between indoor and outdoor inhalation should not total more than the number of hours in a day.

The <u>indoor inhalation period</u> is the number of days in a year that the individual is exposed to indoor air contamination.

The <u>fraction of a day inhalation occurs</u> is the fraction of time in an average day that the individual is exposed to the indoor contamination.

The <u>consider radon and progeny</u> check box is a flag to allow consideration of indoor radon progeny at a constant fraction of their decay equilibrium with the radon parent. If this box is checked, the inhalation calculations performed subsequently assume that the radon progeny are in a fixed activity ratio determined by the <u>radon equilibrium fraction</u> parameter.

# 4.7 Using the GENII Health Impacts Module

This user interface allows the selection of the type of dose and/or risk calculation to be performed, and provides the necessary additional parameters for each. GENII estimates radiation committed doses; acute (non-stochastic or deterministic) effects are not available. The GENII Health Impacts main screen is illustrated in Figure 4.22.

The GENII or other FRAMES-compatible receptor intake modules may be used to supply information to the GENII health impacts model. The two parameters in the **General Info** model selection window (accessed by RIGHT clicking on the exposure icon), Easting Coordinate and the Northing Coordinate for the GENII exposure model (see Figure 3.3), have *no impact* on the calculation – all locations transmitted by the RIF file are processed.

The **File** menu item allows input data to be saved, or existing data to be reviewed and retained unchanged. Nearly all non-control parameters have the ability to associate a reference. These references are intended to help document the selection of parameters and allow traceability of assumptions. To associate a reference with a data entry, place the focus (click the cursor in the box) on the parameter of interest, click on the **Reference** menu item, and select either Add or Select. A window will appear. If the **Add** option was selected, a blank entry will appear allowing text entry of a new reference. The entries are free formatted, so any short and long descriptor may be added. If the **Select** option is chosen, the available entries may be scrolled using the arrow buttons, or a specific entry searched for using the appropriate boxes. In this module, only one kind of **Help** is available, general help.




Figure 4.22. GENII Health Impacts Module Method Selection screen

#### 4.7.1 Method Selections

Three options are available. Check the appropriate box for the method desired.

Calculate dose and risk using ICRP-30/48 factors (Federal Guidance Reports 11 and 12): This option allows calculation of doses and/or risks using DOE-approved methods. The radiation dosimetry is based on ICRP Publication 30 (as updated), as provided in Federal Guidance Reports 11 and 12 or DOE compilations DOE/EH-0070 and DOE/EH-0071.

Selection of this option activates a "Method Parameters" tab, Figure 4.23. Options for calculating radiation dose, fatal cancers, or cancer incidence are available. Select one or more. The cancer calculations are performed using effective dose equivalents and a dose-to-risk conversion factor. Defaults are provided for each, and the allowable range (in the appropriate units) will scroll across the bottom of the screen.




Figure 4.23. Dose and Risk Method Parameters screen

Two additional parameters related to the estimation of external dose rates are also required. These should be set with the values used in preceding modules.

Calculate dose and/or risk using ICRP-60 and EPA risk factors: This option allows calculation of doses and/or risks using EPA-approved methods. The radiation dosimetry is based on ICRP Publication 60, as provided in Federal Guidance Reports 12 and 13.

Selection of this option activates a "Method Parameters" tab, similar to that for the ICRP-30 methods, Figure 4.23. Options for calculating radiation dose, fatal cancers, or cancer incidence are available. Select one or more. The cancer calculations are performed using the Federal Guidance Report 13 factors – the dose-to-risk conversions may be ignored, as indicated by the scrolling message. Two additional parameters related to the estimation of external dose rates are also required. These should be set with the values used in preceding modules.

Selection of this option also activates a "Constituent Parameters" tab Figure 4.24. All fields under this tab must be filled in. Each radionuclide in the case will be displayed using the advance arrows; for each select the appropriate values of inhalation class desired.

**Calculate risk using EPA slope factors:** This option allows calculation of radiation risk using EPA HEAST slope factors (a subset of information from Federal Guidance Report 13). No additional method or parameter information is required.




Figure 4.24. Constituent Parameters tab

### 4.8 Using Specialized Output Processors

FRAMES provides a number of viewers for examining intermediate and final output data. For each icon, these are invoked using a RIGHT click of the mouse cursor over the icon. This action will bring up a menu on which the lower two options are always View/Print User Input and View/Print Module Output. The View/Print User Input selection always results in a screen such as that illustrated in Figure 4.25. This screen allows the user to review the input parameters, as they are stored in the GID file. It also allows the user to review the summary description of the model being used. Either of the windows displayed may also be printed.

Selecting the View/Print Module Output option results in a further selection of two or more possible viewers. All FRAMES modules have the option for a Text View of the intermediate data file. Selection of this option opens a window identical to that shown in Figure 4.25 for the user input, but with the actual output file available for examination. This provides the most direct and immediate capability for examining the files. However, in most instances, the FRAMES intermediate files can be very large and relatively obtuse for novice users. For this reason, the alternative summary output viewers can often be more useful for determining the value of selected parameters.




Figure 4.25. Typical View/Print User Input screen

For the FRAMES User-Defined Source module, a graphical output viewer option is provided. This option will take the output file generated and convert it to a series of EXCEL® tables and figures for each constituent radionuclide, such as that shown in Figure 4.26. Complete functionality of this option requires that the user's computer have Microsoft Office programs installed. Separate entries will be made for each particle size and for gases for atmospheric releases. Similar tables and figures can be made for surface water release histories.

For the atmospheric transport module, a different graphical viewer is available. This is an adaptation of the commercially-available program Gnuplot. This viewer currently only works with outputs that are structured as a radial grid; therefore with GENII it works for the chronic plume model. Invoking this viewer first opens a screen shown in Figure 4.27, which provides Gnuplot with some minimal starting parameters for the graph. Running the viewer will generate a series of three-dimensional plots of air concentration and deposition for each radionuclide in the input inventory. An example of such a plot has been presented as Figure 4.7.

Figure 4.28 is an example of the graphical option for the exposure and receptor intake modules. This viewer allows the user to select location, time period, radionuclide, and environmental pathway and displays the intermediate parameter of interest, either concentration or quantity taken in.




Figure 4.26. Source term graphical viewer output




Figure 4.27. Atmospheric output viewer input screen




Figure 4.28. Graphical viewer screen for exposure and receptor intake modules

The View/Print Model Output option for the Health Impacts module provides a large number of specialized viewers. Some are similar to that shown in Figure 4.28, and others are more specialized. The user is encouraged to experiment with these viewers to find one that is most useful for his or her purpose. One output formatter has been specifically written for GENII output – the **NESHAPS Report Generator for GENII**. This viewer is intended for use with problems involving chronic atmospheric releases. Invoking this viewer opens an input screen shown in Figure 4.29. The input screen may be used to structure the output file that is generated to provide selected kinds of information. The FRAMES structure is such that doses and risks to individuals of varying location, age, diet, and behavior may all be calculated in a single run. This utility will summarize the results for all age groups and locations by total dose and risk, dose and risk by exposure pathway, and dose and risk by radionuclide. If the user has a file structured in a way that matches the atmospheric dispersion grid used and the population structure defined, it may be accessed at this time to provide population summaries of the same nature. If the population file is not available, the code simply provides individual summaries. The user is prompted to put in a population file on the Population File Name screen. The NESHAPS summary may also include the atmospheric transport intermediate results from the FRAMES ATO file if desired. Depending on the number of radionuclides, the number of nodes on the atmospheric grid, the number of age groups, and the amount of physical memory installed on the user's computer, the elapsed time for the summarization step can extend several seconds. The code occasionally prints status information before relinquishing control to a standard FRAMES text viewer.




Figure 4.28. GENII NESHAPS Viewer input screen

The GENII V2 NESHAPS Report Generator prepares an output file that is given the name of the FRAMES GID file (the current case name) with the extension .EPA. This file may be viewed or printed from any word processor or text viewer. A sample output file is provided with the GENII distribution files. It will typically look like the example shown in Figure 4.29. Data are summarized for each time period, for each grid point, and for each age group. The maximally exposed individual location is indicated.




Figure 4.29. Example of a portion of the GENII NESHAPS summary output file.

# 4.9 Additional Specialized FRAMES Input Modules

In addition to the FRAMES User-Defined Source Modules (discussed in Section 4.2), and the standard GENII components, there are several additional FRAMES-provided utility programs that allow the user to bypass portions of the modeling process when concentrations of contaminants are known in the environment. These utilities allow the user to input concentrations in air, surface water, groundwater, soil, and plant and/or animal products.

Brief descriptions of these input options are provided below. These modules do not compute the ingrowth of progeny because the user is assumed to know everything about the source, including progeny emission. Therefore, these modules assume that the progeny emissions are input along with the parent emissions.

**FRAMES ATO Chronic Air Module:** This module is used if the concentrations, deposition rates and/or external dose in the air are known. The radionuclide concentrations, deposition rates, external doses are entered directly through the interface.

**FRAMES EPF Exposure Pathways Concentration Module:** This module is used if the concentrations in components of various human exposure pathways such as plant products, animal products, or aquatic foods are known. The radionuclide concentrations are entered directly through the interface.

**FRAMES RIF Receptor Intakes Module:** This module is used if the intakes of radionuclides by individual humans are known for the different exposure pathways. The radionuclide intake rates are entered directly through the interface.

The input format of each of these utilities is similar. A portion of that for the User-Defined Exposure Pathways Module is shown in Figure 4.30. The utility program will already know the radionuclides selected from the Contaminant Database (Section 4.1). Highlight each item in the "directory structure" in turn, and the necessary inputs will be shown. For example, for the EPF Exposure Pathways Concentration module, the user picks the appropriate contaminating medium (air, soil, water, etc.) and then highlights the desired pathways. Then, by clicking on each pathway, screens similar to that in Figure 4.31 are opened, allowing the input of the known input concentration values.





Figure 4.30. Pathway input screen for FRAMES User-Defined Exposure Pathway Module



**Figure 4.32**. Concentration input screen for FRAMES User-Defined Exposure Pathway Module

#### 5. EXAMPLE PROBLEM

As an example of the use of GENII V2 NESHAPS, the sample problem of Chaki and Parks (2000) for the CAP-88 PC code is replicated. This sample demonstrates the use of the GENII V.2 chronic plume model and its ancillary joint frequency adaptation utility.

The sample of Chaki and Parks (2000) is for an example site in Ohio, using the STAR-formatted joint frequency file for Erie, Pennsylvania. This site has 6 co-located emission points of varying characteristics. One of the 6 emission points has a much smaller release than the others, so because GENII V2 NESHAPS only handles up to 5 release points, this one is combined with one of the others in this example (Chaki and Parks source 4 is combined with their source 5). The source information for the example is summarized in Table 5.1. All radionuclides are assumed to be 1 micron AMAD particles, inhalation Class Y. The ambient temperature is assumed to average 10 degrees celsius. No nearby buildings contribute to building wake effects.

Other parameters of importance to the example are described in the following sections to illustrate how they are entered into the GENII V.2 screens.

The basic conceptual model for this case is illustrated in Figure 5.1. Five sources are feeding the GENII chronic, annual average Gaussian plume atmospheric transport model. (This model is preferred because the available data for this location exist in the form of a STAR file, not hourly data.) The resulting concentrations and deposition rates of the released radionuclides are used in the GENII chronic exposure module to estimate accumulation in the soil, farm products, and other media to which people could be exposed. Individual exposures to these contaminated media are modeled with the GENII receptor intake module. The GENII health impacts module is used to estimate the radiation doses and risks to the people living around the release point. Multiple uses of this last module will be demonstrated.

Input of the source data is illustrated in Figure 5.2 for Source 1. It can be seen from this figure that the data in Table 1 are entered in the appropriate locations. One-micron particulates have been selected using the **Flux Types** button. The data for sources 2 through 4 are entered in similar fashion in the other icons.

	Source 1	Source 2	Source 3	Source 4	Source 5
Area (m <sup>2</sup> )	0.13	0.17	0.26	0.05	0.13
Height (m)	15.24	15.24	15.24	7.62	10.0
Exit velocity (m/s)	13.5	9.25	19.54	7.94	15.04
Release (Ci/year)					
U-234	2.4E-4	3.2E-4	3.2E-9	9.6E-13	2.7E-8
U-325	1.7E-6	2.3E-6	8.0E-7	5.5E-6	3.4E-5
U-236	0	0	0	0	1.8E-6
U-238	2.4E-4	3.2E-4	4.0E-4	7.6E-4	3.6E-3

**Table 5.1.** Sample Problem Release Data Summary




Figure 5.1. The GENII V.2 Conceptual Site Model for the Example Problem




Figure 5.2. Entry of the source term data for Source 1

Figure 5.3 shows the definition of the radial grid used to match the Chaki and Parks (2000) distances and directions. The Chaki and Parks example uses 12 distances, only 10 are available in GENII V.2 so the most important 10 close ones are selected. On the **Model Parameters** tab, the dispersion coefficients for the EPA ISC model are selected as being the most compatible with the CAP-88 capabilities. No changes are made on the **Default Parameters** tab.




Figure 5.3. Defining the radial atmospheric transport grid

A Stability Array data set is available for Erie, Pennsylvania from the GENII library. The data in this file, which is called ERI0610.STR, are shown in Table 5.2. This file contains data for stability classes A-F, 6 standard wind speed groups (the 6 columns), for 16 directions. This data is converted to quasi-hourly information starting with the **Use Joint Frequency Data File** button on the **Meteorological Files** tab.

Table 5.2. Joint frequency of occurrence of meteorological conditions for Erie, PA

N	Α	0.00001	0.00017	0	0	0	0
NNE	Α	0	0	0	0	0	0
NE	Α	0 (	0.00003	0	0	0	0
ENE	Α	0	0	0	0	0	0
E	Α	0	0	0	0	0	0
ESE	Α	0	0	0	0	0	0
SE	Α	0	0	0	0	0	0
SSE	Α	0	0	0	0	0	0
S	Α	0	0	0	0	0	0
SSW	Α	0 (	0.00003	0	0	0	0

SW	Α	0	0	0	0	0	0
WSW	Α	0	0	0	0	0	0
W	Α	0	0.00003	0	0	0	0
WNW	Α	0.00001	0.00014	0	0	0	0
NW	Α	0	0.00007	0	0	0	0
NNW	Α	0	0.00003	0	0	0	0
N	В	0.00022	0.00192	0.00349	0	0	0
NNE	В	0.00002	0.00051	0.00048	0	0	0
NE	В	0.00008	0.00034	0.00024	0	0	0
ENE	В	0.00005	0.00024	0.0001	0	0	0
E	В	0.00011	0.00021	0.00021	0	0	0
ESE	В	0.00015	0.00017	0.00007	0	0	0
SE	В	0.00019	0.00031	0.00003	0	0	0
SSE	В	0.00005	0.00024	0.0001	0	0	0
S	В	0.00048	0.00045	0.00055	0	0	0
SSW	В	0.00026	0.00021	0.00031	0	0	0
SW	В	0.00005	0.00038	0.00027	0	0	0
WSW	В	0.00002	0.00048	0.00041	0	0	0
W	В	0.00013	0.00048	0.00147	0	0	0
WNW	В	0.00016	0.00137	0.00202	0	0	0
NW	В	0.00014	0.00168	0.00301	0	0	0
NNW	В	0.00016	0.00226	0.00356	0	0	0
N	С	0.00011	0.00137	0.00781	0.00134	0	0
NNE	С	0.00005	0.00072	0.00305	0.00113	0.00007	0
NE	С	0.00009	0.00075	0.00315	0.00137	0.00024	0
ENE	С	0.00016	0.00065	0.00171	0.0001	0	0
E	С	0.00009	0.00065	0.00089	0.00003	0	0
ESE	С	0.00001	0.00034	0.00075	0.00003	0	0
SE	С	0.00005	0.00051	0.00093	0.00014	0	0
SSE	С	0.00005	0.00062	0.00161	0.0001	0	0
S	С	0.00037	0.00322	0.00675	0.00082	0.00014	0.00007
SSW	С	0.00007	0.0011	0.00315	0.00051	0.00017	0.00003
SW	С	0.00005	0.00065	0.00243	0.00072	0.00014	0
WSW	С	0.00005	0.00051	0.00377	0.00069	0.00014	0.00003
W	С	0.00005	0.00055	0.00839	0.00353	0.00062	0
WNW	С	0.00009	0.00075	0.0075	0.00219	0.00014	0
NW	С	0.00008	0.00182	0.00497	0.00048	0	0
NNW	С	0.00007	0.00116	0.00541	0.00038	0	0
N	D	0.00052	0.005	0.01288	0.01072	0.00175	0.00014
NNE	D	0.00033	0.0026	0.00737	0.00911	0.0013	0.00017
NE	D	0.00059	0.00356	0.01172	0.01552	0.00339	0.00062
ENE	D	0.00039	0.00387	0.01199	0.00939	0.00185	0.00027
E	D	0.00076	0.00404	0.00675	0.00171	0.00007	0
ESE	D	0.00054	0.00243	0.00322	0.0012	0.00007	0
SE	D	0.00046	0.00216	0.00428	0.00408	0.00171	0.00086
SSE	D	0.00061	0.00233	0.01055	0.01823	0.01052	0 00349
JUL	_	0.00001	0.00200		0.0.0_0	0.0.002	0.000 10

SSW	D	0.00057	0.00531	0.01778	0.02998	0.01247	0.00192
SW	D	0.00061	0.00545	0.01425	0.02398	0.00747	0.0011
WSW	D	0.00037	0.00408	0.01692	0.02402	0.00915	0.00182
W	D	0.00046	0.00459	0.02011	0.03936	0.01559	0.00288
WNW	D	0.00041	0.00349	0.01209	0.02323	0.00894	0.00151
NW	D	0.00035	0.00295	0.00942	0.01206	0.00356	0.00038
NNW	D	0.0004	0.00332	0.00863	0.0097	0.00236	0.00027
N	Е	0	0.00127	0.00168	0	0	0
NNE	Е	0	0.00089	0.00116	0	0	0
NE	Е	0	0.00223	0.0023	0	0	0
ENE	Ε	0	0.00274	0.00291	0	0	0
E	Ε	0	0.00356	0.00158	0	0	0
ESE	Е	0	0.00281	0.00072	0	0	0
SE	Ε	0	0.00212	0.00099	0	0	0
SSE	Е	0	0.00278	0.00428	0	0	0
S	Е	0	0.01199	0.02052	0	0	0
SSW	Е	0	0.00377	0.0062	0	0	0
SW	Е	0	0.00298	0.00401	0	0	0
WSW	Е	0	0.00247	0.00343	0	0	0
W	Е	0	0.0014	0.00301	0	0	0
WNW	Е	0	0.00089	0.00096	0	0	0
NW	Е	0	0.00116	0.00089	0	0	0
NNW	Ε	0	0.00096	0.00161	0	0	0
N	F	0.00062	0.00123	0	0	0	0
NNE	F	0.00033	0.00106	0	0	0	0
NE	F	0.00037	0.0014	0	0	0	0
ENE	F	0.00075	0.00257	0	0	0	0
E	F	0.00186	0.00418	0	0	0	0
ESE	F	0.00188	0.00288	0	0	0	0
SE	F	0.00164	0.00278	0	0	0	0
SSE	F	0.00209	0.00418	0	0	0	0
S	F	0.00804	0.02741	0	0	0	0
SSW	F	0.0017	0.00815	0	0	0	0
SW	F	0.00099	0.00271	0	0	0	0
WSW	F	0.00082	0.0025	0	0	0	0
W	F	0.00036	0.00127	0	0	0	0
WNW	F		0.00106	0	0	0	0
NW	F	0.00041	0.00069	0	0	0	0
NNW	F	0.00037	0.00099	0	0	0	0

The data processor screen appears as shown in Figure 5.4. This screen indicates that the information put into it will be retained in a file named JFDPROC.INP. The data are coming from the file ERI0610.STR, and the quasi-hourly information generated will be stored in the meteorological data file eriePA.met. Basic descriptive data for the Erie site are entered on the **Station Information** tab at the bottom of the window.




Figure 5.4. Joint frequency data processor window for example problem

The supplementary information for the JFD file is entered on the Joint Frequency Info tab illustrated in Figure 5.5. The wind speeds entered are the standard midpoints of the normal STAR ranges:

Wind Speed Range (knots)	Range Mid-point (m/s)
1 - 3	0.9
4 – 6	2.6
7 - 10	4.7
11 - 16	7.2
17 - 21	9.8
>21	12.7

The monthly temperature extremes may be obtained from climatic records. (Those entered here are user-defined approximations.) The ability to handle precipitation as a series of discrete events is one of the strengths of GENII V.2. Joint Frequency of wind data do not include information on precipitation, thus it is necessary to approximate the inputs. This is done on the **Precipitation** tab, using a surrogate location. Because it is nearby and on the lake, Buffalo, NY has been selected for this example problem. This is input using the drop-down box on the **Precipitation** tab, as illustrated in Figure 5.6. A large number of representative cities are included in the GENII V.2 database.




Figure 5.5. Joint Frequency Info tab for example problem




Figure 5.6. Precipitation tab for the example problem

The joint frequency data and associated information are converted to quasi-hourly data by using the Process Joint Frequency Distribution button. When the processing is completed, the eriePA.met file is entered on the Meteorological Files tab.

For the sample problem, all 5 sources have simple plume rise selected with the check boxes on the **Source Information** tab as well.

The chronic atmospheric transport user interface is closed, saving the data, and the model is run, producing a table of annual average concentrations in air of each radionuclide, and its decay progeny.

The CAP-88 code is used to estimate a conservative upper bound on doses from continuous releases. In order to do this, an interesting modeling assumption is made: The release continues for 100 years, allowing contamination to accumulate in the environment. The dose to an exposed individual is estimated for the 100<sup>th</sup> year of the release. (This is the parameter TSUBB in the CAP-88 manual.) In order to simulate an equivalent condition with GENII, a continuous air deposition is indicated in the **Air deposition time prior to exposure** parameter. In order to note the source for this parameter, the reference indicator has been updated; reference 1 for this problem is now Chaki and Parks (2000), as illustrated in Figure 5.8.

GENII V.2 has a greater variety of exposure pathways available than CAP-88. Those most closely resembling the CAP-88 pathways are selected for the example problem as illustrated in Figure 5.9. One other key parameter changed in GENII is the surface soil areal density on the **Soil/Surface Soil** tab; it is set to 215 kg/m². Also, on the **Agriculture/General** tab, the crop weathering time is set to 10 days. No other GENII Chronic Exposure defaults are revised for this example.




Figure 5.7. GENII Chronic Exposure Module Control screen, illustrating time line




Figure 5.8. Input screen for references





Figure 5.9. Exposure pathways selected for the example problem

The GENII Receptor Intakes module is next accessed. One age group – adults – is used to match the CAP-88 limitation. The parameters adjusted to match the CAP-88 values in this module include the consumption rates of leafy vegetables, other vegetables, meat, and milk. The air inhalation rate is reduced to match. The other pathways, because they were not turned on in the GENII Chronic Exposure module, have no effect. The values used for each pathway are:

<u>Parameter</u>	<u>CAP-88</u>	GENII V.2
Leafy Vegetable Intake	18 kg/yr	0.049  kg/d
Other Vegetable Intake	176 kg/yr	0.482  kg/d
Meat Intake	85 kg/yr	0.233  kg/d
Milk Intake	112 L/yr	0.307  L/d
Breathing Rate	$9.167E5 \text{ cm}^3/\text{hr}$	$22 \text{ m}^3/\text{day}$

Finally, the GENII Health Impacts module is used to calculate dose and risk to the individuals around the example source point. To match CAP-88, the ICRP-30 (Federal Guidance Reports 11 and 12) conversion factors are used. The GENII NESHAPS summary generator is used to create an output file to compare with the CAP-88 results of Chaki and Parks (2000). A population distribution file is needed to complete the comparison; a file with equivalent information to that input to CAP-88 is illustrated in Table 5.3. A GENII population file must match the format of the atmospheric model output generated. In this case, the atmospheric model created a grid of 16 directions and 10 distances. A block of population data is needed for each age group. Since only one age group was used, a population file of dimensions 10 by 16 is sufficient. The major difference between a GENII population file and an equivalent CAP-88 file is that GENII directions begin at NNE and continue clockwise around the compass while CAP-88 files begin at N and go counter-clockwise. Thus, a CAP-88 population file must be inverted before being used with GENII.



**Figure 5.10.** Example problem food crop ingestion input. Only Leaf vegetables and Root vegetables (equivalent to CAP-88 Produce) are used

**Table 5.3.** Population file for example calculation

0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0
1	0	0	55	0	0	14641	6332	5986	13324
0	0	0	780	89	793	265	1693	5397	1338
0	0	0	851	0	125	3161	827	3252	3712
0	0	0	0	0	974	1388	2021	3148	5123
0	0	101	0	0	0	984	1792	3659	3759
0	0	0	0	2002	534	8224	2252	2388	5752
0	0	0	4350	4630	3024	3059	3396	3128	6847
0	0	0	0	2435	1688	3376	3448	7591	6999
0	0	421	810	293	1108	779	15354	8786	48943
0	0	0	2435	3302	183	380	0	0	0
0	0	0	2218	0	0	0	0	0	0
0	0	1987	0	0	0	0	0	0	0
0	6	0	113	0	0	0	0	0	0
0	0	0	1043	0	0	0	0	0	0

### Exhibit 5.1

#### **GENII VERSION 2**

NESHAPS SUMMARY REPORT FOR CASE: c:\frames\ash5a

THE HEALTH IMPACTS FILE FOR THIS CASE CONTAINS INFORMATION ON:

- 1 AGE GROUP(S)
- 4 RADIONUCLIDÉS (COUNTING DECAY PROGENY SEPARATELY IN CHAINS)
  - 1 ORGAN(S)/TISSUE(S) FOR RADIATION DOSE
  - 1 POTENTIÁL CANCER SITES, AND
  - 1 EXPOSURE PERIOD(S).

POPULATION DATA FROM FILE ashtapop.csv

TIME PERIOD NUMBER 1, CORRESPONDING TO TIME 99.0 YEARS

MAXIMUM POINT = 151

INDIVIDUAL AGE RANGE 0 TO 70 YEARS

MAXIMUM EXPOSED INDIVIDUAL LOCATION

ORGAN MAX. DOSE (Sv) TISSUE CANCER INCIDENCE CANCER FATALITIES total body 1.75E-05 all sites 1.05E-06 8.74E-07

TIME PERIOD NUMBER 1, CORRESPONDING TO TIME 99.0 YEARS INDIVIDUAL AGE RANGE 0 TO 70 YEARS

#### INDIVIDUAL EFFECTIVE DOSE BY DISTANCE AND DIRECTION (SV)

	310.0	810.0	1500.0	2500.0	3500.0	7500.0	15000.0	25000.0	35000.0	45000.0
22.5	8.93E-06	3.07E-06	1.21E-06	5.39E-07	3.54E-06	8.24E-08	2.30E-08	8.68E-09	4.56E-09	2.83E-09
45.0	7.09E-06	2.48E-06	9.81E-07	4.35E-07	2.71E-06	6.59E-08	1.83E-08	6.97E-09	3.70E-09	2.31E-09
67.5	7.40E-06	2.54E-06	9.93E-07	4.43E-07	2.82E-06	6.67E-08	1.85E-08	6.89E-09	3.61E-09	2.27E-09
90.0	1.06E-05	3.53E-06	1.38E-06	6.17E-07	4.57E-06	9.23E-08	2.57E-08	9.52E-09	4.97E-09	3.08E-09
112.5	6.42E-06	2.17E-06	8.58E-07	3.85E-07	2.70E-06	5.73E-08	1.60E-08	5.96E-09	3.11E-09	1.93E-09
135.0	3.93E-06	1.38E-06	5.53E-07	2.49E-07	1.38E-06	3.60E-08	1.00E-08	3.78E-09	2.01E-09	1.27E-09
157.5	3.50E-06	1.25E-06	5.04E-07	2.30E-07	1.10E-06	3.28E-08	9.15E-09	3.51E-09	1.87E-09	1.18E-09
180.0	4.55E-06	1.67E-06	6.75E-07	3.04E-07	1.21E-06	4.30E-08	1.19E-08	4.58E-09	2.47E-09	1.58E-09
202.5	2.95E-06	1.06E-06	4.19E-07	1.88E-07	9.74E-07	2.77E-08	7.70E-09	2.93E-09	1.56E-09	9.82E-10
225.0	4.91E-06	1.73E-06	6.87E-07	3.06E-07	1.71E-06	4.58E-08	1.28E-08	4.84E-09	2.57E-09	1.61E-09
247.5	4.04E-06	1.47E-06	5.89E-07	2.60E-07	1.07E-06	3.86E-08	1.07E-08	4.08E-09	2.18E-09	1.39E-09
270.0	2.28E-06	9.42E-07	3.85E-07	1.73E-07	2.65E-07	2.61E-08	7.62E-09	3.06E-09	1.66E-09	1.04E-09
292.5	1.32E-06	5.52E-07	2.29E-07	1.04E-07	1.74E-07	1.61E-08	4.81E-09	1.94E-09	1.04E-09	6.43E-10
315.0	1.96E-06	7.40E-07	3.00E-07	1.34E-07	5.38E-07	2.09E-08	6.05E-09	2.37E-09	1.26E-09	7.75E-10
337.5	5.83E-06	1.97E-06	7.80E-07	3.48E-07	2.36E-06	5.46E-08	1.55E-08	5.83E-09	3.01E-09	1.85E-09
360.0	1.75E-05	6.16E-06	2.46E-06	1.10E-06	6.45E-06	1.69E-07	4.74E-08	1.79E-08	9.41E-09	5.86E-09

Exhibits 5.1 and 5.2 are portions of the GENII NESHAPS output file that are comparable with the CAP-88 results presented in Chaki and Parks (2000). The CAP-88 determined location inhabited by an individual is 310 m ENE of the release point; at that point, CAP-88 determined the annual radiation dose to be 0.75 mrem, dominated by inhalation of U-238. For that same location, GENII V.2 indicates a dose of 0.74 mrem (7.40E-6 Sv in Exhibit 5.1), dominated by inhalation of U-238. The CAP-88 estimate of total population dose is 1.35 person-rem; the GENII V.2 estimate is 1.86 person-rem (1.86E-2 Person-Sv in Exhibit 5.2). The GENII population estimate is slightly higher, because the population for the 4500 meter distant ring in CAP-88 was compressed into the 3500 meter ring for GENII to make the population file match. A more exact correspondence of the population geometries would lead to an even better match in the doses.

#### Exhibit 5.2

TIME PERIOD NUMBER 1, CORRESPONDING TO TIME 99.0 YEARS
POPULATION AGE RANGE 0 70 YEARS
ORGAN DOSE (PERSON-SV) TISSUE CANCER INCIDENCE CANCER FATALITIES
total body 1.86E-02 all sites 1.12E-03 9.32E-04

TIME PERIOD NUMBER 1, CORRESPONDING TO TIME 99.0 YEARS POPULATION GROUP AGE RANGE 0 TO 70 YEARS

```
POPULATION EFFECTIVE DOSE BY DISTANCE AND DIRECTION (PERSON-SV)
                                  810.0
                                                      1500.0
                                                                           2500.0 3500.0
                                                                                                                  7500.0
                                                                                                                                       15000.0 25000.0 35000.0
                                                                                                                                                                                                 45000.0
               0.00E+00 \ 0.00E+00 
   45.0
               0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00
   67.5
               7.40E-06 0.00E+00 0.00E+00 2.43E-05 0.00E+00 0.00E+00 2.70E-04 4.37E-05 2.16E-05
                                                                                                                                                                                                3.02E-05
   90.0 0.00E+00 0.00E+00 0.00E+00 4.82E-04 4.07E-04 7.32E-05 6.81E-06 1.61E-05 2.68E-05
                                                                                                                                                                                                4.12E-06
 112.5 0.00E+00 0.00E+00 0.00E+00 3.28E-04 0.00E+00 7.16E-06 5.05E-05 4.93E-06 1.01E-05
                                                                                                                                                                                               7.17E-06
  135.0 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00 3.51E-05
                                                                                                                                       1.39E-05 7.65E-06 6.33E-06
                                                                                                                                                                                                6.49E-06
  157.5 0.00E+00 0.00E+00 5.09E-05 0.00E+00 0.00E+00 0.00E+00 9.01E-06 6.30E-06 6.84E-06
                                                                                                                                                                                                4.45E-06
 180.0 0.00E+00 0.00E+00 0.00E+00 0.00E+00 2.43E-03 2.30E-05
                                                                                                                                       9.80E-05 1.03E-05 5.90E-06
                                                                                                                                                                                                9.06E-06
 202.5 0.00E+00 0.00E+00 0.00E+00 8.19E-04 4.51E-03 8.36E-05 2.36E-05 9.96E-06 4.88E-06
                                                                                                                                                                                                6.73E-06
 225.0 0.00E+00 0.00E+00 0.00E+00 0.00E+00 4.16E-03 7.73E-05
                                                                                                                                       4.33E-05 1.67E-05 1.95E-05
                                                                                                                                                                                                 1.13E-05
 247.5 0.00E+00 0.00E+00 2.48E-04 2.11E-04 3.14E-04 4.27E-05
                                                                                                                                      8.30E-06 6.27E-05 1.92E-05
                                                                                                                                                                                                6.80E-05
 270.0 0.00E+00 0.00E+00 0.00E+00 4.20E-04 8.74E-04 4.78E-06
                                                                                                                                     2.89E-06 0.00E+00 0.00E+00 0.00E+00
 292.5 0.00E+00 0.00E+00 0.00E+00 2.30E-04 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00
                                                                          0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00
 315.0 0.00E+00 0.00E+00 5.95E-04
 337.5 0.00E+00 1.18E-05 0.00E+00 3.93E-05 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00
 360.0 0.00E+00 0.00E+00 0.00E+00 1.15E-03 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00 0.00E+00
```

An interesting comparison is the difference between the GENII V.2 dose and risk results calculated using the ICRP-30 methods with the same inputs used to calculate dose and risk results with the ICRP-60 (Federal Guidance Report 13) methods. This requires one additional type of input, illustrated in Figure 5.11. The lung inhalation clearance class (Fast, Medium, or Slow) must be selected for each radionuclide and all their progeny. The ICRP Class Y materials are represented by the newer ICRP "Slow" clearance class.

If the calculations are rerun, the equivalent doses and risks are estimated and tabulated using the GENII NESHAPS viewer. The results are tabulated as Exhibits 5.3 and 5.4. It can be seen that the results are approximately one-fourth as large as with the older dose conversion factors. This differenced is entirely due to changes in the dose conversion factors between the earlier and later ICRP and FGR 13 compilations.




Figure 5.11. Input of Lung inhalation class for FGR 13 methods

#### Exhibit 5.3

```
GENII VERSION 2
NESHAPS SUMMARY REPORT FOR CASE: c:\frames\ash5a
THE HEALTH IMPACTS FILE FOR THIS CASE CONTAINS INFORMATION ON:
            1 AGE GROUP(S)
            4 RADIONUCLIDES (COUNTING DECAY PROGENY SEPARATELY IN CHAINS)
           24 ORGAN(S)/TISSUE(S) FOR RADIATION DOSE
           15 POTENTIAL CANCER SITES, AND
            1 EXPOSURE PERIOD(S).
POPULATION DATA FROM FILE ashtapop.csv
TIME PERIOD NUMBER 1, CORRESPONDING TO TIME 99.0 YEARS
MAXIMUM POINT = 151
INDIVIDUAL AGE RANGE
                         0 TO
                                70 YEARS
MAXIMUM EXPOSED INDIVIDUAL LOCATION
ORGAN
             MAX. DOSE (Sv)
                               TISSUE
                                           CANCER INCIDENCE
                                                              CANCER FATALITIES
Adrenals
                1.00E-06
                                Esophagus
                                              3.96E-09
                                                                3.53E-09
Bld Wall
                1.05E-06
                                Stomach
                                              1.56E-08
                                                                1.38E-08
B Surface
                1.75E-05
                                Colon
                                              8.93E-08
                                                                5.32E-08
Brain
                1.02E-06
                                Liver
                                              8.29E-09
                                                                7.53E-09
Breasts
                1.19E-06
                                Lung
                                              3.47E-07
                                                                 3.29E-07
Esophagus
                9.75E-07
                                Bone
                                              3.80E-09
                                                                2.98E-09
St Wall
                1.07E-06
                                Skin
                                              1.06E-07
                                                                1.06E-07
SI Wall
                1.09E-06
                                Breast
                                              4.12E-08
                                                                2.09E-08
ULI Wall
                1.46E-06
                                Ovary
                                              6.78E-09
                                                                 4.83E-09
LLI Wall
                2.31E-06
                                Bladder
                                              1.76E-08
                                                                9.49E-09
Kidneys
                6.35E-06
                                Kidneys
                                              7.95E-09
                                                                6.29E-09
Liver
                2.68E-06
                                Thyroid
                                              1.20E-08
                                                                1.77E-09
Lungs
                3.33E-05
                                Leukemia
                                              1.97E-08
                                                                1.94E-08
Muscle
                1.16E-06
                               Residual
                                              7.35E-08
                                                                5.22E-08
Ovaries
                1.01E-06
                                Total
                                              7.52E-07
                                                                6.31E-07
Pancreas
                9.94E-07
R Marrow
                2.22E-06
Skin
                1.61E-04
Spleen
                1.05E-06
Testes
                1.18E-06
Thymus
                1.04E-06
Thyroid
                1.09E-06
Uterus
                1.01E-06
Effective
                7.03E-06
```

TIME PERIOD NUMBER  $\ 1$ , CORRESPONDING TO TIME 99.0 YEARS INDIVIDUAL AGE RANGE  $\ 0$  TO 70 YEARS

INDIVIDU	AL EFFECTI	VE DOSE BY	DISTANCE	AND DIRECT	ION (SV)					
	310.0	810.0	1500.0	2500.0	3500.0	7500.0	15000.0	25000.0	35000.0	45000.0
22.5	3.57E-06	1.23E-06	5.16E-07	2.45E-07	3.38E-06	4.10E-08	1.14E-08	3.98E-09	1.94E-09	1.14E-09
45.0	2.85E-06	9.97E-07	4.17E-07	1.97E-07	2.57E-06	3.25E-08	8.92E-09	3.12E-09	1.53E-09	9.04E-10
67.5	2.96E-06	1.02E-06	4.24E-07	2.03E-07	2.69E-06	3.37E-08	9.24E-09	3.20E-09	1.55E-09	9.16E-10
90.0	4.20E-06	1.42E-06	5.91E-07	2.89E-07	4.39E-06	4.74E-08	1.33E-08	4.60E-09	2.22E-09	1.29E-09
112.5	2.56E-06	8.74E-07	3.74E-07	1.81E-07	2.58E-06	2.89E-08	8.07E-09	2.81E-09	1.36E-09	7.94E-10
135.0	1.58E-06	5.55E-07	2.42E-07	1.18E-07	1.31E-06	1.78E-08	4.86E-09	1.69E-09	8.27E-10	4.92E-10
157.5	1.42E-06	5.01E-07	2.19E-07	1.09E-07	1.04E-06	1.59E-08	4.31E-09	1.51E-09	7.43E-10	4.46E-10
180.0	1.85E-06	6.67E-07	2.95E-07	1.43E-07	1.13E-06	2.06E-08	5.49E-09	1.91E-09	9.53E-10	5.79E-10
202.5	1.19E-06	4.23E-07	1.78E-07	8.64E-08	9.18E-07	1.35E-08	3.63E-09	1.26E-09	6.20E-10	3.71E-10
225.0	1.97E-06	6.95E-07	2.91E-07	1.39E-07	1.62E-06	2.24E-08	6.11E-09	2.12E-09	1.04E-09	6.18E-10
247.5	1.64E-06	5.87E-07	2.47E-07	1.16E-07	9.91E-07	1.85E-08	4.91E-09	1.71E-09	8.48E-10	5.13E-10
270.0	9.56E-07	3.72E-07	1.58E-07	7.37E-08	2.09E-07	1.11E-08	2.95E-09	1.08E-09	5.58E-10	3.43E-10
292.5	5.54E-07	2.17E-07	9.31E-08	4.36E-08	1.40E-07	6.60E-09	1.80E-09	6.62E-10	3.43E-10	2.08E-10
315.0	8.07E-07	2.94E-07	1.24E-07	5.86E-08	4.95E-07	9.44E-09	2.61E-09	9.44E-10	4.72E-10	2.81E-10
337.5	2.33E-06	7.93E-07	3.30E-07	1.57E-07	2.25E-06	2.70E-08	7.64E-09	2.70E-09	1.31E-09	7.59E-10
360.0	7.03E-06	2.46E-06	1.04E-06	4.93E-07	6.11E-06	8.18E-08	2.26E-08	7.91E-09	3.86E-09	2.28E-09

#### Exhibit 5.4

TIME PERIOD NUMBER  $\ 1$ , CORRESPONDING TO TIME 99.0 YEARS POPULATION GROUP AGE RANGE  $\ 0$  TO 70 YEARS

POPULATI	ON EFFECTI	VE DOSE BY	DISTANCE	AND DIRECT	ION (PERSO	N-SV)				
	310.0	810.0	1500.0	2500.0	3500.0	7500.0	15000.0	25000.0	35000.0	45000.0
22.5	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
45.0	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
67.5	2.96E-06	0.00E+00	0.00E+00	1.12E-05	0.00E+00	0.00E+00	1.35E-04	2.02E-05	9.30E-06	1.22E-05
90.0	0.00E+00	0.00E+00	0.00E+00	2.25E-04	3.91E-04	3.76E-05	3.51E-06	7.79E-06	1.20E-05	1.73E-06
112.5	0.00E+00	0.00E+00	0.00E+00	1.54E-04	0.00E+00	3.62E-06	2.55E-05	2.33E-06	4.41E-06	2.95E-06
135.0	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	1.74E-05	6.74E-06	3.41E-06	2.60E-06	2.52E-06
157.5	0.00E+00	0.00E+00	2.22E-05	0.00E+00	0.00E+00	0.00E+00	4.24E-06	2.70E-06	2.72E-06	1.68E-06
180.0	0.00E+00	0.00E+00	0.00E+00	0.00E+00	2.25E-03	1.10E-05	4.52E-05	4.31E-06	2.28E-06	3.33E-06
202.5	0.00E+00	0.00E+00	0.00E+00	3.76E-04	4.25E-03	4.07E-05	1.11E-05	4.28E-06	1.94E-06	2.54E-06
225.0	0.00E+00	0.00E+00	0.00E+00	0.00E+00	3.93E-03	3.78E-05	2.06E-05	7.32E-06	7.90E-06	4.32E-06
247.5	0.00E+00	0.00E+00	1.04E-04	9.43E-05	2.90E-04	2.05E-05	3.82E-06	2.62E-05	7.45E-06	2.51E-05
270.0	0.00E+00	0.00E+00	0.00E+00	1.80E-04	6.90E-04	2.04E-06	1.12E-06	0.00E+00	0.00E+00	0.00E+00
292.5	0.00E+00	0.00E+00	0.00E+00	9.66E-05	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
315.0	0.00E+00	0.00E+00	2.47E-04	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
337.5	0.00E+00	4.76E-06	0.00E+00	1.77E-05	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
360.0	0.00E+00	0.00E+00	0.00E+00	5.14E-04	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00

#### 6. TEMPLATE FILES

The GENII V.2 process for setting up a calculation can be tedious for the first-time user, although it rapidly becomes second nature. To help the beginning or infrequent user, as series of "template" files are included with the FRAMES/GENII distribution. These files are blank Conceptual Site Models for selected conditions.

A series of basic templates are provided are for routine atmospheric releases from a number of discrete release points. Thus, templates are provided for one, two, three, four, and five sources that continuously release materials into the air. Use of these templates is simple – just open them from the FRAMES File/Open menu and save them with a unique filename. These are named TEMPLTx.GID, where "x" is the number of atmospheric sources attached.

The template files included are listed in Table 6.1. The blank template for three sources, TEMPLT3.GID, is illustrated in Figure 6.1. The other templates are similar, but with more or fewer source modules attached. Additional templates may be acquired as needed from the GENII code author.

**Table 1.** GENII V.2 Template Files available

Template Name	Number of Source Modules
TEMPLT1.GID	1
TEMPLT2.GID	2
TEMPLT3.GID	3
TEMPLT4.GID	4
TEMPLT5.GID	5




Figure 6.1. Example GENII V.2 Blank Template

# APPENDIX A

Meteorological Processor Technical Basis

# APPENDIX A Meteorological Processor Technical Basis

The GENII chronic plume atmospheric model CHRONSRC accounts for the transport, diffusion, deposition, depletion, and decay of radionuclides while in the atmosphere. These calculations are based on the use of observed meteorological data. Observed meteorological data can occur in two general forms, hourly meteorological data where the meteorological information is recorded every hour, and a joint frequency distribution of wind speed, wind direction, and atmospheric stability, in which the hourly meteorological data has been summarized. Two programs, HRLYPROC and JJFDPROC, were developed that takes meteorological data stored in the hourly (HRLYPROC) or joint frequency distribution (JJFDPROC) and manipulates the data into a single format that can be read by the atmospheric models. The rest of this section discusses the input data required by the model, adjustments to the data, and calculation of meteorological variables that are not directly measured.

Section A.1 describes the input and output data that can be read by the two programs. The methods used to take the input data and created the output file are described for HRLYPROC and JJFDPROC are presented in Sections A.2 and A.3, respectively.

### A.1 Input/Output of Meteorological Data

This section describes the type of meteorological data that can used as input into the two meteorological processing programs, HRLYPROC and JJFDPROC. Also described is the format of the data that is read by the atmospheric models.

#### A.1.1 Hourly Meteorological Data Input

HRLYPROC can process three types of input data format: 1) CD-144 hourly surface observations, 2) hourly surface observations archived in the SAMSON format, and 3) precipitation data in the TD-3240 format. File structures are provided in Appendix A.

CD-144 - The CD-144 format refers to the "Card Deck 144 format" available from the National Climatic Data Center (NCDC). The file is composed of one record per hour, with all weather elements reported in an 80-column block. The format of these records is described in the Card Deck 144 WBAN Hourly Surface Observation Reference Manual (NOAA 1970), also available from NCDC. Data in this file includes the year, month, day, hour, cloud ceiling height, wind direction, wind speed, dry bulb temperature, and opaque cloud cover (see Appendix A). The following describes the variables found in the CD-144 format.

- Year, Month and Day identifies the year, month and day during which the meteorological data were observed.
- Hour identifies the hour of the meteorological data observation. Hour is based on the 24-hour clock and is recorded as 00 through 23. Times are Local Standard Time (LST).

- Ceiling Height the height of the cloud base above local terrain and is coded in hundreds of feet.
- Wind Direction the direction from which the wind is blowing, rounded to the nearest 10 degrees. Calm is given by 00.
- Wind Speed the wind speed measured in knots. Calm given by 00.
- Dry Bulb Temperature the ambient air temperature measured in whole degrees Fahrenheit.
- Cloud Cover There are two cloud cover parameters, opaque cloud cover and total cloud cover. Both parameters identify the amount of cloud covered measured in tens of percent, e.g. 0 = clear or less than 10%, 4 = 40 49%, "-" = Overcast of 100%. The model uses opaque cloud cover.

<u>SAMSON</u> - NCDC has made available solar and meteorological data form the first order stations in the United States for the period 1961 - 1990 on a set of three CD-ROMs, referred to as the SAMSON data. Additional data from 1991 through 1995 are also available. HRLYPROC can processes data retrieved from these CD-ROMs. It cannot access the data directly from the SAMSON CD-ROM, but the user can run the software provided with the data to retrieve the station, period of time and variables from the site and period to be modeled. The software is a DOS-based, interactive graphical interface.

Multiple years of data can be extracted for a single station and saved to the same file. However, HRLYPROC expects a maximum of one year of data in the data file. The reason for this restriction is explained below.

Retrieving the data from the CD-ROM is completely under the control of the user. When data are retrieved from the CD-ROMs, the user has the option to specify which variables to retrieve from a list of 21 variables for each station. At a minimum, the ceiling height, wind direction, wind speed, dry bulb temperature, opaque cloud cover, and present weather must be retrieved. In most cases, the hourly precipitation amount will also be retrieved, but it is not required to run HRLYPROC.

When the data are retrieved from the CD-ROM, two records are written at the beginning of the file that identify the station (first record) and the variables retrieved (second record). HRLYPROC uses both records to obtain information about the station (e.g., latitude and longitude) and to determine how to process the data that follows. There two records begin with the title character (~). If more than one year or data are retrieved from the CD-ROM, these two records will appear before each year in the file. Thus, an error will occur when the program reads these second set of header records.

The second header record is used by the model to determine if enough variables have been retrieved from the CD-ROM. If there are insufficient variables retrieved, an error will occur during the model execution. The user should return to the CD-ROM and retrieve the data once again to make sure all the necessary variables are retrieved.

Data records follow the header records in the retrieved file. There is one record for each hour of time period selected by the user. Unlike the CD-144 format which reports the hour on the 00 - 23 clock, the hour in the retrieved file is reported on the 01 - 24 hour clock.

Hour 24 of a day from the SAMSON data corresponds to hour 00 of the next day for the CD-144 data.

Data stored in the SAMSON format are in different units than found in the CD-144 data. The output using either format is the same, so the SAMSON and CD-144 data are converted to a specific set of units for each meteorological variable.

Center for Eexposure Assessment Modeling (CEAM) - Data from SAMSON have been extracted, combined with similar data, and made available by the EPA on the CEAM (Center for Exposure Assessment Modeling) website at <a href="http://www.epa.gov/ceampubl/tools/metdata/us\_met.htm">http://www.epa.gov/ceampubl/tools/metdata/us\_met.htm</a> The semi-processed data available on the CEAM site are in a formatted file that may be converted to GENII format using the same processor as SAMSON data. The file data format is provided in Appendix B. The CEAM data are a subset of the full SAMSON data in a fixed format.

<u>TD-3240</u> - Precipitation amounts are available from the NCDC in the TD-3240 format. A description of the TD-3240 data is found in NCDC (1990). These files can be used with hourly data in either the CD-144 format or the SAMSON format. In the case of the SAMSON file, hourly precipitation amount may already be included in the file. The data in the TD-3240 file would be used to supplement this data.

The TD-3240 data as received from NCDC are usually in a variable-length format. In this format, precipitation data for the entire day is stored in one record, and only for those hours during which precipitation was reported. A fixed-length format is also available in which one record contains the precipitation amount for one hour. As with the variable-length files, data are stored only for those days and hours for which precipitation was reported. HRLYPROC can process both types of TD-3240 data. Precipitation is reported in inches and hundredths of an inch in the TD-3240 format. These units are converted to millimeters for use in the atmospheric codes.

#### A.1.2 Joint Frequency Data Input

The JJFDPROC program processes joint frequency distributions of wind direction, wind speed and atmospheric stability (JFD). Two different formats of JFD are read by the JJFDPROC program, the format used by the EPA's Industrial Source Complex (ISC3) model (EPA 1995a) and the format used by the GENII (Napier et al. 1988).

The ISC3 format, also called the STAR summary, is described in EPA(1995a) and is summarized here. The JFD in the STAR format is normally constructed using 16 wind direction sectors, with the first 22.5 sector centered on winds from the North (increasing clockwise), six wind speed classes, and six stability classes. Wind speed classes are usually grouped as 0-3, 3-6, 6-10, 10-16, 16-21, and greater than 21 knots. Stability classes are based on the Pasquill stability categories (A [very unstable] - F [very stable]). Thus, the JFD file in the ISC3 format normally consists of 96 records. Each record is for a specific stability class and wind direction sector. Within each record is the frequency for the six wind speed classes for the given stability class and wind direction sector. In a quasi-programming sense, the file would be read as follows

```
Loop On I = 1, Number of Stability Classes (normally 6)

Loop On K = 1, Number of Wind Direction Sectors (normally 16)

READ (JFDFILE, '(6F10.0)') (FREQ(I,J,K), J = 1 to Wind Speed Classes)

End Loop On K

End Loop on I
```

where FREQ(I,J,K) = Frequency of stability class I, wind speed class J, and wind direction sector K

Thus, in a normal STAR summary the first 16 records are for sixteen direction sectors of stability class A (or 1), the next 16 are for stability class 2, and so forth.

The user provides the number of wind direction sectors, stability classes, and wind speed classes. So, as long as the JFD follows the above format (records containing the frequency by wind speed class; records ordered by wind direction sector then stability class), the number of stability classes, wind direction sectors, and wind speed classes can vary.

The GENII format is different from the ISC3 format. A description of the format is given in Napier et al. (1988), and is summarized here. Unlike the ISC3 format, the GENII format contains the percentages (frequency times 100) rather than frequencies of a given stability class, wind speed class, and wind direction sector. The JFD is usually constructed based on 16 wind direction sectors like the ISC3 format, but a variable number of wind speed class and atmospheric stability classes may be used. Table A.1 shows the format of the GENII JFD file.

The GENII format JFD file has the first four records containing information about the joint frequency data set, and the rest of the records are the joint frequency data set. In the same pseudo-programming language, the joint frequency data set would be read as:

```
LOOP ON I = 1 TO Number of Wind Speed Classes

LOOP ON J = 1 TO Number of Stability Classes

READ( JFDFILE, '(16f5.0)') (PREC(I,J,K), K = 1 to Number of Direction Sectors)

END LOOP ON J

END LOOP ON I
```

As with the ISC3 format, the user provides the number of wind speed classes, wind direction sectors, and atmospheric stability classes.

#### A.1.3 Output File

Both HRLYPROC and JJFDPROC create the same type of output file. The first record of the output file contains the surface roughness of the site (see Section A.2.3) and the height of the wind measurements. Following the first record are the records containing the meteorological data. Each record after the first contains the year, month, day and hour of the record. Following the date and time is the stability class, the flow vector (wind direction plus 180 degrees, the direction the wind is blowing towards), the wind speed, the dry bulb temperature, the mixing height, the precipitation type (e.g, none, light rain, light snow), the precipitation rate, and a weighting factor. The format of the file is given in Appendix A.

Table A.1. Format of Joint Frequency Distribution of Wind Speed, Wind Direction, and Atmospheric Stability for GENII.

Record Number	Field Number	Data Type	Field Size	Description
1	1	CHARACTER	80	Descriptive Title
2	1	CHARACTER	80	Secondary Title
3	1	INTEGER	5	Number of wind speed classes in file
3	2	INTEGER	5	Number of atmospheric stability classes
3	3	INTEGER	5	(Not Used always set to 1)
3	4	INTEGER	5	(Not Used always set to 1)
3	5	REAL	10	Height at which wind speed data was collected (m)
4	1 - 10	REAL	7	Average Wind Speed for each wind speed class (m/s)
Joint Freq	Juency Data	Set		
5 till end	1-16	REAL	5	Percent of time with wind from North, North-Northeast, Northeast, etc.) Each record has the 16 sectors. Data are grouped first by atmospheric stability class and then by wind speed group.
Last	1	EOF		The final JFD entry should be followed by a carriage return/line feed so that the EOF is on the final line.

For HRLYPROC, the meteorological information is based on the hourly observations found in the input files. The output of HRLYPROC will have one output record for each input record that is read in. The weighting factor for each record from HRLYPROC is always one.

For JJFDPROC, the meteorological information in the JFD file does not include date/time information. The JJFDPROC program instead creates pseudo-hourly data where there is one record for each wind speed class, wind direction sector, and stability class found in the JFD. In addition, the number of records will expanded based on variation of the temperature and precipitation type. How these variations expand the number of records is explained in Sections A.3.5 and A.3.6 for temperature and precipitation, respectively. The output records from JJFDPROC have a weighting factor that is the number of hours with

the meteorological data contained in the record. As there is no date/time information, the year, month, day, and hour for each record is given as -1.

Only the chronic plume model, CHRONSRC, can read an output file produced by the JJFDPROC program.

#### A.2 Meteorological Processing Methods for HRLYPROC

In this section the methods used to process the hourly meteorological data are discussed. These issues include simple data manipulation (e.g. converting data to the correct unit) and methods for computing mixing heights and atmospheric stability. The HRLYPROC program is based on the PC-RAMMET (EPA 1995b) meteorological processing code.

#### A.2.1 Time of Day

The HRLYPROC program uses the same convention as the PC-RAMMET code (EPA 1995b) and it is summarized here. When reading the CD-144 format, HRLYPROC skips the first hourly record of the data in the year because the 24-hour period for a year starts with the 1-hour period ending at 0100 LST (Local Standard Time) and the observations in the CD-144 files begin with the observations reported at 0000 LST. Sequential reading of the remaining data automatically make this adjustment for each succeeding day. Meteorological data for the last hour in the year are assumed equal to that for the next to the last hour because the data for a day always ends with hour 23. Data on the SAMSON CD-ROM begin with hour 1 and end with hour 24, eliminating the need to skip a record. However, the last hour of the year may contain missing data and are processed similarly to the CD-144 formatted data.

#### A.2.2 Atmospheric Stability

The HRLYPROC code recognizes the seven stability classes. The first six categories correspond to Pasquill's (1974) classification (A-F). The seventh category corresponds to the 'dashes' in the original classification by Pasquill and indicated a strong, ground-based nocturnal temperature inversion with non-definable wind flow.

The stability classes are calculated based on the method proposed by Turner (1964). The method involves basing the stability class on the cloud cover, ceiling height, solar elevation, and the wind speed. During the day, the cloud cover, ceiling height, and solar elevation give an estimation of the net radiation that is reaching the ground. The net radiation index is used with the wind speed to determine the stability class. At night, the cloud cover is used to determine the net radiation index. The following procedure is used to obtain the net radiation index.

- If the cloud cover is 10/10 and the ceiling is less than 7,000 feet, use net radiation index equal to 0 (whether day or night)
- For night-time (between sunset and sunrise):
  - a. If total cloud cover < 4/10, use net radiation index equal to -2
  - b. If total cloud cover > 4/10, use net radiation index equal to -1

- c. If precipitation occurring, use net radiation index equal to 0
- For daytime:
  - a. Determine the net radiation index as a function of solar elevation angle from Table A.2.
  - b. If total cloud cover > 5/10, modify the net radiation number as follows:
    - A. If ceiling height < 7,000 ft subtract 2 (except for 10/10)
    - B. If ceiling height  $\square$  7,000ft but  $\le$  16,000 ft, subtract 1
    - C. If total cloud cover equal 10/10, subtract 1. (i.e., if ceiling height is >7,000 and < 16,000 ft then would subtract 2; if > 16,000 ft, subtract 1. If >7,000 ft, already covered by 1).
    - D. If modified net radiation number is less than 1, set equal to 1.
    - E. If precipitation, subtract 2 from net radiation index calculated from Table A.1.
    - F. If precipitation and net radiation number is less than 0, set equal to 0.

Table A.2. Insolation Class as a Function of Solar Elevation Angle

Solar Elevation Angle (a)	Insolation Class	Net Radiation Index <sup>a</sup>
0 < a ≤ 15°	Weak	1
$15 \le a \le 35^{\circ}$	Slight	2
$35 < a \le 60^{\circ}$	Moderate	3
60° ≤ a	Strong	4

The stability class is determined using Table A.3 using the corresponding net radiation index and the wind speed.

Solar elevation angle (a) is calculated based on the day of the year, the hour of the day, and the latitude of the station where

$$\Psi = \sin^{-1}[\sin(\phi)\sin(\delta_s) + \cos(\phi)\cos(\delta_s)\cos(h_a)]$$

where  $\Psi$  = local solar elevation angle (deg)

 $\phi$  = latitude of the station (deg)

 $\delta_s$  = solar declination angle (angle of the sun above the equator)

 $h_a = local hour angle of the sun ( = 180 - (h/12)*180 where h is the local hour) (deg)$ 

The solar declination angle is calculated by

Table A.3. Stability Class as a Function of Wind Speed and Net Radiation Index

Wind	Net Ra	adiation Inde	X					
Speed (Knots)	4	3	2	1	0	-1	-2	
0-1	1	1	2	3	4	6	7	
2-3	1	2	2	3	4	6	7	
4-5	1	2	3	4	4	5	6	
6	2	2	3	4	4	5	6	
7	2	2	3	4	4	4	5	
8-9	2	3	3	4	4	4	5	
10	3	3	4	4	4	4	5	
11	3	3	4	4	4	4	4	
≥ 12	3	4	4	4	4	4	4	

$$\delta_{s} = -\phi_{r} \cos[\frac{\pi d}{d_{r}}]$$

where  $\phi_r$  is the latitude of the Tropic of Cancer (23.5), d is the Julian day, and  $d_r$  is the Julian day for the summer solstice (= 173).

The following assumptions are used if the various variables are missing.

- If the wind speed is missing, the stability class is missing.
- If the total sky cover is missing, a total sky cover of 10/10 is assumed.
- If the ceiling height is missing, an unlimited ceiling (> 16,000 feet) is assumed.

#### A.2.3 Surface Winds

The wind direction and wind speed are read in through the input data file by HRLYPROC. The user provides the height of the wind measurements and the surface roughness length where the measurements took place and where the data is to be applied. In some cases wind data is collected over one type of surface, but where the meteorological data will be applied is over a different type of surface. For example, the wind data may be collected over an area with cut grass and relatively small surface roughness, and the data would be applied to area which is forested and has a high surface roughness. The change in surface roughness would change the wind speed seen at the measurement height. Wind direction would be largely unaffected by the change in surface roughness.

To estimate the change in wind speed due to the variation is surface roughness, the diabatic wind profile is used. No attempt is made to model the variation of wind direction with height above the ground. Diabatic profiles account for the effect of surface roughness and atmospheric stability on the variation of wind speed with height.

The diabatic profile model is derived from the atmospheric boundary layer similarity theory proposed by Monin and Obukhov (1954). The basic hypothesis of similarity theory is that a number of parameters in the atmospheric layer near the ground, including the wind profiles, should be universal functions of the friction velocity, a length scale, and the height above ground. The length scale, L, is referred to as the Monin-Obukhov length and the ratio z/L is related to atmospheric stability. When z/L is negative and large (e.g., < -2), the atmosphere is extremely unstable (convective). When z/L is near zero, the atmosphere is neutral, and when it is positive and large (e.g., > 1), the atmosphere is extremely stable. A large body of experimental data supports Monin-Obukhov similarity theory.

The diabatic wind profile is

$$U(z) = \frac{u^*}{k} \left[ \ln(\frac{z}{z_0}) - \psi(\frac{z}{L}) \right]$$

where U(z) = wind speed at height z (m/s)

u<sub>\*</sub> = friction velocity (boundary-layer turbulence scaling velocity) (m/s)

k = von Karman constant, which has a value of about 0.4 (no units)

z = height(m)

 $z_0$  = measure of local surface roughness (roughness length) (m)

 $\Psi$  = stability correction factor

L = Monin-Obukhov Length (m)

The term  $\psi(z/L)$  accounts for the effects of stability of the wind profile. In stable atmospheric conditions,  $\psi(z/L)$  has the form  $-\alpha z/L$ , where  $\alpha$  is a value between 4.7 and 5.2. For the program, a value of 5 is used for  $\alpha$ . In neutral conditions  $\psi(z/L)$  is zero, and the diabatic profile simplifies to a logarithmic profile.

In unstable air,  $\psi(z/L)$  is more complicated. According to Panfosky and Dutton (1984), the most common form of  $\psi(z/L)$  for unstable conditions is based on the work by Businger et al. (1971) and Paulson (1970). It is

$$\psi(\frac{z}{L}) = \ln([\frac{1+x^2}{2}][\frac{1+x}{2}]^2) - 2 \tan^{-1}x + \frac{\pi}{2}$$

where  $x = (1-16z/L)^{1/4}$ . This equation is used to estimate the friction velocity (u<sub>\*</sub>) from wind speed, surface roughness, and the Monin Obukhov Length. In unstable and neutral conditions, the use of this equation is limited to the lowest 100 meters of the atmosphere. In stable conditions, the upper limit of application of this equation is the smaller of 100

meters or three times the Monin-Obukhov length. Skibin and Businger (1985) provide the rationale for limiting application of this equation to three times the Monin-Obukhov length in stable conditions.

The Monin-Obukhov length is a measure of atmospheric stability. It varies from small negative values (a few meters) in extremely unstable atmospheric conditions to negative infinite as the atmospheric stability approaches neutral from unstable. In extremely stable conditions, the Monin-Obukhov length is small and positive. As neutral conditions are approached from stable conditions, the Monin-Obukhov length approaches infinity. Thus, there is a discontinuity in the Monin-Obukhov length at neutral. However, this discontinuity is not a problem because the Monin-Obukhov length is found in the denominator of expressions.

Golder (1972) provides a means for converting from stability class estimates to Monin-Obukhov lengths. Figure 1 derived from Golder (1972, Figure 5) shows the range for 1/L as a function of stability classes and surface roughness. Mid-range values for 1/L from this figure are used by the model to estimate 1/L.

The following method is used to estimate the wind speed at the application surface roughness. First, the friction velocity is calculated from the input wind speed, measurement height and measurement site surface roughness using Equation (3). Using the friction velocity obtained for the measurement site, the wind speed at the upper height limit (100 meters or the smaller of 100 meters and three times the Monin-Obukhov for stable conditions) is calculated using the preceding equation. A new friction velocity is calculated using the wind speed at the upper height limit and the application's surface roughness again from the equation. From the new friction velocity, the wind speed at the measurement height is calculated using the equation. This new wind speed is used as output, and the surface roughness at the application site along with the wind measurement height are outputted as the first record.

# A.2.4 Mixing Height

In the layer of the atmosphere next to the earth's surface, friction caused by surface roughness and heating of the surface combine to generate turbulence that efficiently mixes material released at or near the surface through the layer. This layer is referred to as the mixing layer. The top of the mixing layer is marked by a decrease in turbulence brought about by stable atmospheric conditions above. The depth of the mixing layer, also referred to as the thickness of the mixing layer, changes with atmospheric conditions. The mixing layer is generally thickest during the day and during periods with high wind speeds, and it is thinnest at night during the periods with low wind speeds. In either case, the mixing layer depth tends to increase with surface roughness.

The mixing layer height is not a variable that is read in by HRLYPROC, but must be estimated based on the reported meteorological conditions. Mixing heights are calculated in HRLYPROC using the relationships derived by Zilitinkevich (1972) for stable and neutral conditions. For stable atmospheric conditions, his relationship is

$$H = k \sqrt{\frac{u \cdot L}{f}}$$

where H = mixing-layer height (m)

k = von Karman constant (dimensionless, 0.4)

 $u_* = friction velocity (m/s)$ 

L = Monin-Obukhov Length (m)

f = Coriolis parameter ( = 1.46 x  $10^{-5}$  sin  $\phi$ , where  $\phi$  is the latitude) (s<sup>-1</sup>)

For neutral and unstable conditions, the mixing layer height is estimated using

$$H = \beta \frac{u^*}{f}$$

where H = mixing layer height (m)

 $\beta$  = constant (dimensionless)

 $u_* = friction velocity (m/s)$ 

f = Coriolis parameter

Zilitinkevich (1972) assumes that  $\beta$  is equal to k; Pasquill and Smith (1983) suggest  $\beta$  has a value in the range of 0.2 to 0.3; and Panfosky and Dutton (1984) suggest its range is 0.15 to 0.25. In HRLYPROC,  $\beta$  is assumed to be 0.2.

Using either formula, the mixing layer height is not allowed to exceed 2,000 meters or fall under 10 meters.

#### A.2.5 Temperature

For the CD-144 data, hourly ambient temperature data are converted from the NWS reporting units of degrees Fahrenheit to Kelvin. For the SAMSON data, the reporting units are degrees Celsius and are converted to Kelvin.

#### A.2.6 Precipitation

Both the CD-144 and the SAMSON data include codes for the current weather at the meteorological station. These codes are based on the type of precipitation (e.g., rain, snow, hail) and the intensity of the precipitation (e.g., light, moderate, or heavy). These codes are used to determine a precipitation code and rate that are output by HRLYPROC.

In the output, the weather code is convert to a precipitation code which ranges from 0 to 6. A zero is used when there is no precipitation. Precipitation codes 1, 2, and 3 indicate light, moderate, and heavy liquid precipitation, respectively. Liquid precipitation includes rain, drizzle, freezing rain, and freezing drizzle. All drizzle intensities are coded as 1. Codes 4, 5, 6 indicate light, moderate, and heavy frozen precipitation, respectively. Frozen precipitation include snow, snow grains, snow pellets, ice pellets, ice crystals, and hail. If a mixture of liquid and frozen precipitation is occurring (e.g., rain and snow reported at the same time),

liquid precipitation is assumed unless the intensity of the frozen precipitation is greater than the liquid precipitation. For example, if both moderate rain and moderate snow where reported for the hour, the precipitation code would be 2. If moderate rain and heavy snow were reported for the hour, the precipitation code would be 6.

For the CD-144 data, the precipitation rate is either the value obtain from the TD-3240 date (if available) or a default value. For the SAMSON data, the precipitation rate may be either the precipitation rate found in the SAMSON data, the rate obtained from the TD-3240 data if available and no rate given by the SAMSON data, or a default value. The default value is based on the precipitation code. Table A.4 shows the default precipitation rate as a function of the precipitation code. All precipitation rates (whether from SAMSON, TD-3240 or default) are outputted in units of mm/hr.

Table A.4. Default Precipitation Rates Based on Precipitation Code

Precipitation Code	Precipitation Rate (mm/hr)
1	1
2	5
3	10
4	0.25
5	1.25
6	2.5

#### A.3 Meteorological Processing for JJFDPROC

This section described the methods used to processing the joint frequency distribution (JFD) of wind speed, wind direction, and atmospheric stability. The issues covered include data manipulation (converting units), how mixing heights are calculated, and how to account for variations in temperature and precipitation.

#### A.3.1 Date and Time

A JFD does not contain any information about the date and time associated with meteorological variables that are summarized. Thus, the output from the JJFDPROC program does not include any date and time information. The year, month, day, and hour for the output record from the JJFDPROC program are set to -1. This allows the program using the output of the JJFDPROC program to know that the data was created from a JFD.

#### A.3.2 Atmospheric Stability

Atmospheric stability comes obtained the JFD read in by the JJFDPROC program. Thus, no data manipulation is required to estimate the atmospheric stability.

#### A.3.3 Surface Winds

The wind direction and wind speed are obtained from the JFD read in by the JJFDPROC program. The user provides the midpoints of the wind speed classes, whether the wind directions are given in 16 or 36 sectors, the height of the wind measurement, and the surface roughness at the measurement site and the application site.

Most JFD are calculated using 16 sectors. The 22.5° sectors are used because wind directions were record using these sectors (i.e., North, North-Northeast, ...North-Northwest). However, since 1965 directions have been recorded in tens of degrees. Thus, it is possible to produce a JFD that uses 36 sectors, where the sectors would be centered around the multiples of 10 degrees (e.g., 10, 20, 30). Whether the 16 or 36 sectors are used, the flow vector (where the wind is blow towards) is based on the direction associated with the center of the sector (e.g., 0, 22.5, 45, ... degrees for the 16 sectors, and 0, 10, 20, 30, ... degrees for the 36 sectors).

The wind speed midpoints are used as the wind speed. Similar to the hourly data, the wind speed can be corrected when the surface roughness at the measurement site is different from the application site (see Section A.2.3). The wind speed midpoints input by the user are converted to m/s, if they are not already in these units.

#### A.3.4 Mixing Height

Mixing height is calculated in the same way as for the hourly meteorological data. Section A.2.4 describes how the mixing height is calculated.

#### A.3.5 Temperature

The ambient temperature is a variable not found in the JFD. To provide temperature information, which may be used by the atmospheric models for plume rise and deposition calculation, the user must supply the temperature information. For the JJFDPROC program, the user inputs maximum and minimum temperatures for each month. The maximum and minimum temperature are available in Local Climatological Data summaries available from the National Climatic Data Center.

The variation in temperature is added to the output by dividing the frequency of a given wind speed class, wind direction sector, and atmospheric stability class by 12 (for the 12 months) and using the maximum temperature if the stability class is 1 or 2 (extremely unstable or very unstable), the minimum temperature if the stability class is 6 or 7 (very stable or extremely stable), and the average, (max + min)/2, for the other stability classes. This method is based on the assumption that unstable condition occur during the middle of the day when maximum temperature occur and stable condition occur during the night when minimum temperatures occur. This method does not take into account that frequency of stability classes by month. That is, normally, neutral and stable condition occur more often in winter months than during summer months.

#### A.3.6 Precipitation

Precipitation (type and rate) variables are not found in the JFD and must be provided by the user. The user has an option to include precipitation or not. If the user wants to include precipitation, the user must provide the fraction of time precipitation occurs for the various stability classes. As the precipitation rarely occurs during the extremes of stability, stability class 1 and 2 (extremely unstable and very unstable) are combined into a single class and stability class 6 and 7 (very stable and extremely stable) are combined into another class. In addition, heavy rain does not occur very often, so the moderate and heavy categories of precipitation (rain or snow) are also combined into a single class. Appendix C presents the fractions of time of the various precipitation type based on stability class for a number of stations. For a station not on the list, the precipitation can be estimated by choosing a representative station (which may not be the nearest station) from the list in Appendix C.

The precipitation is added to the records by dividing the frequency of a given wind speed class, wind direction sector and stability class into a percent of time with a precipitation type including no precipitation. The percent of time with a given precipitation type is based on the fractions provided by the user, and are applied after the frequencies have been modified to account for temperature (see Section A.3.5). Because the moderate and heavy intensity have been converted to a single category, the precipitation that occurs is always assumed to be moderate.

#### A.3.7 Weighting

The weight that is found at the end of each output record is the number of hours for the given meteorological data (wind speed, wind direction, atmospheric stability class, etc). It is calculated by multiplying the number of hours that represent the data in the JFD (usually 1 year = 8760 hours) times the frequency of the wind speed class, wind direction sector, atmospheric stability, temperature, and (if selected) the precipitation type and rate. If the resulting number of hours (weight factor) is too small, (less than 0.01 hours), the record is not written to the file. This is to prevent records were the time of occurrence is essentially zero.

#### A.4 References

Businger, J.A., J.C. Wyngaard, Y. Izumi, and E.F. Bradley. 1971. "Flux-Profile Relationships in the Atmospheric Surface Layer." *Journal of the Atmospheric Sciences* 28(2):181-189.

EPA (U.S. Environmental Protection Agency). 1995a. User's Guide for the Industrial Source Complex (ISC3) Dispersion Models Volume II - Description of Model Algorithms. EPA-454/B-95-003b. Research Triangle Park, North Carolina.

EPA (U.S. Environmental Protection Agency). 1995b. *PCRAMMET User's Guide*. Research Triangle Park, North Carolina.

Golder, D. 1982. "Relations Among Stability Parameters in the Surface Layer." *Boundary-Layer Meteorology* 3(1):47-58.

Monin, A.S. and A.M. Obukhov. 1954. "Basic Laws of Turbulent Mixing in the Ground Layer of the Atmosphere." *Trans. Geophys, Inst. Akad. Nauk*, USSR 151:163-187.

Napier, B.A., R.A. Peloquin, D.L. Strenge, and J.V. Ramsdell Jr. 1988. *GENII - The Hanford Environmental Radiation Dosimetry Software System. Volume 2: User's Manual.* PNL-6584 Vol. 2, Pacific Northwest National Laboratory, Richland, Washington.

NCDC. 1990. Hourly Precipitation Data TD-3240. National Climatic Data Center, Asheville, North Carolina.

NOAA. 1970. Card Deck 144 WBAN Hourly Surface Observations Reference Manual. available from the National Climatic Data Center, Asheville, North Carolina.

Panofsky, H.A. and J.A. Dutton. 1984. Atmospheric Turbulence. J. Wiley & Sons, New York.

Pasquill, F. 1974. *Atmospheric Diffusion*. D.Van Nostrand Company, Ltd., London 2nd Edition.

Pasquill, F. and F. B. Smith. 1983. *Atmospheric Diffusion*, 3rd Edition. Halsted Press, New York

Paulson, C.A. 1970. "The Mathematical Representation of Wind Speed and Temperature Profiles in the Unstable Atmospheric Surface Layer." *Journal of Applied Meteorology* 9(6):857-861.

Skibin, D. and J.A. Businger. 1985. "The Vertical Extent of the Log-Linear Wind Profile Under Stable Stratification." *Atmospheric Environment* 19(1):27-30.

Turner, D.B. 1964. "A Diffusion Model for an Urban Area." *Journal of Applied Meteorology*, 3:83-91.

Zilitinkevich, S.S. 1972. "On the Determination of the Height of the Ekman Boundary Layer." *Boundary-Layer Meteorology* 3(2):141-145.

# APPENDIX B

# Meteorological File Formats

#### Appendix B

## Meteorological File Formats

This appendix contains the file formats for the hourly meteorological data files that can be used as input and the format of the output file. The input file formats are taken from the PCRAMMET User's Guide (EPA 1995b).

#### 4.4 Surface Data Record - CD144 Format

The CD-144 format is given in the following table. Note: only the variables of interest are provided in the following table.

Element	Column(s)
Surface Station Number	1-5
Year	6-7
Month	8-9
Day	10-11
Hour	12-13
Ceiling Height (hundreds of feet)	14-16
Present Weather	25-29
Wind Direction (tens of degrees)	39-40
Wind Speed (knots)	41-42
Dry Bulb Temperature	47-49
Opaque Cloud Cover	79

Exhibit 1 shows a sample file in the CD-144 format.

#### Exhibit 1 Sample File in the CD-144 format.

039288801010010002000000000034301101052903016014081449250	1
039288801010100002000000000343011360529030140130880	0
039288801010200002000000000349010020829050160140770	0
039288801010300002000000000352008060829060150130740	0
0392888010104000020000000000353006060629060130110730	0
0392888010105000020000000000354006360329060120100770	0
0392888010106000020000000000358004060629070120100700	0
0392888010107000020000000000369004020729100120100700	0
039288801010800002000000000380005360629130110090770	0
039288801010900002000000000388004361029150130110670	0
039288801011010002000000000393004320929170150120622	0
0392888010111120500020000000000402004030929200180140548	6

0392888010112000020000000000398005000029190210160500 7120	0
0392888010113100020000000000395006300329180230180481	0
0392888010114100020000000000387006240629160230180481	0
039288801011510002000000000038400730072915024019048118250	0
0392888010116100020000000000381008240629140240190502	0
03928880101171000150000000000378010230429130240200552	1
0392888010118100015000000000038301121072914020017068207120282502	1
0392888010119200015000000000380010210529130190160682	2
0392888010120200015000000000385010220429140160140772	2
0392888010121200015000000000038500923042914014012080228250	2
03928880101220000150000000000384010240329140150130810	0
03928880101230000150000000000387010240729150150130810	0
03928880102000000150000000000382010230529140140130840	0

# Surface Data Record - SAMSON Format

Information about the file obtained from PCRAMMET Users Guide (EPA 1995b) and summarized here.

The first record in the file retrieved from the SAMSON CD-ROMs contains station data. The format for this record is

Columns	Element	Definition
001	Indicator	~ to indicate header record
002-006	WBAN number	Station Number
008-029	City	City where station is located
031-032	State	State where station is located
033-036	Time Zone	Number of hours by which local standard time lags or leads Universal Time
039-044 (039 040-041 043-044)	Latitude	Station Latitude N or S = North or South Degrees Minutes
047-053 (047 048-050 052-053)	Longitude	Station Longitude E or W = East or West Degrees Minutes
056-059	Elevation	Elevation of Station in meters above sea level.

The FORTRAN format of this record is: (1x, a5, 1x, a22, 1x, a2, 1x, i3, 2x, a1, i2, 1x, i2, 2x, a1, i3, 1x, i2, 2x, i4)

Each variable in the SAMSON data is represented by a position number. This position number **always** corresponds to that variable, no matter how many or how few variables are retrieved. The second record in the file retrieved from the SAMSON-CD contains the list of variables (by a position number) that appear in the data file. There is no particular format; the variable number appears above the column of data it represents with at least one space (and usually many more) between the position numbers.

The rest of the records contain the weather elements retrieved from the SAMSON CD-ROMs. The data are in free-format (i.e., there is at least one space between each element in the record). The year, month, day, hour, and observation indicator always appear on each record. These are followed by the variables retrieved by the user. If all the variables were retrieved, they would appear in the following order:

Position Number	Description
	Year, month, day, hour (LST), observation indicator
1	Extraterrestrial horizontial radiation
2	Extraterrestrial direct normal radiation
3	Global horizontial radiation
4	Direct normal radiation
5	Diffuse horizontial radiation
6	Total cloud cover
7	Opaque cloud cover
8	Dry bulb temperature
9	Dew point temperature
10	Relative humidity
11	Station pressure
12	Wind direction
13	Wind speed
14	Visibility
15	Ceiling height
16	Present weather
17	Precipitable water
18	Broadband aerosol optical depth
19	Snow depth
20	Days since last snowfall
21	Hourly precipitation amount and flag

The on-line help that accompanies the CD-ROMs contains a complete discussion of these variables, including the units, missing value indicators and any special considerations or comments.

Exhibit 2 shows a sample file in the SAMSON format. Note the SAMSON file does not contain all the possible variables, but the ones required by HRLYPROC.

Exhibit 2 Sample File in the SAMSON format.

~039	928	WIC	CHIT	ГΑ				KS	-6	N37	39	W097 25	408			
~YR	MO	DA	HR	I	6	7	8	9	10	11	12	13	14	15	16	21
88	1	1	1	0	0	0	-10.0 -11	L.7	88	983	360	2.6	32.2	77777	999999999	0
88	1	1	2	0	0	0	-8.9 -12	2.2	77	984	20	4.1	32.2	77777	999999999	
88	1	1	3	0	0	0	-9.4 -13	3.3	74	984	60	4.1	32.2	77777	999999999	
88	1	1	4	0	0	0	-10.6 -14	1.4	73	984	60	3.1	32.2	77777	999999999	
88	1	1	5	0	0	0	-11.1 -14	1.4	77	984	360	1.5	32.2	77777	999999999	
88	1	1	6	0	0	0	-11.1 -15	5.6	70	985	60	3.1	32.2	77777	999999999	
88	1	1	7	0	0	0	-11.1 -15	5.6	70	986	20	3.6	32.2	77777	999999999	
88	1	1	8	0	0	0	-11.7 -15	5.0	77	987	360	3.1	32.2	77777	999999999	
88	1	1	9	0	0	0	-10.6 -15	5.6	67	987	360	5.2	32.2	77777	999999999	
88	1	1	10	0	2	0	-9.4 -15	5.6	62	988	320	4.6	32.2	77777	999999999	
88	1	1	11	0	8	6	-7.8 -15	5.6	54	989	30	4.6	32.2	3660	999999999	
88	1	1	12	0	0	0	-6.1 -15	5.0	50	989	0	.0	32.2	77777	999999999	
88	1	1	13	0	1	0	-5.0 -14	1.4	48	988	300	1.5	32.2	77777	999999999	
88	1	1	14	0	1	0	-5.0 -14	1.4	48	988	240	3.1	32.2	77777	999999999	
88	1	1	15	0	1	0	-4.4 - 13	3.9	48	987	300	3.6	32.2	77777	999999999	
88	1	1	16	0	2	0	-4.4 - 13	3.3	50	987	240	3.1	32.2	77777	999999999	
88	1	1	17	0	2	1	-4.4 - 12	2.2	55	987	230	2.1	24.1	77777	999999999	
88	1	1	18	0	2	1	-6.7 -11	L.7	68	987	210	3.6	24.1	77777	999999999	
88	1	1	19	0	2	2	-7.2 -12	2.2	68	987	210	2.6	24.1	77777	999999999	
88	1	1	20	0	2	2	-8.9 -12	2.2	77	987	220	2.1	24.1	77777	999999999	
88	1	1	21	0	2	2	-10.0 -12	2.8	80	987	230	2.1	24.1	77777	999999999	
88	1	1	22	0	0	0	-9.4 -12	2.2	81	987	240	1.5	24.1	77777	999999999	
88	1	1	23	0	0	0	-9.4 -12	2.2	81	987	240	3.6	24.1	77777	999999999	
88	1	1	24	0	0	0	-10.0 -12	2.2	84	987	230	2.6	24.1	77777	999999999	

#### **CEAM Format**

The hourly values file has a header containing identifying information.

Example:

25501 Kodiak AK +9 N 57 45 W 152 30 5 2002-05-17 22:47:31

<b>T T</b>	- 1	
ш	ead	04
	Cau	C.I.

Fiel	d Columns	Description	Type	Format
1	1	blank	Character	1x
2	02 - 06	WBAN id	Character	a5
3	08 - 37	City where the station is located.	Character	a30
4	39 - 40	State where the station is located.	Character	a2
5	42 - 44	Time Zone	Character	a3

6	47 - 54	Latitude of the station		
	47 - 47	N: North of the Equator	Character	a1
		S: South		
	48 - 51	Degrees	Integer	i4
	53 - 54	Minutes	Integer	i2
7	57 - 64	Longitude of the station		
	57 - 57	W: West E: East	Character	a1
	58 - 61	Degrees	Integer	i4
	63 - 64	Minutes	Integer	i2
			S	
8	67 - 70	Station Elevation(meter)	Integer	i4
		` ,	Q	
9	74 - 92	Generation date of the	Character	a19
		file, i.e, yyyy-mm-dd hh:mm	:ss	
		where		
		yyyy: year		
		mm: month		
		dd: day of the month		
		•		
		hh: hour (24-hour clock)		
		mm: minutes		
		ss: seconds		

Header format: (1x, a5, 1x, a30, 1x, a2, 1x, a3, & 2x, a1, i4, 1x, i2, & 2x, a1, i4, 1x, i2, & 2x, i4, 3x, a19)

Field	l Columns	Description	Units	Туре	Format
1	1	blank	N/A	Character	1x
2	002 - 011	Date	yyyy-mm-dd	Integer	i4,1x,i2,1x,i2
3	012 - 014	*Hour of the day	Hour	Integer	i3
4	016 - 021	Extraterrestrial	*Wh/m2	Integer	i5,a1
		Horizontal Radiation (F	Ra)		
5	023 - 028	Extraterrestrial	Wh/m2	Integer	i5,a1
		Direct Normal Radiatio	n		
6	030 - 037	Global Horizontal	Wh/m2	Integer	i5,a3
		Radiation (Rs)			
7	039 - 046	Direct Normal	Wh/m2	Integer	i5,a3
		Radiation			
8	048 - 055	Diffuse Horizontal	Wh/m2	Integer	i5,a3
		Radiation			
9	057 - 059	Total Sky Cover	tenths of sky covered	Integer	i2,a1
10	061 - 063	Opaque_Sky_Cover	tenths of sky covered	Integer	i2,a1
11	065 - 070	Dry Bulb Temperature	degrees Centigrade	Real	f5.1,a1
12	072 - 077	Dew Point Temperature	edegrees Centigrade	Real	f5.1,a1

13	079 - 082	Relative_Humidity	percent	Integer	i3,a1
14	084 - 089	Station_Pressure	*kPa	Real	f5.1,a1
15	091 - 094	Wind_Direction	degrees(N=0,E=90,	.) Integer	i3,a1
16	096 - 101	Wind_Speed @10mete:	r m/s	Real	f5.1,a1
17	103 - 109	Horizontal Visibility	km	Real	f6.1,a1
18	111 - 117	Ceiling Height	m	Integer	i6,a1
19	119 - 120	Observation Indicator	N/A	Integer	i1,a1
20	122 - 131	Present_weather	N/A	Character	a9,a1
21	133 - 136	Precipitable Water	mm	Integer	i3,a1
22	138 - 144	Broadband Aerosol	Optical_Depth	Real	f6.3,a1
23	146 - 150	Snow Depth	cm	Integer	i4,a1
24	152 - 155	Days since last	day	Integer	i3,a1
		Snowfall			
25	157 - 164	Hourly Precipitation	cm	Real	f6.2,a2
26	166 - 172	Eto, FAO Short Grass	mm/day	Real	f6.2,a1
27	174 - 180	Ep, Class A pan	mm/day	Real	f6.2,a1
		Evaporation			

<sup>\*</sup>Hour of the day: The range of the hour of the day is 1h to 25h: 1h-24h: line contains data for the hour 25: line contains daily values

1 kiloPascal is equivalent to 10 millibar

Fields 26 and 27 represent daily totals. These fields are present only when the hour of the day (field 3) is 25.

Generally, each value has one or more character flags associated with it.

Missing values are denoted by '---' in the numeric value field and flag values of '-'

```
Hourly values file format: (1x,i4,1x,i2,1x,i2, i3, t16,i5,a1, t23,i5,a1, & t30,i5,a3, t39,i5,a3, t48,i5,a3, & t57,i2,a1, t61,i2,a1, t65,f5.1,a1, t72,f5.1,a1, & t79,i3,a1, t84,f5.1,a1, t91,i3,a1, t96,f5.1,a1, & t103,f6.1,a1, t111,i6,a1, t119,i1,a1, t122,a9,a1, & t133,i3,a1, t138,f6.3,a1, t146,i4,a1, t152,i3,a1, & t157,f6.2,a2, t166,f6.2,a1, t174,f6.2,a1)
```

<sup>\*</sup>Wh/m2: Watt hour meter^-2 Watt hour meter^-2 is equivalent to 3.6e-3 MJoule meter^-2 Watt hour meter^-2 is equivalent to 8.59845e-02 Langley

<sup>\*</sup>kPa: kiloPascal

#### Hourly Precipitation - TD-3240 Format

Precipitation data are reported only for those hours during which precipitation occurred. Variable-length blocks contain a station's precipitation record for one day on a physical record. The format of the precipitation data for variable-length blocks is as follows.

Field	Column(s)	Description
001	001-003	Record Type
002	004-011	Station indentifier
003	012-015	Meteorological element type
004	016-017	Measurement units
005	018-021	Year
006	022-023	Month
007	024-027	Day (right justified, zero filled)
008	028-030	Number of data groups to follow
009	031-034	Hour (left justified, zero filled)
010	035-040	Value of meteorological element
011	041	Measurement flag #1
012	042	Quality flag #2 (not used, blank)

Data groups in the same form as field 009 through 012 are repeated as many times as necessary to contain one day of values on one record. These data would occupy fields 013 through 108, the maximum number of fields.

Fixed length block contain a stations's precipitation record for one hour on a physical record. The structure is indentical to the variable-length blocks, except that only one hour of data appears on the record (i.e., fields 001 through 012 on one record).

#### Output File

The first record in the output file is the surface roughness length and measurement height for the site. The two variables are read in free format, so they only need to be seperated by a space or a comma. The rest of the records are as follows

Column(s)	Variable	Description
002-005	Year	Is a four digit year (or two digits if from CD-144) or -1 if from JJFDPROC
007-008	Month	Is the month or -1 if from JJFDPROC
010-011	Day	Is the day or -1 if from JJFDPROC
013-014	Hour	Is the hour or -1 if from JJFDPROC
016	Stability Class	Stability Class (if > 7 then missing)
018-022	Flow Vector	The direction the wind is blowing towards (in degrees). If greater than 360, then missing.
024-028	Wind Speed	Wind Speed in m/s. If less than zero or greater than 90, then missing.
030-035	Temperature	Dry bulb temperature in degrees K. If less than zero or greater than 385, then missing.
037-042	Mixing Height	Height of mixing layer in meters. If less than zero or greater than 8000 than missing.
044	Precipitation Code	Code for Precipitation (0 - none, 1, 2, 3 - light, moderate, and heavy rain, 4,5,6 - light, moderate, and heavy snow). If > 6, then missing.
046-051	Precipitation Rate	Precipitation Rate in mm/hr. Missing if less than zero.
053-058	Weight	Weighting Factor (1 if from HRLYPROC) which is the number of hours with meteorological data as given in the record.

The FORTRAN format of the record would be as follows: (1x,I4,1x,I2,1x,I2,1x,I2,1x,I1,1x,F5.0,1x,F5.1,1x,F6.2,1x,F6.0,1x,I1,1x,F6.2,1x,F6.0)

Exhibt 3 shows a sample output file from HRLYPROC. Exhibit 4 show a sample output file from JJFDPROC.

#### Exhibit 3 Sample Output File from HRLYPROC

.20	0,	10	. 0								
88	1	1	1	6	180.	2.6	263.15	151.	0	.00	1.
88	1	1	2	5	200.	4.1	264.26	367.	0	.00	1.
88	1	1	3	5	240.	4.1	263.70	367.	0	.00	1.
88	1	1	4	6	240.	3.1	262.59	165.	0	.00	1.
88	1	1	5	7	180.	1.5	262.04	45.	0	.00	1.
88	1	1	6	6	240.	3.1	262.04	165.	0	.00	1.
88	1	1	7	5	200.	3.6	262.04	343.	0	.00	1.
88	1	1	8	4	180.	3.1	261.48	709.	0	.00	1.
88	1	1	9	4	180.	5.1	262.59	1181.	0	.00	1.
88	1	1	10	3	140.	4.6	263.70	1204.	0	.00	1.
88	1	1	11	4	210.	4.6	265.37	1063.	0	.00	1.
88	1	1	12	2	210.	1.0	267.04	289.	0	.00	1.
88	1	1	13	2	120.	1.5	268.15	445.	0	.00	1.
88	1	1	14	3	60.	3.1	268.15	803.	0	.00	1.
88	1	1	15	3	120.	3.6	268.71	937.	0	.00	1.
88	1	1	16	4	60.	3.1	268.71	709.	0	.00	1.
88	1	1	17	4	50.	2.1	268.71	472.	0	.00	1.
88	1	1	18	5	30.	3.6	266.48	343.	0	.00	1.
88	1	1	19	6	30.	2.6	265.93	151.	0	.00	1.
88	1	1	20	6	40.	2.1	264.26	135.	0	.00	1.
88	1	1	21	6	50.	2.1	263.15	135.	0	.00	1.
88	1	1	22	7	60.	1.5	263.70	45.	0	.00	1.
88	1	1	23	5	60.	3.6	263.70	343.	0	.00	1.
88	1	1	24	6	50.	2.6	263.15	151.	0	.00	1.

# Exhibit 4 Sample Output File from JJFDPROC

```
2.000, 10.0
                                               .00
                        5.3 277.65 2000. 0
 -1 -1 -1 -1 1 180.
                                                      2.62
                                    2000. 0
                                               .00
  -1 -1 -1 -1 1 180.
                        5.3 281.65
                                                      2.62
 -1 -1 -1 -1 1 180.
-1 -1 -1 -1 1 180.
                        5.3 285.54
                                    2000. 0
                                                .00
                                                      2.62
                        5.3 289.93
                                    2000. 0
                                                .00
                                                     2.62
 -1 -1 -1 -1 1 180.
                        5.3 294.76
                                    2000. 0
                                               .00
                                                     2.62
                        5.3 299.43
                                    2000. 0
 -1 -1 -1 -1 1 180.
                                                .00
                                                     2.62
  -1 -1 -1 -1 1 180.
                        5.3 304.71
                                    2000. 0
                                                .00
                                                     2.62
  -1 -1 -1 1
                 180.
                        5.3 303.15
                                    2000. 0
                                                .00
                                                      2.62
  -1 -1 -1 1
                        5.3 298.32
                                    2000. 0
                 180.
                                                .00
                                                      2.62
 -1 -1 -1 -1 1 180.
                        5.3 290.93
                                    2000. 0
                                               .00
                                                     2.62
 -1 -1 -1 -1 1 180.
                        5.3 282.59
                                    2000. 0
                                               .00
                                                     2.62
 -1 -1 -1 -1 1 180.
                        5.3 279.26
                                    2000. 0
                                               .00
                                                     2.62
                                               .00
 -1 -1 -1 -1 1 203.
                        5.3 277.65
                                    2000. 0
                                                     1.46
 -1 -1 -1 -1 1
-1 -1 -1 -1 1
                203.
                        5.3 281.65
                                    2000. 0
                                                .00
                                                      1.46
                                    2000. 0
                 203.
                        5.3 285.54
                                                .00
                                                     1.46
  -1 -1 -1 -1 1 203.
                                    2000. 0
                        5.3 289.93
                                               .00
                                                     1.46
 -1 -1 -1 -1 1 203.
                        5.3 294.76
                                    2000. 0
                                                .00
                                                     1.46
                        5.3 299.43
                                    2000. 0
  -1 -1 -1 -1 1 203.
                                                .00
                                                     1.46
  -1 -1 -1 -1 1 203.
                        5.3 304.71
                                    2000. 0
                                                .00
                                                      1.46
  -1 -1 -1 -1 1
                                    2000. 0
                 203.
                        5.3 303.15
                                                .00
                                                      1.46
 -1 -1 -1 1
                        5.3 298.32
                                    2000. 0
                 203.
                                                .00
                                                     1.46
  -1 -1 -1 1
                203.
                        5.3 290.93
                                    2000. 0
                                               .00
                                                     1.46
 -1 -1 -1 -1 1 203.
                        5.3 282.59
                                    2000. 0
                                               .00
                                                     1.46
                        5.3 279.26
                                                .00
  -1 -1 -1 -1 1 203.
                                    2000. 0
                                                     1.46
 -1 -1 -1 -1 1
-1 -1 -1 -1 1
                 225.
                        5.3 277.65
                                    2000. 0
                                                .00
                                                      1.68
                        5.3 281.65
                                    2000. 0
                 225.
                                                .00
                                                      1.68
 -1 -1 -1 1
                225.
                        5.3 285.54
                                    2000. 0
                                                .00
                                                     1.68
 -1 -1 -1 -1 1 225.
                        5.3 289.93
                                    2000. 0
                                               .00
                                                     1.68
 -1 -1 -1 -1 1 225.
                       5.3 294.76
                                    2000. 0
                                               .00
                                                     1.68
 -1 -1 -1 -1 1 225.
                        5.3 299.43 2000. 0
                                               .00
                                                     1.68
```

# APPENDIX C

# PRECIPITATION PROBABILITIES FOR SELECT UNITED STATES STATIONS

Appendix C

Precipitation Probabilities for Select United State Stations

Fairbanks International	A 1/2	I .			Stab D	Stab E	Stab F-G	All Stab
AP	AK	Light Rain	3.91E-03	8.62E-03	9.68E-02	1.15E-02	2.53E-03	4.55E-02
Fairbanks International AP	AK	Mod/Hvy Rain	0.00E+00	9.07E-05	7.08E-04	0.00E+00	0.00E+00	3.20E-04
Fairbanks International AP	AK	Light Snow	1.30E-03	1.40E-02	2.13E-01	3.31E-02	2.55E-02	1.05E-01
Fairbanks International AP	AK	Mod/Hvy Snow	0.00E+00	4.81E-03	9.70E-03	5.68E-03	3.87E-02	1.57E-02
Fairbanks International AP	AK	All	5.21E-03	2.75E-02	3.20E-01	5.03E-02	6.68E-02	1.67E-01
Kodiak State CG Base	AK	Light Rain	1.36E-03	1.16E-02	3.21E-01	1.41E-02	9.35E-03	2.49E-01
Kodiak State CG Base	AK	Mod/Hvy Rain	0.00E+00	2.47E-04	2.13E-02	0.00E+00	0.00E+00	1.64E-02
Kodiak State CG Base	AK	Light Snow	0.00E+00	2.72E-03	6.61E-02	1.03E-02	3.29E-03	5.21E-02
Kodiak State CG Base	AK	Mod/Hvy Snow	0.00E+00	0.00E+00	1.08E-03	0.00E+00	0.00E+00	8.33E-04
Kodiak State CG Base	AK	All	1.36E-03	1.46E-02	4.10E-01	2.44E-02	1.26E-02	3.19E-01
Mobile Bates Field AP	AL	Light Rain	1.76E-02	2.47E-02	1.32E-01	2.18E-02	3.43E-03	6.47E-02
Mobile Bates Field AP	AL	Mod/Hvy Rain	3.08E-04	9.03E-04	2.01E-02	5.07E-04	0.00E+00	8.77E-03
Mobile Bates Field AP	AL	Light Snow	0.00E+00	0.00E+00	4.82E-04	0.00E+00	0.00E+00	2.05E-04
Mobile Bates Field AP	AL	Mod/Hvy Snow	0.00E+00	0.00E+00	2.68E-05	0.00E+00	0.00E+00	1.14E-05

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Mobile Bates Field AP	AL	All	1.79E-02	2.56E-02	1.52E-01	2.23E-02	3.43E-03	7.37E-02
Fort Smith Municipal AP	AR	Light Rain	7.84E-03	1.35E-02	1.37E-01	1.93E-02	3.57E-03	6.24E-02
Fort Smith Municipal AP	AR	Mod/Hvy Rain	0.00E+00	0.00E+00	1.61E-02	1.85E-04	0.00E+00	6.67E-03
Fort Smith Municipal AP	AR	Light Snow	0.00E+00	0.00E+00	1.06E-02	1.85E-04	0.00E+00	4.40E-03
Fort Smith Municipal AP	AR	Mod/Hvy Snow	0.00E+00	0.00E+00	3.03E-04	0.00E+00	0.00E+00	1.26E-04
Fort Smith Municipal AP	AR	All	7.84E-03	1.35E-02	1.64E-01	1.96E-02	3.57E-03	7.36E-02
Little Rock Adams Field	AR	Light Rain	5.23E-03	1.02E-02	1.61E-01	1.69E-02	2.93E-03	6.69E-02
Little Rock Adams Field	AR	Mod/Hvy Rain	0.00E+00	3.54E-04	1.61E-02	6.39E-04	4.24E-05	6.38E-03
Little Rock Adams Field	AR	Light Snow	0.00E+00	0.00E+00	8.33E-03	2.74E-04	4.24E-05	3.27E-03
Little Rock Adams Field	AR	Mod/Hvy Snow	0.00E+00	0.00E+00	4.12E-04	0.00E+00	0.00E+00	1.60E-04
Little Rock Adams Field	AR	All	5.23E-03	1.05E-02	1.85E-01	1.78E-02	3.01E-03	7.67E-02
Tucson International AP	AZ	Light Rain	1.21E-03	6.41E-03	7.88E-02	6.23E-03	1.62E-03	2.83E-02
Tucson International AP	AZ	Mod/Hvy Rain	0.00E+00	8.33E-05	6.36E-03	1.05E-04	0.00E+00	2.10E-03
Tucson International AP	AZ	Light Snow	0.00E+00	0.00E+00	1.58E-03	0.00E+00	0.00E+00	5.14E-04
Tucson International AP	AZ	Mod/Hvy Snow	0.00E+00	0.00E+00	3.16E-04	0.00E+00	0.00E+00	1.03E-04
Tucson International AP	AZ	All	1.21E-03	6.50E-03	8.71E-02	6.34E-03	1.62E-03	3.10E-02
Fresno Air Terminal	CA	Light Rain	4.13E-04	5.07E-03	9.25E-02	9.10E-03	2.10E-03	2.75E-02
Fresno Air Terminal	CA	Mod/Hvy Rain	0.00E+00	0.00E+00	5.03E-03	1.60E-04	0.00E+00	1.37E-03
Fresno Air Terminal	CA	Light Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Fresno Air Terminal	CA	Mod/Hvy Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Fresno Air Terminal	CA	All	4.13E-04	5.07E-03	9.75E-02	9.26E-03	2.10E-03	2.88E-02
Los Angeles International AP	CA	Light Rain	8.49E-04	1.98E-03	5.31E-02	8.52E-03	1.51E-03	2.40E-02
Los Angeles International AP	CA	Mod/Hvy Rain	0.00E+00	0.00E+00	4.10E-03	8.19E-05	0.00E+00	1.72E-03
Los Angeles International AP	CA	Light Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Los Angeles International AP	CA	Mod/Hvy Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Los Angeles International AP	CA	All	8.49E-04	1.98E-03	5.72E-02	8.60E-03	1.51E-03	2.58E-02
San Diego Miramar NAS	CA	Light Rain	1.13E-03	2.30E-03	5.09E-02	8.08E-03	1.33E-03	2.38E-02
San Diego Miramar NAS	CA	Mod/Hvy Rain	0.00E+00	0.00E+00	5.65E-03	0.00E+00	0.00E+00	2.45E-03
San Diego Miramar NAS	CA	Light Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
San Diego Miramar NAS	CA	Mod/Hvy Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
San Diego Miramar NAS	CA	All	1.13E-03	2.30E-03	5.65E-02	8.08E-03	1.33E-03	2.63E-02
San Francisco International AP	CA	Light Rain	2.15E-04	2.90E-03	8.49E-02	8.85E-03	3.08E-03	4.99E-02
San Francisco International AP	CA	Mod/Hvy Rain	0.00E+00	0.00E+00	6.46E-03	1.75E-04	8.10E-05	3.69E-03
San Francisco International AP	CA	Light Snow	0.00E+00	0.00E+00	2.02E-05	0.00E+00	0.00E+00	1.14E-05
San Francisco International AP	CA	Mod/Hvy Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
San Francisco International AP	CA	All	2.15E-04	2.90E-03	9.13E-02	9.02E-03	3.16E-03	5.36E-02
Denver Stapleton International AP	СО	Light Rain	1.91E-03	9.34E-03	7.78E-02	7.98E-03	1.64E-03	3.22E-02
Denver Stapleton International AP	СО	Mod/Hvy Rain	0.00E+00	8.42E-05	3.33E-03	0.00E+00	0.00E+00	1.26E-03
Denver Stapleton International AP	СО	Light Snow	1.12E-04	1.35E-03	1.11E-01	6.05E-03	2.46E-03	4.32E-02
Denver Stapleton International AP	СО	Mod/Hvy Snow	2.24E-04	8.42E-05	9.38E-03	1.24E-03	1.38E-03	4.05E-03
Denver Stapleton International AP	СО	All	2.24E-03	1.09E-02	2.01E-01	1.53E-02	5.47E-03	8.07E-02
Grand Junction Walker Field AP	СО	Light Rain	2.57E-03	6.12E-03	7.32E-02	5.42E-03	1.16E-03	2.95E-02
Grand Junction Walker Field AP	СО	Mod/Hvy Rain	0.00E+00	0.00E+00	1.25E-03	0.00E+00	0.00E+00	4.60E-04
Grand Junction Walker Field AP	СО	Light Snow	1.17E-04	7.06E-04	4.68E-02	1.22E-03	1.61E-03	1.79E-02
Grand Junction Walker Field AP	СО	Mod/Hvy Snow	0.00E+00	1.57E-04	1.81E-03	1.11E-04	6.45E-05	7.24E-04
Grand Junction Walker Field AP	СО	All	2.69E-03	6.98E-03	1.23E-01	6.75E-03	2.84E-03	4.86E-02
Washington National AP	DC	Light Rain	4.12E-03	1.09E-02	1.40E-01	1.25E-02	5.12E-03	8.31E-02
Washington National AP	DC	Mod/Hvy Rain	0.00E+00	3.15E-04	1.44E-02	1.47E-04	9.30E-05	8.20E-03
Washington National AP	DC	Light Snow	0.00E+00	1.05E-04	1.42E-02	2.93E-04	0.00E+00	8.04E-03

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Washington National AP	DC	Mod/Hvy Snow	0.00E+00	0.00E+00	1.11E-03	0.00E+00	0.00E+00	6.28E-04
Washington National AP	DC	All	4.12E-03	1.14E-02	1.70E-01	1.30E-02	5.21E-03	9.99E-02
Miami International AP	FL	Light Rain	2.84E-02	2.76E-02	7.10E-02	1.68E-02	7.76E-03	4.04E-02
Miami International AP	FL	Mod/Hvy Rain	3.71E-03	3.27E-03	1.65E-02	5.31E-04	3.13E-04	7.85E-03
Miami International AP	FL	Light Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Miami International AP	FL	Mod/Hvy Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Miami International AP	FL	All	3.21E-02	3.09E-02	8.75E-02	1.74E-02	8.07E-03	4.82E-02
Orlando International AP	FL	Light Rain	6.61E-03	1.85E-02	1.05E-01	1.87E-02	3.22E-03	4.77E-02
Orlando International AP	FL	Mod/Hvy Rain	0.00E+00	7.77E-04	1.46E-02	3.01E-04	0.00E+00	5.82E-03
Orlando International AP	FL	Light Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Orlando International AP	FL	Mod/Hvy Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Orlando International AP	FL	All	6.61E-03	1.93E-02	1.19E-01	1.90E-02	3.22E-03	5.35E-02
Atlanta Hartsfield International AP	GA	Light Rain	5.36E-02	5.93E-02	7.53E-02	7.08E-02	7.66E-02	7.19E-02
Atlanta Hartsfield International AP	GA	Mod/Hvy Rain	1.01E-02	1.01E-02	8.42E-03	8.57E-03	8.66E-03	8.77E-03
Atlanta Hartsfield International AP	GA	Light Snow	1.55E-03	1.34E-03	1.29E-03	2.41E-03	1.56E-03	1.52E-03
Atlanta Hartsfield	GA	Mod/Hvy Snow	9.68E-04	2.06E-04	9.08E-05	0.00E+00	3.61E-04	1.94E-04

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
International AP								
Atlanta Hartsfield International AP	GA	All	6.62E-02	7.09E-02	8.51E-02	8.18E-02	8.71E-02	8.24E-02
Savannah Municipal AP	GA	Light Rain	9.62E-03	1.93E-02	1.34E-01	2.71E-02	5.75E-03	6.34E-02
Savannah Municipal AP	GA	Mod/Hvy Rain	2.75E-04	5.52E-04	1.63E-02	3.79E-04	4.92E-05	6.83E-03
Savannah Municipal AP	GA	Light Snow	0.00E+00	0.00E+00	1.84E-03	7.58E-05	0.00E+00	7.66E-04
Savannah Municipal AP	GA	Mod/Hvy Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Savannah Municipal AP	GA	All	9.89E-03	1.99E-02	1.52E-01	2.76E-02	5.80E-03	7.10E-02
Honolulu International AP	НІ	Light Rain	2.70E-03	9.74E-03	1.01E-01	2.86E-02	9.05E-03	5.83E-02
Honolulu International AP	НІ	Mod/Hvy Rain	0.00E+00	0.00E+00	5.18E-03	3.87E-04	2.25E-04	2.69E-03
Honolulu International AP	НІ	Light Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Honolulu International AP	НІ	Mod/Hvy Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Honolulu International AP	НІ	All	2.70E-03	9.74E-03	1.06E-01	2.90E-02	9.28E-03	6.10E-02
Des Moines Municipal AP	IA	Light Rain	1.11E-02	1.82E-02	1.18E-01	1.62E-02	2.87E-03	7.14E-02
Des Moines Municipal AP	IA	Mod/Hvy Rain	0.00E+00	2.20E-04	1.05E-02	3.22E-04	0.00E+00	5.95E-03
Des Moines Municipal AP	IA	Light Snow	2.77E-04	7.69E-04	6.67E-02	4.18E-03	1.13E-03	3.83E-02

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Des Moines Municipal AP	IA	Mod/Hvy Snow	0.00E+00	4.40E-04	1.93E-03	4.02E-04	2.26E-03	1.53E-03
Des Moines Municipal AP	IA	All	1.14E-02	1.97E-02	1.97E-01	2.11E-02	6.26E-03	1.17E-01
Boise Air Terminal	ID	Light Rain	2.46E-03	7.87E-03	1.07E-01	9.49E-03	2.41E-03	4.81E-02
Boise Air Terminal	ID	Mod/Hvy Rain	0.00E+00	0.00E+00	2.04E-03	1.35E-04	0.00E+00	8.79E-04
Boise Air Terminal	ID	Light Snow	4.10E-04	9.73E-04	5.72E-02	1.75E-03	8.03E-04	2.46E-02
Boise Air Terminal	ID	Mod/Hvy Snow	2.74E-04	7.07E-04	2.61E-03	5.38E-04	1.09E-03	1.52E-03
Boise Air Terminal	ID	All	3.15E-03	9.55E-03	1.69E-01	1.19E-02	4.30E-03	7.51E-02
Chicago-O'Hare International AP	IL	Light Rain	3.26E-03	6.88E-03	1.17E-01	5.61E-03	1.39E-03	7.50E-02
Chicago-O'Hare International AP	IL	Mod/Hvy Rain	0.00E+00	0.00E+00	3.96E-03	1.84E-04	9.25E-05	2.51E-03
Chicago-O'Hare International AP	IL	Light Snow	0.00E+00	6.04E-04	5.75E-02	1.56E-03	5.55E-04	3.64E-02
Chicago-O'Hare International AP	IL	Mod/Hvy Snow	0.00E+00	0.00E+00	1.31E-03	0.00E+00	1.85E-04	8.45E-04
Chicago-O'Hare International AP	IL	All	3.26E-03	7.48E-03	1.80E-01	7.36E-03	2.22E-03	1.15E-01
Peoria - Greater Peoria AP	IL	Light Rain	9.48E-03	1.54E-02	1.24E-01	1.25E-02	2.63E-03	7.19E-02
Peoria - Greater Peoria AP	IL	Mod/Hvy Rain	2.37E-04	4.28E-04	1.11E-02	3.68E-04	6.56E-05	6.21E-03
Peoria - Greater Peoria AP	IL	Light Snow	0.00E+00	2.14E-04	5.08E-02	1.47E-03	1.97E-04	2.81E-02

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Peoria - Greater Peoria AP	IL	Mod/Hvy Snow	0.00E+00	1.07E-04	1.81E-03	2.76E-04	0.00E+00	1.04E-03
Peoria - Greater Peoria AP	IL	All	9.72E-03	1.62E-02	1.88E-01	1.46E-02	2.89E-03	1.07E-01
Evansville Dress Regional AP	IN	Light Rain	6.46E-03	1.33E-02	1.68E-01	1.97E-02	3.75E-03	8.09E-02
Evansville Dress Regional AP	IN	Mod/Hvy Rain	0.00E+00	9.91E-05	8.10E-03	1.15E-04	8.94E-05	3.70E-03
Evansville Dress Regional AP	IN	Light Snow	1.43E-04	1.98E-04	3.90E-02	9.22E-04	2.23E-04	1.78E-02
Evansville Dress Regional AP	IN	Mod/Hvy Snow	0.00E+00	0.00E+00	8.61E-04	0.00E+00	0.00E+00	3.88E-04
Evansville Dress Regional AP	IN	All	6.60E-03	1.36E-02	2.16E-01	2.07E-02	4.07E-03	1.03E-01
Russell Municipal AP	KS	Light Rain	3.67E-03	4.20E-03	7.13E-02	2.79E-03	1.57E-03	4.57E-02
Russell Municipal AP	KS	Mod/Hvy Rain	0.00E+00	1.27E-04	3.56E-03	1.39E-04	0.00E+00	2.26E-03
Russell Municipal AP	KS	Light Snow	0.00E+00	0.00E+00	2.88E-02	4.87E-04	3.94E-04	1.81E-02
Russell Municipal AP	KS	Mod/Hvy Snow	0.00E+00	0.00E+00	1.26E-03	0.00E+00	0.00E+00	7.87E-04
Russell Municipal AP	KS	All	3.67E-03	4.33E-03	1.05E-01	3.41E-03	1.97E-03	6.69E-02
Lake Charles Municipal AP	LA	Light Rain	2.11E-02	2.42E-02	1.34E-01	1.88E-02	3.58E-03	6.61E-02
Lake Charles Municipal AP	LA	Mod/Hvy Rain	0.00E+00	1.05E-03	1.52E-02	4.96E-04	0.00E+00	6.81E-03
Lake Charles Municipal	LA	Light Snow	0.00E+00	0.00E+00	1.85E-04	0.00E+00	0.00E+00	8.04E-05

State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
LA	Mod/Hvy Snow	0.00E+00	0.00E+00	5.27E-05	0.00E+00	0.00E+00	2.30E-05
LA	All	2.11E-02	2.53E-02	1.49E-01	1.93E-02	3.58E-03	7.31E-02
MA	Light Rain	8.97E-03	1.06E-02	1.28E-01	7.29E-03	2.97E-03	9.84E-02
MA	Mod/Hvy Rain	0.00E+00	1.49E-04	8.25E-03	0.00E+00	0.00E+00	6.21E-03
MA	Light Snow	0.00E+00	1.49E-04	3.43E-02	7.77E-04	0.00E+00	2.59E-02
MA	Mod/Hvy Snow	0.00E+00	0.00E+00	2.06E-03	0.00E+00	0.00E+00	1.55E-03
MA	All	8.97E-03	1.09E-02	1.73E-01	8.06E-03	2.97E-03	1.32E-01
ME	Light Rain	2.77E-03	9.46E-03	1.52E-01	9.49E-03	3.14E-03	8.26E-02
ME	Mod/Hvy Rain	0.00E+00	1.15E-04	7.30E-03	3.24E-04	5.32E-05	3.90E-03
ME	Light Snow	0.00E+00	1.96E-03	6.33E-02	3.99E-03	1.44E-03	3.43E-02
ME	Mod/Hvy Snow	0.00E+00	0.00E+00	4.62E-03	1.08E-04	1.59E-04	2.48E-03
ME	All	2.77E-03	1.15E-02	2.27E-01	1.39E-02	4.78E-03	1.23E-01
MI	Light Rain	5.16E-03	1.22E-02	1.18E-01	9.58E-03	1.38E-03	7.82E-02
MI	Mod/Hvy Rain	0.00E+00	1.33E-04	5.05E-03	9.30E-05	0.00E+00	3.25E-03
MI	Light Snow	0.00E+00	9.29E-04	7.13E-02	1.49E-03	1.97E-04	4.59E-02
	LA LA MA MA MA ME ME ME ME ME MI	LA Mod/Hvy Snow  LA All  MA Light Rain  MA Mod/Hvy Rain  MA Light Snow  MA Mod/Hvy Snow  MA All  ME Light Rain  ME Mod/Hvy Rain  ME Mod/Hvy Rain  ME Light Snow  ME Mod/Hvy Snow  ME All  MI Light Rain  MI MI Light Rain  MI Mod/Hvy Rain	LA       Mod/Hvy Snow       0.00E+00         LA       All       2.11E-02         MA       Light Rain       8.97E-03         MA       Mod/Hvy Rain       0.00E+00         MA       Light Snow       0.00E+00         MA       All       8.97E-03         ME       Light Rain       2.77E-03         ME       Mod/Hvy Rain       0.00E+00         ME       Mod/Hvy Snow       0.00E+00         ME       All       2.77E-03         MI       Light Rain       5.16E-03         MI       Mod/Hvy Rain       0.00E+00	LA Mod/Hvy Snow 0.00E+00 0.00E+00  LA AII 2.11E-02 2.53E-02  MA Light Rain 8.97E-03 1.06E-02  MA Mod/Hvy Rain 0.00E+00 1.49E-04  MA Light Snow 0.00E+00 0.00E+00  MA Mod/Hvy Snow 0.00E+00 1.09E-02  ME Light Rain 2.77E-03 9.46E-03  ME Mod/Hvy Rain 0.00E+00 1.15E-04  ME Light Snow 0.00E+00 1.96E-03  ME Mod/Hvy Snow 0.00E+00 0.00E+00  ME AII 2.77E-03 1.15E-02  MI Light Rain 5.16E-03 1.22E-02  MI Mod/Hvy Rain 0.00E+00 1.33E-04	LA Mod/Hvy Snow 0.00E+00 0.00E+00 5.27E-05  LA All 2.11E-02 2.53E-02 1.49E-01  MA Light Rain 8.97E-03 1.06E-02 1.28E-01  MA Mod/Hvy Rain 0.00E+00 1.49E-04 8.25E-03  MA Light Snow 0.00E+00 0.00E+00 2.06E-03  MA Mod/Hvy Snow 0.00E+00 1.09E-02 1.73E-01  ME Light Rain 2.77E-03 9.46E-03 1.52E-01  ME Mod/Hvy Rain 0.00E+00 1.15E-04 7.30E-03  ME Light Snow 0.00E+00 1.96E-03 6.33E-02  ME Mod/Hvy Snow 0.00E+00 0.00E+00 4.62E-03  ME All 2.77E-03 1.15E-02 2.27E-01  MI Light Rain 5.16E-03 1.22E-02 1.18E-01  MI Light Rain 0.00E+00 1.33E-04 5.05E-03	LA Mod/Hvy Snow 0.00E+00 0.00E+00 5.27E-05 0.00E+00  LA All 2.11E-02 2.53E-02 1.49E-01 1.93E-02  MA Light Rain 8.97E-03 1.06E-02 1.28E-01 7.29E-03  MA Mod/Hvy Rain 0.00E+00 1.49E-04 8.25E-03 0.00E+00  MA Light Snow 0.00E+00 1.49E-04 3.43E-02 7.77E-04  MA Mod/Hvy Snow 0.00E+00 0.00E+00 2.06E-03 0.00E+00  MA All 8.97E-03 1.09E-02 1.73E-01 8.06E-03  ME Light Rain 2.77E-03 9.46E-03 1.52E-01 9.49E-03  ME Mod/Hvy Rain 0.00E+00 1.96E-03 6.33E-02 3.99E-03  ME Mod/Hvy Snow 0.00E+00 0.00E+00 4.62E-03 1.08E-04  ME All 2.77E-03 1.15E-02 2.27E-01 1.39E-02  MI Light Rain 5.16E-03 1.22E-02 1.18E-01 9.58E-03  MI Light Rain 0.00E+00 1.33E-04 5.05E-03 9.30E-05	LA Mod/Hvy Snow 0.00E+00 0.00E+00 5.27E-05 0.00E+00 0.00E+00  LA All 2.11E-02 2.53E-02 1.49E-01 1.93E-02 3.58E-03  MA Light Rain 8.97E-03 1.06E-02 1.28E-01 7.29E-03 2.97E-03  MA Mod/Hvy Rain 0.00E+00 1.49E-04 8.25E-03 0.00E+00 0.00E+00  MA Light Snow 0.00E+00 1.49E-04 3.43E-02 7.77E-04 0.00E+00  MA Mod/Hvy Snow 0.00E+00 0.00E+00 2.06E-03 0.00E+00 0.00E+00  MA All 8.97E-03 1.09E-02 1.73E-01 8.06E-03 2.97E-03  ME Light Rain 2.77E-03 9.46E-03 1.52E-01 9.49E-03 3.14E-03  ME Mod/Hvy Rain 0.00E+00 1.96E-03 6.33E-02 3.99E-03 1.44E-03  ME Light Snow 0.00E+00 1.96E-03 6.33E-02 3.99E-03 1.44E-03  ME Mod/Hvy Snow 0.00E+00 0.00E+00 4.62E-03 1.08E-04 1.59E-04  ME All 2.77E-03 1.15E-02 2.27E-01 1.39E-02 4.78E-03  MI Light Rain 5.16E-03 1.22E-02 1.18E-01 9.58E-03 1.38E-03  MI Light Rain 5.16E-03 1.22E-02 1.18E-01 9.58E-03 1.38E-03

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Detroit Metropolitan AP	MI	Mod/Hvy Snow	0.00E+00	0.00E+00	1.48E-03	1.86E-04	0.00E+00	9.70E-04
Detroit Metropolitan AP	MI	All	5.16E-03	1.33E-02	1.96E-01	1.14E-02	1.58E-03	1.28E-01
Sault Ste Marie Wx Station Office	MI	Light Rain	4.49E-03	7.87E-03	1.28E-01	6.86E-03	2.61E-03	7.71E-02
Sault Ste Marie Wx Station Office	MI	Mod/Hvy Rain	0.00E+00	1.29E-04	3.81E-03	0.00E+00	0.00E+00	2.25E-03
Sault Ste Marie Wx Station Office	MI	Light Snow	3.37E-03	1.12E-02	1.80E-01	2.62E-02	1.10E-02	1.12E-01
Sault Ste Marie Wx Station Office	MI	Mod/Hvy Snow	0.00E+00	5.16E-04	6.67E-03	1.06E-04	4.80E-04	4.05E-03
Sault Ste Marie Wx Station Office	МІ	All	7.87E-03	1.98E-02	3.19E-01	3.31E-02	1.41E-02	1.95E-01
International Falls AP	MN	Light Rain	7.50E-03	1.30E-02	9.91E-02	1.24E-02	2.11E-03	5.97E-02
International Falls AP	MN	Mod/Hvy Rain	0.00E+00	1.23E-04	1.83E-03	1.93E-04	0.00E+00	1.07E-03
International Falls AP	MN	Light Snow	0.00E+00	3.57E-03	1.77E-01	1.87E-02	3.84E-03	1.04E-01
International Falls AP	MN	Mod/Hvy Snow	3.44E-03	4.80E-03	7.50E-03	1.76E-02	1.46E-02	9.61E-03
International Falls AP	MN	All	1.09E-02	2.15E-02	2.85E-01	4.88E-02	2.06E-02	1.74E-01
Minneapolis-St.Paul International AP	MN	Light Rain	7.98E-03	1.35E-02	8.78E-02	8.86E-03	2.44E-03	5.74E-02
Minneapolis-St.Paul International AP	MN	Mod/Hvy Rain	0.00E+00	0.00E+00	5.11E-03	1.81E-04	0.00E+00	3.20E-03
Minneapolis-St.Paul International AP	MN	Light Snow	6.94E-04	2.04E-03	8.21E-02	6.14E-03	2.27E-03	5.23E-02
Minneapolis-St.Paul	MN	Mod/Hvy Snow	0.00E+00	4.09E-04	2.63E-03	1.90E-03	2.94E-03	2.31E-03

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
International AP								
Minneapolis-St.Paul International AP	MN	All	8.67E-03	1.59E-02	1.78E-01	1.71E-02	7.66E-03	1.15E-01
Kansas City International AP	МО	Light Rain	5.90E-03	1.02E-02	1.03E-01	8.17E-03	2.85E-03	6.26E-02
Kansas City International AP	МО	Mod/Hvy Rain	0.00E+00	0.00E+00	4.25E-03	1.51E-04	0.00E+00	2.49E-03
Kansas City International AP	МО	Light Snow	0.00E+00	0.00E+00	2.79E-02	3.03E-04	8.90E-05	1.62E-02
Kansas City International AP	МО	Mod/Hvy Snow	0.00E+00	0.00E+00	9.05E-04	7.56E-05	4.45E-04	5.93E-04
Kansas City International AP	МО	All	5.90E-03	1.02E-02	1.36E-01	8.70E-03	3.38E-03	8.19E-02
Meridian Naval Air Station	MS	Light Rain	5.93E-03	1.81E-02	1.91E-01	3.69E-02	8.41E-03	6.37E-02
Meridian Naval Air Station	MS	Mod/Hvy Rain	1.14E-03	4.09E-03	4.86E-02	5.61E-03	8.84E-04	1.55E-02
Meridian Naval Air Station	MS	Light Snow	0.00E+00	2.10E-04	3.22E-03	4.01E-04	0.00E+00	9.86E-04
Meridian Naval Air Station	MS	Mod/Hvy Snow	0.00E+00	0.00E+00	5.79E-04	0.00E+00	0.00E+00	1.70E-04
Meridian Naval Air Station	MS	All	7.07E-03	2.24E-02	2.43E-01	4.29E-02	9.30E-03	8.03E-02
Billings Logan International AP	МТ	Light Rain	2.22E-03	4.55E-03	5.92E-02	5.18E-03	9.00E-04	3.77E-02
Billings Logan	MT	Mod/Hvy Rain	0.00E+00	0.00E+00	1.43E-03	0.00E+00	0.00E+00	8.79E-04

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
International AP		, ,,						
Billings Logan International AP	MT	Light Snow	0.00E+00	2.16E-03	8.44E-02	5.99E-03	3.60E-03	5.31E-02
Billings Logan International AP	MT	Mod/Hvy Snow	6.06E-04	5.69E-04	2.34E-03	1.62E-03	1.41E-03	1.88E-03
Billings Logan International AP	MT	All	2.83E-03	7.28E-03	1.47E-01	1.28E-02	5.91E-03	9.36E-02
Missoula Johnson-Bell Field	MT	Light Rain	1.78E-03	1.02E-02	1.05E-01	1.03E-02	1.40E-03	5.28E-02
Missoula Johnson-Bell Field	MT	Mod/Hvy Rain	0.00E+00	0.00E+00	1.86E-03	0.00E+00	0.00E+00	8.90E-04
Missoula Johnson-Bell Field	MT	Light Snow	5.56E-04	4.64E-03	9.16E-02	5.52E-03	3.09E-03	4.55E-02
Missoula Johnson-Bell Field	MT	Mod/Hvy Snow	0.00E+00	5.01E-04	9.31E-04	3.45E-04	9.47E-04	7.42E-04
Missoula Johnson-Bell Field	MT	All	2.33E-03	1.53E-02	2.00E-01	1.62E-02	5.43E-03	1.00E-01
Asheville Regional AP	NC	Light Rain	7.83E-03	1.44E-02	1.75E-01	1.88E-02	5.20E-03	9.12E-02
Asheville Regional AP	NC	Mod/Hvy Rain	1.37E-04	2.23E-04	1.11E-02	0.00E+00	0.00E+00	5.50E-03
Asheville Regional AP	NC	Light Snow	0.00E+00	1.12E-04	1.99E-02	7.45E-04	1.06E-04	9.89E-03
Asheville Regional AP	NC	Mod/Hvy Snow	0.00E+00	0.00E+00	9.73E-04	0.00E+00	0.00E+00	4.79E-04
Asheville Regional AP	NC	All	7.96E-03	1.47E-02	2.06E-01	1.96E-02	5.31E-03	1.07E-01
Raleigh-Durham AP	NC	Light Rain	5.27E-03	9.12E-03	1.76E-01	1.78E-02	3.99E-03	8.16E-02
Raleigh-Durham AP	NC	Mod/Hvy Rain	0.00E+00	0.00E+00	1.74E-02	1.56E-04	5.12E-05	7.60E-03

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Raleigh-Durham AP	NC	Light Snow	0.00E+00	0.00E+00	6.08E-03	0.00E+00	0.00E+00	2.65E-03
Raleigh-Durham AP	NC	Mod/Hvy Snow	0.00E+00	0.00E+00	6.81E-04	0.00E+00	0.00E+00	2.97E-04
Raleigh-Durham AP	NC	All	5.27E-03	9.12E-03	2.00E-01	1.80E-02	4.04E-03	9.22E-02
Bismark Municipal AP	ND	Light Rain	6.37E-03	1.55E-02	7.00E-02	1.17E-02	2.21E-03	4.20E-02
Bismark Municipal AP	ND	Mod/Hvy Rain	0.00E+00	4.86E-04	4.18E-03	0.00E+00	1.20E-04	2.36E-03
Bismark Municipal AP	ND	Light Snow	5.10E-04	3.16E-03	1.22E-01	9.11E-03	2.75E-03	6.86E-02
Bismark Municipal AP	ND	Mod/Hvy Snow	1.02E-02	1.11E-02	1.65E-02	1.67E-02	2.12E-02	1.66E-02
Bismark Municipal AP	ND	All	1.71E-02	3.02E-02	2.12E-01	3.76E-02	2.62E-02	1.30E-01
North Platte Lee Bird Field AP	NE	Light Rain	2.58E-03	5.25E-03	7.76E-02	7.09E-03	1.43E-03	4.23E-02
North Platte Lee Bird Field AP	NE	Mod/Hvy Rain	0.00E+00	1.12E-04	5.11E-03	8.35E-05	0.00E+00	2.68E-03
North Platte Lee Bird Field AP	NE	Light Snow	2.35E-04	7.82E-04	7.05E-02	3.25E-03	8.94E-04	3.75E-02
North Platte Lee Bird Field AP	NE	Mod/Hvy Snow	0.00E+00	0.00E+00	3.22E-03	0.00E+00	5.96E-05	1.69E-03
North Platte Lee Bird Field AP	NE	All	2.82E-03	6.14E-03	1.56E-01	1.04E-02	2.38E-03	8.41E-02
Albuquerque International AP	NM	Light Rain	1.77E-03	5.51E-03	7.46E-02	9.66E-03	8.61E-04	2.82E-02
Albuquerque International AP	NM	Mod/Hvy Rain	0.00E+00	1.75E-04	3.48E-03	4.20E-04	0.00E+00	1.28E-03
Albuquerque International AP	NM	Light Snow	0.00E+00	6.12E-04	2.53E-02	2.80E-04	5.06E-05	8.76E-03

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Albuquerque International AP	NM	Mod/Hvy Snow	0.00E+00	0.00E+00	7.43E-04	0.00E+00	0.00E+00	2.53E-04
Albuquerque International AP	NM	All	1.77E-03	6.29E-03	1.04E-01	1.04E-02	9.11E-04	3.84E-02
Las Vegas McCarran International AP	NV	Light Rain	9.81E-04	3.91E-03	4.30E-02	3.28E-03	9.43E-04	1.74E-02
Las Vegas McCarran International AP	NV	Mod/Hvy Rain	0.00E+00	0.00E+00	1.24E-03	5.65E-05	0.00E+00	4.68E-04
Las Vegas McCarran International AP	NV	Light Snow	0.00E+00	0.00E+00	6.18E-04	0.00E+00	0.00E+00	2.28E-04
Las Vegas McCarran International AP	NV	Mod/Hvy Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Las Vegas McCarran International AP	NV	All	9.81E-04	3.91E-03	4.49E-02	3.33E-03	9.43E-04	1.81E-02
Reno Cannon International AP	NV	Light Rain	1.39E-03	6.67E-03	7.25E-02	7.95E-03	1.54E-03	2.51E-02
Reno Cannon International AP	NV	Mod/Hvy Rain	0.00E+00	1.99E-04	2.22E-03	9.58E-05	0.00E+00	7.30E-04
Reno Cannon International AP	NV	Light Snow	7.70E-05	3.68E-03	4.42E-02	4.50E-03	7.88E-04	1.51E-02
Reno Cannon International AP	NV	Mod/Hvy Snow	7.70E-05	3.98E-04	3.64E-03	1.92E-04	1.13E-04	1.26E-03
Reno Cannon International AP	NV	All	1.54E-03	1.09E-02	1.23E-01	1.27E-02	2.44E-03	4.22E-02
Binghamton Link Field AP	NY	Light Rain	3.84E-03	1.02E-02	1.33E-01	7.93E-03	2.06E-03	8.81E-02

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Binghamton Link Field AP	NY	Mod/Hvy Rain	0.00E+00	1.36E-04	8.48E-03	0.00E+00	0.00E+00	5.50E-03
Binghamton Link Field AP	NY	Light Snow	0.00E+00	1.90E-03	1.43E-01	1.39E-02	5.96E-03	9.53E-02
Binghamton Link Field AP	NY	Mod/Hvy Snow	0.00E+00	4.07E-04	2.66E-03	1.67E-04	2.29E-04	1.80E-03
Binghamton Link Field AP	NY	All	3.84E-03	1.26E-02	2.87E-01	2.20E-02	8.25E-03	1.91E-01
Buffalo Greater International AP	NY	Light Rain	6.79E-03	1.32E-02	1.46E-01	1.76E-02	2.79E-03	1.01E-01
Buffalo Greater International AP	NY	Mod/Hvy Rain	0.00E+00	1.40E-04	9.20E-03	1.97E-04	0.00E+00	6.16E-03
Buffalo Greater International AP	NY	Light Snow	1.02E-03	6.46E-03	1.40E-01	1.39E-02	7.14E-03	9.60E-02
Buffalo Greater International AP	NY	Mod/Hvy Snow	0.00E+00	0.00E+00	3.73E-03	7.89E-04	7.80E-04	2.66E-03
Buffalo Greater International AP	NY	All	7.81E-03	1.98E-02	2.99E-01	3.25E-02	1.07E-02	2.06E-01
New York JFK International AP	NY	Light Rain	6.33E-03	7.93E-03	1.27E-01	1.15E-02	5.24E-03	8.43E-02
New York JFK International AP	NY	Mod/Hvy Rain	0.00E+00	1.09E-04	9.63E-03	0.00E+00	1.25E-04	6.19E-03
New York JFK International AP	NY	Light Snow	0.00E+00	1.09E-04	1.90E-02	4.24E-04	0.00E+00	1.22E-02
New York JFK International AP	NY	Mod/Hvy Snow	0.00E+00	0.00E+00	7.85E-04	0.00E+00	0.00E+00	5.02E-04

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
New York JFK International AP	NY	All	6.33E-03	8.14E-03	1.56E-01	1.19E-02	5.36E-03	1.03E-01
Dayton Cox International AP	ОН	Light Rain	6.28E-03	1.47E-02	1.55E-01	2.00E-02	3.89E-03	8.98E-02
Dayton Cox International AP	ОН	Mod/Hvy Rain	0.00E+00	2.37E-04	1.04E-02	3.43E-04	1.39E-04	5.77E-03
Dayton Cox International AP	ОН	Light Snow	0.00E+00	7.11E-04	8.18E-02	4.37E-03	9.73E-04	4.55E-02
Dayton Cox International AP	ОН	Mod/Hvy Snow	1.90E-04	0.00E+00	1.57E-03	6.85E-04	6.95E-05	9.70E-04
Dayton Cox International AP	ОН	All	6.47E-03	1.56E-02	2.49E-01	2.54E-02	5.08E-03	1.42E-01
Medford Jackson County AP	OR	Light Rain	2.51E-03	1.77E-02	2.06E-01	3.45E-02	6.63E-03	7.71E-02
Medford Jackson County AP	OR	Mod/Hvy Rain	0.00E+00	0.00E+00	3.70E-03	1.34E-04	3.59E-05	1.28E-03
Medford Jackson County AP	OR	Light Snow	7.60E-05	2.13E-03	1.49E-02	2.41E-03	1.11E-03	5.85E-03
Medford Jackson County AP	OR	Mod/Hvy Snow	7.60E-05	0.00E+00	1.01E-04	0.00E+00	3.59E-05	5.71E-05
Medford Jackson County AP	OR	All	2.66E-03	1.98E-02	2.24E-01	3.70E-02	7.82E-03	8.43E-02
Pendelton Municipal AP	OR	Light Rain	2.11E-03	9.31E-03	1.21E-01	1.31E-02	3.74E-03	5.54E-02
Pendelton Municipal AP	OR	Mod/Hvy Rain	0.00E+00	0.00E+00	3.48E-03	0.00E+00	0.00E+00	1.49E-03
Pendelton Municipal AP	OR	Light Snow	0.00E+00	7.68E-04	4.57E-02	9.09E-04	5.06E-04	1.98E-02

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Pendelton Municipal AP	OR	Mod/Hvy Snow	0.00E+00	9.60E-05	1.05E-03	4.54E-04	3.03E-04	5.83E-04
Pendelton Municipal AP	OR	All	2.11E-03	1.02E-02	1.71E-01	1.44E-02	4.55E-03	7.72E-02
Pittsburgh-Greater International AP	PA	Light Rain	1.13E-03	5.22E-03	1.53E-01	9.24E-03	2.14E-03	9.00E-02
Pittsburgh-Greater International AP	PA	Mod/Hvy Rain	0.00E+00	0.00E+00	1.01E-02	1.99E-04	0.00E+00	5.82E-03
Pittsburgh-Greater International AP	PA	Light Snow	6.77E-04	1.43E-03	1.10E-01	6.26E-03	1.13E-03	6.43E-02
Pittsburgh-Greater International AP	PA	Mod/Hvy Snow	0.00E+00	1.30E-04	2.75E-03	5.96E-04	0.00E+00	1.67E-03
Pittsburgh-Greater International AP	PA	All	1.81E-03	6.78E-03	2.75E-01	1.63E-02	3.27E-03	1.62E-01
Rapid City Regional AP	SD	Light Rain	4.01E-03	7.74E-03	7.46E-02	4.81E-03	5.55E-04	4.25E-02
Rapid City Regional AP	SD	Mod/Hvy Rain	0.00E+00	1.07E-04	2.22E-03	0.00E+00	6.93E-05	1.23E-03
Rapid City Regional AP	SD	Light Snow	0.00E+00	2.15E-03	1.06E-01	3.97E-03	2.29E-03	5.88E-02
Rapid City Regional AP	SD	Mod/Hvy Snow	1.00E-03	7.52E-04	6.59E-03	2.14E-03	1.59E-03	4.29E-03
Rapid City Regional AP	SD	All	5.01E-03	1.07E-02	1.89E-01	1.09E-02	4.51E-03	1.07E-01
Nashville Metropolitan AP	TN	Light Rain	3.00E-03	8.64E-03	1.53E-01	1.80E-02	4.40E-03	7.16E-02
Nashville Metropolitan AP	TN	Mod/Hvy Rain	2.73E-04	1.88E-04	1.36E-02	5.95E-04	5.50E-05	6.06E-03
Nashville Metropolitan AP	TN	Light Snow	0.00E+00	0.00E+00	1.57E-02	5.21E-04	0.00E+00	6.89E-03
Nashville Metropolitan	TN	Mod/Hvy Snow	1.36E-04	0.00E+00	6.84E-04	0.00E+00	0.00E+00	3.08E-04

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
AP								
Nashville Metropolitan AP	TN	All	3.41E-03	8.83E-03	1.83E-01	1.91E-02	4.45E-03	8.48E-02
Austin Mueller Municipal AP	TX	Light Rain	8.28E-03	1.01E-02	1.23E-01	1.43E-02	3.53E-03	6.37E-02
Austin Mueller Muncipal AP	TX	Mod/Hvy Rain	1.53E-04	1.91E-04	1.09E-02	5.10E-04	1.20E-04	5.35E-03
Austin Mueller Muncipal AP	TX	Light Snow	0.00E+00	0.00E+00	2.09E-03	0.00E+00	0.00E+00	1.00E-03
Austin Mueller Muncipal AP	TX	Mod/Hvy Snow	0.00E+00	0.00E+00	4.74E-05	0.00E+00	0.00E+00	2.28E-05
Austin Mueller Muncipal AP	TX	All	8.44E-03	1.03E-02	1.36E-01	1.48E-02	3.65E-03	7.00E-02
Corpus Christi NAAS	TX	Light Rain	1.37E-02	1.27E-02	8.16E-02	7.33E-03	6.20E-03	5.15E-02
Corpus Christi NAAS	TX	Mod/Hvy Rain	1.05E-03	1.10E-03	1.14E-02	5.79E-04	3.00E-04	6.96E-03
Corpus Christi NAAS	TX	Light Snow	0.00E+00	0.00E+00	1.92E-04	0.00E+00	0.00E+00	1.12E-04
Corpus Christi NAAS	TX	Mod/Hvy Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Corpus Christi NAAS	TX	All	1.47E-02	1.38E-02	9.32E-02	7.91E-03	6.50E-03	5.86E-02
Dallas Hensley Field NAS	TX	Light Rain	1.25E-04	8.11E-04	4.54E-03	1.05E-04	0.00E+00	2.08E-03
Dallas Hensley Field NAS	TX	Mod/Hvy Rain	7.50E-04	1.16E-03	1.68E-02	1.05E-03	3.19E-04	7.66E-03
Dallas Hensley Field NAS	TX	Light Snow	0.00E+00	0.00E+00	4.94E-04	0.00E+00	0.00E+00	2.14E-04

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Dallas Hensley Field NAS	TX	Mod/Hvy Snow	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Dallas Hensley Field NAS	TX	All	8.75E-04	1.97E-03	2.18E-02	1.16E-03	3.19E-04	9.96E-03
El Paso International AP	TX	Light Rain	2.20E-03	6.68E-03	8.39E-02	1.43E-02	3.12E-03	2.62E-02
El Paso International AP	TX	Mod/Hvy Rain	0.00E+00	7.68E-05	5.11E-03	6.73E-05	0.00E+00	1.34E-03
El Paso International AP	TX	Light Snow	7.59E-05	1.54E-04	1.15E-02	6.06E-04	0.00E+00	3.09E-03
El Paso International AP	TX	Mod/Hvy Snow	0.00E+00	0.00E+00	9.33E-04	0.00E+00	0.00E+00	2.40E-04
El Paso International AP	TX	All	2.28E-03	6.91E-03	1.01E-01	1.50E-02	3.12E-03	3.08E-02
Lubbock International AP	TX	Light Rain	4.86E-03	3.72E-03	6.29E-02	3.72E-03	7.55E-04	3.92E-02
Lubbock International AP	TX	Mod/Hvy Rain	3.47E-04	1.10E-04	3.97E-03	6.76E-05	0.00E+00	2.43E-03
Lubbock International AP	TX	Light Snow	0.00E+00	0.00E+00	1.36E-02	6.76E-05	0.00E+00	8.21E-03
Lubbock International AP	TX	Mod/Hvy Snow	0.00E+00	0.00E+00	7.19E-04	6.76E-05	0.00E+00	4.45E-04
Lubbock International AP	TX	All	5.21E-03	3.83E-03	8.12E-02	3.92E-03	7.55E-04	5.03E-02
Cedar City Municipal AP	UT	Light Rain	1.80E-03	5.31E-03	6.34E-02	4.14E-03	1.61E-03	2.43E-02
Cedar City Municipal AP	UT	Mod/Hvy Rain	0.00E+00	0.00E+00	1.30E-03	0.00E+00	0.00E+00	4.60E-04
Cedar City Municipal AP	UT	Light Snow	4.00E-04	2.82E-03	7.83E-02	3.35E-03	2.08E-03	2.91E-02
					I	I		

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Cedar City Municipal AP	UT	Mod/Hvy Snow	4.00E-04	1.08E-04	5.19E-03	3.52E-04	3.13E-04	2.04E-03
Cedar City Municipal AP	UT	All	2.60E-03	8.24E-03	1.48E-01	7.84E-03	3.99E-03	5.59E-02
Salt Lake City International AP	UT	Light Rain	1.85E-03	6.22E-03	8.42E-02	5.66E-03	1.88E-03	4.12E-02
Salt Lake City International AP	UT	Mod/Hvy Rain	1.85E-04	2.59E-04	5.28E-03	6.36E-05	0.00E+00	2.50E-03
Salt Lake City International AP	UT	Light Snow	2.22E-03	2.16E-03	7.26E-02	4.07E-03	2.85E-03	3.52E-02
Salt Lake City International AP	UT	Mod/Hvy Snow	0.00E+00	2.59E-04	5.99E-03	1.27E-04	4.17E-04	2.90E-03
Salt Lake City International AP	UT	All	4.26E-03	8.90E-03	1.68E-01	9.92E-03	5.15E-03	8.18E-02
Norfolk Naval Air Station	VA	Light Rain	3.08E-03	1.13E-02	1.46E-01	1.24E-02	5.73E-03	8.07E-02
Norfolk Naval Air Station	VA	Mod/Hvy Rain	1.93E-04	6.53E-04	2.02E-02	1.24E-03	3.45E-04	1.09E-02
Norfolk Naval Air Station	VA	Light Snow	1.93E-04	0.00E+00	7.33E-03	3.09E-04	6.91E-05	3.92E-03
Norfolk Naval Air Station	VA	Mod/Hvy Snow	0.00E+00	0.00E+00	1.38E-03	0.00E+00	0.00E+00	7.25E-04
Norfolk Naval Air Station	VA	All	3.47E-03	1.20E-02	1.75E-01	1.39E-02	6.15E-03	9.63E-02
Burlington International AP	VT	Light Rain	4.87E-03	1.19E-02	1.28E-01	1.43E-02	2.87E-03	8.41E-02
Burlington International AP	VT	Mod/Hvy Rain	3.25E-04	0.00E+00	6.21E-03	0.00E+00	0.00E+00	3.94E-03
Burlington International AP	VT	Light Snow	6.50E-04	3.24E-03	9.90E-02	1.02E-02	3.42E-03	6.44E-02
Burlington International	VT	Mod/Hvy Snow	0.00E+00	0.00E+00	4.98E-03	4.52E-04	7.77E-04	3.31E-03

State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
VT	All	5.85E-03	1.51E-02	2.38E-01	2.50E-02	7.07E-03	1.56E-01
WA	Light Rain	4.93E-03	1.03E-02	2.14E-01	1.13E-02	4.37E-03	1.32E-01
WA	Mod/Hvy Rain	0.00E+00	0.00E+00	4.47E-03	0.00E+00	0.00E+00	2.68E-03
WA	Light Snow	0.00E+00	0.00E+00	7.17E-03	2.47E-04	0.00E+00	4.34E-03
WA	Mod/Hvy Snow	0.00E+00	0.00E+00	3.99E-04	0.00E+00	0.00E+00	2.40E-04
WA	All	4.93E-03	1.03E-02	2.26E-01	1.16E-02	4.37E-03	1.39E-01
WI	Light Rain	3.86E-03	8.76E-03	1.06E-01	1.05E-02	2.98E-03	6.21E-02
WI	Mod/Hvy Rain	0.00E+00	0.00E+00	2.73E-03	0.00E+00	0.00E+00	1.52E-03
WI	Light Snow	2.76E-04	1.71E-03	8.79E-02	6.59E-03	1.22E-03	5.02E-02
WI	Mod/Hvy Snow	0.00E+00	2.28E-04	2.71E-03	0.00E+00	0.00E+00	1.53E-03
WI	All	4.14E-03	1.07E-02	2.00E-01	1.71E-02	4.20E-03	1.15E-01
WV	Light Rain	4.98E-03	1.36E-02	1.95E-01	2.76E-02	3.50E-03	9.46E-02
WV	Mod/Hvy Rain	0.00E+00	0.00E+00	6.33E-03	8.69E-05	0.00E+00	2.88E-03
	WA WA WA WA WA WI WI WI WI WI WI WV	VT All  WA Light Rain  WA Mod/Hvy Rain  WA Light Snow  WA Mod/Hvy Snow  WA All  WI Light Rain  WI Light Rain  WI Mod/Hvy Rain  WI Mod/Hvy Rain  WI Light Snow  WI Light Snow  ULight Snow  WI Light Rain  WI Light Rain  WI Light Rain	VT       All       5.85E-03         WA       Light Rain       4.93E-03         WA       Mod/Hvy Rain       0.00E+00         WA       Light Snow       0.00E+00         WA       Mod/Hvy Snow       0.00E+00         WA       All       4.93E-03         WI       Light Rain       3.86E-03         WI       Mod/Hvy Rain       0.00E+00         WI       Light Snow       2.76E-04         WI       Mod/Hvy Snow       0.00E+00         WI       All       4.14E-03         WV       Light Rain       4.98E-03	VT         All         5.85E-03         1.51E-02           WA         Light Rain         4.93E-03         1.03E-02           WA         Mod/Hvy Rain         0.00E+00         0.00E+00           WA         Light Snow         0.00E+00         0.00E+00           WA         Mod/Hvy Snow         0.00E+00         0.00E+00           WA         All         4.93E-03         1.03E-02           WI         Light Rain         3.86E-03         8.76E-03           WI         Mod/Hvy Rain         0.00E+00         0.00E+00           WI         Light Snow         2.76E-04         1.71E-03           WI         Mod/Hvy Snow         0.00E+00         2.28E-04           WI         All         4.14E-03         1.07E-02           WV         Light Rain         4.98E-03         1.36E-02	VT         All         5.85E-03         1.51E-02         2.38E-01           WA         Light Rain         4.93E-03         1.03E-02         2.14E-01           WA         Mod/Hvy Rain         0.00E+00         0.00E+00         4.47E-03           WA         Light Snow         0.00E+00         0.00E+00         7.17E-03           WA         Mod/Hvy Snow         0.00E+00         0.00E+00         3.99E-04           WA         All         4.93E-03         1.03E-02         2.26E-01           WI         Light Rain         3.86E-03         8.76E-03         1.06E-01           WI         Mod/Hvy Rain         0.00E+00         0.00E+00         2.73E-03           WI         Light Snow         2.76E-04         1.71E-03         8.79E-02           WI         Mod/Hvy Snow         0.00E+00         2.28E-04         2.71E-03           WI         All         4.14E-03         1.07E-02         2.00E-01           WV         Light Rain         4.98E-03         1.36E-02         1.95E-01	VT         All         5.85E-03         1.51E-02         2.38E-01         2.50E-02           WA         Light Rain         4.93E-03         1.03E-02         2.14E-01         1.13E-02           WA         Mod/Hvy Rain         0.00E+00         0.00E+00         4.47E-03         0.00E+00           WA         Light Snow         0.00E+00         0.00E+00         7.17E-03         2.47E-04           WA         Mod/Hvy Snow         0.00E+00         0.00E+00         3.99E-04         0.00E+00           WA         All         4.93E-03         1.03E-02         2.26E-01         1.16E-02           WI         Light Rain         3.86E-03         8.76E-03         1.06E-01         1.05E-02           WI         Mod/Hvy Rain         0.00E+00         0.00E+00         2.73E-03         0.00E+00           WI         Light Snow         2.76E-04         1.71E-03         8.79E-02         6.59E-03           WI         Mod/Hvy Snow         0.00E+00         2.28E-04         2.71E-03         0.00E+00           WI         All         4.14E-03         1.07E-02         2.00E-01         1.71E-02           WV         Light Rain         4.98E-03         1.36E-02         1.95E-01         2.76E-02 <td>VT         All         5.85E-03         1.51E-02         2.38E-01         2.50E-02         7.07E-03           WA         Light Rain         4.93E-03         1.03E-02         2.14E-01         1.13E-02         4.37E-03           WA         Mod/Hvy Rain         0.00E+00         0.00E+00         4.47E-03         0.00E+00         0.00E+00           WA         Light Snow         0.00E+00         0.00E+00         7.17E-03         2.47E-04         0.00E+00           WA         Mod/Hvy Snow         0.00E+00         0.00E+00         3.99E-04         0.00E+00         0.00E+00           WI         Light Rain         3.86E-03         1.03E-02         2.26E-01         1.16E-02         4.37E-03           WI         Mod/Hvy Rain         0.00E+00         0.00E+00         2.73E-03         0.00E+00         0.00E+00           WI         Light Snow         2.76E-04         1.71E-03         8.79E-02         6.59E-03         1.22E-03           WI         Mod/Hvy Snow         0.00E+00         2.28E-04         2.71E-03         0.00E+00         0.00E+00           WI         All         4.14E-03         1.07E-02         2.00E-01         1.71E-02         4.20E-03           WV         Light Rain         4.98E-03</td>	VT         All         5.85E-03         1.51E-02         2.38E-01         2.50E-02         7.07E-03           WA         Light Rain         4.93E-03         1.03E-02         2.14E-01         1.13E-02         4.37E-03           WA         Mod/Hvy Rain         0.00E+00         0.00E+00         4.47E-03         0.00E+00         0.00E+00           WA         Light Snow         0.00E+00         0.00E+00         7.17E-03         2.47E-04         0.00E+00           WA         Mod/Hvy Snow         0.00E+00         0.00E+00         3.99E-04         0.00E+00         0.00E+00           WI         Light Rain         3.86E-03         1.03E-02         2.26E-01         1.16E-02         4.37E-03           WI         Mod/Hvy Rain         0.00E+00         0.00E+00         2.73E-03         0.00E+00         0.00E+00           WI         Light Snow         2.76E-04         1.71E-03         8.79E-02         6.59E-03         1.22E-03           WI         Mod/Hvy Snow         0.00E+00         2.28E-04         2.71E-03         0.00E+00         0.00E+00           WI         All         4.14E-03         1.07E-02         2.00E-01         1.71E-02         4.20E-03           WV         Light Rain         4.98E-03

Station Name	State	Precip Type	Stab A-B	Stab C	Stab D	Stab E	Stab F-G	All Stab
Huntington Tri-City AP	WV	Light Snow	0.00E+00	1.34E-03	7.09E-02	3.74E-03	0.00E+00	3.27E-02
Huntington Tri-City AP	WV	Mod/Hvy Snow	0.00E+00	0.00E+00	3.39E-03	0.00E+00	5.07E-05	1.55E-03
Huntington Tri-City AP	WV	All	4.98E-03	1.49E-02	2.76E-01	3.15E-02	3.55E-03	1.32E-01
Lander Hunt Field AP	WY	Light Rain	2.14E-03	4.53E-03	7.72E-02	2.24E-03	4.07E-04	2.54E-02
Lander Hunt Field AP	WY	Mod/Hvy Rain	0.00E+00	0.00E+00	1.76E-03	6.80E-05	0.00E+00	5.61E-04
Lander Hunt Field AP	WY	Light Snow	7.41E-04	3.29E-03	1.40E-01	5.30E-03	2.90E-03	4.58E-02
Lander Hunt Field AP	WY	Mod/Hvy Snow	3.29E-04	3.55E-04	8.97E-03	2.72E-04	3.62E-04	3.02E-03
Lander Hunt Field AP	WY	All	3.21E-03	8.17E-03	2.28E-01	7.89E-03	3.67E-03	7.48E-02

## APPENDIX D

## STABILITY DISTRIBUTIONS FOR SELECT UNITED STATES STATIONS

## APPENDIX D STABILITY DISTRIBUTIONS FOR SELECT UNITED STATES STATIONS

A compact method of storing meteorological information is use of STability ARray (STAR) format files. This type of file format is described in Section 4.4.5.

A large database of STAR files was provided for the GENII Version 2 development by Mr. Barry Parks, US Department of Energy. These STAR files are provided in a subdirectory under FRAMES when the GENII package is installed. Each of these files has 6 windspeeds; the standard 1-3 knot, 3-6 knot, 6-10 knot, 10-16 knot, 17-21 knot, and 21+ knots grouping. Depending on the manner in which the data were collected, the number of stability classes represented may range from 5 (A-E) through 7 (A-G). The data available in this collection are listed in Table C.1. All file names end with the extension \*.STR.

Table C.1. STAR files available with the GENII Version 2 installation package.

City	State	Dates	File Name
ANCHORAGE	AK	65/1-69/12	XXX0372
BARTER ISLAND	AK	68/1-77/12	XXX1517
BIG DELTA	AK	67/1-71/12	XXX1317 XXX0370
CORDOVA	AK	59/1-62/12	XXX0627
EIELSON	AK	61/1-70/12	XXX0527 XXX0536
FAIRBANKS	AK	61/1-70/12	XXX0530
GULKANA	AK	67/1-71/12	XXX0371
JUNEAU	AK	74/1-74/12	XXX1337
KENAI	AK	66/1-70/12	XXX0373
MIDDLETON ISLAND	AK	59/1-62/12	XXX0626
NENANA	AK	64/1-68/12	XXX1479
SUMMIT	AK	64/1-68/12	XXX1478
ANNISTON	AL	49/1-54/12	ANB0118
BIRMINGHAM	AL	72/1-76/12	BHM1387
CAIRNS FIELD	AL	65/1-69/12	SIR0937
CRAIG	AL	54/1-58/12	SEM0114
HUNTSVILLE	AL	60/1-64/12	HSV0544
MOBILE	AL	66/1-70/12	MOB0144
MONTGOMERY	AL	60/1-64/12	MGM1320
TUSCALOOSA	AL	49/1-54/12	TCL1083
EL DORADO	AR	50/1-54/12	ELD0547
LITTLE ROCK	AR	55/1-64/12	LIT0516
TEXARKANA	AR	63/1-67/12	TXK1043
DOUGLAS	AZ	50/1-54/12	DUG0376
PHOENIX	AZ	55/1-64/12	PNX0309
PRESCOTT	AZ	67/1-71/12	PRC0311
TUCSON	AZ	59/1-63/12	TUS0296
WINSLOW	AZ	49/1-54/12	INW0314
YUMA	AZ	67/1-71/12	YUM0315
ALAMEDA	CA	60/1-64/12	NGZ0322
ARCATA	CA	68/1-72/12	ACV1443
BAKERSFIELD	CA	67/1-71/12	BFL0292
BISHOP	CA	60/1-64/12	BIH0894
BLYTHE	CA	69/9-74/8	BLH0810
CHINA LAKE INYOKE	CA	54/1-63/12	NID0840

DAGGET/SAN BERNA	CA	55/1-64/12	DAG0300
EDWARDS	CA	66/1-70/12	EDW0852
EL CENTRO	CA	55/1-58/12	IPL1455
FRESNO	CA	60/1-64/12	FAT1213
HOLLYWOOD-BURBANK	CA	60/1-64/12	BUR1051
LONG BEACH	CA	60/1-64/12	LGB1052
LOS ALAMITOS	CA	65/1-69/12	SLI1053
LOS ANGELES	CA	64/5-69/4	LAX0304
LOS ANGELES	CA	55/1-64/12	LAX0587
MARCH	CA	66/1-70/12	RIV0930
MOFFET FIELD	CA	60/1-64/12	NUQ1056
MONTEREY	CA	59/1-63/12	MRY1456
NEEDLES	CA	69/9-74/8	EED0811
NORTON	CA	66/1-70/12	SBD1344
OAKLAND	CA	60/1-64/12	OAK0319
OXNARD	CA	60/1-64/12	OXR0704
POINT ARGUELLO	CA	60/1-64/6	PSU0938
POINT MUGU	CA	60/1-64/12	NTD0705
RED BLUFF	CA	72/1-76/12	RBL1415
SACRAMENTO	CA	66/1-70/12	SAC0320
SAN DIEGO	CA	67/1-71/12	NZY0380
SAN DIEGO SAN FRANCISCO	CA	69/1-73/12	SF01122
SAN RAFAEL/HAMILT	CA		SRF0318
- ,		66/1-70/12	
SANTA BARBARA	CA	60/1-64/12	SBA0313
SANTA MARIA	CA	49/1-53/12	SMX0750
STOCKTON	CA	72/1-76/12	SCK1465
TRAVIS	CA	60/1-64/12	SUU0316
TUSTIN	CA	72/1-76/12	SNA1467
UKIAH	CA	55/1-64/12	UKI0568
VANDENBERG	CA	61/1-70/12	VBE0660
VICTORVILLE/GEORG	CA	58/1-67/12	VCV0289
AKRON	CO	50/1-54/12	AKD0667
ALAMOSA	CO	72/1-76/12	ALS1462
COLORADO SPRINGS	CO	69/1-73/12	COS0573
DENVER	CO	60/1-64/12	DEN0618
DENVER	CO	70/1-74/12	DEN0952
GRAND JUNCTION	CO	60/1-64/12	GJT0476
PUEBLO	CO	66/1-70/12	PUB0564
BRIDGEPORT	CT	65/1-69/12	BDR0558
HARTFORD	CT	55/1-64/12	BDL1262
WILMINGTON	DE	60/1-64/12	ILG1058
CAPE CANAVERAL	${ t FL}$	65/1-69/12	XMR1173
DAYTONA BEACH	${ t FL}$	67/1-71/12	DAB0541
FORT MYERS	${ t FL}$	69/1-73/12	FMY0744
JACKSONVILLE	${ t FL}$	70/1-74/12	JAX1037
MIAMI	${ t FL}$	70/1-74/12	MIA0979
ORLANDO	${ t FL}$	60/1-64/12	XXX0615
PENSACOLA	FL	67/1-71/12	XXX0018
TALLAHASSEE	FL	60/1-64/12	TLH0663
TAMPA	FL	65/1-69/12	TAMPA
TAMPA	FL	60/1-64/12	TPA0662
TAMPA	FL	69/1-73/12	TPA0915
TYNDALL	FL	66/1-70/12	PAM0113
	FL	70/1-70/12	PBI0054
WEST PALM BEACH WHITING	FL	62/1-71/12	XXX0491
ALBANY	GA	69/1-74/4	ABY0721
		125	

AT MA	C7	54/1-58/12	AMB0771
ALMA	GA GA	69/1-73/12	AMB0771 AHN0763
ATHENS	GA GA	67/1-73/12	ATL0121
ATLANTA	GA GA	70/1-71/12	AGS1018
AUGUSTA BRUNSWICK	GA GA	67/1-71/12	SSI0417
COLUMBUS	GA	69/1-73/12	CSG0767
MACON	GA	69/1-73/12	MCN0768
SAVANNAH	GA	66/1-70/12	SAV0012
BARBERS POINT	HI	72/1-76/12	XXX1416
HILO	HI	62/8-67/7	XXX0273
HONOLULU	HI	72/1-76/12	XXX1417
KAHULUI	HI	66/1-70/12	XXX0275
PUUNENE	HI	53/1-57/12	XXX0276
DES MOINES	IA	72/1-72/12	DSM0753
MASON CITY	IA	70/1-74/12	MCW1049
SIOUX CITY	IA	70/1-74/12	SUX1050
WATERLOO	IA	60/1-64/12	ALO0729
BOISE	ID	60/1-64/12	B0I0653
IDAHO FALLS	ID	55/1-64/12	IDH0910
MALAD CITY	ID	48/1-54/12	MLD0909
MOUNTAIN HOME	ID	65/1-69/12	MUO0654
MULLAN PASS	ID	50/1-54/12	MLP1448
POCATELLO	ID	58/1-62/12	PIH0359
BELLEVILLE	$_{ m IL}$	61/1-70/12	BLV0826
CHICAGO	$_{ m IL}$	60/1-64/12	ORD1120
CHICAGO	$_{ m IL}$	70/1-74/12	ORD1247
CHICAGO/MIDWAY	$_{ m IL}$	73/1-73/12	MDW0675
CHICAGO/OHARE	$_{ m IL}$	65/1-69/12	ORD0452
GLENVIEW	$_{ m IL}$	60/1-64/12	XXX0584
L SPRINGFIELD	$_{ m IL}$	67/1-71/12	SPI0415
MOLINE	$_{ m IL}$	67/1-71/12	MLI0269
PEORIA	$_{ m IL}$	73/1-73/12	PIA0644
PEORIA	$_{ m IL}$	65/1-69/12	PIA0716
QUINCY	$_{ m IL}$	50/1-54/12	UIN0422
RANTOUL/CHANUTE AF	$_{ m IL}$	63/1-67/12	RAN0234
ROCKFORD	$_{ m IL}$	70/1-74/12	RFD0866
EVANSVILLE	IN	60/1-64/12	EVV0406
EVANSVILLE	IN	70/1-74/12	EVV1009
FORT WAYNE	IN	60/1-64/12	FWA1156
INDIANAPOLIS	IN	55/1-74/12	IND1080
SOUTH BEND	IN	67/1-71/12	SBN0257
TERRE HAUTE	IN	48/1-54/12	HUF1241
FORT LEAVENWORTH	KS	62/1-70/12	FLV0561
GARDEN CITY	KS	50/1-54/12	GCK0818
GOODLAND	KS	69/1-73/12	GLD0760
TOPEKA	KS	63/1-72/12	TOP0534
WICHITA	KS	63/1-72/12	ICT0604
BOWLING GREEN	KY	50/1-54/12	BWE0402
CORBIN	KY	49/10-54/0	LOZ0005
COVINGTON	KY	58/1-62/12	CVG0403
COVINGTON	KY	70/1-74/12	CVG1916
FORT CAMPBELL	KY	58/1-62/12	XRW0109
FORT KNOX	KY	64/1-68/12	FTK0110
LEXINGTON	KY	55/1-64/12	LEX1327
LOUISVILLE	KY	66/1-70/12	SDF0411
PADUCAH	KY	50/1-54/12	PAH0006
	111	126	111110000

Danidau	7237	60/1 64/12	DAII0470
PADUCAH	KY	60/1-64/12 70/1-73/12	PAH0479 ESF0657
ALEXANDRIA BATON ROUGE	LA LA	55/1-64/12	BTR0166
		54/1-58/12	
LAFAYETTE	LA		LFT0755
LAKE CHARLES	LA	66/1-70/12	LCH0025
MONROE	LA	54/1-58/12	MLU0684
NEW ORLEANS	LA	67/1-71/12	NBG1379
SHREVEPORT	LA	67/1-71/12	SHV0157
U BATON ROUGE	LA	72/1-72/12	BTR0169
BEDFORD	MA	63/1-67/12	BED0181
BOSTON	MA	67/1-71/12	BOS0211
BOSTON	MA	74/5-75/4	BOS1072
BOSTON	MA	66/1-70/12	BOS1123
CHICOPEE FALLS	MA	60/1-64/12	CEF0182
FALMOUTH	MA	60/1-64/12	FMH0642
PITTSFIELD	MA	48/1-53/12	PSF0219
SOUTH WEYMOUTH	MA	70/1-74/12	NZW1144
ABERDEEN	MD	55/1-57/12	APG0072
BALTIMORE	MD	69/1-73/12	BAL1059
FORT MEADE	MD	60/1-64/12	FME1207
FREDERICK	MD	49/1-52/12	MD30756
HAGERSTOWN	MD	74/1-74/12	HER0858
PATUXENT RIVER	MD	75/1-75/12	NHK1306
SALISBURY	MD	49/1-58/12	SBY0590
AUGUSTA/STATE	ME	50/1-54/12	AUG0795
BRUNSWICK	ME	60/1-69/12	NHZ0180
CARIBOU	ME	53/1-62/12	CAR0179
OLD TOWN/DEWITT 1	ME	60/1-64/12	OLD0809
PORTLAND	ME	55/1-64/12	PWM0220
ALPENA	MI	72/1-76/12	APN1413
BATTLE CREEK	MI	50/1-54/12	BTL1460
BENTON HARBOR	MI	74/1-74/12	BEH0853
DETROIT	MI	69/1-73/12	DET0672
DETROIT	MI	63/10-68/9	YIP1061
FLINT	MI	67/3-77/2	FNT1395
GWINN	MI	63/1-67/12	SAW0738
LANSING/CAPITAL C	MI	69/1-73/12	LAN0673
MOUNT CLEMENS	MI	65/1-69/12	MTC1425
MUSKEGON	MI	67/1-71/12	MKG0251
SAGINAW	MI	49/1-54/12	MBS0254
TRAVERSE CI	MI	74/1-74/12	TVC0844
ALEXANDRIA	MN	52/1-54/12	AXN0262
DULUTH	MN	67/1-71/12	DLH0263
INTERNATIONAL FALLS	MN	70/1-74/12	INL1264
MINNEAPOLIS	MN	67/1-71/12	MSP0267
ST CLOUD/WHITNEY	MN	67/1-71/12	STC0995
	MO	64/1-68/12	COU0170
COLUMBIA KANSAS CITY	MO	67/1-71/12	MKC1323
KIRKSVILLE		50/1-54/12	IRK1081
	MO	66/1-70/12	SGF0178
O SPRINGFIELD	MO		
BILOXI	MS	60/1-64/12	BIX0538
COLUMBUS	MS	66/1-70/12	CGM0670
GREENVILLE	MS	55/11-60/1	GLH0153
JACKSON	MS	55/1-64/12	JAN1169
MCCOMB	MS	49/1-54/12	MCB0830
MERIDIAN	MS	66/1-70/12	MEI0115

DIMME	N/CC	FC /1 CO /10	DEN 40 2 F 7
BUTTE	MT	56/1-60/12	BTM0357
CUSTER	MT	48/1-50/5	CUS0512
CUT BANK	MT	49/1-58/12	CTB0616
GLASGOW	MT	70/1-74/12	GGW0974
GREAT FALLS	MT	71/1-75/12	GTF1322
HAVRE	MT	67/1-71/12	HVR0507
HELENA	MT	65/1-74/10	HLN0806
KALISPELL	MT	68/1-72/12	FCA0543
LEWISTOWN	MT	67/1-71/12	LWT0508
MILES CITY	MT	67/1-71/12	MLS0333
MISSOULA	MT	67/1-71/12	MSO0522
ASHEVILLE	NC	66/1-70/12	AVL0001
CAPE HATTERAS	NC	66/1-70/12	HAT0392
CHARLOTTE	NC	69/1-73/12	CLT0682
ELIZABETH CITY	NC	64/1-68/12	ECG1461
FAYETTEVILLE	NC	66/1-70/12	FBG0075
GOLDSBORO	NC	66/1-70/12	GSB0074
GREENSBORO, HIGH POINT	NC	68/1-72/12	GS00529
RALEIGH	NC	66/1-70/12	RDU0083
T CHERRY PT	NC	67/1-71/12	NKT0106
WILMINGTON	NC	66/1-70/12	ILM0104
WINSTON SALEM	NC	60/1-64/12	INT0531
BISMARCK	ND	67/1-71/12	BIS0324
DICKINSON	ND	60/1-64/12	DIK0509
FARGO	ND	67/1-71/12	FAR0994
MINOT	ND	67/1-71/12	MOT0510
WILLISTON	ND	67/1-71/12	ISN0511
GRAND ISLAND	NE	64/1-64/12	GRI1243
LINCOLN	NE	59/1-63/12	LNK1142
NORTH PLATTE	NE	69/1-73/12	LBF0761
OMAHA	NE	55/1-64/12	OMA0991
SCOTTSBLUFF	NE	68/1-72/12	BFF0599
CONCORD	NH	60/1-64/12	CON0787
PORTSMOUTH	NH	69/1-69/12	PSM0034
ATLANTIC CITY	NJ	70/1-74/12	ALY1139
BELMAR	NJ	55/1-59/12	BLM0033
LAKEHURST	NJ	68/1-72/12	NEL0505
MILLVILLE	NJ	50/1-54/12	MIV1000
NEWARK	NJ	55/1-64/12	EWR0195
TETERBORO	NJ	52/1-56/12	TEB0428
WRIGHTSTOWN/MCGUI	NJ	66/1-70/12	WRI0709
ALBUQUERQUE	NM	60/1-64/12	ABO0282
ALBUOUEROUE	NM	75/1-75/12	ABQ1171
CARLSBAD	NM	50/1-54/12	CNM1741
FARMINGTON	NM	63/5-68/4	FMN0285
FARMINGTON	NM	54/1-59/12	FMN0928
FARMINGTON	NM	54/1-64/12	FMN1282
GALLUP	NM	73/1-75/12	GUP1167
GRANTS	NM	54/1-54/12	GNT1246
HOBBS	NM	49/1-54/12	HOB1199
HOLLOMAN	NM	49/1-70/12	HMN1039
LAS CRUCES/WHITE	NM	51/1-55/12	LRU1183
RATON	NM	49/1-51/12	RTN1481
ROSWELL	NM	49/1-51/12	ROW1291
SANTA FE	NM	50/1-54/12	SAF1184
		67/1-71/12	ZUN0378
ZUNI	NM	0// 1 = / 1 / 1 Z	70M02/9

EL VO	NTS 7	60/1 72/12	EROUGES
ELKO	NV	69/1-73/12	EKO0833
ELY	NV	67/1-71/12	ELY0291
FALLON	NV	66/1-70/12	FLX0999
LAS VEGAS	NV	60/1-64/12	LAS1077
LAS VEGAS	NV	58/1-67/12	LSV0658
LOVELOCK	NV	69/1-73/12	LOL0832
RENO	NV	60/1-64/12	RNO1180
WINNEMUCCA	NV	69/1-73/12	WMC0831
YUCCA FLATS	NV	61/12-64/1	UCC1026
ALBANY	NY	60/1-64/12	ALB0523
ALBANY	NY	60/1-64/12	ALB1305
BINGHAMTON	NY	60/1-64/12	BGM0525
BUFFALO	NY	73/1-73/12	BUF0741
DUNKIRK	NY	49/1-53/12	DKK1011
ELMIRA	NY	50/1-54/12	ELM0906
GLENS FALLS	NY	50/1-54/12	GFL0907
GRIFFISS	NY	66/1-70/12	RME0789
HEMPSTEAD	NY	59/1-60/12	XXX1368
MASSENA	NY	67/1-76/12	MSS1524
NY/FT TOTTE	NY	65/1-69/12	LEA0435
PLATTSBURG	NY	66/1-70/12	PBG1012
POUGHKEEPSIE	NY	50/1-54/12	POU0217
ROCHESTER	NY	55/1-64/12	ROC0598
STEWART	NY	65/1-69/12	SWF0185
SYRACUSE	NY	55/1-64/12	SYR0878
UTICA	NY	50/1-54/12	UCA0908
WATERTOWN	NY	60/1-64/12	ART0790
WHITE PLAINS	NY	49/1-53/12	HPN0429
AKRON/AKRON CANTO	OH	70/1-74/12	CAK0934
CLEVELAND	OH	69/1-73/12	CLE0816
CLEVELAND	OH	70/1-74/12	CLE1140
COLUMBUS	OH	60/1-64/12	CMH0243
COLUMBUS	OH	70/1-74/12	CMH1041
COLUMBUS	ОН	70/1-74/12	CMH1090
DAYTON	ОН	65/1-69/12	DAY0404
DAYTON	OH	69/1-73/12	DAY0813
DAYTON	ОН	76/1-76/12	DAY1502
FINDLAY	OH	50/1-54/12	FDY0244
MANSFIELD	OH	70/1-74/12	MFD1092
PERRY	OH	49/1-49/12	IBG0745
TOLEDO	OH	60/1-64/12	TOL0990
YOUNGSTOWN	OH	67/1-71/12	YNG0260
ZANESVILLE	OH	50/1-54/12	ZZV1036
ENID/VANE	OK	65/1-69/12	END0151
FORT SILL	OK	66/1-70/12	FSI1326
MCALESTER	OK	54/1-54/12	MLC1076
OKLAHOMA CITY/TIN	OK	65/7-70/6	TIK0152
PONCA CITY	OK	49/1-54/12	PNC0888
TULSA	OK	62/1-71/12	TUL0473
ASTORIA	OR	60/1-64/12	AST0423
BAKER	OR	60/1-64/12	BKE1364
EUGENE		67/1-71/12	EUS0470
	OR OR	61/1-65/12	LMT0424
KLAMATH FALLS MEDFORD	OR	70/1-74/12	MFR1163
		66/1-75/12	OTH1376
NORTH BEND	OR OR		
ONTARIO	OR 4.2	48/1-54/12	ONO1377

DENDI ETION	OD	55/1-64/12	PTD0585
PENDLETON DORTLAND	OR OR	67/1-71/12	PDX0364
PORTLAND	OR OR	55/1-64/12	RDM0586
REDMOND SALEM	OR OR	67/1-71/12	SLE0471
	PA	65/1-69/12	ABE0209
ALLENTOWN		49/10-54/9	
ALTOONA	PA		A000207
BRADFORD/REGIONAL	PA	60/1-64/12	BDF0035
ERIE	PA	64/1-73/12	ERI0610
HARRISBURG	PA	65/1-69/12	HAR0214
HARRISBURG	PA	64/1-64/12	HAR0631
MARTINS CREEK	PA	36/1-38/03	MC10432
PHILADELPHIA	PA	71/1-75/12	PHL1263
PHILIPSBURG	PA	50/1-54/12	PSB0218
PITTSBURGH	PA	74/1-75/12	AGC1210
PITTSBURGH	PA	64/1-73/12	PIT0880
READING	PA	49/1-49/12	RDG0184
WILKES-BARRE	PA	60/1-64/12	AVP0499
WILLOW GROVE	PA	68/1-71/12	NXX0951
SAN JUAN	PR	65/1-73/12	XXX0757
PROVIDENCE	RI 	68/1-72/12	PVD0560
PROVIDENCE	RI	64/1-73/12	PVD0611
ANDERSON	SC	54/1-58/12	AND0421
CHARLESTON	SC	68/1-72/12	CHS0129
COLUMBIA	SC	56/1-75/12	CAE1371
FLORENCE	SC	60/1-64/12	FL00600
GREER	SC	68/1-72/12	GSP0528
MYRTLE BEACH	SC	66/1-70/12	MYR1027
SPARTANBURG	SC	57/1-61/12	SPA0530
PIERRE	SD	67/1-71/12	PIR0327
RAPID CITY	SD	67/1-71/12	RAP0336
SIOUX FALLS	SD	68/1-72/12	FSD0527
BRISTOL	TN	74/1-74/12	TRI1191
CHATTANOOGA	TN	68/1-73/12	CHA0711
KNOXVILLE	TN	55/1-64/12	TYS1328
MEMPHIS	TN	67/1-71/12	MEM0143
MEMPHIS	TN	74/1-78/12	MEM1824
NASHVILLE	TN	66/1-70/12	BNA0149
NASHVILLE	TN	71/1-75/12	BNA1232
NASHVILLE	TN	74/1-78/12	BNA1825
SMITHVILLE	TN	49/1-53/12	SA31482
ABILENE	TX	67/1-71/12	ABI0524
AMARILLO	TX	55/1-64/12	AMA0621
AUSTIN	TX	69/1-73/12	AUS0869
BEEVILLE	TX	66/1-70/12	NIR0067
CORPUS CHRISTI	TX	73/7-77/6	CRP1459
COTULLA	TX	50/1-54/12	COT0699
DALLAS	TX	67/1-71/12	DAL0161
DALLAS/FORT WORTH	TX	72/5-76/4	DFW1269
DEL RIO/LAUGHLIN	TX	65/1-69/12	DLF0274
EL PASO	TX	60/1-64/12	ELP0489
GALVESTON	TX	58/1-62/12	GLS0066
HOUSTON	TX	64/1-68/12	HOU0062
HOUSTON	TX	70/01-70/1	HOUSTON
KINGSVILLE	TX	72/1-76/12	NQI1470
LAREDO	TX	65/4-70/3	LOI0056
LUBBOCK	TX	69/1-73/12	LBB0970
		120	

TITULTN	шх	67/1 71/10	T 1712 O 4 C O
LUFKIN	TX TX	67/1-71/12 60/1-64/12	IFK0469 MAF0278
MIDLAND	TX	64/1-64/12	YXS1310
PORT ARTHUR	TX	60/1-64/12	SJT0280
SAN ANGELO			
SAN ANTONIO	TX	60/1-64/12	SAT0064
SHERMAN	TX	66/1-76/12	SWI1414
TYLER	TX	50/1-54/12	TYR0922
VICTORIA	TX	73/7-77/6	VCT1458
WACO	TX	69/1-73/12	ACT0862
BRYCE CANYON	UT	49/1-54/12	BCE0294
DELTA	UT	50/1-54/12	XXX0301
HANKSVILLE	UT	49/1-54/12	HV40302
MILFORD	UT	48/7-51/12	MLF0849
OGDEN	UT	65/1-69/12	HIF0337
SALT LAKE CITY	UT	72/1-76/12	SLC1411
DANVILLE	VA	50/1-54/12	DAN0825
GORDONSVILLE	VA	56/1-60/12	GVE0824
LANGLEY	VA	66/1-70/12	LFI1412
LYNCHBURG	VA	69/1-73/12	LYH0645
NORFOLK	VA	62/1-71/12	NGU1374
QUANTICO	VA	65/1-69/12	XXX0107
RICHMOND	VA	64/1-73/12	RIC0706
ROANOKE	VA	68/1-72/12	ROA0526
WALLOPS ISLAND	VA	69/1-73/12	WAL0687
WASHINGTON DC	VA	68/1-73/12	DCA1047
WASHINGTON DC	VA	66/1-70/12	IAD0398
BURLINGTON	VT	70/1-74/12	BTV0867
BELLINGHAM	WA	48/1-58/12	BLI1503
DALLESPORT	WA	64/1-64/12	XXX1196
ELLENSBURG	WA	50/1-54/12	ELN0518
EPHRATA	WA	50/1-54/12	EPH0521
EVERETT	WA	63/1-67/12	PAE1506
HOQUIAM	WA	54/1-58/12	HQM0487
KELSO	WA	48/1-49/12	KLS1378
MOSES LAKE	WA	61/1-65/12	MWH0486
OLYMPIA	WA	60/1-64/12	OLM0520
PORT ANGELES	WA	48/1-53/12	CLM0363
OUILLAYUTE	WA	74/1-74/12	UIL1505
SEATTLE/TACOMA	WA	67/1-71/12	SEA0366
SPOKANE	WA	67/1-71/12	GEG0360
SPOKANE	WA	68/1-77/12	GEG1806
TACOMA	WA	66/1-70/12	TCM0361
TOLEDO	WA	50/1-54/12	TD00488
WALLA WALLA	WA	50/1-54/12	ALW0485
WHIDBEY ISLAND	WA	67/1-71/12	NUW0925
YAKIMA	WA	60/1-64/12	YKM0484
EAU CLAIRE	WI	69/1-73/12	EAU0715
GREEN BAY	WI	64/1-73/12	ERB0776
LA CROSSE	WI	67/1-71/12	LSE0266
MADISON	WI	64/1-73/12	MSN0773
MILWAUKEE	WI	64/1-73/12	MKE0774
BECKLEY	WY	71/1-75/12	BKW1346
ELKINS	WV	63/1-67/12	EKN1497
HUNTINGTON	WV	67/1-71/12	HTS0019
MARTINSBURG	WV	60/1-64/12	MRB1067
		50/1-54/12	MGW0797
MORGANTOWN	WV	JU/ I=JH/ IZ	ו ל / טאטויו

PARKERSBURG	WV	50/1-54/12	PKB0117
CASPER	WY	67/1-71/12	CPR0335
CASPER	WY	70/1-74/12	CPR1564
CHEYENNE	WY	67/1-71/12	CYS0325
FORT BRIDGER	WY	50/1-54/12	FBR1311
LANDER	WY	70/1-74/12	LND1100
LARAMIE	WY	50/1-54/12	LAR1454
MOORCROFT	WY	50/1-52/07	MC40334
RAWLINS	WY	55/1-64/12	RWL1261
S ROCK SPRINGS	WY	71/1-75/12	RKS1588
SHERIDAN	WY	49/1-53/12	SHR0330