CLASSE

Sigma SSP Infrared Codes

The Classé Sigma SSP uses RC6 protocol for infrared communications. The following list of infrared codes can be used to program a universal or learning remote control. The Classé Remote Control uses a frequency of 56.0 kHz. Please refer to your remote control's user manual for information on how to program your remote control.

Sys code	IR code	Action
116	2	Change input to input 1
116	3	Change input to input 2
116	4	Change input to input 3
116	5	Change input to input 4
116	6	Change input to input 5
116	7	Change input to input 6
116	8	Change input to input 7
116	9	Change input to input 8
116	10	Go to next input
116	11	Go to previous input
116	12	Toggle Standby/Operate
200	13	Toggle Mute/Unmute
116	14	Info (go to status screen)
116	15	Cycle through display intensities
200	16	Volume up
200	17	Volume down
116	18	Tone
116	19	Late Night Toggle
116	21	Balance (go to balance screen)
200	56	Function key F1
200	57	Function key F2
116	68	DSP Mode Up
116	84	Menu
116	85	Home
116	88	Step up (navigate up, +)
116	89	Step down (navigate down, -)
116	90	Step left (navigate left, front USB prev track)
116	91	Step right (navigate right, front USB next track)
116	92	Enter
116	120	Change input to input 9
116	121	Change input to input 10
116	122	Change input to input 11
116	123	Change input to input 12

Sys code	IR code	Action
116	124	Change input to input 13
116	125	Change input to input 14
116	126	Change input to input 15
116	127	Change input to input 16
116	128	Change input to input 17
116	129	Change input to input 18
200	134	Function key F3
200	135	Function key F4
200	136	Function key F5
200	137	Function key F6
200	138	Function key F7
200	139	Function key F8
116	150	Set unit to Operate (Turn unit on)
116	151	Set unit to Standby (Turn unit off)
200	152	Set Mute mode on (Mute)
200	153	Set Mute mode off (Unmute)
116	160	Late Night On
116	161	Late Night Off
116	167	DSP Mode Down
116	185	Configuration 1
116	186	Configuration 2
116	187	Configuration 3
116	188	Configuration 4
116	189	Configuration 5
116	190	Configuration 6
116	206	Go to next Configuration
116	207	Go to previous Configuration
116	214	Front USB Play/Pause
116	216	Dolby Volume Toggle
116	217	Access Lipsync menu page
116	220	Mode01: Mono
116	221	Mode02: Stereo
116	222	Mode03: Party
116	223	Mode04: Mono Plus
116	224	Mode05: Movie Plus
116	225	Mode06: Music Plus
116	226	Mode07: PLII
116	227	Mode08: PLIIz Music
116	228	Mode09: PLIIz Movie
116	229	Mode10: PLIIz Matrix
116	230	Mode11: PLIIz Game
116	231	Mode12: DTS Neo6
116	232	Mode13: DTS Neo6 Music
116	233	Mode14: DTS Neo6 Cinema

Sys code	IR code	Action
116	234	Mode15: Discrete
116	235	Mode16: Dolby EX
116	236	Mode17: DTS Neo6 Music ES
116	237	Mode18: DTS Neo6 Cinema ES
116	247	Go to EQ Menu

SIGMA SSP HEX CODES

RC6 MODE 0, SYSTEM CODE 116

IR CODE 2 TOGGLE 0

INPUT 1

IR CODE 2 TOGGLE 1

INPUT 1

IR CODE 3 TOGGLE 0

INPUT 2

IR CODE 3 TOGGLE 1

INPUT 2

IR CODE 4 TOGGLE 0

INPUT 3

IR CODE 4 TOGGLE 1

INPUT 3

IR CODE 5 TOGGLE 0

INPUT 4

IR CODE 5 TOGGLE 1

INPUT 4

IR CODE 6 TOGGLE 0

IR CODE 6 TOGGLE 1

INPUT 5

INPUT 5

IR CODE 7 TOGGLE 0

INPUT 6

 $0000\ 004A\ 0000\ 0013\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0019\ 0032\ 0032\ 0019$

IR CODE 7 TOGGLE 1

INPUT 6

IR CODE 8 TOGGLE 0

INPUT 7

IR CODE 8 TOGGLE 1

INPUT 7

IR CODE 9 TOGGLE 0

INPUT 8

IR CODE 9 TOGGLE 1

INPUT 8

IR CODE 10 TOGGLE 0

NEXT INPUT

 $0000\ 004A\ 0000\ 0012\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0019\ 0032\ 0032\ 0031\ 0019$

IR CODE 10 TOGGLE 1

NEXT INPUT

IR CODE 11 TOGGLE 0

PREVIOUS INPUT

IR CODE 11 TOGGLE 1

PREVIOUS INPUT

IR CODE 12 TOGGLE 0

STANDBY/OPERATE

IR CODE 12 TOGGLE 1

STANDBY/OPERATE

IR CODE 14 TOGGLE 0

INFO

IR CODE 14 TOGGLE 1

INFO

IR CODE 15 TOGGLE 0

TOGGLE DISPLAY INTENSITY

 $0000\ 004A\ 0000\ 0013\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0019\ 0032\ 0032\ 0019\ 0019$ $0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019$ $0019\ 0019\ 0019\ 0019\ 0019\ 0019$

IR CODE 15 TOGGLE 1

TOGGLE DISPLAY INTENSITY

IR CODE 18 TOGGLE 0 TONE

IR CODE 18 TOGGLE 1

TONE

IR CODE 19 TOGGLE 0

LATE NIGHT TOGGLE

IR CODE 19 TOGGLE 1

LATE NIGHT TOGGLE

IR CODE 21 TOGGLE 0

BALANCE

IR CODE 21 TOGGLE 1

BALANCE

IR CODE 68 TOGGLE 0

NEXT DSP MODE

IR CODE 68 TOGGLE 1

NEXT DSP MODE

IR CODE 84 TOGGLE 0

MENU

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0019 0019 0032 0031 0032 0031 0019 0019 0019 0019 125C

IR CODE 84 TOGGLE 1

MENU

0000 004A 0000 0010 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0019 0032 0032 0031 0019 0019 0019 0019 0032 0031 0032 0031 0032 0031 0019 0019 0019 125C

IR CODE 85 TOGGLE 0

HOME

IR CODE 85 TOGGLE 1

HOME

0000 004A 0000 000F 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0019 0032 0032 0031 0032 0031 0032 0031 0032 0031 0032 1275

IR CODE 88 TOGGLE 0

CURSOR UP

IR CODE 88 TOGGLE 1

CURSOR UP

IR CODE 89 TOGGLE 0

CURSOR DOWN

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0019 0032 0031 0019 0019 0019 0032 0031 0032 0019 0019 0032 0019 0019 0032 1275

IR CODE 89 TOGGLE 1

CURSOR DOWN

 $0000\ 004A\ 0000\ 0010\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 004B\ 004A\ 0032\ 0019\ 0019\ 0019$ $0019\ 0032\ 0031\ 0032\ 0031\ 0032\ 0019\ 0019\ 0032\ 0019\ 0019\ 0032\ 1275$

IR CODE 90 TOGGLE 0

CURSOR LEFT

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0019 0032 0031 0032 0031 0032 0031 0019 125C

IR CODE 90 TOGGLE 1

CURSOR LEFT

IR CODE 91 TOGGLE 0 CURSOR RIGHT

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0019 0032 0031 0019 0019 0019 0032 0031 0032 0019 0019 0019 0019 1275

IR CODE 91 TOGGLE 1 CURSOR RIGHT

0000 004A 0000 0010 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0019 0032 0031 0032 0032 0032 0032 0019 0019 1275

IR CODE 92 TOGGLE 0 ENTER

IR CODE 92 TOGGLE 1 ENTER

IR CODE 120 TOGGLE 0 INPUT 9

 $0000\ 004A\ 0000\ 0013\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0019\ 0032\ 0032\ 0019$

IR CODE 120 TOGGLE 1 INPUT 9

IR CODE 121 TOGGLE 0 INPUT 10

 $0000\ 004A\ 0000\ 0012\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0019\ 0032\ 0032\ 0019$

IR CODE 121 TOGGLE 1 INPUT 10

IR CODE 122 TOGGLE 0 INPUT 11

IR CODE 122 TOGGLE 1

INPUT 11

IR CODE 123 TOGGLE 0

INPUT 12

IR CODE 123 TOGGLE 1

INPUT 12

IR CODE 124 TOGGLE 0

INPUT 13

IR CODE 124 TOGGLE 1

INPUT 13

IR CODE 125 TOGGLE 0

INPUT 14

IR CODE 125 TOGGLE 1

INPUT 14

IR CODE 126 TOGGLE 0

INPUT 15

IR CODE 126 TOGGLE 1

INPUT 15

 $0000\ 004A\ 0000\ 0012\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 004B\ 004A\ 0032\ 0019\ 0019\ 0019$ $0019\ 0032\ 0032\ 0031\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019$ $0019\ 0032\ 0019\ 125C$

IR CODE 127 TOGGLE 0

INPUT 16

 $0000\ 004A\ 0000\ 0013\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0019\ 0032\ 0032\ 0019$

IR CODE 127 TOGGLE 1

INPUT 16

IR CODE 128 TOGGLE 0

INPUT 17

IR CODE 128 TOGGLE 1

INPUT 17

IR CODE 129 TOGGLE 0

INPUT 18

IR CODE 129 TOGGLE 1

INPUT 18

IR CODE 150 TOGGLE 0

OPERATE

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0031 0019 0019 0032 0031 0019 0032 0031 0019 0032 0031 0032 0019 0032 0019 125C

IR CODE 150 TOGGLE 1

OPERATE

IR CODE 151 TOGGLE 0

STANDBY

 $0000\ 004A\ 0000\ 0011\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0032\ 0032\ 0031\ 0019\ 0019\ 0032\ 0031\ 0019\ 0019\ 0032\ 0031\ 0032\ 0031\ 0019\ 0019$

IR CODE 151 TOGGLE 1

STANDBY

IR CODE 160 TOGGLE 0

LATE NIGHT MODE ON

IR CODE 160 TOGGLE 1

LATE NIGHT MODE ON

IR CODE 161 TOGGLE 0

LATE NIGHT MODE OFF

IR CODE 161 TOGGLE 1

LATE NIGHT MODE OFF

IR CODE 167 TOGGLE 0

PREVIOUS DSP MODE

IR CODE 167 TOGGLE 1

PREVIOUS DSP MODE

IR CODE 185 TOGGLE 0

CONFIGURATION 1

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0032 0031 0032 0019 0019 0019 0019 0019 0032 0019 0019 0032 1275

IR CODE 185 TOGGLE 1

CONFIGURATION 1

IR CODE 186 TOGGLE 0

CONFIGURATION 2

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0032 0031 0032 0019 0019 0019 0019 0019 0032 0032 0031 0019 125C

IR CODE 186 TOGGLE 1

CONFIGURATION 2

0000 004A 0000 0010 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0031 0019 0019 0019 0019 0019 0019 0032 0031 0019 125C

IR CODE 187 TOGGLE 0

CONFIGURATION 3

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0032 0031 0032 0019 0019 0019 0019 0019 0032 0032 0019 0019 1275

IR CODE 187 TOGGLE 1

CONFIGURATION 3

IR CODE 188 TOGGLE 0

CONFIGURATION 4

IR CODE 188 TOGGLE 1

CONFIGURATION 4

IR CODE 189 TOGGLE 0

CONFIGURATION 5

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0031 0019 0019 0032 0031 0032 0019 0019 0019 0019 0019 0019 0032 0032 1275

IR CODE 189 TOGGLE 1

CONFIGURATION 5

IR CODE 190 TOGGLE 0

CONFIGURATION 6

 $0000\ 004A\ 0000\ 0012\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0032\ 0032\ 0019\ 0019$ $0019\ 0019\ 0032\ 0031\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019$ $0019\ 0032\ 0019\ 125C$

IR CODE 190 TOGGLE 1

CONFIGURATION 6

IR CODE 206 TOGGLE 0

NEXT CONFIGURATION

IR CODE 206 TOGGLE 1

NEXT CONFIGURATION

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0032 0019 0019 0032 0019 0019 0019 0032 0019 125C

IR CODE 207 TOGGLE 0

LAST CONFIGURATION

 $0000\ 004A\ 0000\ 0012\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0032\ 0032\ 0019\ 0019$ $0019\ 0019\ 0032\ 0032\ 0019\ 0019\ 0032\ 0019\ 0019\ 0032\ 0019\ 0019$ $0019\ 0019\ 0019\ 0019\ 0019\ 0019$

IR CODE 207 TOGGLE 1

LAST CONFIGURATION

IR CODE 214 TOGGLE 0

FRONT USB PLAY/PAUSE

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0032 0031 0032 0019 0032 0039 0019 125C

IR CODE 214 TOGGLE 1

FRONT USB PLAY/PAUSE

 $0000\ 004A\ 0000\ 0010\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 004B\ 004A\ 0032\ 0019\ 0019\ 0019$ $0019\ 0032\ 0032\ 0031\ 0032\ 0019\ 0019\ 0032\ 0019\ 0019\ 0032\ 0031$

IR CODE 216 TOGGLE 0

DOLBY VOLUME TOGGLE

IR CODE 216 TOGGLE 1

DOLBY VOLUME TOGGLE

 $0000\ 004A\ 0000\ 0011\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 004B\ 004A\ 0032\ 0019\ 0019\ 0019$ $0019\ 0032\ 0032\ 0032\ 0019\ 0019\ 0032\ 0019\ 0019\ 0032\ 0019\ 0019$ $0019\ 0032\ 0019\ 0019\ 0032\ 0019\ 0019$

IR CODE 217 TOGGLE 0

LIPSYNC MENU

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0032 0032 0019 0019 0032 0019 0019 0032 1275

IR CODE 217 TOGGLE 1

LIPSYNC MENU

0000 004A 0000 0010 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0032 0032 0032 0031 0019 0019 0032 0019 0019 0032 0032 0019 0019 0032 1275

IR CODE 220 TOGGLE 0

MODE 1: MONO

IR CODE 220 TOGGLE 1

MODE 1: MONO

IR CODE 221 TOGGLE 0

MODE 2: STEREO

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0032 0032 0019 0019 0032 0032 1275

IR CODE 221 TOGGLE 1

MODE 2: STEREO

0000 004A 0000 0010 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0032 0032 0032 0031 0019 0019 0032 0019 0019 0032 0032 0019 0019 0019 0019 0032 0032 1275

IR CODE 222 TOGGLE 0

MODE 3: PARTY

IR CODE 222 TOGGLE 1

MODE 3: PARTY

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0032 0032 0019 0019 0019 0019 0019 0019 0032 0019 125C

IR CODE 223 TOGGLE 0

MODE 4: MONO PLUS

 $0000\ 004A\ 0000\ 0012\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0032\ 0032\ 0019\ 0019$ $0019\ 0019\ 0032\ 0032\ 0032\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019$ $0019\ 0019\ 0019\ 1275$

IR CODE 223 TOGGLE 1

MODE 4: MONO PLUS

IR CODE 224 TOGGLE 0

MODE 5: MOVIE PLUS

IR CODE 224 TOGGLE 1

MODE 5: MOVIE PLUS

IR CODE 225 TOGGLE 0

MODE 6: MUSIC PLUS

 $0000\ 004A\ 0000\ 0012\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0032\ 0032\ 0019\ 0019$ $0019\ 0019\ 0032\ 0032\ 0031\ 0019\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0032\ 0019\ 0019$ $0019\ 0032\ 1275$

IR CODE 225 TOGGLE 1

MODE 6: MUSIC PLUS

IR CODE 226 TOGGLE 0

MODE 7: DOLBY PRO LOGIC II

IR CODE 226 TOGGLE 1

MODE 7: DOLBY PRO LOGIC II

IR CODE 227 TOGGLE 0

MODE 8: DOLBY PRO LOGIC IIZ MUSIC

 $0000\ 004A\ 0000\ 0012\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 0032\ 0032\ 0019\ 0032\ 0019$ $0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019\ 0019$ $0019\ 0019\ 0019\ 0019\ 0019\ 0019$ $0019\ 0019\ 0019\ 0019$

IR CODE 227 TOGGLE 1

MODE 8: DOLBY PRO LOGIC IIZ MUSIC

IR CODE 228 TOGGLE 0

MODE 9: DOLBY PRO LOGIC IIZ MOVIE

0000 004A 0000 0012 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0019 0019 0032 0019 0019 0032 0031 0019 0019 0019 125C

IR CODE 228 TOGGLE 1

MODE 9: DOLBY PRO LOGIC IIZ MOVIE

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0019 0032 0019 0019 0032 0031 0019 0019 0019 0019 125C

IR CODE 229 TOGGLE 0

MODE 10: DOLBY PRO LOGIC IIZ MATRIX

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0019 0019 0032 0019 0019 0032 0031 0032 1275

IR CODE 229 TOGGLE 1

MODE 10: DOLBY PRO LOGIC IIZ MATRIX

IR CODE 230 TOGGLE 0

MODE 11: DOLBY PRO LOGIC IIZ GAME

IR CODE 230 TOGGLE 1

MODE 11: DOLBY PRO LOGIC IIZ GAME

IR CODE 231 TOGGLE 0

MODE 12: DTS NEO:6

0000 004A 0000 0012 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0019 0019 0032 0019 0019 0019 0019 0019 1275

IR CODE 231 TOGGLE 1

MODE 12: DTS NEO:6

IR CODE 232 TOGGLE 0

MODE 13: DTS NEO:6 MUSIC

0000 004A 0000 0012 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0031 0019 0019 0019 0019 0019 0019 0032 0032 0031 0019 0019 0019 0019 0019 125C

IR CODE 232 TOGGLE 1

MODE 13: DTS NEO:6 MUSIC

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0019 0019 0019 125C

IR CODE 233 TOGGLE 0

MODE 14: DTS NEO:6 CINEMA

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0019 0032 0032 0031 0019 0019 0032 1275

IR CODE 233 TOGGLE 1

MODE 14: DTS NEO:6 CINEMA

0000 004A 0000 0010 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0019 0019 0032 0031 0019 0019 0032 1275

IR CODE 234 TOGGLE 0

MODE 15: DISCRETE

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0019 0019 0019 0019 0032 0032 0031 0032 0031 0019 125C

IR CODE 234 TOGGLE 1

MODE 15: DISCRETE

0000 004A 0000 0010 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0019 0019 0019 0019 0032 0031 0032 0031 0019 125C

IR CODE 235 TOGGLE 0

MODE 16: DOLBY EX

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0019 0032 0032 0031 0032 0019 0019 1275

IR CODE 235 TOGGLE 1

MODE 16: DOLBY EX

 $0000\ 004A\ 0000\ 0010\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 004B\ 004A\ 0032\ 0019\ 0019\ 0019$ $0019\ 0032\ 0031\ 0032\ 0031\ 0019\ 0019\ 0019\ 0019\ 0019\ 0032\ 0031\ 0032\ 0019\ 0019\ 1275$

IR CODE 236 TOGGLE 0

MODE 17: DTS NEO:6 MUSIC ES

IR CODE 236 TOGGLE 1

MODE 17: DTS NEO:6 MUSIC ES

 $0000\ 004A\ 0000\ 0011\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 004B\ 004A\ 0032\ 0019\ 0019\ 0019$ $0019\ 0032\ 0032\ 0032\ 0019\ 0019\ 0032\ 0032\ 0019\ 0019\ 0019$ $0019\ 0032\ 0032\ 0019\ 0019\ 0032\ 0019\ 0019$ $0019\ 125C$

IR CODE 237 TOGGLE 0

MODE 18: DTS NEO:6 CINEMA ES

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0019 0019 0032 0032 0019 0019 0032 0032 1275

IR CODE 237 TOGGLE 1

MODE 18: DTS NEO:6 CINEMA ES

0000 004A 0000 0010 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0019 0019 0032 0032 0032 0019 0032 0032 1275

IR CODE 247 TOGGLE 0

EQ MENU

0000 004A 0000 0012 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 0032 0019 0032 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0019 0019 0019 0019 0032 0032 0019 0019 0019 0019 0019 1275

IR CODE 247 TOGGLE 1

EQ MENU

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 004B 004A 0032 0019 0019 0019 0019 0019 0032 0032 0031 0019 0019 0032 0019 0019 0019 0019 0019 0019 0032 0032 0032 0019 0019 0019 0019 0019 1275

RC6 MODE 0, SYSTEM CODE 200

IR CODE 13 TOGGLE 0

MUTE TOGGLE

IR CODE 13 TOGGLE 1

MUTE TOGGLE

IR CODE 16 TOGGLE 0

VOLUME UP

IR CODE 16 TOGGLE 1

VOLUME UP

IR CODE 17 TOGGLE 0 VOLUME DOWN

IR CODE 17 TOGGLE 1

VOLUME DOWN

IR CODE 56 TOGGLE 0 F1

IR CODE 56 TOGGLE 1 F1

IR CODE 57 TOGGLE 0 F2

IR CODE 57 TOGGLE 1 F2

IR CODE 134 TOGGLE 0 F3

IR CODE 134 TOGGLE 1 F3

IR CODE 135 TOGGLE 0 F4

IR CODE 135 TOGGLE 1

F4

 $0000\ 004A\ 0000\ 0012\ 0095\ 0032\ 0019\ 0032\ 0019\ 0019\ 0019\ 0019\ 004B\ 0031\ 0019$

IR CODE 136 TOGGLE 0

F5

IR CODE 136 TOGGLE 1

F5

IR CODE 137 TOGGLE 0

F6

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 004B 0018 0019 0032 0019 0019 0032 0031 0019 0019 0019 0032 0031 0019 0019 0019 0019 0019 0019 0032 0031 0019 0019 0032 1275

IR CODE 137 TOGGLE 1

F6

IR CODE 138 TOGGLE 0

F7

IR CODE 138 TOGGLE 1

F7

IR CODE 139 TOGGLE 0

F8

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 004B 0018 0019 0032 0019 0019 0032 0031 0019 0019 0019 0032 0031 0019 0019 0019 0019 0019 0032 0031 0032 0019 0019 1275

IR CODE 139 TOGGLE 1

F8

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 004B 0031 0019 0019 0019 0032 0019 0019 0032 0031 0019 0019 0019 0032 0031 0019 0019 0019 0019 0019 0019 0032 0031 0019 0019 1275

IR CODE 152 TOGGLE 0

MUTE

IR CODE 152 TOGGLE 1 MUTE

IR CODE 153 TOGGLE 0 UNMUTE

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 0019 0032 004B 0018 0019 0032 0019 0019 0032 0031 0019 0019 0019 0032 0031 0019 0019 0032 0019 0019 0032 0019 0019 0032 1275

R CODE 153 TOGGLE 1 UNMUTE

0000 004A 0000 0011 0095 0032 0019 0032 0019 0019 0019 0019 004B 0031 0019 0019 0019 0032 0019 0019 0032 0031 0019 0019 0019 0032 0031 0019 0019 0032 0019 0019 0032 0019 0019 0032 0019 0019 0032 1275