

FactoryIQ Demo Corpus — CNC-01_Start_Procedure_v1.2.pdf

Document Family: CNC-01_Start_Procedure | Revision: 1.2

Startup procedure

Check coolant level, verify circulation, verify safety interlocks and confirm emergency-stop readiness before startup.

Abnormal condition

If an abnormal condition is observed during startup, stop the operation and contact maintenance.