

S.R. POWA IBMIACS 135 · model small · data n dw 4 r dw 2 nce du 0 mov ax, @data mov de, ax mov ax n mov bx, & call neepso call disp jmp final ncepes proc near comp ax, bx ; h=n je sest cmp bx, 0 2 ; 2=0 je søl comp bx,1 ; & e1 con je sesn dec ax ; &=n-1 cmp bx, ax je ince push an push bx call neepeo bab pr pop ax push ax push bx call nappe pop ax

	S-R-POOTA IBM19CS135	5
	set	lle
	ine inc nec	
	sesn: add nes, ax	
	Ret	
	ncepro endp	
	disp peac near	
	mod bx, na	da
3	add by, 3030 th	
	mov dl, bh	
	mor ah, orth	
	int alh	
	mov dl, bl	6
	mov ah, ozh	
	int 21h	2021
	O.L	3d 3
	dies ende	1
	disp endp final! mov ah, 4ch	- 0
	int 21h	i
	end 132	1
		0.80





File Edit Search View Options Help C:\MASM\NCR.ASM incr:inc ncr resn:add ncr,ax ret ncrpro endp disp proc near mov bx,ncr add bx,3030h mov dl,bh mov ah, 02h int 21h mov dl,bl mov ah, 02h int 21h ret disp endp final: mov ah,4ch int 21h end F1=Help Line:63 Col:1

```
C:\MASM>MASM NCR ;;
Microsoft (R) Macro Assembler Version 5.00
Copyright (C) Microsoft Corp 1981-1985, 1987. All rights reserved.

51758 + 464786 Bytes symbol space free

0 Warning Errors
0 Severe Errors

C:\MASM>LINK NCR ;;

Microsoft (R) Overlay Linker Version 3.60
Copyright (C) Microsoft Corp 1983-1987. All rights reserved.

LINK : warning L4021: no stack segment

C:\MASM>NCR
96
C:\MASM>NCR
```

C:\>CD MASM