UCCD1133 Introduction to Computer Organisation and Architecture

Assignment Project Exam Help

https://powcoder.com
Chapter 7

Add Wedth Reriphersoder

Disclaimer

• This slide may contain copyrighted material of which has not been specifically authorized by the copyright owner. The use of copyrighted materials are solely for educational purpose. If you wish to use this copyrighted material for other purposes, you must first obtain permission from the original copyright owner.

Assignment Project Exam Help

https://powcoder.com


Add WeChat powcoder

Computer I/O

- I/O is one of the most complex areas of computer design
 - Wide variety of different I/O devices
 - The quest for fast handling of programs and data

Five Major Components of Computer Organization

Assignment Project Exam Help



CD-ROM, modems, scanners, sound cards with speakers and microphones,

Peripherals

• I/O devices attached to the computer online are called peripherals.

Connected online = control by CPU.


• Example: Keyboard, hard drive, graphic display etc.

LCD Screen Hard Drive Keyboard Assignment Project Exam Help https://powcoder.com Bus Interface Add WeChat poweoc Graphics Adapter

Example: Keyboard

- One of the slowest data rates.
- It is necessary to detect which of the keys have been depressed/ released.
 - A scan matrix lies beneath the keys.
 - Microcontroller is programmed to periodically scan all intersections in the matrix.
- Data transfer rate less than 10 bytes/s.

Assignment Project Exam Help



Keyboard Scan Matrix

I/O Interfaces

• The properties of peripherals and CPU & memory are different:


Peripherals	CPU & Memory
Electromechanical devices	Electronic devices
Usually slow data transfer rate	Usually faster than peripherals
Data unit = Ste, signment Pro	ojeci kozamaHelp

https://powcoder.com

- The computer need special hardware to interface the peripherals with CPU: Interface units We Chat powcoder
 - Interface between the **bus** from the **CPU** and **peripheral devices**.
 - Supervise and synchronize all input and output transfer.
 - Each device has its own controller to supervise the operations of the particular mechanism of that peripherals
 - Example: the controller in a printer controls the motion of paper, timing of printing, the selection of the characters to be printed.

I/O Bus and Interface Unit


- Bus = a group of electrical signals / wires that carry these signals.
- The **three major components** of system bus:
 - Data bus: Carry data from source to destination (e.g., CPU to memory)
 - Address bus: Used to designate source or destination of the data.
 - Control bus: Carry functional information defining and controlling the current bus activity, e.g., clock, memory R/W, IO R/W, Bus request, etc.



Connection of I/O devices to CPU

Interface Unit

- Function of the interface:
 - Translate the signals between the CPU buses and the I/O devices.
 - Provide the needed hardware to satisfy the two sets of timing constraints.



Example of I/O Interface Unit

I/O Data Transfer

- I/O requests are made by applications or OS
 - involve moving data between peripheral device and main memory
- Two main ways for programs to communicate with devices:
 - Memory-mapped I/O
 - Isolated I/O

Assignment Project Exam Help

- Several ways to transfer data between devices and main memory:
 - Programmed I/O https://powcoder.com
 Interrupt-driven I/O

 - Direct memory accessed WeChat powcoder


Accessing I/O Devices

- Most devices can be considered as memories, with an "address" for reading or writing
- Many ISAs* often make this analogy explicit — to transfer data to/from a particular device, State ment Project can access special addresses
 - Example: Video cart can be accessed via addresses 3B0-3BB, 3C0-3DF and A0000-BFFFF

Add WeChat powchicing device is to a conflicting device in the conflicting device is to a conflicting device in the conflicting device is to a conflicting device in the conflicting device is to a conflicting device in the conflicting device is to a conflicting device in the conflicting device is to a conflicting device in the conflicting device is to a conflicting device in the conflicting device is to a conflicting device in the conflicting device in


- Two ways to access these addresses:
 - Memory-mapped I/O
 - Isolated I/O

*ISA (Industry Standard Architecture) is a type of computer bus and expansion card standard.



Memory-mapped I/O

- With memory-mapped I/O, one address space is divided into two parts.
 - Some addresses refer to physical memory locations.
 - Other addresses actually reference peripherals.
- For example, an old PC with a 16-bit address bus could access A WHOLD THE PROJECT. Exam Help
 - Addresses C000-CFFF in hexadecimal were not part of memory, but were used to access 1/O devices.
 - All the other addresses did reference main memory.
- The I/O addresses are shared by many peripherals. For instance, C010 might be attached to the keyboard while C030 goes to the speaker.
- Some devices may need several I/O addresses.




Memory-mapped I/O

- In summary, memory-mapped I/O maps I/O port address to memory address space.
 - Writing to an I/O port is similar to writing to a memory location.
 - Does not require any special consideration from the processor.
 - However, it Assignment Project Exam Help for I/O mapping.


https://powcoder.com

 Processors such as MIPS and PowerPC support only memory-mapedd/oweChat powcoder



Memory-mapped I/O


- To send a data to a device,
 - The CPU places a device address on the address bus to activates the path.
 - The CPU provides a function code on the control lines.
 - The interface proceed to execute the function and sychronise the data transfer.



Synchronous bus (Changes occur relative to the falling or rising edge of the clock)


MIPS Memory-mapped I/O

- MIPS processor uses memory-mapped I/O.
- Everything above 0x7FFF FFFF is used by the system
 - Special operating system functions
 - I/O registers mapped to memory address
 - Kernel data, etc.



SPIM Input

- SPIM allows you to read from the keyboard (which is similar to reading something from the true I/O register)
- □ Input is controlled via two memory-mapped device registers:
 - Receiver control
 - Receiver data



SPIM output


- Transmitter writes characters to the display (console).
- Output is controlled via two memory-mapped device registers:
 - Transmitter control (0xFFFF 0008)
 - Bit 1: interrupt enable
 - * Bit 0: read Assignment Project Exam Help
 - Transmitter data (0xFFFF 000C)
 - Bit 0-7: data byte https://powcoder.com
- If you need to show soldething chattepans 612 the following:
 - 1. Check if ready bit is 1. If yes, proceed. Otherwise, wait.
 - 2. Write to the data. The ready bit will be reset to 0, and will be set to 1 after the byte is transmitted.

Isolated I/O


- For isolated I/O, there are separate address spaces for memory and I/O devices
 - special instructions that access the I/O space
- The complete memory address space can be used for memory, but it require special I/O instructions to access the I/O address space. Help Main memory

https://powcoder.com

- *Example* (x86):
 - regular instructions like ₩Q¥ reference RAM
 - special instructions Thand Out access a separate I/O address space
- An address could refer to either main memory or an I/O device, depending on the instruction used.



Isolated I/O



Modes of Data Transfer

- How data is transferred between peripherals and main memory?
- Several modes:
 - Programmed I/O
 - Interrupt-driven I/O
 - Direct memory access
 Assignment Project Exam Help

https://powcoder.com

Add WeChat powcoder

Programmed I/O


- With programmed I/O, it's all up to the program or the OS
 - CPU makes a request and then waits (loops) until device is ready (loop 1)
 - Buses are typically 32-64 bits wide, so loop 2 is repeated for large transfers

Assignment Project Exam Help

- A lot of CPU time is needed for this!
 - most devices are spott pompaped to colder.com
 - CPU also "wastes time" doing actual data transfer


Add WeChat powcoder

Does not require any hardware support to implement.




Interrupt-driven I/O

- Continually checking to see if a device is ready is called polling
- Wastes CPU time:
 - CPU must ask repeatedly
 - CPU must ask often enough to ensure that it doesn't
 miss anything, which means it capt do much else
 while waiting Significant to ensure that it doesn't
- Solution: Interrupt-dilutips //powcoder.com
 - Instead of waiting, the CPU continues with other calculations
 - The device interrupts the processor when the Wagager ready
- CPU still does the data transfer




Yes


Interrupt Driven Input




Interrupt Driven Input



Interrupt Driven Output




Interrupt Driven Output




Direct memory access

- One final method of data transfer is to introduce a direct memory access, or DMA, controller
- The DMA controller is a simple processor which does most of the functions that the CPU would otherwise have to handle
 - The CPU asks the DMA controllento transfer data between a device and main memory. After that, the CPU can continue with other tasks
 - The DMA controller issues requests to the right on device, waits, and manages the transfers between the device and main memory
 - Once finished, the Avido of the trupts the order
- DMA relieves the CPU of the low-level data transfer chore. But it needs hardware support as it is implemented by using a DMA controller.




Programmed I/O vs DMA



- (a) In Programmed I/O, data are read by the processor and then written to the memory.
- (b) In DMA transfer, the DMA controller generates the control signals to transfer data directly between the I/O device and memory.

Direct memory access



• Since both the proclassprandprovonder may need to access main memory, some form of arbitration is required

Add WeChat powcoder

Bus arbitration

- More than one bus master can request the bus
 - Need an arbitration mechanism to allocate the bus
- Bus arbitration can be done either
 - Statically
 - Dynamically


Assignment Project Exam Help


- Static arbitration

 - Done in a predetermined way
 Easy to implement https://powcoder.com
 - Does not take needs into account
 - Poor utilization Bus And d by assign edge very when not regeded
- Dynamic bus arbitration
 - Bus allocated only in response to a request
 - Each master is equipped with
 - Bus request line
 - · Bus grant line
 - A master uses the bus request line to let others know that it needs the bus
 - Before a master can use the bus, it must receive permission to use the bus via the bus grant line


- Transfer of data may be parallel or serial.
- Parallel data transfer:
 - Each bit has its own path, and the entire message is transmitted at one time.
 - Faster, because multiple signal lines operate in parallel.
 - Used for short distances and when speed is important.
 - Data skew problem.
- Serial data transfersignment Project Exam Help
 Each bit is sent in sequence, one at a time.

 - Slower, but less expensive since it requires only one conductor.
 - Become increasingly important lease of connecting smaller cables, and less signal skew problem as data rates increase.





- Serial transmission can be asynchronous or synchronous.
- Asynchronous transmission
 - Each byte is encoded for transmission
 - Start and stop bits.
 - No need for sender and receiver synchronisation.
- Synchronous transmission
 - · Sender and receive summent Project Exam Help
 - Done in hardware using phase locked loops (PLLs)
 - Block of data can be 14thps://powcoder.com
 - More efficient
 - Less overhead than asynchronous transmission powcoder
 - Expensive
- Universal Serial Bus (USB) and Firewire use the synchronous transmission.




(b) Synchronous transmission

Universal Serial Bus (USB)

- Intended to help retire all legacy varieties of serial and parallel ports.
 - Single standardized interface socket
 - Plug-and-play + hot swapping
 - Providing power to low-consumption devices
 - Allowing many standard devices to be used without requiring manufacturer specific
- The computer appointment Project Exam Helputer devices can be classified as hubs, devices, or compound devices.

 Root Hub levices.
 - Description of the A hub provides attachment points for USB deviced week that power other hubs. It contains a USB interface for control and status handling.
 - If a hub is combined with a device such as the keyboard in the figure, the keyboard is referred to as compound devices.



Interrupts and Exceptions

- Interrupts are external events that require the processor's attention
 - Examples: I/O device needs attention, timer interrupts to mark cycle
- The mechanism of interrupt is similar to procedure call, but interrupts can be initiated by both software and hardware.
 - Procedures are purely software-initiated.

Assignment Project Exam Help

- Interrupts are normal, not errors
 - All interrupts are recoverable, interrupted program will need to be resumed after the interrupt of the lead powcoder. Com
- The MIPS processor uses the system call power instruction for software interrupts.
 - We used syscall to invoke the SPIM simulator I/O services.
- The interrupt service routine is commonly called interrupt handler.

Interrupts and Exceptions

- Exceptions are typically errors that are detected within the processor
 - Examples: illegal instruction opcode, arithmetic overflow, or attempts to divide by 0.
 - There are two possible ways of resolving these errors:
 - If the error is un-recoverable, the operating system kills the program
 - Less serious problems can eften be pixed by Osfor the program itself p
- The underlying mechanism of interrupts and exceptions is essentially the number of powcoder.com same.

Add WeChat powcoder OS responsible to do the right thing, such as:

- - Save the current state and shut down the hardware devices
 - Find and load the correct data from the hard disk
 - Transfer data to/from the I/O device, or install drivers

Interrupt Processing in MIPS

- On interrupts
 - Disables further interrupts
 - Record the cause of interrupts/exception Cause register
 - Transfers control to exception handler located at a 0x80000180 (fixed address)
 - Handler saves the context
 - Program counter (PC)
 - Current Exam Help
 Status of interrupts (enables or disabled)
 - Stores return address
 - Uses a register: Eta (tapeption pogyars outer) legista.

Add WeChat po	owcoderse
Hardware Interrupt	0x00000000
System Call	0x00000020
Breakpoint / Divide by 0	0x00000024
Undefined Instruction	0x00000028
Arithmetic Overflow	0x00000030

Interrupt Processing in MIPS

Cause and EPC registers are loaded into k0 and k1 registers

```
mfc0 $k0,$13 # copy Cause register (Register 13) into $k0
mfc0 $k1,$14 # copy EPC register (Register 14) into $k1
```

- Cause and EPC registers are not part of the MIPS register file.
 - · Located in coprocessor (CPO) ASSIGNMENT Project Exam Help
- The processor returns to the address in EPC after handling the exception.
 - Return address = address the Date with the content of the conten
 - We need to add 4 to get to the instruction following the interrupted instruction

```
Add WeChat powcoder sk1, $k1, $k1, 4
```