intensity is often confounded with the word secondary. This is because we usually see the primary current,—*i.e.*, that known as voltaic or galvanic and coming directly from the cups—obviously active only when the amount of generating surface and the resultant amount of electricity are very considerable; its flow being quiescent. But the secondary or "induced current,"—obtained by means of a coil of fine wire simply brought near to the primary, and known also as faradic, from Faraday, who described it,—is generally seen in a state of concentrated and precise mobility which enables it to pass with a sort of momentum through matter which would only absorb, as it were, the more indefinitely and sluggishly moving primary current. The two differing somewhat as do a conical bullet from a rifle, and the charge of small shot from a fowling-piece. But the primary current gets tension from a subdivision of the pair of primary plates into co-operative series; and the secondary current gets both amount and measurably the condition called quantity, by changing mere matters of mechanism, and the character of the conducting media.

Using the word "quantity" rightly, we mean that this is a condition in which either a large or a small amount of electricity is indifferent in regard to any given line of polarization; hence diffuses itself near and around its point of liberation, and readily becomes transformed by obstacles into other forces, as in the heating of a wire, which forces the electricity suddenly into concentration.

Of "intensity," in like manner, we say that it is