




System Firmware and Device Firmware Updates using Unified Extensible Firmware Interface (UEFI) Capsules

Fall 2018 UEFI Plugfest
October 15 – 19, 2018
Presented by Brian Richardson (Intel)

Materials by Michael Kinney (Intel)

Building and Distributing UEFI Capsules for Firmware Update






^{*} Other names and brands may be claimed as property of others

Platform Initialization (PI) Architecture Firmware Phases






PI Architecture Firmware Phases Example: UEFI Capsule Processing




Save UEFI Capsule



Process UEFI Capsule





FMP = UEFI Firmware Management Protocol GUID = Globally Unique Identifier

EDK II UEFI Capsule Features

EFI Development Kit II (https://www.tianocore.org)



Feature	UDK2017 / UDK2018	edk2-stable201808
Generate UEFI Capsule	Integrated EDK II Build	Standalone Python* Script
Update Granularity	Focused on Monolithic	Designed to support Multiple Components
Authentication	PKCS7 Single Key	PKCS7 Multiple Keys
Pre Check	N/A	Power/Battery, Thermal, System
Update Indicator	Requires platform code	Built-in with Consistent UX and Progress Bar
Firmware Management Protocol (FMP)	Requires full implementation	Produced by FmpDxe module customized using configuration data and small libraries
Test Key Detection	Requires platform code	Built-in
Watchdog	Requires platform code	Built-in
ESRT Driver	Legacy + FMP	Smaller/Simpler FMP only version


^{*} Other names and brands may be claimed as property of others

Firmware Update Indicators

ST .


UEFI Graphics Console

EFI_GRAPHICS_OUTPUT_PROTOCOL




UEFI Text Console

EFI_SIMPLE_TEXT_OUTPUT_PROTOCOL



Customize with a new DisplayUpdateProgressLib instance

FmpDxe Module Overview



FmpDxe Module Configuration

Name	Description
FILE_GUID	ESRT GUID Value
PcdFmpDeviceImageIdName	FMP Image Descriptor - Unicode string
PcdFmpDeviceBuildTimeLowestSupportedVersion	Build time FMP/ESRT default value
PcdFmpDeviceLockEventGuid	Event GUID to lock FW storage device. Default is End of DXE.
PcdFmpDeviceProgressWatchdogTimeInSeconds	Watchdog armed on each progress update
PcdFmpDeviceProgressColor	24-bit Progress Bar Color (0x00rrggbb)
PcdFmpDevicePkcs7CertBufferXdr	One or more PKCS7 Certs in XDR format. Encode w/BaseTools/Scripts/BinToPcd
PcdFmpDeviceTestKeySha256Digest	Set to {0} to disable test key detection

XDR = External Data Representation using Variable-Length Opaque Data format from RFC 4506

CapsuleUpdatePolicyLib APIs Platform Specific Library



Name	Description
CheckSystemPower()	Is system power/battery ok for FW update?
CheckSystemThermal()	Is system temperature ok for FW update?
CheckSystemEnvironment()	Is the system environment ok for FW update?
<pre>IsLowestSupportedVersionCheckRequired()</pre>	Skip lowest supported version check? (e.g. Service Mode)
<pre>IsLockFmpDeviceAtLockEventGuidRequired()</pre>	Skip firmware storage device lock action? (e.g. Manufacturing Mode)


FmpDeviceLib APIs Device Specific Library



Name	Description
RegisterFmpInstaller()	Future expansion for add-in controllers.
FmpDeviceGetSize()	Size of <i>currently stored FW image</i> .
FmpDeviceGetImageTypeIdGuidPtr()	ESRT/FMP GUID. Overrides FILE_GUID value.
FmpDeviceGetAttributes()	FMP Attributes Supported/Settings.
FmpDeviceGetLowestSupportedVersion()	LSV from <i>currently stored FW image</i> .
<pre>FmpDeviceGetVersionString()</pre>	Unicode version string from currently stored FW image.
FmpDeviceGetVersion()	32-bit version value from <i>currently stored FW image</i> .
FmpDeviceGetImage()	Retrieve copy of <i>currently stored FW image</i> .
FmpDeviceCheckImage()	Check if a new FW image is valid for this device.
FmpDeviceSetImage()	Update FW storage with a new FW image.
FmpDeviceLock()	Lock FW storage to prevent any further changes.

ESRT GUIDs and Keys (Multiple Components)






ESRT GUID A GUID B GUID C GUID D

ESRT GUIDs and Keys 3rd Party FMP Driver






ESRT
GUID A
GUID B

3rd Party UEFI Capsules must be re-signed with System Key

ESRT GUIDs and Keys 3rd Party FMP Driver





ESRT
GUID A
GUID B

System allows UEFI Capsules from 3rd Party to be installed

Add FMP to Existing Device Driver





Device Driver

FMP Library

ImageTypeId GUID A

Public Key(s)

FMP Driver

ImageTypeId GUID B

Public Key(s)

FMP Driver

ImageTypeId GUID C

Public Key(s) **ESRT**

GUID A

GUID B

GUID C

Summary



- New UEFI Capsule Update Features in EDK II
 - Platform firmware and device firmware (ESRT/FMP)
 - Multiple authentication keys & test key detection
 - Improved UX and system update pre-checks
- Simplified capsule generation (Python script)
- Supports OS-based firmware update workflow
 - Model Based Servicing via Microsoft Windows Update
 - Linux Vendor Firmware Service (LVFS) via fwupd.org

Call to Action



- Add UEFI Capsule Support to platforms
- Implement UEFI Capsule Update for devices
- Take advantage of EDK II FmpDevicePkg features
- Use Windows Update & LVFS to simplify distribution of firmware updates
- Provide feedback and contribute!
 - TianoCore https://www.tianocore.org/
 - LVFS https://fwupd.org/

Thanks for attending the Fall 2018 UEFI Seminar and Plugfest



For more information on the Unified EFI Forum and UEFI Specifications, visit http://www.uefi.org



Intel Legal Notice



Intel, the Intel logo are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries.

*Other names and brands may be claimed as the property of others

© Intel Corporation.