Rev. C Printed Parts Guide (Voron 2.4 Kit)

Refer to the **Part Printing Guidelines** section of the official <u>assembly manual</u> \boxtimes for general print settings. For the latest parts files, visit the Voron <u>Github repository</u> \boxtimes . If you do not have the means to print your own parts in ABS, the <u>Voron Print It Forward program</u> \boxtimes is a great option to obtain the parts at a very reasonable cost. If you do plan on printing the parts, refer to the following directions for LDO kit specific options:

Colour Coding

- ▶ Purple These are not optional and must be printed for our kit to work.
- ▶ Blue These are optional parts/changes that improve fit, appearance, or quality of life.

Printed Parts

- ▶ Stealthburner Toolhead Our kit ships with parts to make the Stealthburner + Clockwork 2 toolhead, print the stealthburner and clockwork 2 parts here \textit{\textit{C}}. We also provide a two piece toolhead PCB to aid in wiring, print the PCB spacer here \textit{C} and use this cable_door designed for an external chamber thermistor instead of the standard cable_door.
- ▶ Nozzle Probe- Our kit includes a Z endstop PCB for better modularity, use this part ☑ instead
- ▶ Cable Chain Parts Our cable chain ends use the 2 hole configuration. When printing parts that interface with cable chains, always use the **2hole** version instead of **3hole**(e.g. *xy_joint_cable_bridge_2hole* instead of *xy_joint_cable_bridge_3hole*) or use our version with hole offsets for more flexibility with this part .
- ▶ **Plug Panel** Our kits ship with 1.2mm AC inlets with integrated switches. Use <u>power_inlet_IECGS_1.2mm</u> ☐ instead of <u>power_inlet_filtered</u> or the <u>power_inlet_IECGS_1mm</u>.
- ➤ XY Endstop Our kit includes the XY microswitch PCB ② , print [a]_endstop_pod_D2F_switch instead of [a]_endstop_pod_hall_effect.
- ▶ **Breakout PCB Mount** This <u>part</u> ☑ works with the toolhead breakout PCB. Use 4 M2x10 self-tapping screws to attach the PCB to the part. Also print a DIN clip ☑ to mount onto the DIN rail.
- ► Controller Mount Our rev. A kits ship with the BigTreeTech Octopus V1.1 controllers, the corresponding PCBmount can be found in the here ☑, don't forget to also print two DIN clips ☑.
- ▶ **Heatbed Wiring Mount** Print this part to mount the WAGO terminals and PCB, which are used to breakout the heatpad power and thermistor cables. 2xM3x8 SHCS and 2x Heatset Inserts
- ▶ **Touch Screen Mount** The BigTreeTech touchscreen, print the mount from here Lo not print the mini12864 parts under STLs/Skirt.
- ▶ **Beefy Raspberry Pi Mount** this ☑ optional Raspberry Pi mount uses two DIN clips instead of one for an

extra secure grip on the DIN rails. **Tip**: if you find it difficult to insert the USB/Ethernet cables due to a lack of space, try rotating the RPi in relation to its mount.

- ▶ **Deck Support Clips** Our kit ships with 4mm deck panels, using 4mm deck support clips ☑ will help prevent the deck from potential sagging.
- ▶ **LED/Fan Splitter Spacer** Our kits ship with LED strips and an LED/Fan splitter PCB. Print this 2 x <u>part</u> ☑ to mount the splitter PCBs to a 2020 extrusion.
- ▶ **LED Light Clip** The included LED light strips can be mounted using these <u>bar clips</u> ☑ by eddie. In total, you will need 36 or 42 clips for V2-300 and V2-350 respectively
- ▶ Handlebar Spacer This optional part ☑ offsets the top panel thickness and helps mount the included aluminum handlebar. Mount with M5x14 screws and M5 T-Nut Hammer Heads.
- ▶ **Z stoppers** Totally optional <u>stoppers</u> that you can install at the top of the Z linear rails to prevent the carts from falling out.
- ▶ **LDO Insert** Show some LDO love and print this <u>optional insert</u>

 that can be installed into the skirts on your machine.
- ▶ Exhaust_Filter The exhaust filter ☑ is optional since the kit includes only parts for the Nevermore filter.

 The kit does NOT include the necessary fan for this assembly.
- ▶ **Z Belt Cover A** This modified <u>z-belt cover A</u> 🖸 allows for the routing of the led strips through the Z-belt opening as an alternate path.

Mods

- ▶ **LDO Door Handles/Hinges** The LDO alternative set of <u>handles and hinges</u> ☑ has a special spot to display your unique LDO Voron Kit #. You can use either M3x30, M3x35 or M3x40 SHCS screws for the hinges. You will also need the standard door latches ☑.
- ➤ **Klicky Probe** We include parts for the optional Klicky probe mod by jlas1, check out more info on the mod here ☑ .
- ▶ Nevermore Filter Our kits include parts to build a <u>Nevermore Micro V5 Duo</u> ☑ by 0dsk4. print the version which uses 3x6 magnets. If you decide to build the Nevermore filter, print this <u>exhaust cover</u> ☑ with the stock exhaust grill ☑ to seal the back panel.
- ▶ **Steppy Keychain** Last but not least your kit comes with the <u>steppy mascot</u> ☑ keychain kit, you will need these printable parts.
- ▶ **Purge Bucket** Starting from Rev. B, our kit includes a brass brush which you can convert into automated nozzle scrubber using this mod ☑ . Our build plate is slightly taller than standard so modified sheet stop files can be printed here ☑ .