COLOR ON

1. Home Page

2. Live View

3. Remote Playback

4. Account Management

5. Gallery

6. Notification

7. Local

8. Device List

9. Push Settings

10.Event

1 Menu Button
• Tap to open side menu.
• Access all app sections like Device List, Live View, Playback, Gallery, Settings, etc.
2 Add Device
• Tap to add NVR, DVR, IP Camera or scan QR code.
3 Notifications
• Tap to view all alerts and event notifications.
4 Search Bar
• Search devices by Name or Serial Number (SN).
5 Total Devices
• Shows total number of devices added in the app.
6 Online
• Shows how many devices are currently online.
7 Channels
• Total number of channels from all devices.
8 Alerts
• Total number of events and alarm messages.
Welcome !
Dragon Praki
Search for Devices by Name or SN
Status Overview
3
Total Devices
5
2
Online
6
33
Channels
7
52
Alerts
8
Quick Actions
Device
Live View
Play Back
Events
9
10
11
12
9 Device
• Manage devices.
• Add, edit, delete and configure devices.
10 Live View
• Open live camera monitoring.
• Select device and channel to watch live.
11 Play Back
• Play recorded videos from devices.
• Search by date and channel.
12 Events
• View all event history.
• Includes Motion, Human, Vehicle, etc.
Device List
13
All
Favorites
13 All / Favorites Tab
• All: Show all devices.
• Favorites: Show only favorite devices.
Demo
Offline
16 Channels
14
15
16
14 Favorite Icon
• Tap to add or remove device from favorites.
15 Quick Live View Icon
• Tap to open live view of first channel.
16 Play Button
• Tap to open device and select channel.
• Start live view immediately.
Office
Online
16 Channels
LIVE
Search
Scan
Profile
17 Search
• Tap to search devices by Name or SN.
18 Scan
• Tap to scan QR code of device.
• Add device quickly.
19 Profile
• Open profile, settings, account info and logout.



1 Profile Area

- Shows your profile picture, name and account.
- Tap to open Profile Settings screen.

2 Remote Setting

- Configure and manage remote device settings.
- Change network, record, alarm, storage, etc. remotely.

3 Local

- Access and manage files saved on your phone.
- View local recordings and snapshots.

4 Device List

- View all added devices.
- Manage, edit or check device status.

5 Gallery

- View snapshots and recorded videos.
- Export or share files easily.

6 Push Setting

- Configure push notifications.
- Enable/disable alerts like motion, human, vehicle, etc.

7 Notifications

- View all alerts and event notifications.
- Mark as read or clear alerts.

8 Help

- Get help and support.
- FAQs and guidelines.

9 About

- App information and version.
- Terms and privacy policy.

10 Logout

- Tap to logout from the app.
- Your account session will be ended.

What You Can Do from This Menu?

- Configure devices remotely or access local files.
- Manage devices and view gallery.
- Stay updated with notifications and alerts.
- Get help or check app information.
- Logout securely from the app.

DEMO – CHANNEL LIST POPUP EXPLAINED

This popup appears when you tap on a device (like “Demo”) from the Device List.
It shows all available channels in that device. Select any channel to view live or recorded video.



1 **Face**
Tap to view live stream from the Face detection camera.

2 **IP Camera**
Tap to view live stream from the IP Camera.

3 **COLOR ON**
Tap to view live stream in color mode.

4 **Two Way**
Tap to open two way audio camera (listen & talk).

5 **FirstFloorBay 1**
Tap to view live stream from First Floor Bay 1 camera.

6 **Firstfloor Ent**
Tap to view live stream from First Floor Entrance camera.

7 **Reception1**
Tap to view live stream from the Reception area camera.

8 **DATA ENTRY**
Tap to view live stream from the Data Entry camera.

How to Use

- Tap on any channel name to open its live view.
- Make sure the device is online to view live stream.
- Use back button or tap “X” to close this popup.

Note

- The channel list depends on how many channels are added in the device (NVR/DVR).

DEMO LIVE VIEW SCREEN – EXPLAINED

This screen shows the live video of the selected channel (here: DATA ENTRY).
You can view live feed, do playback, capture images, record, check alarms and more.

1 Back Button

- Tap to go back to the previous screen (Device List).

2 Refresh Button

- Tap to refresh the live video stream if it stops or lags.

3 Channel Name

- Shows the name of the selected channel. (Here: DATA ENTRY)

4 Date & Time

- Shows the current date and time of the live feed.

5 Live Video

- This is the live video feed from the selected channel.

12 Change Device

- Tap to switch to another device or channel.

13 Alarm Timeline

- The dots show multiple alarms. The filled one indicates the current alarm.

14 Alarm Item

- Shows the alarm type, related channel and time of the event.
- Tap to view details.

15 Home

- Tap to go to the Home Dashboard.

16 Audio

- Tap to enable/ disable two-way audio (if supported).

17 Scan (QR)

- Tap to scan QR code to add device quickly.

18 Sound/Mute

- Tap to mute or unmute the live audio.

19 Profile

- Tap to open your profile menu.

LIVE VIEW CONTROLS – EXPLAINED

6 Playback	Play recorded videos from the selected channel.	9 Quality	Change video quality (SD / HD).	12 Change Device	Switch to another device or channel.
7 Snapshot	Capture and save the current image.	10 Grid	Enable/disable grid lines on the screen.	13 Alarm Timeline	Shows multiple alarms. Select one to view.
8 Record	Start/stop manual recording of live video.	11 Cam List	View list of channels in this device.	14 Alarm Item	Tap to see full alarm details and event info.

1. LIVE VIEW SCREEN (MAIN SCREEN)

This is the live video screen of the selected channel (here: Face).
You can watch live feed and use different controls.

1 Back Button

Tap to go back to the **previous** screen (**Device List**).

2 Refresh Button

Tap to **refresh** the **live video stream** if it stops or lags.

3 Channel Name

Shows the name of the **currently** selected channel. (Here: **Face**)

4 Date & Time

Shows the current **date** and **time** of the live **feed**.

5 Live Video Window

Displays the live **video** from the selected channel.



6 Playback

Tap to play recorded videos from this channel.

7 Snapshot

Tap to capture and save a current image.

8 Record

Tap to start/stop manual recording of live video.

9 Quality

Tap to change video quality (SD / HD).

10 Grid

Tap to enable / disable grid lines on the screen.

11 Cam List

Tap to view the list of channels in this device.

2. DEVICE LIST (BOTTOM SHEET)

This bottom sheet shows all devices added in the app.
You can switch to any device by tapping on it.



12 Device List Title

Shows the list of all devices added in the app.

13 Device Item

Tap on any device to open its live view / channels.

14 Online Status

Green dot means the device is online.

15 Device IP & Channels

Shows the IP address and total number of channels in the device.

16 More Devices

All other added devices are listed here.

Note

- Swipe **up/down** on the bottom sheet to view more devices.
- Make sure the device is **online** to view live video.

DEMO PLAYBACK SCREEN – EXPLAINED

This screen helps you play recorded videos, switch channels, filter events and navigate using the bottom menu.

1 Back Button

Tap to go back to the previous screen.

2 Calendar Icon

Tap to open calendar and choose any date for playback.

3 Refresh Button

Tap to refresh the recordings for the selected date.

4 Date Selector

Tap any date to view its recorded videos.

5 Video Player

Displays the recorded video of the selected channel and time.

6 Playback Controls

- **Pause**: Pause / Resume video.
- **Snapshot**: Capture current frame.
- **Record**: Start / Stop manual recording.
- **Forward**: Play forward.
- **Rewind**: Play backward.
- **Grid**: Change view layout.
- **Device**: Go to device list.

7 Channel Selection

- Tap any channel name to view its recordings.
- The selected channel is shown in dark red.

8 Filter Options

- **All**: Show all recordings.
- **Event**: Show only event recordings.
- **Time Display**: Current playback time.
- **Motion**: Show motion events.
- **Vehicle**: Show vehicle events.
- **Zoom**: Zoom in / Zoom out timeline.

9 Timeline

- Red bars show recorded activity.
- Drag left / right to seek any time in video.

10 Home

Tap to go to the Home Dashboard.

11 Audio

Tap to enable / disable two-way audio (if supported).

12 Scan (QR)

Tap to scan QR code to add device quickly.

13 Sound / Mute

Tap to mute or unmute the playback audio.

14 Profile

Tap to open your profile menu.

Note

- Make sure the device is online to view recordings.
- The available channels and filters depend on the device features.
- Use zoom and timeline to find the exact event you want to view.

SELECT DEVICE POPUP – EXPLAINED

This popup appears when you tap “Device” from the playback screen.
Use it to switch between different devices.



1 Close Button

Tap “X” to close this popup.

2 Selected Device

The currently active device is highlighted with a red border and a check mark.

3 Device Icon

This icon represents a device / DVR / NVR.

4 Device Status

“Online” in green means the device is connected and ready.

5 Other Devices

Tap on any other device to switch and view its playback.

HOW IT WORKS

1. Tap “Device” on the playback screen. →
2. The “Select Device” popup will appear. →
3. Tap on the device you want to view. →
4. The selected device will load its playback.

NOTES

- Only online devices are shown in the list.
- You can add or remove devices from the Device List in app settings.
- Make sure the device is online to view its playback.

PROFILE / ACCOUNT SCREEN – EXPLAINED

This screen shows your account details, connected devices & cameras, and allows you to change your password.



1 Back Button

Tap to go back to the previous screen.

2 Logout Button

Tap to log out from your account.

3 Profile Picture

Displays your profile picture.

4 Edit Profile

Tap the pencil icon to update your profile picture.

5 User Name

Shows your registered account name.

6 Devices & Cameras Summary

- **Devices:** Total number of connected devices.
- **IP Cameras:** Total number of IP cameras added.

7 Basic Info

Shows your registered email address and phone number.

8 Edit Password Section

Tap the pencil icon to enable password change fields.

9 Create New Password

Enter your new password here.

10 Confirm Password

Re-enter your new password to confirm.

11 Save Button

Tap to save all changes (profile or password update).

QUICK SUMMARY

1. **Back Button** – Return to previous screen.
2. **Logout Button** – Log out of your account.
3. **Profile Picture** – Your account picture.
4. **Edit Profile** – Change your profile picture.
5. **User Name** – Your registered name.
6. **Devices & Cameras** – Connected counts.
7. **Basic Info** – Email and phone details.
8. **Edit Password Section** – Enable editing.
9. **Create New Password** – Set new password.
10. **Confirm Password** – Confirm new password.
11. **Save Button** – Save all changes.

NOTE

- Keep your password strong and secure.
- Update your profile picture for easy identification.
- All changes will be saved only after tapping “Save”.

GALLERY SCREEN – EXPLAINED

The Gallery screen shows all your saved images and videos.
You can view, manage and switch between media types.



1 Back Button

Tap to go back to the previous screen.

2 Refresh Button

Tap to refresh the gallery list and load latest media.

3 Screen Title

Shows the current screen name.

4 Account Email

Displays the email ID of the logged-in user.

5 Media Type Tabs

Switch between Images and Videos.

The selected tab is highlighted in red.

6 Media Preview

Shows thumbnail preview of the image or video.

7 File Name

Displays the name of the image or video file.

8 Date & Time

Shows when the media was captured or saved.

9 File Size

Displays the size of the media file.

10 More Options

Tap the three dots to get more actions (share, delete, rename, etc.).

11 Tap to View

Tap to open and view the selected media in full screen.

MEDIA LIST ITEM – DETAILS

Thumbnail
Small preview of the media.

File Name
Name of the media file.

Date & Time
When the media was captured or saved.

File Size
Storage size of the media.

More Options
Additional actions for the media file.

Tap to View
Open and view the media in full screen.

QUICK TIPS

- Use "Images" tab to view all saved pictures.
- Use "Videos" tab to view all saved videos.
- Tap Refresh to see the latest media files.
- Tap on any item or "Tap to View" to open it in full screen.
- Use More Options (⋮ for share, delete or other actions.

GALLERY – VIDEOS TAB EXPLAINED

This screen shows all your saved videos. You can view, manage and open any video in full screen.



1 Back Button

Tap to go back to the previous screen.

2 Refresh Button

Tap to refresh the video list and load latest videos.

3 Screen Title

Shows the current screen name: Gallery.

4 Account Email

Displays the email ID of the logged-in user.

5 Videos Tab

Shows the list of all saved videos. This tab is currently selected.

6 More Options

Tap the three dots to open more options (share, delete, rename, etc.).

10 Video Preview

Shows a thumbnail preview of the video. Tap the play icon on the thumbnail to start playback.

7 Date & Time

Shows the exact date and time when the video was recorded.

8 File Size

Displays the size of the video file.

9 Tap to View

Tap to open and play the selected video in full screen.

VIDEO LIST ITEM – DETAILS EXPLAINED

Thumbnail

Small preview image of the video.

File Name

Name of the video file.

Date & Time

When the video was recorded or saved.

File Size

Storage size of the video file.

More Options

Additional actions: share, delete, rename, etc.

Tap to View

Open the video and watch in full screen.

QUICK TIPS

- Use “Videos” tab to view all saved videos.
- Tap the play icon on thumbnail or “Tap to View” to play the video.
- Use Refresh to load the latest videos.
- Use the three dots ⋮ for more actions on any video.

NOTIFICATIONS SCREEN – EXPLAINED

This screen shows all alerts and activities from your devices.
You can search, filter and quickly play event recordings.



1 Back Button
Tap to go back to the previous screen.

2 Clear All / Delete
Tap to clear all notifications from the list.

3 Search Bar
Search alerts by keyword, device name or event type.

4 Filter Tabs
Tap to filter notifications by type.

- All
- Motion
- AI Alert
- System

5 Play Button
Tap to play the recorded video of that alert.

6 Event Icon
Shows the type of event. (Example: Motion detected)

7 Event Time
Displays the time when the alert was triggered.

8 Date & Device Info
Shows the date of the alert and the device name where it occurred.

9 NEW Badge
Indicates that the notification is new and unread.

QUICK REFERENCE GUIDE

1 Back Button
Go back to the previous screen.

2 Clear All / Delete
Remove all notifications from the list.

3 Search Bar
Search alerts by keyword or device name.

4 Filter Tabs
Filter alerts by category.

5 Play Button
Play the recorded video of the selected alert.

6 Event Icon
Shows the type of event (e.g., Motion detected).

7 Event Time
Shows the exact time of the alert.

8 Date & Device Info
Displays date of alert and device name.

9 NEW Badge
Shows that the alert is new and unread.

TIPS

- Use filters to quickly find the type of alerts you want.
- Tap the play button to review the event recording.
- Clear all notifications when they are no longer needed.

NOTIFICATION DETAIL (BOTTOM SHEET) – EXPLAINED

When you tap on any notification in the list, a bottom sheet opens showing detailed information and quick actions for that alert.



1 Close Button

Tap "X" to close this bottom sheet and return to the notifications list.

2 Event Icon

Shows the type of event that triggered the notification. (Example: Motion detected)

3 Event Title

Displays the name of the event. (Example: Motion Alarm)

4 Date & Time

Shows the exact date and time when the event occurred.

5 Device & Camera Information

Displays the device name and camera where the event was captured. (Example: Device Demo, Camera Face)

6 Live View

Tap to watch the live video from the same camera.

7 Playback

Tap to play back the recorded video of this event.

8 Delete

Tap to delete this notification and its recorded video.

QUICK REFERENCE GUIDE

1	×	**Close Button (X)** Close the bottom sheet.	5		**Device & Camera Info** Shows device name and camera name.
2		**Event Icon** Indicates the type of event (e.g., Motion detected).	6		**Live View** Watch live video from the camera.
3	Motion Alarm	**Event Title** Name of the event.	7		**Playback** Play the recorded video of this event.
4		**Date & Time** Exact date and time of the event.	8		**Delete** Delete the notification and its video.

TIPS

- Use Live View to check what's happening in real-time.
- Use Playback to review the event recording.
- Delete old notifications to keep your list clean and organized.
- You can close the sheet by tapping 'X' or dragging it down.

LOCAL SETTINGS SCREEN – EXPLAINED

This screen allows you to customize app behavior, video & playback preferences and storage & capture settings.



1 Notification Permissions

Tap Enable to allow system-level notification access for the app.

2 Foreground Notification

Turn ON to receive alerts while the app is open and in use.

3 Playback Pre-Time

Set time (in seconds) to start playback before the event occurs.

4 Resolution Adaption

Auto adjust video quality when network is poor.

5 Original Scale

Turn ON to play video in native aspect ratio. (May crop on some screens).

6 OSD

Show On-Screen Display like camera name, time, bitrate on video.

7 Reserved Space

Set minimum free storage space to keep your device running smoothly.

8 Loop Recording

Turn ON to overwrite the oldest files when storage is full.

9 Snap Num

Choose how many photos to capture per snapshot action.

10 Split Snap

Turn ON to split large snapshots into multiple parts.

QUICK REFERENCE GUIDE

1. **Notification Permissions** — Allow system notifications for the app.
2. **Foreground Notification** — Receive alerts while using the app.
3. **Playback Pre-Time** — Start playback a few seconds before the event.
4. **Resolution Adaption** — Auto switch video quality on poor network.
5. **Original Scale** — Play video in native aspect ratio.
6. **OSD** — Show camera info, time, bitrate on video.
7. **Reserved Space** — Keep minimum storage free.
8. **Loop Recording** — Overwrite oldest files automatically.
9. **Snap Num** — Set number of photos per snapshot.
10. **Split Snap** — Split large images into multiple parts.

TIPS

- Enable important notifications to never miss alerts.
- Adjust pre-time and resolution settings for better playback experience.
- Manage storage settings to prevent recording interruptions.
- Tap the gear icon (⚙) to access advanced configuration.

LOCAL SETTINGS SCREEN – EXPLAINED

This screen helps you customize camera operation, app behavior and system preferences to suit your needs.



1 Reverse Control

Turn ON to invert the directions of the PTZ joystick (up/down/left/right).

2 PTZ Gesture Prompts

Turn ON to show on-screen guides that help you use PTZ gestures.

3 Automatic Connection

Turn ON to automatically connect to the last viewed device when the app starts.

4 Lock Landscape

Turn ON to lock the app in landscape mode while viewing live or playback.

5 Rotation Correction

Turn ON to correct image orientation if the camera is installed rotated.

6 Favorites

Tap to manage and organize your favorite devices for quick access.

7 WiFi Configuration

Tap to set up or change the WiFi network of the device.

8 Launch Setting

Set what the app should show or do when it launches. (Example shown: DEVICE_LIST)

9 Domain

Select the cloud or P2P server region/endpoint for connecting the device.

QUICK REFERENCE GUIDE

1. **Reverse Control** – Invert PTZ joystick directions.
2. **PTZ Gesture Prompts** – Show visual guides for PTZ control.
3. **Automatic Connection** – Auto connect to last device.
4. **Lock Landscape** – Force landscape view.
5. **Rotation Correction** – Fix rotated camera view.
6. **Favorites** – Manage favorite devices.
7. **WiFi Configuration** – Configure device WiFi.
8. **Launch Setting** – Define app behavior on startup.
9. **Domain** – Set cloud / P2P server endpoint.

TIPS

- Enable only the features you need for a smoother experience.
- Use Favorites to access important devices quickly.
- Keep WiFi and Domain settings correct for stable connection.
- Rotation Correction is useful when the camera is mounted at an angle.

SCAN QR CODE SCREEN – EXPLAINED

This screen is used to scan a QR code and add a new device to your account.



1 Back Button

Tap to go back to the previous screen.

2 Help / Info

Tap to view help or instructions on how to scan a QR code.

3 QR Code Scanner Area

Position the QR code inside this box. The app will automatically scan the code.

4 Instruction Text

Guides you to scan any QR code to add a new device.

5 Gallery Option

Tap to select a QR code image from your phone's gallery and scan it.

6 Flash Option

Tap to turn the flashlight ON/OFF for better scanning in low light.

QUICK GUIDE

1 Back Button
Returns to the previous screen.

2 Help / Info
Open help to learn how to scan QR codes.

3 QR Code Scanner Area
Place the QR code inside the box to scan automatically.

4 Instruction Text
Tells you to scan any QR code to add a new device.

5 Gallery Option
Choose a QR code from the gallery to scan.

6 Flash Option
Toggle flash ON/OFF for better visibility.

TIPS

- Make sure the QR code is clear and well-lit.
- Hold your phone steady and keep the QR code within the box.
- You can also scan QR codes from images in your gallery.

DEVICE LIST SCREEN – EXPLAINED

This screen shows all the devices added to your account.
You can search, view, manage and organize your devices easily.



1 Back Button
Tap to go back to the previous screen.

2 Add Device
Tap '+' to add a new device to your list.

3 Search Bar
Type the device name, IP or any keyword to search devices.

4 Tabs
- **All Devices**: Shows all added devices.
- **Favorites**: Shows only favorite devices.

5 Favorite Icon
Tap the heart icon to mark / unmark the device as favorite.

6 Device Information
Displays the main information about the device.
- IP Address
- Port
- Device Type (NVR/DVR)
- Channels (Ch)
- Protocol (Proto)
- Model
- Version (Ver)

7 Device Actions
Manage the device using available actions.
- Edit
- View (Live View)
- Channels
- Config
- Delete

8 Bottom Navigation
Quick access to Search / Devices, Scan and Profile.

QUICK REFERENCE GUIDE

1 Back Button — Go back to the previous screen.	**5 Favorite Icon** — Add or remove device from favorites.
2 Add Device — Add a new device to your account.	**6 Device Information** — View detailed device information.
3 Search Bar — Search devices by name, IP or keyword.	**7 Device Actions** — Edit, View, Channels, Config or Delete the device.
4 Tabs — Switch between All Devices and Favorites.	**8 Bottom Navigation** — Quick access to Search, Scan and Profile.

TIPS

- Mark important devices as Favorites for quick access.
- Use Search to find devices faster in a large list.
- Keep your device information updated for better performance.
- Use View to watch live feed and Channels to manage camera channels.

PUSH SETTING SCREEN – EXPLAINED

This screen helps you manage push notification settings for all your devices and view their push history.



1 Back Button
Tap to go back to the previous screen.

2 Add Button (+)
Tap to add a new device to your list.

3 Search Bar
Search for a device by name, IP address or keyword.

4 Tabs
- **All Devices:** Shows all added devices.
- **Favorites:** Shows only favorite devices.

5 Favorite Icon
Tap the heart icon to add or remove the device from favorites.

6 Device Info
Shows the device details like IP address, port, type, channel count and protocol.

7 Online Status
Green dot indicates the device is online.

8 Push Settings
Tap to configure push notification settings for this device.

9 History
Tap to view push notification history of this device.

QUICK REFERENCE GUIDE

1	←	**Back Button** Go back to the previous screen.
2	+	**Add Button (+)** Add a new device.
3	🔍	**Search Bar** Search devices easily.
4	Tabs	**Tabs** Switch between All Devices and Favorites.
5	♡	**Favorite Icon** Add or remove device from favorites.
6	ⓘ	**Device Info** Shows IP, Port, Type, Channel and Protocol details.
7	●	**Online Status** Green dot = Device is online.
8	⚙	**Push Settings** Open push notification settings for the device.
9	🕘	**History** View push notification history.

TIPS

- Enable push notifications from *Push Settings* for each device.
- Add important devices to *Favorites* for quick access.
- Regularly check History to review notification records.

PUSH SETTINGS (CONFIGURATION) SCREEN – EXPLAINED

This screen is used to enable push notifications and choose the types of alerts you want to receive from your device.



1 Back Button

Tap to go back to the previous screen without saving changes.

2 Save Button

Tap to save all changes and apply the push settings for this device.

3 Enable Push Message

Master switch. When **ON**, all users will receive push notifications from this device.

4 Message Subscription

Personal setting. Turn **ON** to receive alerts on your own device.

5 AI Detection Section

List of all AI events. Tap any item to configure which cameras will send that type of alert.

6 Event Type

Shows different AI events that can trigger push notifications.

7 Camera Mapping

Shows cameras **selected** for this **event**. The numbers indicate camera **indexes (1st, 2nd, 3rd, 4th, 5th, 6th)**. Tap to change.

QUICK REFERENCE GUIDE

1 Back Button
Go back to previous screen.

2 Save Button
Save and apply all changes.

3 Enable Push Message
Master switch for all users of this device.

4 Message Subscription
Personal switch to receive alerts.

5 AI Detection Section
All available AI event types are listed here.

6 Event Type
Tap an event to configure its camera and notification settings.

7 Camera Mapping
Shows which cameras will send alerts for this event.

TIPS

- Turn ON *Enable Push Message* to allow notifications for everyone.
- Keep **Message Subscription ON** to receive alerts on your phone.
- Select cameras for each event to get only relevant alerts.
- Tap the Save (✓) button to apply your settings.

DASHBOARD SCREEN – EXPLAINED

This is the main dashboard of the app.
You can add devices, view status, access quick actions and manage your devices easily.



1 Menu Button
Tap to open the side menu with more options.

2 More Options
Tap the three dots to open the device addition menu.

3 Search Bar
Search devices by name, IP address or keyword.

4 Add Device Menu
- **Scan QR Code:** Add device by scanning QR.
- **Add Device Manually:** Add device by entering details manually.
- **LAN Search:** Search and add devices on the same network.

3 Status Overview
Shows summary of your system: Total Devices, Online Devices, Channels and Alerts.

6 Quick Actions
Quick access to important features.
- Device
- Live View
- Play Back
- Events

7 Device List
Displays all added devices. Tap play button to view live feed.

8 Tabs
Switch between All Devices and Favorite Devices.

9 Bottom Navigation - Search
Tap to open the search screen.

11 Bottom Navigation - Profile
Tap to open your profile and account settings.

10 Bottom Navigation - Scan
Tap to scan QR code and add a device.

QUICK REFERENCE GUIDE

1	☰	**Menu Button** Opens the side menu.	7		**Device List** View and manage your devices.
2	⋮	**More Options** Open device addition menu.	8		**Tabs** Filter between All and Favorites.
3	🔍	**Search Bar** Search devices by name or IP.	9	🔍	**Bottom Nav – Search** Go to search screen.
4	☰	**Add Device Menu** Add device via QR, Manual or LAN.	10		**Bottom Nav – Scan** Scan QR code to add device.
5		**Status Overview** View system summary at a glance.	11		**Bottom Nav – Profile** Open profile & settings.
6	⚡	**Quick Actions** Access key features quickly.			

TIPS

- Use Search to find devices quickly.
- Tap **Quick Actions** for instant access to key features.
- Use the three dots menu to add devices in different ways.

◆ ADD DEVICE SCREEN – EXPLAINED

This screen is used to add a new device manually by entering its details and connection information.



1 Device Name

Enter a name for your device to identify it easily in the app.

3 Device Category

Select the type of device you want to add.

- NVR
- DVR
- XVR
- IP Cam

5 Connection Method

Choose how you want to connect to the device.

- IP/Domain Name
- NVR
- Serial Number

7 IP Address

Enter the IP address of your device.

9 Port

Default port is shown. Change it only if your device uses a different port.

11 Username

Enter the username for your device (default is admin).

2 Protocol Type

Select the protocol used to connect the device.

- TVT Private (Default)
- ONVIF

4 Protocol Info

Shows the protocol information used for connection.

6 LAN Search

Tap to search for devices in your local area network if you don't know the IP address.

8 Brand

Select the brand of your device.

10 Password

Enter the password of your device.

Tap the eye icon to show or hide the password.

QUICK REFERENCE GUIDE

1 **Device Name** — Give a unique name to your device.	7 **IP Address** — Enter the device IP address.
2 **Protocol Type** — Choose the connection protocol.	8 **Brand** — Choose the device brand.
3 **Device Category** — Select the device type.	9 **Port** — Enter the port number.
4 **Protocol Info** — Shows the selected protocol details.	10 **Password** — Enter the device password.
5 **Connection Method** — Select the connection method.	11 **Username** — Enter the device username.
6 **LAN Search** — Search devices in the local network.	

TIPS

- Make sure your device and mobile are on the same network.
- Use correct IP address, port, username and password for successful connection.
- If you don't know IP, use **LAN Search** to find your device automatically.

ADD DEVICE (SERIAL NUMBER METHOD) – EXPLAINED

This screen is used to add a device using its Serial Number.
Enter all details correctly and tap **Save** to add the device.

1 Device Name

Enter a unique name for your device to easily identify it in the app.

2 Device Category

Select the type of device you are adding.

- NVR
- DVR
- XVR
- IP Cam

3 Connection Method

Choose how you want to add the device.

- IP/Domain Name
- NVR
- Serial Number (Selected here)

4 Serial Number

Enter the **Serial** Number of your device.

(Usually found on the device label or in settings.)

5 Username

Enter the username to login to the device.

(Default is usually **admin**.)

6 Password

Enter the password of your device.

Tap the **eye** icon (if available) to show/hide password.

7 Save Button

Tap **Save** to add the device with the entered details.



QUICK REFERENCE GUIDE

1 Device Name — Give a unique name to your device.	**5 Username** — Enter the login username.
2 Device Category — Select the device type: NVR, DVR, XVR or IP Cam.	**6 Password** — Enter the device password.
3 Connection Method — Choose the method to add device: IP/Domain, NVR or Serial Number.	**7 Save Button** — Save the details to add the device.
4 Serial Number — Enter the device Serial Number.	

TIPS

- Make sure the device is powered on and connected to the same network.
- Double check the Serial Number, Username and Password.
- If you don't know the Serial Number, check the device label or system settings.