DDEELTCHT	
PREFLIGHT Doors & Windows Control Lock Required Documents (AR Maintenance Summary Squawk Log (SM & Paper Aircraft Log Battery Master Lights & Pitot Heat Flaps Fuel Gauges Fuel	CHECK
 L Wing Strobe L Position Light (Red) Tail Beacon Tail Position Light (White) R Wing Strobe R Position Light (Green) Landing / Taxi Light Pitot Heat Battery Master Lights & Pitot Heat 	FLASHING LIT FLASHING LIT FLASHING LIT LIT WARM OFF
 Pitot Cover Baggage Door Fuel Tester & Dipstick L Fuel Sump L Flap Support & Linkage L Aileron Linkage & Hinge L Wing Underside L Wing Tip L Position & Strobe Lights L Aileron & Flap Top Surfe 	es CHECK CHECK UNDAMAGED S SECURE
 L Horizontal Stabilizer L Elevator & Counterweig Elevator Cables (2) Rudder Cables (2) Tail Tie Down Chain Tail Beacon & Position Lig R Elevator & Counterweig Trim Tab & Linkage 	CHECK TENSION CHECK TENSION REMOVE pht SECURE

0	R Aileron & Flap Top S	urface	UNDAMAGED
0	R Position & Strobe Lie		SECURE
0	R Wing Tip	90	UNDAMAGED
0	R Flap Support & Link	age	CHECK
0	R Aileron Linkage & Hi		CHECK
0	R Wing Underside	9	CHECK
0	R Tire Tread & Inflatio	n CHE	CK/NO CORDS
0	R Brake		JRE/NO LEAKS
0	R Fuel Sump		DRÁIN/CHECK
0	R Strut		/UNDAMAGED
0	R Tie Down Chain		REMOVE
0	R Fuel Level		DIP/VERIFY
	R Wing Surface		UNDAMAGED
0	R Fuel Tank Cap		SECURE
	R Wing Openings		UNBLOCKED
0	Nose Strut		TED (3 fingers)
0	Nose Wheel Tread & In	ntlation	CHECK
0	Cowl Access Panel	DEL E 4 0	RELEASE
0	Engine Fuel Drain		E/CHECK FUEL
0	Engine Oil	CHE	CK QUANTITY
_	Add oil if needed		CECUPE
0	Cowl Screws	NO NITOL	SECURE
0	Propeller		(S/SCRATCHES
0	Spinner		/UNDAMAGED
0		CURE/CF	IECK TENSION
0	Engine Openings	CECUDE	UNBLOCKED
0	Landing Light	SECURE	/UNDAMAGED
0	Engine Access Panel Static Port		SECURE
0			UNBLOCKED
0	L Wing Openings L Fuel Level		UNBLOCKED
0			DIP/VERIFY SECURE
0	L Fuel Tank Cap L Wing Surface		UNDAMAGED
0	L Strut	SECLIDE	/UNDAMAGED
0	L Tie Down Chain	SECORE	REMOVE
0	Pitot Tube	SECTION	E/UNBLOCKED
0	L Tire Tread & Inflation		CK/NO CORDS
0	Fuel Tester & Dipstick	II CHL	STOW
0	Towbar		REMOVE
0		OTL AND	FUEL LEVELS
_	Allordin Log LIVILA	OIL AINL	J. OLL LL VLLS
Tow	aircraft out of spot		
0	Towbar		STOM
0		CL	STOW
J	Baggage Door	CL	OSED/LOCKED

ENGINE START

0	Seats/Belts/Harness	ADJUST
0	Doors	SECURE
0	Passenger Briefing	COMPLETE
0	Fire Extinguisher	LOCATE
0	Avionics Master	OFF
0	Circuit Breakers	IN
0	Brakes	SET
0	Battery Master	ON
0	Beacon	ON
0	Mixture	FULL RICH (in)
0	Throttle	¼ INCH
0	Primer (if needed)	2 - 3 STROKES
0	Primer	LOCK
0	Key (do not turn)	IN
0	CLEAR!!	
0	Key	START
0	Throttle	ADJUST 1000 RPM
0	Oil Pressure	GREEN
0	Mixture	LEAN OUT 1"
0	Alternator Master	ON
0	Ammeter	CHARGING
0	High/Low Voltage Light	OFF
0	Fuel Quantity (EGT)	CHECK/SET
0	Lights	AS NEEDED
0	Avionics Master	ON
0	Flaps	UP
0	GPS Database	CURRENT
0	Radio Frequencies	SET
0	ATIS/AWOS	RECORD
0	Altimeter	SET
0	Altimeter	VERIFY FIELD ELEV.
0	Directional Gyro	SET
0	Parking Brake	RELEASE
0	Toe Brakes	TEST/VERIFY

For Taxi: [Airport] ground, Skyhawk [Tail#] at [Location]. Taxi for takeoff with [ATIS Code].

0	Runway and Route	RECORD/REVIEW
l _	T. '1. B A	

Taxi to Runup Area

AI/DG/TC/Ball
 VERIFY DURING TAXI

RUNUP (CIGARRS)	TAKEOFF
BrakesSET	LIGHTS
CONTROLS	Beacon/StrobesON
Controls (box pattern)FREE & CORRECT	 Position & Landing Lights AS REQUIRED
INSTRUMENTS	CAMERA
 Altimeter SET/VERIFY APT. ELEV. 	TransponderALT
 Attitude Indicator VERIFY ERECT/SET 	Carb HeatOFF
 Turn Coordinator VERIFY/LIQUID/BALL 	MixtureFULL RICH (In)
 Directional Gyro VERIFY/SET 	ACTION
 Vertical Speed Indicator NOTE POSITION 	 Line up on Runway
GAS	• Throttle FULL
□ Fuel Selector BOTH	 Yoke LIGHT BACK PRESSURE
 Fuel Quantity VERIFY 	 Rudder STAY ON CENTERLINE
ATTITUDE	 Engine Instruments VERIFY
□ Trim TAKEOFF	
• Flaps SET AS REQUIRED	BEFORE LANDING (GUMPS)
•	GAS
RUNUP Mixture FULL RICH (In)	□ Fuel Selector BOTH
MixtureThrottleFULL RICH (In)1700 RPM	UNDERCARRIAGE
 Magnetos DROP <125 RPM / DIFF. <50 RPM 	Gegr DOWN AND LOCKED
L-Both-R-Both	
Carb Heat On RPM DROP	MIXTURE
Carb Heat Off	 Mixture FULL RICH
Suction (if applicable)GREEN	<u>P</u> ROPELLER
 Ammeter CHARGING (>0) 	PropellerFULL FORWARD
 Oil Pressure GREEN 	<u>S</u> ECURITY
 Oil Temperature GREEN 	Seatbelts & HarnessesSECURE
• Throttle IDLE - SMOOTH?	 Doors & Windows LOCKED
MixtureLEAN 1"	
□ Speeds (Vx, Vy, etc.) REVIEW	LANDING
RADIOS	Carb HeatON
GPS - Route SET	□ Flaps FULL
□ GPS - Radio SET	
□ COM2/NAV2 SET	AFTER LANDING
□ Transponder SET CODE/ALT.	 Fuel Selector BOTH
SECURITY	 Elevator Trim TAKEOFF
Doors & WindowsLOCK	 Carb Heat COLD
 Seat belts & Harnesses SECURE 	• Throttle 1000 RPM
For Takeoff: [Airport] Tower. Skyhawk [Tail#]	Mixture LEAN 1"
holding short [Rwy#]. [Departure Request].	□ Flaps UP
	 Lights OFF AS APPROPRIATE
 Takeoff Clearance READ BACK 	 Radio Frequencies SET

[Airport] Ground. Skyhawk [Tail#] clear of [Rwy#]. Taxi [Back for takeoff] or [to row #].

SHUTDOWN

כ	ELT (121.5/pu	ill squeich)	CHECK
כ	Radio		SET ORIGINAL FREQ
כ	Avionics Mas	ter	OFF
כ	Throttle		1000 RPM
כ	Mixture	LEAN TO I	DLE CUTOFF (full out)
D	Master (Batt.	& Alt.)	OFF
כ	Key		OFF & REMOVE

PARKING & SECURING

0	Push into parking spo	t
0	Chocks	INSERT
0	Aircraft Log ENTER	/TAKE PICTURE FOR SM
0	Gust Lock	INSTALL
0	Pitot Cover	INSTALL
0	Sunshade (?)	INSTALL
0	Trash	CLEAR
0	Personal Items	REMOVE
0	Doors & Windows	LOCK
0	L Tie Down Chain	INSTALL
0	Tail Tie Down Chain	INSTALL
0	R Tie Down Chain	INSTALL
0	Exterior Cover (?)	INSTALL

FREQUENCIES

SAN GABRIEL VALLEY (El Monte) - KEMT

112	
ATIS	118.75
Ground	125.90
Tower	121.20
Airport Operations (Fuel)	(626) 695-2585
Billion Air Aviation (Fuel)	(626) 825-1661

BRACKETT FIELD - KPOC

ATIS	124.40
Ground	125.00
Tower	118.20
Clearance Delivery	121.875

CHINO - KCNO

ATIS	125.85
Ground	121.60
Tower	118.50
Unicom	122.95