A quick introduction to Transit Oriented Development (TOD)

Pramesh Kumar

IIT Delhi

July 23, 2024

TOD was introduced by the architect and urban planner Peter Calthorpe in his book The Next American Metropolis in 1993.

Definition (Transit oriented development (TOD) (Calthorpe 1993: 56)). "Mixed-use community within average 2000-foot [~ 600 m] walking distance of a transit stop and core commercial area. TODs mix residential, retail, office, open space, and public uses in a walkable environment, making it convenient for residents and employees to travel by transit, bicycle, foot, or car."

A few suggestions from Ibraevaa et. al¹

- Major commercial and employment areas should be located in close proximity to a station ("primary area") and nearby public space should ensure neighborhood vitality.
- ► A residential zone should be developed in the remaining area, with densities gradually decreasing.
- ➤ A "secondary area" related to TOD might appear at the maximum distance of 1.6 km from the core zone, where low-density housing, vast park areas, schools and other facilities for local community could be placed.
- ► The street network of this outer area should secure easy, fast and direct access to the core by bicycle and transit through park-and-ride lots.

¹Ibraeva, Anna, et al. "Transit-oriented development: A review of research achievements and challenges." Transportation Research Part A: Policy and Practice 132 (2020): 110-130.

Typologies²

1. Regional centers

- Primary centers of economic and cultural activity in any region
- Regional downtowns characterized by mix of housing and employment types, retail and entertainment that cater to the regional market.
- Served by a rich mix of transit modes including high capacity regional rail and bus.
- Examples?

²Taken from report "Station Area Planning" by Reconnecting America

2. Urban Center

- A mix of residential, employment, retail and entertainment uses, usually at slightly lower densities and intensities than in regional centers.
- Destinations draw residents from surrounding neighborhoods.
- ► These centers serve as commuter hubs for the larger region and are served by multiple transit options, often including rail and high-frequency regional bus or bus rapid transit (BRT).
- ▶ Densities are typically higher within a quarter-mile radius of stations than the half-mile radius.
- Examples?

3. Suburban Center

- A mix of residential, employment, retail and entertainment uses, usually at intensities similar to that found in urban centers but lower than that in regional centers.
- Suburban centers can serve as both origins and destinations for commuters.
- ► They are typically connected to the regional transit network and include a mix of transit types regional rail and bus, BRT, and local bus with high-frequency service.
- ► Intensity of uses is often noticeably greater within a quarter-mile radius of stations than in the half-mile radius.
- Examples?

4. Transit Town Center

- ► Function more as local-serving centers of economic and community activity than either urban or suburban centers, and they attract fewer residents from the rest of the region.
- ► A variety of transit modes serve transit town centers, and there is a mix of origin and destination trips primarily commuter service to jobs in the region.
- Secondary transit lines feed primary lines, often at intervals timed to facilitate transfers at the primary transit stations.
- Residential densities are usually lower than in the previous place types.
- Examples?

5. Urban Neighborhood

- ► Urban neighborhoods are primarily residential areas that are well-connected to regional centers and urban centers.
- ▶ Densities are moderate to high, and housing is usually mixed with local-serving retail.
- Commercial uses are limited to small businesses or some industry.
- ▶ Development is usually oriented along a well-connected street grid that is served by a secondary transit network.
- Examples?

6. Transit Neighborhood

- ► Transit neighborhoods are primarily residential areas that are served by rail service or high frequency bus lines that connect at one location.
- Densities are low to moderate and economic activity is not concentrated around stations, which may be located at the edge of two distinct neighborhoods.
- ► There is often not enough residential density to support much local-serving retail, but there are often retail nodes.
- Examples?

7. Special Use/Employment District

- ► Special-use or employment districts are often single-use either they are low to moderate density employment centers, or are focused around a major institution such as a university, or an entertainment venue such as a stadium.
- Transit stations are not a focus of economic activity.
- ► There can be significant opportunities for mixed-use development if these stations are well-connected to other parts of the region and there is demand for housing.
- Examples?

8. Mixed-Use Corridor

- Mixed-use corridors are a focus of economic and community activity but have no distinct center
- These corridors are typically characterized by a mix of moderate-density buildings that house services, retail, employment, and civic or cultural uses.
- Mixed-use corridors are especially suitable for streetcars, bus rapid transit or other high-quality bus service with closely-spaced stops.
- Mixed-use corridors offer a good opportunity for infill and mixed-use development, and development is usually more intense within a quarter-mile of transit stops.
- Examples?

Different typologies require different strategies for TOD to be successful.

TOD Impact on Travel³

Literature reported the following:

- Owning fewer cars: TOD households are twice as likely to not own a car and own roughly half as many cars as comparable households not living in TODs.
- ▶ Ridership increased: Between 1970-2000, transit ridership for work trips increased in TOD zones, although ridership declined markedly in the metro areas surrounding TODs. TOD residents used transit 2~5 times more than those in other communities.
- ▶ Residential choice: Among the factors that attract households to TOD, households consistently place high value on neighborhood design, home prices and perceived value, and transit proximity (top 3).
- ► Firm location choice: Access to high quality transit is becoming increasingly important to firms trying to attract creative class workers in the knowledge economy.
- Others
 - Effect on VMT, fuel use, and emissions
 - Improving employment accessibility

Less congestion and parking requirement
Taken from CEGE 5213 taught by Prof. Jason Cao

Factors influencing transit ridership⁴

Literature reported the following:

- Quality of transit services (availability, comfort, convenience)
- ► Traffic congestion
- ► Parking supply and costs
- ▶ Job accessibility by transit and density at stations (job vs. pop.)
- Mixed uses and design elements (primary for place making to attract residents and customers and secondary for travel)

 $^{^4\}mathrm{Taken}$ from CEGE 5213 taught by Prof. Jason Cao

Barriers to TOD⁵

- ► Node vs place
- ► Congestion paradox
- ► Fiscal
- Political will
- ▶ Difficult to change the existing settlement
- ► Others?

⁵Taken from CEGE 5213 taught by Prof. Jason Cao

Suggested readings

- ▶ Dittmar, Hank, and Gloria Ohland, eds. The new transit town: Best practices in transit-oriented development. Island Press, 2012.
- Station Area Planning Reconnecting America and the Center for Transit-Oriented Development: How To Make Great Transit-Oriented Places.
- ► TCRP Report 128
- City of Edmonton video

TOD is not a new concept!




Figure: Twin Cities streetcar network 1930⁶

⁶Source: https://streets.mn/2022/12/01/living-in-a-streetcar-city/

Thank you!