SPECIFICATIONS

Model Number: UR-ST4X1

Dimensions : 55.1"x23.6"x(29.1"-47.6")

140cmx60cmx(74-121)cm

Material : Aluminum, Plastic, Steel

CUSTOMER SERVICE

We welcome any opportunity to serve you better. You can choose how you prefer to reach us.

USA +1-203-653-2624 Netherlands +31-646-682-888

Email: support@iurbo.com

For return or exchange, please visit www.iurbo.com/return

To register warranty, please visit www.iurbo.com/warranty









www.iurbo.com





Welcome Guide

Standing Work Desk



I Preface

This manual height adjustable standing desk consists of a heavy-duty steel desk frame, a desktop and a manual height adjustment system. Please read and completely understand this manual before installation in order to make sure the safe and correct use of the system and maintain the longevity of the overall construction.

Instructions of Safety and Warnings:


- Any failure to comply with the safety and installation instructions in this manual may cause serious bodily injury.
- Any incomplete observation of the instructions, warnings and additional information marked with the "Note" and "\textsum" may result in serious damage to the system or its components.
- This product can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Persons with reduced physical, mental abilities and or lack of experience and knowledge must not use the product, unless they're under supervision, understand the hazards involved or they have been thoroughly instructed in the use of the apparatus by a person who is responsible for the safety of these persons.
- Users should make sure that they never sit on the desktop in order to prevent serious bodily injury.



Other Safety Instructions:

- · Clear up all obstacles within the height adjustment range.
- Don't leave the cords or plug unorganized in order to prevent tripping hazards.
- Any attempts to reconstruct the desk frame aren't allowed.
- Don't add anything to the adjustable junctions of the desk frame.
- Outdoor use is prohibited.

I Preparation







Weight Capacity
40kg (88lbs)

Operation Temperature (-5°C~+40°C)

What are the tools you require while installation?








Bubble Level

Allen Wrench (Included)

Phillips Screwdriver

What's the thing you'd better have before installation?



A Shipping Blanket to protect the desk and the floor


Things you need to know before installation

Please check all of the components shown in the component checklist. If any of the components are missing or damaged, contact your point of purchase for a replacement.



Disposal: The product with this mark indicates that this product shouldn't be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the local recycle service or contact your point of purchase to withdrawn the product.

I Checklist and Installation






This page can be torn so that it's easier for you to match the components with the images.

3




Now let's start the installation.


I Assembling One Lifting Column




5


I Inserting the Sync Rod





 Insert one end of the sync rod into the left column.






- Place the right column on the back of the desk board.
- Make sure another end of the sync rod inserted into the right column.


I Assembling another Lifting Column

- Align holes on the right column with the pilot holes on the desk board.
- Fix the column using **3 S-B screws** as shown with the **Phillips screwdriver**.



I Assembling the Crossbar

 Attach the crossbar to the columns using 4 S-A screws and tighten the screws as shown with Allen wrench.




I Low Profile Adjustment


1. Insert the crank into the corresponding holes supported by both left and right columns, then adjust to the desired position.


2. Remove the crank and insert into the holes as shown for storage.


3. There are adjustable foot pads under each foot. If the floor isn't even, simply turn the pad to adjust the height to make the desk stable.


4. Tip: Use a bubble level to check if the desktop is even.











9