AquaPure W200 Water Purifier User Manual (fictional)

1. Safety and Installation

Use the AquaPure W200 only with potable water between 5 and 35 degrees Celsius. Do not connect it to hot water lines.

The inlet water pressure must be between 1.0 and 4.0 bar. Install the unit under a sink or on a countertop with at least 15 cm of free space behind it.

The purifier runs on a 24 V DC adapter rated at 40 W. The storage tank holds 8 litres and the purified water flow rate is 2.5 litres per minute.

AquaPure W200 Water Purifier User Manual (fictional)

2. Filter Replacement

The W200 has three filtration stages. Replace the sediment pre-filter every 6 months, the carbon block every 12 months and the RO membrane every 24 months.

The indicator light turns amber when a filter has reached 90 percent of its life.

After replacing a filter, hold the reset button for 5 seconds until the unit beeps twice. Flush new filters by running water through for 10 minutes before drinking.

AquaPure W200 Water Purifier User Manual (fictional)

3. Troubleshooting

A blinking red light means a leak was detected. Turn off the water supply and check all fittings.

If no water comes out, check that the inlet valve is open and that the supply pressure is not below 1.0 bar. A bad taste usually means the carbon block is exhausted.

Error code E3 indicates a fault in the TDS sensor. Error code E5 means the tank-full sensor is not responding. To pair the unit with Wi-Fi, hold the Wi-Fi button for 3 seconds.

AquaPure W200 Water Purifier User Manual (fictional)

4. Warranty and Support

The unit carries a 24-month warranty and filters are covered for 6 months. Register the product within 30 days of purchase to activate the warranty.

The warranty does not cover damage caused by supply water with more than 1500 ppm TDS.

Customer support is available from 9 am to 6 pm, Monday to Saturday, on 1800-000-0142 or at support@aquapure.example.