

GUIDE TO CHOOSING A CURTAIN STYLE



American Pleats

This is the most common type of pleat and has good aesthetics.

This kind of style consumes more fabric than the others.

If installing for the first time, we recommend the use of channels.

If you already have a curtain rod installed, then you can use the rod and plastic loops to attach the curtain.

The curtain standard is a double pleat placed at approximately 5 inches (125mm) center to center.



Ripple Pleats

This is a relatively new kind of style, it has a contemporary, fresh appearance

It requires a depth of about 7 inches (175mm) to install this properly.

You must use a special channel for this, it cannot be installed on rods.



Eyelet and Rods

This is economical and does not consume much fabric.

It is less aesthetically appealing than the other two options.