Acer Predator X34 Monitor

34-inch curved ultrawide gaming monitor with NVIDIA G-SYNC

Setup and service guide

How to recognise this device

A very wide, curved 34-inch screen with thin black borders. It stands on a silver aluminium stand with two angled legs that spread out in a V shape. The Predator name and logo are on the bottom edge of the screen.

The back is black with red accents and a strip of lighting along the underside. The ports face downward at the back: one DisplayPort, one HDMI, a USB hub and the power input. Five control buttons sit under the bottom-right corner of the screen.

Parts and tools

- Monitor with stand
- Power adapter and power cord
- DisplayPort cable
- HDMI cable
- USB upstream cable
- Optional: VESA 100 by 100 millimetre mount and a Phillips screwdriver

Sample document written to demonstrate the Hermes Glasses machine guide. It is not the manufacturer's manual; check the official manual before servicing a real device.

Section 1. Unpack and place the monitor

Caution. The curved panel is heavy and fragile. Lift it by the stand and the frame, with two people, and never press on the screen surface.

Step 1. Open the box with the screen lying face down on its foam packing.

Step 2. With a second person, lift the monitor by the stand column and the lower frame and stand it on the desk.

Step 3. Peel off the protective film from the screen and the stand.

Step 4. Adjust the height by sliding the screen up or down on the stand column, and tilt it so the top edge is at eye level.

Section 2. Connect the cables

Caution. G-SYNC and the high refresh rates work over DisplayPort only. Over HDMI the monitor is limited to sixty hertz and G-SYNC is not available.

Step 5. Plug the DisplayPort cable into the DisplayPort socket on the back of the monitor, and into a DisplayPort output on the graphics card - not the motherboard.

Step 6. Plug the power adapter into the monitor's power input, then connect the power cord to a wall socket.

Step 7. To use the monitor's USB ports, connect the USB upstream cable from the monitor to a USB port on the computer.

Step 8. Press the power button, the rightmost button under the bottom-right corner. The light turns blue when a signal is found.

Section 3. Set the resolution and refresh rate

Step 9. In Windows, right-click the desktop and open Display settings.

Step 10. Set the resolution to 3440 by 1440, the monitor's native resolution.

Step 11. Open Advanced display settings and set the refresh rate to sixty hertz to begin with.

Step 12. On the monitor, press any button under the bottom-right corner to open the on-screen menu.

Step 13. Open the Setting page, switch Overclock on, and choose the refresh rate: up to one hundred hertz on the X34, or one hundred and twenty hertz on the X34P.

Step 14. Confirm. The monitor restarts. Return to Advanced display settings in Windows and select the new refresh rate.

Section 4. Turn on G-SYNC

Step 15. Right-click the desktop and open the NVIDIA Control Panel.

Step 16. Under Display, choose Set up G-SYNC.

Step 17. Tick Enable G-SYNC, and choose whether it applies to full screen only or to windowed and full screen mode.

Step 18. Select the Predator monitor in the list and press Apply.

Step 19. To confirm it is working, open the Display menu at the top of the NVIDIA Control Panel and tick G-SYNC Compatible Indicator. A label appears on screen when G-SYNC is active.

Section 5. Fit a wall or arm mount

Caution. Disconnect all cables first. Support the screen at all times once the stand is unscrewed - it will fall forward.

Step 20. Lay a soft cloth on a flat table and place the monitor face down on it.

Step 21. Remove the four screws that hold the stand to the back of the monitor and lift the stand away.

Step 22. Fit the VESA adapter plate over the four holes, which are one hundred millimetres apart.

Step 23. Fasten the mount with four screws, tightening them in a cross pattern until snug. Do not overtighten.

Step 24. With a second person, lift the monitor onto the arm or wall bracket and reconnect the cables.