MacBook Pro M2 Pro

Apple laptop computer, 14-inch, 2023

Setup and service guide

How to recognise this device

A silver or space grey aluminium laptop with a black keyboard and a large glass trackpad. The display has thin black borders with a small camera notch at the top centre, and an Apple logo is on the lid.
On the left side are a MagSafe charging port, two Thunderbolt USB-C ports and a headphone jack. On the right side are an HDMI port, one Thunderbolt USB-C port and an SD card slot. The words MacBook Pro are engraved on the underside.

Parts and tools

- MacBook Pro
- USB-C power adapter
- MagSafe 3 charging cable
- Optional: HDMI or USB-C display cable

Sample document written to demonstrate the Hermes Glasses machine guide. It is not the manufacturer's manual; check the official manual before servicing a real device.

Section 1. Charge with MagSafe

Step 1. Plug the USB-C end of the MagSafe cable into the power adapter, and the adapter into a wall socket.

Step 2. Bring the flat magnetic end of the cable to the MagSafe port, the first port on the left side. It snaps into place.

Step 3. Check the small light on the connector. Amber means charging, green means fully charged.

Step 4. To disconnect, pull the connector straight out or tilt it away. The magnet releases without pulling the laptop.

Section 2. Start up and set up Touch ID

Step 5. Open the lid. The laptop starts by itself. If it does not, press the Touch ID button at the top-right corner of the keyboard.

Step 6. Follow the setup assistant: choose a language, join a Wi-Fi network and sign in with an Apple ID.

Step 7. When asked to set up Touch ID, rest a finger on the Touch ID button and lift it repeatedly until the fingerprint picture fills in.

Step 8. To add another fingerprint later, open System Settings, choose Touch ID and Password, and press Add Fingerprint.

Section 3. Connect an external display

Step 9. Choose the cable. Use the HDMI port on the right side, or any of the three Thunderbolt USB-C ports.

Step 10. Plug the cable into the laptop and into the display, then switch the display on.

Step 11. Open System Settings and choose Displays. The external display appears next to the built-in one.

Step 12. Press Arrange to drag the displays into the positions they have on the desk.

Step 13. Choose the external display and set Use As to Extended Display for more space, or Mirror to show the same picture.

Step 14. This model drives up to two external displays at once.

Section 4. If the laptop stops responding

Caution. A forced restart discards unsaved work. Try closing the frozen app first.

Step 15. Press Option, Command and Escape together, choose the frozen app and press Force Quit.

Step 16. If the whole laptop is frozen, press and hold the Touch ID button for about ten seconds until the screen goes black.

Step 17. Wait a few seconds, then press the Touch ID button once to start again.

Step 18. To reach the startup options, shut down, then press and hold the Touch ID button until Loading startup options appears.

Section 5. Check battery health and clean the laptop

Caution. Never spray liquid directly onto the laptop, and keep moisture out of every opening.

Step 19. Open System Settings and choose Battery. Battery Health shows Normal or Service Recommended.

Step 20. Press the information button next to Battery Health to see the maximum capacity as a percentage.

Step 21. To clean the screen, shut the laptop down and unplug it.

Step 22. Wipe the screen with a soft, lint-free cloth dampened with water only.

Step 23. Wipe the keyboard and case with a dry cloth, then let everything dry before opening the lid again.