EVM - COMMISSIONING.

- 1) CHECK NOS- EVM+VVPAT, PINKPAPER SEAL.
- 2) CHECK SIGNS Address tags, PINK paperseal, Annexures.
- 3) prepare-Tags-10 (Assembly) 14-(parlament)
- 4) Ballot unit commissioning BU-OUTERCOVER- BALLOT PAPER- RO, SIGN-Allinment Thumb wheel -01 (Assembly) (BU-1-01 BU-02-parlament) Two Address tags - Pink pare seal - Rosigns/Agents signs.
 - BU- Stickers (Parlament)

 5) VVPAT- POWERPACK- BHEL/ Symbol-Loding-
 - 6, control unit-Powerpack
 - 7) Ballotunit WPAT control unit Cables connection
 - 8, VVPAT- Knob-working mode *
 - 9, CU-switchon" Candiate set Press NOTA -BUTTON PRESS.
 - 10, CU of Total Button SHOW-ZERO
 - 11, MOCK POLL WITH SINGLE VOTE OBSERVE-VVPAT
 - 12, CLOSE RESULT- VERIFY
 - 13, COUNT SLIPS TALLY WITH RESULT -(STAMP- VVPAT TESTING SLIP- RETURN-RO) VERTICAL.
- * 14, SWITCH OFF CU REMOVE Cables VUPATKNOB
 - 15, sealing CU ONLY-BATTERY section 2 Fags. candiate section.
 - 16 Sealing VVPAT- ONLY TOP COVER. (BOTH SIDES).
 - 17. BU-CU-VVPAT colorying cases Address tags -
 - 18. 1000 Votes MOCK POLL. COMPLETED. Remove - POWER Packs - PAPER ROLL -(CU- VUPAT) SET NEW ONE.