
Instruction

- Instruction is a command or information given to the microprocessor to perform a given specific task on specified data.
- Each instruction has two parts:
 - one the task to be performed, and
 - the other is data to be operated.
- The code which specifies what operation to be performed is called operation code or opcode.
- The data on which operation is performed is called operand.
- For e.g. ADD B

ADD is opcode and **B** is operand.

• The complete instruction is combination of opcode and operand.

Types of Instruction



Types of Instruction

- On the basis of length of word size
 - 1. One-byte instruction
 - 2. Two-byte instruction
 - 3. Three-byte instruction
- On the basis of function or operation mode
 - 1. Data transfer instructions
 - 2. Arithmetic instructions
 - 3. Logic and bit manipulation instructions
 - 4. Branch instructions
 - 5. Machine control instructions

On the basis of Word Size

One-Byte Instruction

- In 1-byte instruction, the opcode and the operand of an instruction are represented in one byte.
- A one-byte instruction includes opcode & operand in the same byte.
- Operand(s) are internal registers and are in the instruction in form of codes.
- If there is no numeral present in the instruction then that instruction will be of one-byte.
- E.g. MOV C

ADD B

Two-Byte Instruction

- Two-byte instruction is the type of instruction in which
 - the first 8 bits indicates the opcode, and
 - the next 8 bits indicates the operand.
- This type of instructions need two bytes to store the binary codes.
- The mnemonic is always followed by 8-bit (byte) data.
- If an 8-bit numeral is present in the instruction then that instruction will be of two-byte.
- E.g. MVI H, 24H

IN F1H

Three-Byte Instruction

- Three-byte instruction is the type of instruction in which
 - the first 8 bits indicates the opcode and
 - the next two bytes specify the 16-bit address.
- The low-order address is represented in second byte and the high-order address is represented in the third byte.
- This instruction will require three memory locations to store in the memory.
- The mnemonic is always followed by 16-bit (or adr).
- If a 16-bit numeral is present in the instruction then that instruction will be of three-byte.
- E.g. LXI H, 2400H LDA 2500H

On the basis of Function

Data Transfer Instruction

- These instructions move (or copy) data from source to destination.
 - Between register to register
 - Between register to memory
 - Between memory to register
 - Between I/O and accumulator
 - Load an 8-bit number in a register
 - Load an 16-bit number in a register pair
- Memory to memory transfer is not possible.
- After the data transfer,
 - the content of the source is not modified, and
 - the earlier content of the destination is altered.
- No flags are affected.
- E.g. MOV A , B LDA 1200H LXI H , 2800H LHLD 2500H

Arithmetic Instruction

- Arithmetic operations like addition, subtraction, increment and decrement are performed by this category of instructions.
- One of the operand is taken from the Accumulator and the other operand may be from registers or memory.
- The result of the arithmetic operations is stored in the Accumulator.
- All the flags are affected.
- E.g. ADD A INR D
 - SUB B DCR E

Logical Instruction

- Logical functions like AND, OR and EX-OR are performed by this instructions.
- All logic functions are performed in relation with the contents of the Accumulator.
 - The logical operations cannot be performed directly with the content of two registers.
- After a logical operation has been performed, the result are placed in the accumulator replacing the original content of the accumulator.
- All the flags are affected.
- E.g. ANA B CMP B
 - ORA B CMA

Branch Instruction

- Branch instructions change the sequence of the program execution unconditionally or conditionally.
- The condition of flags is used to take the decision for conditional branches.
- These instructions are the key to the flexibility and versatility of computer.
- No flags are affected.
- E.g. JMP 4000H JNZ 4000H

Stack, I/O & Machine Control Instruction

- The instructions dealing with interrupt handling and system operations are classified into this category.
- This type of instruction includes the instructions for input/output, stack and machine control.
- No flags are affected.
- E.g. PUSH B DI POP B HLT

Addressing Modes

Addressing Modes

- Addressing modes refers to the way in which the operand of an instruction is specified.
- The various addressing modes that are defined in a given instruction set architecture define
 - how machine language instructions in that architecture identify the operand(s) of each instruction.
- In any microprocessor instruction, the source and destination operands can be a:
 - Register
 - Memory Location
 - 8-bit number
- The method by which the address of source of data and the address of the destination of the result is given in the instruction are called the Addressing Modes.



- Addressing modes refers to the way in which the operand of an instruction is specified.
- It focuses on presenting the operand's address in the instructions.
- Types of Addressing Modes
 - 1. Immediate Addressing Mode
 - 2. Register Addressing Mode
 - 3. Direct Addressing Mode
 - 4. Register Indirect Addressing Mode
 - 5. Implied/Implicit Addressing Mode

Immediate Addressing Mode

- In this immediate addressing mode, the operand is specified within the instruction itself.
 - an immediate value is given to operate on.
- In 8085, the instructions having 'I' letter fall under this category.
 - 'I' indicates immediate addressing mode.
- Some Immediate Addressing modes mnemonics:

LXI MVI ADI ACI SUI SBI CPI ANI XRI ORI

E.g. MVI A , 01H (Move 01 in register A)
 LXI H 3050H (Load the H-L pair with operand 3050 immediately)

Direct Addressing Mode

- In this mode of addressing the address of the operand (data) is given in the instruction itslef.
- The data to be operated is available inside a memory location and that memory location is directly specified as an operand.
- The operand is directly available in instruction itself.
- This type of addressing is called absolute addressing.
- E.g. LDA 1020H (load content of memory location 1020 in A) SHLD 3050H (Load the content of L into memory location 3050

Load the content of H into memory location 3051)

Register Direct Addressing Mode

- In this addressing mode, the data to be operated is in the general purpose register.
- The data to be operated is available inside the register(s) and register(s) is(are) operands.
- Therefore, the operation is performed within various registers of the microprocessor.
- E.g. ADD B (Add content of A and reg. B and store result in A) MOV A , B(Move content of register B to the accumulator)

Register Indirect Addressing Mode

- In this mode, the address of operand is specified by a register pair.
- The data to be operated is available inside a memory location and that memory location is indirectly specifies a register pair.
- So, in this type of addressing mode, it is the address of the address rather than the address itself.
- E.g. LDAX B (move content of the B-C register to the accumulator) MOV A , M (Move content of memory location pointed by

register pair to the accumulator)

Implied/Implicit Addressing Mode

- The instruction of this mode do not have operands.
- In this mode, opcode specifies the address of the operands.
- If address of the source of data as well as address of destination of result is fixed, then there is no need to give any operand along with the instruction.

• E.g. CMA (complement accumulator)

RRC (rotate accumulator A right by one bit)

RLC (rotate accumulator A left by one bit)

Operations Types in 8085

- All of the operations of the microprocessor can be classified into three types:
 - Microprocessor Initiated Operations
 - Internal Operations
 - Externally Initiated Operations

Microprocessor Initiated Operation

- These are the operations that the microprocessor itself starts.
- There are basically four different microprocessor initiated operations:
 - Memory Read
 - Memory Write
 - I/O Read (Get input from the input device)
 - I/O Write (Send data to the output device)

Internal Data Operations

- The 8085 can perform a number of internal operations such as:
 - storing data,
 - arithmetic and logic operations,
 - testing for condition,
 - Sequencing the execution of instructions
 - Store/retrieve data from the stack during execution.
- To perform these operations, the microprocessor needs an internal registers like B, C, D, E, H, L, Accumulator, temporary registers, Flags, and others.

Externally Initiated Operations

- 8085 microprocessor support some Externally initiated operations, which are also known as Peripheral operations.
- Different external input/output devices or signals can initiate these type operations.
- External devices can initiate one of the 4 following operations:
 - Reset
 - Interrupt
 - Ready
 - Hold

Externally Initiated Operations (contd...)

Reset

- All operations are stopped and the program counter is reset to 0000.
- When this RESET pin is activated by any external key, then all the internal operations are suspended for that time.
- After that the execution of the program can begin at the zero memory address.

Interrupt

- 8085 MP chip have some pins for interrupt like TRAP, RST 5.5, RST 6.5 and RST 7.5.
- The microprocessor's operations are interrupted and the microprocessor executes other emergency operations, what is called a "service routine".
- This routine handles the interrupt, (perform the necessary operations).
- Then the microprocessor returns to its previous operations and continues.

Externally Initiated Operations (contd...)

Ready

- The 8085 has a pin called READY.
- This pin is used by external devices to stop the 8085 until they catch up.
- The Input/Output devices that are connected to microprocessor are of different speed,
 - which is need to be synchronized with the speed of microprocessor.
- This signal is used mainly to synchronize slower external devices with the microprocessor.

Externally Initiated Operations (contd...)

Hold


- The 8085 has a pin called HOLD.
- This pin is used by external devices to gain control of the buses.
- When the HOLD signal is activated by an external device, the 8085 stops executing instructions and stops using the buses.
- This would allow external devices to control the information on the buses.
- Eg: DMA
- In this DMA, the external Input/Output devices are directly communicate with the memory without interfering the processor every time.

Data flow between memory and MPU

- First of all, the 16-bit address is placed on the address bus from the PC.
- Lets say, the address is 1020H where the data is placed.
- The higher order address i.e. 10H is placed on the address bus A8-A15 while the lower order address i.e. 20H is placed on the multiplexed address and data bus AD0-AD7.
- The lower order address continues to remain on this address bus so long as ALE (Address Latch Enable) remains high. Once ALE goes low, it carries data.
- The control unit sends the signal to indicate what type of the operations is to be performed.
- Since, the data is to be read from the memory therefore it is sends to enable the memory chip.
- The byte, from the memory location is then placed in the data bus, is placed on the data bus and sent to the instruction decoder.
- The instruction is decoded and accordingly the task is performed by the ALU.

Flag and Flag Register

- The Flag register is a Special Purpose Register which shows the status of the task (microprocessor calculation).
- This is an 8-bit register but the only 5bit is used for the operation.
- The flag becomes set or reset after arithmetic and logical operation.
- The flag register has 5 flags which are
 - 1. Sign flag,
 - 2. Zero flag,
 - 3. Auxiliary carry flag,
 - 4. Parity flag, and
 - 5. the Carry flag.



Sign Flag

- Represented by the symbol S.
- After any type of arithmetic operation or logical operation,
 - if the value of D7 becomes 1 it basically shows that the number is negative and the sign flag is now set,
 - if the value of D7 becomes is 0, it basically shows that the number is positive and the sign flag is now reset.
- These set of instructions will basically reset the sign flag to 0 as 25 5 is always a positive number.

Zero Flag

- After any type of arithmetical or logical operation, if the output becomes 0 (00)H,
 - then zero flag is said to be set with value 1,
 - if not it becomes reset with the value 0.



- Eg: MVI A 25H (load the value 25H in register A) SUB A (A = A - A)
- These set of instructions will basically results 00H as 25 − 25 is always zero, so the zero flag is set to 1.

Carry Flag

- Carry is generated when performing n bit operations and the result is more than n bits,
 - then this flag becomes set i.e. 1,
 - otherwise it becomes reset i.e. 0.



- Eg: MVI A 25H (load the value 25H in register A)

 MVI B 85H (load the value 05H in register B)


 ADD B (A = A + B)
- These set of instructions will basically results answer with borrow.
- So, carry flag is set to 1.

Auxiliary Carry Flag

- Carry is generated when performing n bit operations and the result is more than n bits,
 - then this flag becomes set i.e. 1,
 - otherwise it becomes reset i.e. 0.
- This is the only flag register which is not accessible by the programmer
- Eg: MVI A 2CH (load the value 25H in register A)

 MVI B 85H (load the value 05H in register B)

 ADD B (A = A + B)



- These set of instructions will basically results auxiliary during calculation as addition of lower order nibbles C and 5 will generate a carry.
- So, auxiliary carry flag is set to 1.

Parity Flag

- If after any arithmetic or logical operation the result has even parity, an even number of 1 bits,
 - the parity register becomes set i.e. 1,
 - otherwise it becomes reset i.e. 0.




- Eg: MVI A 01H (load the value 01H in register A)

 MVI B 05H (load the value 05H in register B)

 ADD B (A = A + B)
- This instruction will results 06H (i.e BCD -> 00000110), which contains even number of ones.
- So, parity flag is set to 1.

Multiplexing and Demultiplexing of Address-Data bus in 8085

Multiplexing and Demultiplexing of Address-Data bus in 8085



Control Bus and Control Signal


Control Bus in 8085

- This is a group of parallel lines used by the microprocessor to issue control signals such as IO/M, RD, WR.
- As you have known from the pin diagram of 8085, there are three different pins at which the microprocessor issues these control signals.
 - 1. Pin 30 for IO/M
 - 2. Pin 31 for WR
 - 3. Pin 32 for RD
- Control signals are the signals used to control the operations related to memory and other associated peripherals.
- How do we control which operation (read/write) is supposed to be done at which location (Memory/IO)?
 - The same data bus is used for read as well as write operations.
 - These two types of operations also need to be done at two possible locations (memory or I/O).
- The control signals issued by the microprocessor distinguish between these different types of operations.

Control Signals in 8085

- The three control signals are explained here in brief.
 - IO/M (Control signal)
 - This signal specifies whether the operation (read or write) is being performed on memory or an i/o device.
 - RD (Control signal)
 - Goes low for read operation and becomes high otherwise.
 - WR (Control signal)
 - Goes low for a write operation and becomes high otherwise.

Control Signals in 8085




Truth Table of Control Signal


• The table explaining the control signals and status signals during various processes.

Operation	Status			Control signals
	IO/M	S1	SO	Control signals
Opcode Fetch	0	1	1	\overline{RD} = 0
Memory Read	0	1	0	\overline{RD} = 0
Memory Write	0	0	1	$\overline{WR} = 0$
I/O Read	1	1	0	\overline{RD} = 0
I/O Write	1	0	1	$\overline{WR} = 0$
Interrupt Acknowledge	1	1	1	$\overline{INTA} = 0$

Memory Operation



Memory Read/Write



Machine Cycle

Important terms related to timing diagrams:

• Instruction cycle:

- this term is defined as the number of steps required by the processor to complete the entire process
 - ie. Fetching and execution of one instruction.
- The fetch and execute cycles are carried out in synchronization with the clock.

Machine cycle:

- It is the time required by the microprocessor to complete the operation of accessing the memory devices or I/O devices.
- In machine cycle various operations like opcode fetch, memory read, memory write, I/O read, I/O write are performed.

• T-state:

Each clock cycle is called as T-states.