













```
🚇 Note1 - Windows Journal
C:\Windows\System32\cmd.exe
C:\iverilog\bin>iverilog.exe -o example_circuit1 Example_1_TB.v Example_1.v
                                                                                     Edit View Insert Actions Tools Help
                                                                                  V / V / + Ø + 9 4 * *
C:\iverilog\bin>vvp.exe example_circuit1
VCD info: dumpfile example_circuit1.vcd opened for output.
                0A = 0, B = 0, C = 0, Z = 0
                20A = 0, B = 0, C = 1, Z = 0
                40A = 0, B = 1, C = 0, Z = 0
                60A = 0, B = 1, C = 1, Z = 1
                80A = 1, B = 0, C = 0, Z = 1
               100A = 1, B = 0, C = 1, Z = 1
                                                                                      Example:
               120A = 1, B = 1, C = 0, Z = 1
               140A = 1, B = 1, C = 1, Z = 1
               160A = 0, B = 0, C = 0, Z = 0
                                                                                                          63
C:\iverilog\bin>gtkwave.exe example_circuit1.vcd_
                                                                                                                               64
                                                                                                                                        OUT
                                                                                                              v0
                                                                                                                       v0
        NPTEL
```

