

# Technical Specifications Document

For

# e-Dirham POS RS232 Integration

Version 1.12

STS – EFT POS Solutions





# **Table of contents**

1	Intr <sub>*</sub>	oduction	2
	1.1	Scope	2
	1.2	Audience	
2	Doc	cument Modification History	
3	List	t of Acronyms	4
4	POS	S Hardware Types	5
	4.1	T4210 (Dialup only)	
	4.2	T4220 (LAN, IP-TCP with Dialup backup modem)	5
	4.3	T4230 (GSM/GPRS, IP-TCP and Dialup backup Modem)	5
	4.4	M4230 (Mobile POS, GSM/GPRS IP-TCPIP)	5
	4.5	POS Applications	6
5	ECF	R Integration	7
	5.1	ECR Interface Specifications	7
	5.2	Physical Interface	
	5.3	Link Level Protocol	
		.1 Message Block Format	
	5.3.	.2 Communication characters	8
	5.4	Message Flow	
	5.4.	.1 Normal Message Flow	
		.2 Message Flow with Repeats	
	_	5.4.2.1 Initial Request Message	
	5	5.4.2.2 After Host Communication	10
	5.4.		
	5.5	Transaction Termination Messages	
	5.6	Serial Message Specifications	
		.1 Request Message from PC	
	5.6.		
	5.6.		
6	Apr	plication Specifications Acceptance and Sign offff	26





#### 1 Introduction

This document describes POS RS232 integration specifications for e-dirham POS application with a PC.

#### 1.1 Scope

The scope of this document covers all RS232 integration requirements including message specifications and transaction flow.

#### 1.2 Audience

This document is primarily for the POS application developers and RS232 integrators who are planning to provide PC/Web applications to communicate with Hypercom POS using RS232 port.





# **2 Document Modification History**

Revision	Date	Description	Author
Initial Release	03/08/2009	Initial Draft	STS PayOne
Version 0.01	17/01/2010	Changes based on comments from review committee.	STS PayOne
Version 1.00	21/01/2010	First Release	STS PayOne
Version 1.01	08/03/2010	Changes requested by MoF	STS PayOne
Version 1.02	04/04/2010	Added Error Code Table	STS PayOne
Version 1.03	29/09/2010	Add country code, area code and subarea code to ECR Request message.	STS PayOne
Version 1.04	12/12/2010	Updated Response Code Table to include all supported codes from PayONE server.	STS PayOne
Version 1.05	14/12/2010	Added Field Format and Padding tables.	STS PayOne
Version 1.06	22/06/2011	Added Amounts break-down in response message to PC. Added new message to check last transaction status.	STS PayOne
Version 1.07	14/09/2011	- Add new Response Code	STS PayOne
Version 1.08	14/09/2011	- Add new Response Code	STS PayOne
Version 1.09	03/04/2012	<ul> <li>Add eGuarantee and eAttestation transaction types.</li> <li>Add 'Merchant ID' field to ECR response.</li> <li>Change 'Unique TXN Number' to 'ECR ID Number' in the response message.</li> <li>Add "ECR ID Number" to Check Last Transaction Status request message.</li> <li>Add new ECR response code "037".</li> <li>Add Amount fields with ECR request</li> </ul>	STS PayOne
		to be passed to Host.  - Add Merchant ID to be verified by POS with its local values.  - Add new ECR error code and text "041".  - Add ECR version to the PC request.  - Add new ECR Error code, for invalid ECR version.  - Specify number of eServices as per Terminal Type.	, and the second
Version 1.11	10/03/2013	<ul> <li>Add new ECR response code "043".</li> <li>Add "ECR Application ID" to PC request message.</li> <li>Add "Terminal ID" to PC request message.</li> </ul>	STS PayOne
<mark>1.12</mark>	2/12/2014	- Support Dynamic Fees.	STS PayOne





# 3 List of Acronyms

Below table lists all used acronyms in this document

Acronym	Meaning
ACK	Acknowledgement
ECR	Electronic Cash Register
ETX	End of Text
FS	Field Separator
HOST	e-dirham host system
ICC	Integrated chip card
Inq.	Inquiry
kbps	Kilo bit per second
LRC	Longitudinal redundancy check
NAK	Negative acknowledgement
PAN	Personal account number
PC	Personal Computer
PIN	Personal identification number
PN	Part Number
POS	Point of Service
RS232	Serial Communication Port
STX	Start of text
SYNC	Synchronous Communication Type
ASYNC	Asynchronous Communication Type
TXN	Transaction
USB	Universal Serial Bus





#### 4 POS Hardware Types

POS application will be developed to run on Hypercom X4200 family, which includes a variety of models with different connection types.

#### 4.1 T4210 (Dialup only)

This terminal has one connection type, which is a dialup modem supporting different communication protocols (SYNC/ASYNC) running over different speeds and connection properties. This terminal can be connected to PayONE over standard phone line.

More details are available on Hypercom website: <a href="http://www.hypercom.com/products/T4210.asp">http://www.hypercom.com/products/T4210.asp</a>

#### 4.2 T4220 (LAN, IP-TCP with Dialup backup modem)

In addition to the dialup modem described above, this terminal has an Ethernet communication port which can be connected to standard TCP-IP networks by a standard network cable, Ethernet speed is much faster than dialup modem, this high speed can be utilized for major application updates and big file downloads, in addition to locations where short transaction processing time is required.

More details are available on Hypercom website: <a href="http://www.hypercom.com/products/T4220.asp">http://www.hypercom.com/products/T4220.asp</a>

#### 4.3 T4230 (GSM/GPRS, IP-TCP and Dialup backup Modem)

A desktop terminal which supports GSM/GPRS connection, just like T4220, but cordless, where GSM network is used to connect to e-dirham host via TCP-IP, in addition to a dialup backup modem, where if GSM network has failed for a reason or another, terminal can still process transactions using its dialup modem.

More details are available on Hypercom website: <a href="http://www.hypercom.com/products/T4230.asp">http://www.hypercom.com/products/T4230.asp</a>

#### 4.4 M4230 (Mobile POS, GSM/GPRS IP-TCPIP)

When services are required in a remote location, or a mobile service center, this type of terminals can be used, as it is powered by a rechargeable battery which can process hundreds of transaction without requiring a recharge. Unlike other X4200 terminals, this terminal is not equipped with a built in modem or RS232 port, if needed, these two add-ons can be used by using a special docking station, which can be used for charging the battery as well.

More details are available on Hypercom's website:

http://www.hypercom.com/products/M4230.asp





#### 4.5 POS Applications

The same POS application binary file can run on the above models, it has smart functionality which can detect POS hardware type and adjust itself to use the different types of attached hardware/drivers.





Hypercom X4200 POS Terminals





#### 5 ECR Integration

Unlike stand alone POS implementation, with an ECR (PC-Application) integrated with the POS, the transaction is initiated from the PC by sending information to the POS over the RS232 cable.

#### **5.1 ECR Interface Specifications**

ECR protocol between POS and PC Application will be based on a fixed length protocol with Field separators, any unused field should be filled with spaces.

#### 5.2 Physical Interface

The physical interface between the POS and the PC will be a direct RS232 connection from POS RS232 port to the PC serial port using Hypercom cable PN: 810356-001.

Data transmission is Asynchronous up to 115200 kbps, with 8 data bits, no parity, and 1 stop bits.

It is recommended to use the highest baud rate, unless PC application requires slower rates to operate properly.

If the PC doesn't have an RS232 port, USB to Serial converter can be used to provide this communication port to the PC.

#### 5.3 Link Level Protocol

Like most standard devices working with ECR-RS232 port, Hypercom POS uses standard communication setup with a PC.

#### 5.3.1 Message Block Format

The table below describes the messaging block format between POS and PC.

<stx></stx>	Length	Data	<etx></etx>	<lrc></lrc>
<0x02>	Length	Txn Type <fs>Txn ID<fs>Txn Amount<fs></fs></fs></fs>	<0x03>	<0xHX>

- Length = length of DATA, number of bytes to follow (excluding ETX and LRC).
- LRC = the result of XORing all data bytes of [Length, Data, ETX].



#### 5.3.2 Communication characters

Standard communication characters listed in below table are used.

Character	Hex Value	Meaning
STX 02 Start of text		Start of text
ETX	03	End of text
ACK 06 Positive Acknowledgment		Positive Acknowledgment
NAK 15 Negative Acknowledgment		Negative Acknowledgment
FS 1C		Field Separator
Length 2-bytes Data size in bytes excluding STX, ET		Data size in bytes excluding STX, ETX and LRC

#### 5.4 Message Flow

Message flow consists of Request message, Response message and control characters.

Transaction is always initiated by a request message from PC.

#### 5.4.1 Normal Message Flow

Normal message flow consists of the below steps:

- 1- PC sends initial request message.
- 2- POS validates request and sends <ACK> to PC if message was valid, <NAK> otherwise.
- 3- POS prompts user to swipe/insert the card.
- 4- POS calls e-dirham Host for service charge inquiry.
- 5- POS validates host response, constructs the financial request and sends it to edirham host.
- 6- POS validates host response and prints a receipt (only if Transaction was approved)
- 7- POS sends response message to PC.
- 8- PC sends <ACK> if response is valid, <NAK> otherwise.

PC	Flow	POS	Flow	e-dirham host
Request Message	$\rightarrow$	POS Process Request		
	<b>←</b>	<ack></ack>		
		Service inq. Request	$\rightarrow$	Host process Request
		POS Process Response	<b>←</b>	Inq. Response
		Authorization Request	$\rightarrow$	Host process Request
		POS Process Response	←	Authorization Response
PC Process Response	←	Response		
<ack></ack>	$\rightarrow$	Transaction End		







#### 5.4.2 Message Flow with Repeats

If there was any problem during message flow or a timeout has happened, <NAK> will be sent instead of <ACK> which causes the message to be sent again, if retry counter reaches the configured retry limit without success, transaction will be terminated.

#### 5.4.2.1 Initial Request Message

During initial request message from PC, some communication problems might happen, like POS is turned off, or cable is not connected, in such cases, PC will not get any response from POS and request will be times out, or if the request from PC wasn't successfully verified by the POS or the LCR was incorrect, in this case an <NAK> will be sent back to PC from POS indicating something wrong with the request message.

PC	Flow	POS	Flow	e-dirham Host
Request Message	$\rightarrow$	POS Process Request		
	<b>←</b>	<nak></nak>		
Request Message	$\rightarrow$	POS Process Request		
	<b>←</b>	<nak></nak>		
Request Message	$\rightarrow$	POS Process Request		
	<b>←</b>	<nak></nak>		
Transaction End				

In the above case, no reversals are generated, since no communication was done with the host, POS will simply show a failure message on screen and might print a receipt showing the cause of the error.






#### 5.4.2.2 After Host Communication

Communication errors might happen also after POS has talked to e-dirham host, this could be due to several reasons. In this case, POS will try to retransmit response details to PC as show in below diagram.

PC	Flow	POS	Flow	e-dirham Host
Request Message	$\rightarrow$	POS Process Request		
	1	<ack></ack>		
		Service inq. Request	$\rightarrow$	Host process Request
		POS Process Response	←	Inq. Response
		Authorization Request	$\rightarrow$	Host process Request
		POS Process Response	←	Authorization Response
PC Process Response	<b>←</b>	Response		
<nak></nak>	$\rightarrow$			
PC Process Response	<b>←</b>	Response		
<nak></nak>	$\rightarrow$			
PC Process Response	<b>←</b>	Response		
<nak></nak>	$\rightarrow$			
Transaction End		User to complete transaction manually on PC.		

If the transaction was approved by e-dirham host, but the response wasn't sent successfully to the PC, User should complete the transaction manually and enter approval details on PC application. POS will show a screen asking the user to do this.






Fig. 5.4.2.2 POS Error Message


POS will always try to send host response to PC, even if the transaction was declined. There are some cases with Chip cards, where a transaction is approved by Host but declined by the Chip, in this case, POS will decline the transaction also and generate a reversal, and a response with the transaction result will be sent to PC.





#### 5.4.3 Terminal Interaction

Terminal can interact with PC application requests only if it was at idle state and showing a status message of "Waiting for PC Request", if the terminal is busy doing another transaction, or closing its batch, or no user is logged on, it will send an error message to the PC.






Fig. 5.4.3.1 Integrated POS Idle Screen

Pressing "Enter" key on POS keypad will open the Main Menu, from which the user can access other functionalities like Reports, Batch Review, Settlement... etc.

After receiving a successful initial request from PC, POS will prompt the user to swipe or insert the client card.

SWIPE OR INSERT CARD
PLEASE SWIPE OR
INSERT CLIENT CARD

أدخل أو مرر البطاقة
الرجاء تمرير أو إدخال بطاقة العميل

Fig. 5.4.3.2 Integrated POS Idle Screen

If cancel was pressed, or long time has passed, or there was a problem with the card, POS will terminate the transaction and send an error message to the PC.





## **5.5 Transaction Termination Messages**

POS might send error messages to PC during transaction process to tell what the error reason was, these errors are encapsulated with the standard serial control characters as described before, these errors are:

0 1	LE B
Code	Error Description
001	No user is logged on POS
002	POS is not connected to host (Check Phone Line) or IP
003	POS Batch is full, please settle batch
004	Settlement was attempted, batch should be settled first
005	Used card is expired
006	Card is not readable
007	Card Swipe/Insertion Timed Out
800	Card range is not supported on POS
009	Card Track I is not readable
010	User Canceled Transaction on POS
011	POS wasn't able to reach host
012	Transaction is not allowed on POS
013	Original Transaction not found in POS batch
014	User pressed Cancel for PIN, PIN Bypass is not allowed
015	User Failed to Verify Transaction Password
016	Chip Card Was Removed From POS
017	Transaction Declined by Chip Card
018	Fall back from ICC to Magnetic stripe has failed
019	Message LRC is not correct
020	Message length in header doesn't match physical length
021	Requested transaction type is not recognized
022	Parsing error, message is not formatted correctly
023	PC response wasn't received in time
024	Card Mismatch
025	Change Password Required
026	Paper Out
027	Invalid PAN, MOD-10 check
028	Manual PAN entry not allowed
029	Settlement was attempted, batch is empty
030	Service Code Check, Chip card swiped
031	Service Code Check, no PIN verification available
032	Service Code Check, Reject
033	Service Code Check, wrong value
034	Manual not Allowed By Issuer
035	Swipe not Allowed By Issuer
036	Chip not Allowed By Issuer
037	Requested eServices exceed the maximum
038	ECR ID Number Mismatch
039	"SERVICE PROCESS FAILED"
040	General ECR Error "INCOMPLETE ECR TRANSACTION"
040	INVALID MERCHANT ID
041	INVALID MERCHANT ID INVALID ECR VERSION
	INVALID ECR VERSION INVALID TERMINAL ID
043	INVALID TERMINAL ID INVALID ECR APPLCIATION ID
044	
H01	Referral - Call card issuer
H02	Call Late
H03	Call Help
H04	Pickup Card
H05	Transaction declined, don't honor
H06	Pickup Card
H07	Invalid transaction amount
H12	Invalid Transaction
H15	Card unknown





H25 Un-able to locate record on file H30 Format Error H31 Bank not supported by switch H32 Card not Supported H41 Lost Card H43 Stolen Card - Pickup Card H51 No sufficient Funds H54 Expired Card H55 Incorrect PIN H56 Incorrect PassCode H58 Payment Request is Invalid H60 Transaction not permitted to terminal H61 Maximum Sale value reached H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H82 Password Changed Successfully H85 Batch not Found H06 H86 Terminal Not Active H87 Transaction Declined, Wrong CVV H80 Batch Not Found H87 Terminal Not Active H88 Terminal Not Active H89 Terminal ID is not valid H99 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error HA4 Card is Not Numeric HA5 Length Is Invalid HA6 System Malfunction HA7 Terminal Not Active H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error Found HA7 Terminal Not Active H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error Found HA7 Terminal Not Active H89 Terminal Merchant Error HA4 Card is Not Numeric HA5 Length Is Invalid HA6 Card is Banned HA7 Holder Name Missing HA7 Holder Name Missing HA7 Holder Name Missing HA8 Bank Inf Navaliable H85 Merchant Does Not Exist H86 No Active Merchant H89 Currency Does Not Exist H86 Inactive Merchant H87 Transaction Not Available H87 Transaction Not Available H77 Transaction Not Available H78 Transaction Not Available H79 Currency Does Not Exist H70 Currency Not Supported H71 Transaction Not Available	H19	Re-Enter Transaction
H30 Format Error H31 Bank not supported by switch H32 Card not Supported H41 Lost Card H43 Stolen Card - Pickup Card H45 No sufficient Funds H56 Incorrect PIN H56 Incorrect PIN H56 Incorrect PIN H67 Insaction not permitted to terminal H60 Transaction not permitted to terminal H61 Maximum Sale value reached H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Active H70 Section Not Active H71 Shortcut Not Assigned H72 Oild Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H89 Password Changed Successfully H80 Batch not Found H81 Terminal Not Found H82 Password Changed Successfully H84 Password Less than Minimum Length H75 Terminal Not Found H87 Terminal Not Found H88 Terminal Merchant Error H78 Terminal Not Found H89 Terminal ID is not valid H90 Invalid Froduct Code H77 Reconcile Error H88 Terminal Merchant Error H89 Terminal Not Active H80 Batch not Found H87 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA7 Holder Name Missing HA8 Bank Is Missing HA9 Card Is Banned H80 Invalid Card Type H80 Invalid Card Type H81 Bank Is Missing HA9 Card Is Banned H85 Merchant Took Out Exist H86 No Active Merchant H87 Merchant Not Received H88 Inactive Merchant H89 Merchant Not Received H89 Merchant Not Received H89 Invalid Card Type H80 Currency Does Not Exist H60 Currency Does Not Exist H60 Currency Does Not Exist H60 Currency Does Not Available H61 Currency Does Not Available H62 Transaction Not Available		
H32 Card not Supported H41 Lost Card H43 Stolen Card - Pickup Card H55 No sufficient Funds H55 Incorrect PIN H56 Incorrect PIN H56 Incorrect Pin H60 Transaction not permitted to terminal H61 Maximum Sale value reached H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Active H70 Section Not Active H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H89 Password Changed Successfully H80 Batch Not Found H81 Terminal Not Active H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found On Host H86 Terminal Not Found H87 Terminal Not Found H87 Terminal Not Active H88 Terminal Not Found H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error H44 Card is Not Numeric H45 Length Is Invalid H46 Card # Is Missing H47 Bank Isn Missing H48 Bank Isn Missing H49 Card Is Banned H80 Invalid Card Type H80 No Active Merchant H81 Bank Id Missing H84 Bank Isn Maximum H85 Merchant Does Not Exist H86 No Active Merchant H87 Merchant Not Received H88 Inactive Merchant H89 Currency Does Not Exist H86 Inactive Merchant H87 Merchant Not Received H88 Inactive Merchant H89 Currency Does Not Exist H60 Currency Does Not Exist H60 Currency Does Not Exist H60 Currency Does Not Available H61 Currency Does Not Available H62 Transaction Not Validated	H30	
H32 Card not Supported H41 Lost Card H43 Stolen Card - Pickup Card H55 No sufficient Funds H55 Incorrect PIN H56 Incorrect PIN H56 Incorrect Pin H60 Transaction not permitted to terminal H61 Maximum Sale value reached H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Active H70 Section Not Active H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H89 Password Changed Successfully H80 Batch Not Found H81 Terminal Not Active H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found On Host H86 Terminal Not Found H87 Terminal Not Found H87 Terminal Not Active H88 Terminal Not Found H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error H44 Card is Not Numeric H45 Length Is Invalid H46 Card # Is Missing H47 Bank Isn Missing H48 Bank Isn Missing H49 Card Is Banned H80 Invalid Card Type H80 No Active Merchant H81 Bank Id Missing H84 Bank Isn Maximum H85 Merchant Does Not Exist H86 No Active Merchant H87 Merchant Not Received H88 Inactive Merchant H89 Currency Does Not Exist H86 Inactive Merchant H87 Merchant Not Received H88 Inactive Merchant H89 Currency Does Not Exist H60 Currency Does Not Exist H60 Currency Does Not Exist H60 Currency Does Not Available H61 Currency Does Not Available H62 Transaction Not Validated	H31	Bank not supported by switch
H41 Lost Card H43 Stolen Card - Pickup Card H51 No sufficient Funds H54 Expired Card H55 Incorrect PIN H56 Incorrect PIN H56 Incorrect PassCode H58 Payment Request is Invalid H60 Transaction not permitted to terminal H61 Maximum Sale value reached H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H80 Batch Number not Found H81 Password Changed Successfully H82 Password Changed Successfully H85 Batch not Found H87 Terminal Not Active H88 Terminal Not Active H89 Terminal Not Active H80 Invalid Terminal IP H91 Issuer or switch inoperative H89 Terminal Dis not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H49 Card Is Not Numeric H44 Card Is Not Numeric H45 Bank Isn't Available H80 Invalid Card Type H81 Bank Isn't Available H82 Merchant Does Not Exist H86 No Active Merchant H87 Merchant Does Not Exist H88 Terminal Poes Not Exist H89 Currency Not Supported H80 Invalid Card Type H81 Bank Isn't Available H85 Merchant Does Not Exist H86 No Active Merchant H87 Merchant Not Received H88 Inactive Merchant H89 Currency Does Not Exist H68 No Active Merchant H89 Currency Does Not Exist H60 Currency Does Not Exist H60 Currency Does Not Available H79 Transaction Not Available	H32	
H51 No sufficient Funds H54 Expired Card H55 Incorrect PIN H56 Incorrect PassCode H58 Payment Request is Invalid H60 Transaction not permitted to terminal H61 Maximum Sale value reached H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H82 Password Changed Successfully H85 Batch not Found On Host H86 Terminal Not Found H87 Terminal Not Found H87 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Ouplicate Transmission H85 Reconcile Error HA4 Card Is Not Numeric HA4 Card Is Not Numeric HA5 Invalid Product H96 System Malfunction HA6 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error HA4 Card Is Not Numeric HA5 Length Is Invalid H86 Terminal ID is not valid H99 Terminal ID is not valid H90 System Malfunction HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA8 Bank Ind Missing HA9 Card Is Banned HB8 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Terminal Does Not Exist HB8 Currency Does Not Exist HB9 Currency Does Not Exist HB9 Currency Does Not Exist HC0 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated	H41	
H51 No sufficient Funds H54 Expired Card H55 Incorrect PIN H56 Incorrect PassCode H58 Payment Request is Invalid H60 Transaction not permitted to terminal H61 Maximum Sale value reached H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H82 Password Changed Successfully H85 Batch not Found On Host H86 Terminal Not Found H87 Terminal Not Found H87 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Ouplicate Transmission H85 Reconcile Error HA4 Card Is Not Numeric HA4 Card Is Not Numeric HA5 Invalid Product H96 System Malfunction HA6 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error HA4 Card Is Not Numeric HA5 Length Is Invalid H86 Terminal ID is not valid H99 Terminal ID is not valid H90 System Malfunction HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA8 Bank Ind Missing HA9 Card Is Banned HB8 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Terminal Does Not Exist HB8 Currency Does Not Exist HB9 Currency Does Not Exist HB9 Currency Does Not Exist HC0 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated	H43	Stolen Card - Pickup Card
H55 Incorrect PIN H56 Incorrect PassCode H58 Payment Request is Invalid H60 Transaction not permitted to terminal H61 Maximum Sale value reached H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H80 Batch Number not Found H81 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission HA6 Card # Is Not Numeric HA7 Holder Name Missing HA7 Holder Name Missing HA7 Holder Name Missing HA8 Bank Inst Name Austinal H89 Card Is Banned H89 Card Is Banned H89 No Details Found H89 Bank In Nameric HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned H89 Merchant Does Not Exist H80 Merchant Does Not Exist H86 No Active Merchant H87 Merchant Not Aceived H88 Bank In Missing HA9 Card Is Banned H89 Card round H89 Merchant Does Not Exist H80 Merchant Not Received H81 Bank In Taxiliad Deleted H82 Merchant Does Not Exist H86 No Active Merchant H87 Merchant Not Received H88 Merchant Does Not Exist H89 Currency Does Not Exist H89 Currency Does Not Exist H89 Currency Does Not Exist H69 Currency Does Not Validated	H51	
H56 Incorrect PassCode H58 Payment Request is Invalid H60 Transaction not permitted to terminal H61 Maximum Sale value reached H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H80 Batch Number not Found H81 Tramsaction Declined, Wrong CVV H80 Batch Number not Found H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Found H87 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H85 Reconcile Error HA4 Card Is Not Numberic HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA8 Bank Isn't Available H89 Terminal In Invalid Card Type H80 Invalid Card Type H81 Bank Isn't Available H85 Bank In Missing HA9 Card Is Banned H86 No Active Merchant H87 Holder Name Missing HA9 Card Is Banned H88 Bank Isn't Available H89 Merchant Does Not Exist H86 No Active Merchant H87 Merchant Not Received H88 Merchant Does Not Exist H89 Currency Does Not Validated	H54	Expired Card
H58 Payment Request is Invalid H60 Transaction not permitted to terminal H61 Maximum Sale value reached H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Deleted H67 Branch Deleted H68 Section Not Found H69 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H89 Password Changed Successfully H80 Batch Number not Found H81 Terminal Not Active H88 Terminal Not Active H88 Terminal ID is not valid H99 Invalid Ternial IP H90 Invalid Ternial IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error HA4 Card Is Not Numeric HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA8 Bank Ind Missing HA9 Card Is Banned HB9 Invalid Card Type HB9 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Does Not Exist HB8 Merchant Does Not Exist HB9 Currency Not Validated HB9 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Validated	H55	Incorrect PIN
H60 Transaction not permitted to terminal H61 Maximum Sale value reached H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H80 Batch Number not Found H82 Password Chound Host H85 Batch not Found Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA7 Holder Name Missing HA8 Bank Id Missing H89 Bank Id Missing H80 Invalid Card Type H80 Invalid Card Type H81 Bank Id Missing H82 Marchant Does Not Exist H85 Bank Id Missing H86 Bank Id Missing H87 Holder Name Missing HA7 Holder Name Missing HA80 Bank Id Missing H881 Bank Id Missing H882 Morehant Does Not Exist H883 Bank Id Missing H89 Currency Does Not Exist H89 Currency Does Not Exist H89 Currency Does Not Exist H60 Transaction Not Validated	H56	Incorrect PassCode
H61 Maximum Sale value reached H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Deleted H68 Section Not Found H69 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Active H88 Terminal Not Active H88 Terminal Not Active H88 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H85 Reconcile Error H78 Reconcile Error H89 Terminal IN Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission HAA Card Is Not Numeric HAA Card Is Not Numeric HAA Card Is Roissing HA7 Holder Name Missing HA7 Holder Name Missing HA8 Bank Isn't Available H85 Merchant Does Not Exist H86 No Active Merchant H87 Holder Name Missing HA8 Card # Bank Isn't Available H88 Bank Isn't Available H89 Currency Does Not Exist H88 Dactive Merchant H89 Currency Does Not Exist H60 Currency Not Supported H77 Moder Transaction Not Available H78 Transaction Not Validated	H58	Payment Request is Invalid
H63 Error in Cryptogram H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Found H69 Section Not Active H70 Section Not Active H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Found H87 Terminal Merchant Error H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HAA Card Is Not Numeric HAA Card Is Not Numeric HAA Card Is Not Numeric HAB Bank Id Missing HAA Card Is Banned HBO Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HA4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Available HC3 Transaction Not Vailidated	H60	Transaction not permitted to terminal
H64 Requested Action Not allowed H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Found H69 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned H80 Invalid Card Type H81 Bank Isn't Available H85 Merchant Does Not Exist H86 No Active Merchant H87 Merchant Does Not Exist H88 Bank Id Missing H84 Bank Isn't Available H85 Merchant Does Not Exist H86 No Active Merchant H87 Ternacy Does Not Exist H88 Decurrency Does Not Exist H88 Decurrency Does Not Exist H89 Currency Does Not Exist H89 Currency Does Not Exist H89 Currency Does Not Exist H60 Currency Not Supported H77 Molder Name Misailable H77 Marchant Not Validated	H61	
H65 Batch Not Found H66 Branch Not Found H67 Branch Deleted H68 Section Not Found H69 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Active H88 Terminal Not Active H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA7 Holder Name Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Does Not Exist HB8 Decurrency Does Not Exist HB8 Decurrency Does Not Exist HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated	H63	
H66 Branch Not Found H67 Branch Deleted H68 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found On Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal More Chant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA8 Bank Isn't Available H89 Merchant Does Not Exist H89 Merchant Not Received H88 Bank Inactive Merchant H89 Merchant Not Received H89 Bank Inactive Merchant H89 Merchant Not Received H89 No Active Merchant H89 Currency Does Not Exist H89 Currency Does Not Exist H69 Currency Does Not Exist H60 Currency Not Supported H62 Transaction Not Validated		
H67 Branch Deleted H68 Section Not Found H69 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned H80 Invalid Card Type H81 Bank Isn't Available H85 Merchant Not Received H88 Bank Isn't Available H89 Merchant Not Received H89 Danctive Merchant H80 Invalid Card Type H81 Bank Isn't Available H85 Merchant Not Received H88 Bank Inactive Merchant H89 Danctive Merchant H89 Danctive Merchant H89 Darrency Does Not Exist H80 Currency Does Not Exist H80 Currency Does Not Exist H60 Currency Not Supported H70 Transaction Not Validated		
H68 Section Not Found H69 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H85 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backed Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Does Not Exist HC0 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
H69 Section Not Active H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Found H87 Terminal Merchant Error H88 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA8 Bank Id Missing HB9 Merchant Not Received HB9 Merchant Not Received HB8 Inactive Merchant HB9 Merchant Not Received HB9 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Does Not Exist HC0 Transaction Not Validated		
H70 Section Deleted H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Active H87 Terminal Not Active H88 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA8 Bank Id Missing HB8 Bank Id Missing HB8 Bank Isn't Available HB5 Merchant Not Received HB8 Inactive Merchant HB9 Merchant Not Received HB9 Currency Does Not Exist HB9 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
H71 Shortcut Not Assigned H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Found H87 Terminal ID is not valid H89 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Not Supported HC2 Transaction Not Validated		
H72 Old Password is Empty H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA7 Holder Name Missing HA8 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HB0 Currency Does Not Exist HB0 Currency Not Supported HC2 Transaction Not Validated		
H73 New Password is Empty H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned H80 Invalid Card Type H82 No Details Found H83 Bank Id Missing H84 Bank Isn't Available H85 Merchant Does Not Exist H86 No Active Merchant H87 Merchant Not Received H88 Inactive Merchant H89 Currency Does Not Exist H80 Currency Not Supported HC2 Transaction Not Available HC3 Transaction Not Available		
H74 Password Less than Minimum Length H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
H75 Password More than Maximum Length H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
H76 Invalid Product Code H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA7 Holder Name Missing HA9 Card Is Banned H80 Invalid Card Type H81 Bank Id Missing H84 Bank Isn't Available H85 Merchant Does Not Exist H86 No Active Merchant H87 Merchant Not Received H88 Inactive Merchant H89 Currency Does Not Exist H60 Currency Not Supported HC2 Transaction Not Validated		
H77 Reconcile Error H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned H80 Invalid Card Type H82 No Details Found H83 Bank Id Missing H84 Bank Isn't Available H85 Merchant Does Not Exist H86 No Active Merchant H87 Merchant Not Received H88 Inactive Merchant H89 Currency Does Not Exist H60 Currency Not Supported HC2 Transaction Not Validated		
H78 Trace Number not Found H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Available		
H79 Transaction Declined, Wrong CVV H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Available		
H80 Batch Number not Found H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Active H87 Terminal Merchant Error H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
H82 Password Changed Successfully H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
H85 Batch not Found on Host H86 Terminal Not Found H87 Terminal Not Active H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA7 Holder Name Missing HB9 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
H86 Terminal Not Found H87 Terminal Not Active H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
H87 Terminal Not Active H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
H88 Terminal Merchant Error H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Available HC3 Transaction Not Validated		
H89 Terminal ID is not valid H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Available HC3 Transaction Not Validated		
H90 Invalid Terminal IP H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
H91 Issuer or switch inoperative H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Available HC3 Transaction Not Validated		
H94 Duplicate Transmission H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
H95 Reconcile Error, Batch upload started H96 System Malfunction HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Available HC3 Transaction Not Validated		†
H96System MalfunctionHA0Backend ErrorHA4Card Is Not NumericHA5Length Is InvalidHA6Card # Is MissingHA7Holder Name MissingHA9Card Is BannedHB0Invalid Card TypeHB2No Details FoundHB3Bank Id MissingHB4Bank Isn't AvailableHB5Merchant Does Not ExistHB6No Active MerchantHB7Merchant Not ReceivedHB8Inactive MerchantHB9Currency Does Not ExistHC0Currency Not SupportedHC2Transaction Not AvailableHC3Transaction Not Validated		
HA0 Backend Error HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
HA4 Card Is Not Numeric HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
HA5 Length Is Invalid HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Validated		
HA6 Card # Is Missing HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Available HC3 Transaction Not Validated		
HA7 Holder Name Missing HA9 Card Is Banned HB0 Invalid Card Type HB2 No Details Found HB3 Bank Id Missing HB4 Bank Isn't Available HB5 Merchant Does Not Exist HB6 No Active Merchant HB7 Merchant Not Received HB8 Inactive Merchant HB9 Currency Does Not Exist HC0 Currency Not Supported HC2 Transaction Not Available HC3 Transaction Not Validated		U
HA9 Card Is Banned  HB0 Invalid Card Type  HB2 No Details Found  HB3 Bank Id Missing  HB4 Bank Isn't Available  HB5 Merchant Does Not Exist  HB6 No Active Merchant  HB7 Merchant Not Received  HB8 Inactive Merchant  HB9 Currency Does Not Exist  HC0 Currency Not Supported  HC2 Transaction Not Available  HC3 Transaction Not Validated		
HB0 Invalid Card Type  HB2 No Details Found  HB3 Bank Id Missing  HB4 Bank Isn't Available  HB5 Merchant Does Not Exist  HB6 No Active Merchant  HB7 Merchant Not Received  HB8 Inactive Merchant  HB9 Currency Does Not Exist  HC0 Currency Not Supported  HC2 Transaction Not Available  HC3 Transaction Not Validated		
HB2 No Details Found  HB3 Bank Id Missing  HB4 Bank Isn't Available  HB5 Merchant Does Not Exist  HB6 No Active Merchant  HB7 Merchant Not Received  HB8 Inactive Merchant  HB9 Currency Does Not Exist  HC0 Currency Not Supported  HC2 Transaction Not Available  HC3 Transaction Not Validated		
HB3 Bank Id Missing  HB4 Bank Isn't Available  HB5 Merchant Does Not Exist  HB6 No Active Merchant  HB7 Merchant Not Received  HB8 Inactive Merchant  HB9 Currency Does Not Exist  HC0 Currency Not Supported  HC2 Transaction Not Available  HC3 Transaction Not Validated		
HB4 Bank Isn't Available  HB5 Merchant Does Not Exist  HB6 No Active Merchant  HB7 Merchant Not Received  HB8 Inactive Merchant  HB9 Currency Does Not Exist  HC0 Currency Not Supported  HC2 Transaction Not Available  HC3 Transaction Not Validated		
HB5 Merchant Does Not Exist  HB6 No Active Merchant  HB7 Merchant Not Received  HB8 Inactive Merchant  HB9 Currency Does Not Exist  HC0 Currency Not Supported  HC2 Transaction Not Available  HC3 Transaction Not Validated		
HB6 No Active Merchant  HB7 Merchant Not Received  HB8 Inactive Merchant  HB9 Currency Does Not Exist  HC0 Currency Not Supported  HC2 Transaction Not Available  HC3 Transaction Not Validated		
HB7 Merchant Not Received  HB8 Inactive Merchant  HB9 Currency Does Not Exist  HC0 Currency Not Supported  HC2 Transaction Not Available  HC3 Transaction Not Validated		
HB8 Inactive Merchant  HB9 Currency Does Not Exist  HC0 Currency Not Supported  HC2 Transaction Not Available  HC3 Transaction Not Validated		Merchant Not Received
HB9 Currency Does Not Exist  HC0 Currency Not Supported  HC2 Transaction Not Available  HC3 Transaction Not Validated		
HC0 Currency Not Supported  HC2 Transaction Not Available  HC3 Transaction Not Validated		
HC2 Transaction Not Available HC3 Transaction Not Validated		
HC3 Transaction Not Validated	HC2	
HC4 Error Not Available		
	HC4	Error Not Available





HC5	Parameter Not Available
HC6	Sign Isn't Verified
HC7	Amount Not Received
HC8	Currency Not Received
HC9	Pun Wasn't Received
HD0	Lang Not Received
HD1	Action not Received
HD2	Date Not Received
HD3	Conf Id Not Received
HD4	Status Not Received
HD5	Stat Msg Not Received
HD6	Action Type Not Avail
HD7	Payment Not Supported
HD8	Parameters Not Received
HD9	Payment Not Safe Pg
HE0	Payment Not Safe
HE1	Missing Signature
HE2	Missing Parameter
HE3	Wrong Account Format
HE4	Amount Is Zero Error
HE5	Amount Exceed Limit
HE6	Pun Already Exists
HE7	Transaction Request Received
HE8	Signature Verification Failed
HE9	Currency Not Supported
HEF	Inquiry Not Found
HES	Inquiry Not Successful
HEV	Inquiry Not Valid
HF0	Missing Parameters - Pc
HF1	Missing Parameters
HF2	Invalid Signature
HF4	Invalid Pay Method
HF6	Invalid Cancel Method
HF7	Cancel Error
HF9	Payment Failed
HH0	Invalid Action
HH2	Invalid Action
HH3	Merchant Validation Error
HH4	Currency Validation Error
HH5	Trans Validation Error
HH6	Invalid Msg Format
HH7	Trans Sign Error
HH8	Trans Corrupted Data
HH9	Trans Not Enough Credit
10	Request Not Supported
HI1	User Does Not Exist
HI3	Min Amount
HI4	Max Amount
HI5	Ineligible Card Info
HI6	Payment Attempted
HI7	Payment Auth Error
HI8	Payment Auth Failed
HI9	Invalid Err Code
HJ0	Card Enrolled
HJ2	Pay Invalid Response
HJ3	
1100	INVAIID RESPONSE LIEFT
	Invalid Response Cert  Backend Error
HJ4	Backend Error
HJ4 HJ5	Backend Error Authnet Not Available
HJ4 HJ5 HJ7	Backend Error Authnet Not Available Action Not Supported
HJ4 HJ5 HJ7 HJ8	Backend Error Authnet Not Available Action Not Supported IP Not Supported
HJ4 HJ5 HJ7	Backend Error Authnet Not Available Action Not Supported





	T
HK1	Inquiry Already Used
HK2	Merchant Not Authorized
HK3	Query Missing
HK4	Query Doesn't Exist
HK5	Query Not Unique
HK6	Terminal Id Mismatch
HK7	Amounts Don't Match
HK8	Method Not Supported
HL0	Service Mismatch
HL1	Invalid URLs
HL2	Merchant Id Mismatch
HL3	Received Parameter Missing
HL4	URLs Incorrect
HL5	Authorization Failed
HL6	Verification Failed
HL7	No Records Found
HL8	Request Reversal
HL9	Trans Not Found
HN0	Trans Previously Voided
HN1	As Not Authorized
HN2	Pay Voucher Generated
HN3	Void Grace Period Finished
HN4	Backend Error
HN5	No Available Trans
HN6	Backend Error
HN7	Unexpected Msg Strc
HN8	Trans Not Marked
HN9	Void Trans Failed
HM0	Pending Trans Error
HM1	Failed Transaction
HM2	Backend Error
HM3	Trans Previously Updated
HM4	Original Trans Missing
HM6	Encryption Error
HM7	Decryption Error
HM8	Failed Conversion Card Type Not Supported
HM9 HO1	
HO3	Void Trans Not Found Refund Not Pre-Approved
HO4	Trans Previously Refunded
	Acq Server Not Authorized
HO5 HO6	Voucher Previously Generated
HO7	Exceeded Refund Grace Period
HO9	Refund Trans Error
HP1	Fraud Authentication Failed
HP2	Account Num Missing
HP3	Id Black List Match
HP4	Bank Black List Match
HP5	Account Black List Match
HP6	Bin Black List Match
HP7	Card Rejection Match
HP8	Country Black List Match
HP9	IP Black List Match
HQ0	Risk Rule Violation
HQ1	Risk Rule Violation
HQ2	Risk Rule Violation
HQ3	Risk Rule Violation
HQ4	Pay Invoice Missing
HQ5	Invoice Item Missing
HQ6	Invalid Xmlpay Tendr
HQ7	Pay Duplicate Payment
HQ8	Pay Merchant Id Missing
1100	i ay moronani la misoing





HQ9	3ds Check Failed
HR0	Pay Trxn Not Found
HR1	Pay Amount < 1
HR2	Currency Not Found
HR4	Inactive Service Owner
HR5	Inactive Eservice
HR6	Inactive E-Dirham Service
HR7	Exceeding Max #
HR8	Exceeding Max #
HR9	Service Not Assigned
HS0	Wrong Transaction
HS1	Trans Inquiry Failed
HS2	Amounts Differ
HS3	Service With 0 Price
HS4	Service Not Assigned
HS5	Service Not Assigned
HS6	Backend Error
HS7	Trans Not Pre-Auth
HS8	Update Trans Failed
HTO	Session Time Out
HT1	Transaction Started
HT2	Transaction Complete
HT3	Transaction Pending
HT4	Transaction Rejected
HT5	Original Trans Not Found
HTP	Payment Trans Pending
HV1	EOD Settlement Mismatch
HV2	Original Trans Not Auth
HV3	Sale Request Code
HV4	Complete Request Code
HV5	Topup Request Code
HV6	Refund Request Code
HV7	Void Request Code
HV8	Comp IP Not Supported
HV9	Amounts Differ
HW1	Card None Existent
HW2	Query None Existent
HW3	Request None Existent
HW4	Account None Existent
H**	All Other Response Codes

Above response messages can be translated on the PC application into more informative messages to explain the error type to user so the proper action can be taken if required.

Some of the listed errors above require user interaction with the POS to solve the issue, like checking phone line / IP connectivity for example or diagnose other types of errors.

On the other hand, there could be an issue with the communication with PC, in this case POS will display an error message on screen, and try to send (NAK) to the PC.

Codes from H01 to H96 in addition to H\*\* are returned by the host after sending the online request message.





## Below sample error screens:

#### COMMAND FROM PC

INVALID REQUEST
CALL FOR HELP - 005

أمر من الحاسوب

خطأ في العملية اتصل للمساعدة - 005

Fig. 5.5.1 Wrong LRC Error Screen





#### COMMAND FROM PC

INVALID REQUEST

CALL FOR HELP - 006

#### أمر من الحاسوب

خطأ في العملية اتصل للمساعدة - 006

Fig 5.5.2 Wrong Transaction Type Screen

#### COMMAND FROM PC

INVALID REQUEST

CALL FOR HELP - 007

## أمر من الحاسوب

خطأ في العملية اتصل للمساعدة - 007

Fig 5.5.3 Format Error Screen

#### COMMAND FROM PC

INVALID REQUEST
CALL FOR HELP - 008

#### أمر من الحاسوب

خطأ في العملية اتصل للمساعدة - 008

Fig 5.5.4 Original Transaction Not found



## 5.6 Serial Message Specifications

This section describes request/response messages between POS and PC, it is important to follow the tables below in details to have successful integration between POS and PC.

#### 5.6.1 Request Message from PC

This message initiates the transaction by sending required information to POS.

Field Attribute		ute	Bytes	Value
<stx></stx>	С	1	1	Start of text (0x02)
Message Length	AN	4	4	Message Length (0436)
ECR Version Number	AN	3	3	ECR version number (111)
<fs></fs>	С	1	1	Field separator (0x01C)
Transaction Type	AN	2	2	Transaction Type ( Sale = 01 )
<fs></fs>	С	1	1	Field separator (0x01C)
ECR Application ID(***)	AN	8	8	ECR Application Identifier
<fs></fs>	С	1	1	Field separator (0x01C)
Terminal ID	AN	8	8	POS Terminal ID
<fs></fs>	С	1	1	Field separator (0x01C)
Service 1 Code	ANS	20	20	Service 1 Main & Sub Code
<fs></fs>	С	1	1	Field separator (0x01C)
Service 1 Amount	ANS	12	12	Service 1 Amount
<fs></fs>	С	1	1	Field separator (0x01C)
Service 1 Quantity	AN	6	6	Service 1 Quantity (000000-999999)
<fs></fs>	С	1	1	Field separator (0x01C)
Service 2 Code	ANS	20	20	Service 2 Main & Sub Code
<fs></fs>	С	1	1	Field separator (0x01C)
Service 2 Amount	ANS	12	12	Service 2 Amount
<fs></fs>	С	1	1	Field separator (0x01C)
Service 2 Quantity	AN	6	6	Service 2 Quantity (000000-999999)
<fs></fs>	С	1	1	Field separator (0x01C)
Service 3 Code	ANS	20	20	Service 3 Main & Sub Code
<fs></fs>	С	1	1	Field separator (0x01C)
Service 3 Amount	ANS	12	12	Service 3 Amount
<fs></fs>	С	1	1	Field separator (0x01C)
Service 3 Quantity	AN	6	6	Service 3 Quantity (000000-999999)
<fs></fs>	С	1	1	Field separator (0x01C)
Service 4 Code	ANS	20	20	Service 4 Main & Sub Code
<fs></fs>	С	1	1	Field separator (0x01C)
Service 4 Amount	ANS	12	12	Service 4 Amount
<fs></fs>	С	1	1	Field separator (0x01C)
Service 4 Quantity	AN	6	6	Service 4 Quantity (000000-999999)
<fs></fs>	С	1	1	Field separator (0x01C)
Service 5 Code(**)	ANS	20	20	Service 5 Main & Sub Code
<fs></fs>	С	1	1	Field separator (0x01C)
Service 5 Amount(**)	ANS	12	12	Service 5 Amount
<fs></fs>	С	1	1	Field separator (0x01C)
Service 5 Quantity(**)	AN	6	6	Service 5 Quantity (000000-999999)
<fs></fs>	С	1	1	Field separator (0x01C)
Service 6 Code(**)	ANS	20	20	Service 6 Main & Sub Code
<fs></fs>	С	1	1	Field separator (0x01C)
Service 6 Amount(**)	ANS	12	12	Service 6 Amount
<fs></fs>	С	1	1	Field separator (0x01C)
Service 6 Quantity(**)	AN	6	6	Service 6 Quantity (000000-999999)





T				
<fs></fs>	С	1	1	Field separator (0x01C)
Number of Applications	AN	4	4	Number of Applications (0001-0300)
<fs></fs>	С	1	1	Field separator (0x01C)
Additional Amount	AN	12	12	Additional Custom Amount
<fs></fs>	С	1	1	Field separator (0x01C)
Application Number	ANS	20	20	Application Number
<fs></fs>	С	1	1	Field separator (0x01C)
POS Assign Appl. Number	AN	1	1	Flag for POS to auto generate app. number
<fs></fs>	С	1	1	Field separator (0x01C)
Original Invoice Number	ANS	6	6	Original Transaction Invoice Number
<fs></fs>	С	1	1	Field separator (0x01C)
ECR Invoice Number	ANS	6	6	PC Application Invoice Number
<fs></fs>	С	1	1	Field separator (0x01C)
ECR ID Number	ANS	16	16	PC Unique ID Number
<fs></fs>	С	1	1	Field separator (0x01C)
ECR User ID	ANS	8	8	PC User ID
<fs></fs>	С	1	1	Field separator (0x01C)
ECR Transaction Date	AN	6	6	PC Date (DDMMYY)
<fs></fs>	С	1	1	Field separator (0x01C)
ECR Transaction Time	ANS	4	4	PC Time (HHMM) H24 format
<fs></fs>	С	1	1	Field separator (0x01C)
Country Code	ANS	4	4	Country Code
<fs></fs>	С	1	1	Field separator (0x01C)
Main Area Code	ANS	16	16	Main Area Code
<fs></fs>	С	1	1	Field separator (0x01C)
Sub Area Code	ANS	8	8	Sub Area Code
<fs></fs>	С	1	1	Field separator (0x01C)
PAN(*)	ANS	19	19	Card Number
<fs></fs>	С	1	1	Field separator (0x01C)
Expiry Date(*)	ANS	4	4	Card Expiry Date
<fs></fs>	С	1	1	Field separator (0x01C)
Merchant ID	ANS	15	15	Merchant ID
<fs></fs>	С	1	1	Field separator (0x01C)
<etx></etx>	С	1	1	End of text (0x03)
<lrc></lrc>	В	2	1	Message LRC.

- (\*) It might be required by MoF in future to add Card Number and Expiry date in request message.
- (\*\*) The maximum number of services per one transaction is 4 on dialup terminals (T4210) and 6 on IP terminals (T4220/T4230/M4230), user can have up to 4 or 6 services for each sale transaction depends on the terminal type used.
- (\*\*\*)POS terminal can maintain and manage up to (4) ECR\PC applications separately; where each application uses [ECR Application ID] to identify its origin to the POS terminal.





#### Field Attributes:

Attribute	Description
С	Control Character (STX, ETX, FS, LRC)
AN	Alphanumeric, could be numeric only, or numeric & characters
ANS	Alphanumeric and Special characters
В	Binary (Only for LRC)

## Transaction Types:

Transaction	Value	Description
Sale	01	Initiates Sale Transaction
Pre-Auth	02	Initiates Pre-Auth Transaction
Completion	03	Initiates Completion Transaction
Refund	10	Initiates Refund Transaction
Void	11	Initiates Void Transaction
Service Charge Inq.	15	Initiates Service Charge Inq. Transaction
Card Balance / Status	16	Initiates Balance Inquiry Transaction
Card Activation	17	Initiates Card Activation Transaction
Close Batch	18	Initiates Settlement Transaction
Last Transaction Status	TS	Checks last processed transaction status
eGuarantee	EG	Initiates eGuarantee Sale Transaction
eAttestation	EA	Initiates eAttestation Sale Transaction

For Completion, Refund Void and Completion, original transaction ID is required to locate the original transaction on POS transaction memory.

If any other values were sent from PC to POS, an error message will be shown on POS screen.





#### Fields Format and Padding:

Field Name	Format
Service Code & Sub-Code	Left padding with zeros for the first 11 digits, right padding with spaces.
Service Quantity	6-digit number padded with zeros from left.
Number of Applications	0001 – 0300, always padded with zeros.
Additional Amount	Zero filled, right justified.
Application Number	Space filled, left justified.
Original Invoice Number	Zero filled, right justified.
ECR Invoice Number	Zero filled, right justified.
ECR ID Number	Space Filled, left justified.
ECR User ID	Space Filled, left justified.
ECR Transaction Date	DDMMYY, always 6 digits.
ECR Transaction Time	HHMM H24 format, always 4 digits.
Country Code	3-digit ISO 3166-1 Country Code, padded with a zero form left.
Main Area Code	Space Filled, left justified
Sub Area Code	Space Filled, left justified
PAN	Filled with 'F", left justified, All 'F' if not used.
Expiry Date	4-digits expiry date YYMM format, space filled if not used.

#### 5.6.2 Last Transaction Status Request

This message retrieves last processed transaction details from the POS.

POS responds with the same response to Payment Transaction (5.6.3), POS will always respond with the details of last processed transaction even if the batch was settled, the only time it might return an error message (*HB2*) is when the POS is newly deployed and no transactions were processed yet.

Field	Attribute		Bytes	Value
<stx></stx>	С	1	1	Start of text (0x02)
Message Length	AN	4	4	Message Length (0042)
ECR Version Number	AN	3	3	ECR version number (111)
<fs></fs>	С	1	1	Field separator (0x01C)
Transaction Type	AN	2	2	Transaction Type (TS)
<fs></fs>	С	1	1	Field separator (0x01C)
ECR Application ID	AN	8	8	ECR Application Identifier
<fs></fs>	С	1	1	Field separator (0x01C)
Terminal ID	AN	8	8	POS Terminal ID
<fs></fs>	С	1	1	Field separator (0x01C)
ECR ID Number	ANS	16	16	PC Unique ID Number (ID to verify)
<fs></fs>	С	1	1	Field separator (0x01C)
<etx></etx>	С	1	1	End of text (0x03)
<lrc></lrc>	В	2	1	Message LRC.





# 5.6.3 Response Message from POS

This message is sent from POS to PC after getting e-dirham Host response.

Field	Attribu	ıte	Bytes	Value
<stx></stx>	C	1	1	Start of text (0x02)
Message Length	N	4	4	Message Length (0979)
Transaction Type	AN	2	2	Transaction Type ( Sale = 01 )
<fs></fs>	C	1	1	Field separator (0x01C)
Transaction ID	N	16	16	POS Unique transaction ID
<fs></fs>	C	1	1	Field separator (0x01C)
Services Number	N	1	1	Number of Services (Maximum of 6)
<fs></fs>	C	1	1	Field separator (0x01C)
<f32< td=""><td><u> </u></td><td>l <mark>I</mark></td><td><u> </u></td><td>rield Separator (0x010)</td></f32<>	<u> </u>	l <mark>I</mark>	<u> </u>	rield Separator (0x010)
Service 1 Amount	NI	40	<mark>12</mark>	Service 1 Amount
	N C	12	1	
<fs></fs>		1		Field separator (0x01C)
Service 1 Fee 1 Amount	N	12	12	Service 1, Fee 1 Amount
<fs></fs>	C	1	1	Field separator (0x01C)
Service 1 Fee 1 Name	ANS	20	20	Service 1, Fee 1 Name
<fs></fs>	C	1	1	Field separator (0x01C)
Openia a re Arra avent	N.	40	140	Opening a Agrange
Service n Amount	N	12	12	Service n Amount
<fs></fs>	C	1	1	Field separator (0x01C)
Service n Fee 1 Amount	N	12	12	Service n, Fee 1 Amount
<fs></fs>	C	1	1	Field separator (0x01C)
Service n Fee 1 Name	ANS	20	20	Service n, Fee 1 Name
<fs></fs>	C	<mark>1</mark>	1	Field separator (0x01C)
-	I			
Dynamic Fee Count	N	2	2	Number of Fees (Maximum 10)
<fs></fs>	C	<mark>1</mark>	1	Field separator (0x01C)
Dynamic Fee 1 Amount	N	<mark>12</mark>	<mark>12</mark>	Dynamic Fee 1 Amount
<fs></fs>	С	1	1	Field separator (0x01C)
Dynamic Fee 1 Text	ANS	40	40	Fee 1 Text Description
<fs></fs>	С	1	1	Field separator (0x01C)
	I I	<u> </u>	- I	
Dynamic Fee n Amount	N	<mark>12</mark>	<mark>12</mark>	Dynamic Fee n Amount
<fs></fs>	С	1	1	Field separator (0x01C)
Dynamic Fee n Text	ANS	40	40	Fee n Text Description
<fs></fs>	С	1	1	Field separator (0x01C)
		l e	<u> </u>	
Response Code	N	2	2	Host Response Code
<fs></fs>	C	1	1	Field separator (0x01C)
Approval Code	ANS	6	6	Transaction Approval Code
<fs></fs>	C	1	1	Field separator (0x01C)
ECR ID Number	ANS	16	16	PC Unique ID Number (echo from Request)
<fs></fs>	C	1	1	Field separator (0x01C)
Reference Number	N	12	12	Retrieval Reference Number
<fs></fs>	C	1	1	Field separator (0x01C)
Invoice Number	N	6	6	POS Invoice Number
<fs></fs>	C	1	1	Field separator (0x01C)
POS User ID	AN	8	8	POS User ID
<fs></fs>	C	1	1	
	AN		8	Field separator (0x01C)
Terminal ID		8		POS Terminal ID
<fs></fs>	C	1	1	Field separator (0x01C)
Merchant ID	AN	15	15	POS Merchant ID
<fs> Batch Number</fs>	C	1	1	Field separator (0x01C)
Haten Nilmhar	N	6	6	POS Current Batch Number





<fs></fs>	С	1	1	Field separator (0x01C)
POS Date	N	6	6	POS Date (DDMMYY)
<fs></fs>	С	1	1	Field separator (0x01C)
POS Time	N	4	4	POS time (HHMM) H24
<fs></fs>	С	1	1	Field separator (0x01C)
Chip Transaction TC	AN	16	16	Chip TC, space filled if not present.
<fs></fs>	С	1	1	Field separator (0x01C)
Chip Transaction TVR	AN	16	16	Transaction TVR, space filled if not present.
<fs></fs>	С	1	1	Field separator (0x01C)
<etx></etx>	С	1	1	End of text (0x03)
<lrc></lrc>	В	2	1	Message LRC.

(\*) The maximum number of services per one transaction is 4 on dialup terminals (T4210) and 6 on IP terminals (T4220/T4230/M4230), user can have up to 4 or 6 services for each sale transaction depends on the terminal type used.

(\*\*) PC application is responsible of calculating the totals.

POS will send full transaction information only if the transaction was approved, and response code was "00".

Any transaction status other than approval will be sent to PC as an error message.

Field	Attribute		Bytes	Value
<stx></stx>	С	1	1	Start of text (0x02)
Message Length	Ν	4	4	Message Length (0027)
Error Message	ANS	5	5	'ERROR'
<fs></fs>	С	1	1	Field separator (0x01C)
Error Code	ANS	3	3	3-digit response code as in Error Code Table
<fs></fs>	С	1	1	Field separator (0x01C)
ECR ID Number	ANS	16	16	PC Unique ID Number (echo from Request)
<fs></fs>	С	1	1	Field separator (0x01C)
<etx></etx>	С	1	1	End of text (0x03)
<lrc></lrc>	В	2	1	Message LRC.

If the number of applications was more than one (Batch Application), POS will send a separate response to PC for each application processed, and PC should respond with an <ACK> for each message.

Fields Format and Padding:

Field Name	Format	
Transaction Type	Always 2 digit value.	
Transaction ID	Always 16-digit value.	
Transaction Amount	12-digit value, right justified, padded with zeros from left.	
Response Code	Always 2 characters and should always be "00" if successful.	
Approval Code	Left justified, padded with spaces from right.	
Unique TXN Number	Transaction Unique ID number, always 16 characters.	
Reference Number	Should always be 12 digits numeric.	
Invoice Number	6 digits, right justified, padded with zeros from left.	
POS User ID	8 characters, left justified, padded with spaces from right.	
Terminal ID	8 characters, left justified, padded with spaces from right.	
Batch Number	6 digits, right justified, padded with zeros from right.	
POS Date	Always 6 digits, Format DDMMYY.	
POS Time	Always 4 digits, Format HHMM H24.	





Chip Transaction TC	If chip transaction, 16 characters, if not, space filled.
Chip Transaction TVR	If chip transaction, 16 characters, if not, space filled.





# 6 Application Specifications Acceptance and Sign off

Please confirm that the above specifications fully cover the required functionalities of the requested features on the POS Application as agreed between Specialized Technical Services (STS) and National Bank of Abu Dhabi (NBAD) / Abu Dhabi Ministry of Finance (MOF)

Specialized Technical Services (STS)	National Bank of Ab Dhabi (NBAD)	Ministry of Finance (MOF)
Sign:	Sign:	Sign:
Name:	Name:	Name:
Title:	Title:	Title:
Date:	Date:	Date:
Stamp:	Stamp:	Stamp: