

PCB Design

Turn circuits into real boards · Equigrow short notes

The flow (KiCad)

- Schematic → assign footprints → board layout → route tracks → design rule check (DRC) → Gerber files → order.

Layout tips

- Place connectors and parts that must be at the edge first, then group by function.
- Keep decoupling capacitors (e.g. 100 nF) right next to IC power pins.
- Use a solid ground plane; keep high-current and sensitive analog tracks apart.
- Wider tracks carry more current; check with a track-width calculator.

Before ordering

- Run DRC and ERC with zero errors.
- Check footprints against real part datasheets.
- Add labels: board name, version, pin names.