MACHINES INSTRUCTIONS & ABDRESSING MODES D'Instruction is read into instruction register from the memory. met histruction is divided into modes, opcodes, and operands. (2) Types of ePU organisations: TALU TAC a) single accumulater organization b) gemal regleter organizatdon e) stack organisation. (single on no address instru.) LDVV, ABB B · Hultiple regleters present. Time og gets reduced · Zero address instruction. · size gets Increased highly · PUSH / POP matruction · 2 or 3 address Instruction Advatatages of address modes :a) 70 give programmers facilitées such as pointers, counters for loop control indering of data, and program relocation.

b) To reduce the number of bles in the addressing field of

metaurten.

Scanned by TapScanner

) Implied made , separate operand be not provided and be present which we butrustlan.

Ex: INCA

2) Immediate made: Immediately load a constant value.

Into register.

Ex: MUI B, 05 H; LD 05 H

3) Regleter Mode: Only regleter number is provided and us operand. Execution is fact.

Ex: ADD C.

4) Righter Indirect Mode: Regetter will contain the address where the operand is present.

En: Abb c - c have 300 - 50 - 30

- 5) Auto Inexement of: Lanu as regleter inolinect made, best secrement after execution the regleter value gets becomented.

 Inexemented or decremented.
- 6) Direct Addressing Mode: This is also called absolute AM.

 The address of memory is absently provided

#) Inderect Addresing biode:

Register - Address - Address - Value.

- . 2 memory access / Time high.
- · We can use fainters.

(a) Eventive AM: we specify in terms of program counter, how wany memory address do were vised to ascend or descend.

(b) Endered AM: used when CPU have lost of registers.

Here each register is given a single value.

(c) Hore index of away in index register

(d) Base register mode: A base address of storage whose is storage whose is storage whose is denote anything in that beaut.