The Printing Mechanism

- Printer reads .stl file layer by layer

- It prints a layer by moving in X and Y, moves one step in Z and repeats for next


X, Y, and Z ARE ALL EXPANDABLE





The Printing Mechanism

- Printer reads .stl file layer by layer
- It prints a layer by moving in X and Y, moves one step in Z and repeats for next