



The logo consists of a blue square containing a white stylized 'S' or 'U' shape.

TRICKS OF THE TRADE

Eric Prebys, UC Davis



The logo consists of a blue circle containing a white stylized 'U' shape.





The logo consists of a blue square containing a white stylized 'S' or 'U' shape.

USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 2 

Multi-stage Acceleration

- Early synchrotrons had low energy injection and provided all the acceleration in a single stage.
- The energy range of a single synchrotron is limited by
 - An aperture large enough for the injected beam is unreasonably large at high field.
 - Hysteresis effects result in excessive nonlinear terms at low energy (very important for colliders)
- Typical range 10-20 for colliders, larger for fixed target
 - Fermilab Main Ring: 8-400 GeV (50x)
 - Fermilab Tevatron: 150-980 GeV (6.5x)
 - LHC: 400-7000 GeV (17x)
- The highest energy beams require multiple stages of acceleration, with high reliability at each stage
- How is this done?



 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 



Initial Acceleration

Old: Static



Static acceleration from Cockcroft-Walton.
FNAL = 750 keV
max ~1 MeV

New: RF Quadrupole (RFQ)





RF structure combines an electric focusing quadrupole with a longitudinal accelerating gradient.

 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 

Early Stages

- The front end of any modern hadron accelerator looks something like this (Fermilab front end)



200 MHz RFQ:
 $35 \rightarrow 750 \text{ keV}$

Medium Energy Beam Transport (MEBT, pronounced "mebbit"): 750 keV

Solenoidal focusing for low energy beam

Einzel Lens chopper

2 ion sources

Redundant H⁻ sources: 0-35 keV

Low Energy Beam Transport (LEBT, pronounced "lebbit"): 35 keV

Drift Tube (Alvarez) Cavity

- Because the velocity is changing quickly, the first linac is generally a Drift Tube Linac (DTL), which can be beta-matched to the accelerating beam.
- Put conducting tubes in a larger pillbox, such that inside the tubes $E=0$

$d = \frac{v}{f}$ Gap spacing changes as velocity increases

Bunch of pillboxes

Drift tubes contain quadrupoles to keep beam focused

Fermilab low energy linac Inside

- As energy gets higher, switch to “pi-cavities”, which are more efficient



Linac -> Synchrotron Injection

- Eventually, the linear accelerator must inject into a synchrotron

- In order to maximize the intensity in the synchrotron, we can
 - Increase the linac current as high as possible and inject over one revolution
 - There are limits to linac current
 - Inject over multiple (N) revolutions of the synchrotron
 - Preferred method
- Unfortunately, Liouville's Theorem says we can't inject one beam on top of another
 - Electrons can be injected off orbit and will “cool” down to the equilibrium orbit via synchrotron radiation.
 - Protons can be injected at small, changing angle to “paint” phase space, resulting in increased emittance


$$\epsilon_s \geq N\epsilon_{LINAC}$$

Synchrotron emittance Linac emittance

 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 9 

Ion (or Charge Exchange) Injection

Magnetic chicane pulsed to move beam out during injection




- Instead of ionizing Hydrogen, and electron is added to create H⁻, which is accelerated in the linac
- A pulsed chicane moves the circulating beam out during injection
- An injected H⁻ beam is bent in the opposite direction so it lies on top of the circulating beam
- The combined beam passes through a foil, which strips the two electrons, leaving a single, more intense proton beam.
- Fermilab was converted from proton to H⁻ during the 70's
- CERN *still* uses proton injection, but is in the process of upgrading (LINAC4 upgrade)


 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 10 

Injection and Extraction

- We typically would like to extract (or inject) beam by switching a magnetic field on between two bunches (order ~10-100 ns)



- Unfortunately, getting the required field in such a short time would result in prohibitively high inductive voltages, so we usually do it in two steps:




 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 

Extraction Hardware


“Fast” kicker

- usually an impedance matched strip line, with or without ferrites




“Slow” extraction elements “Lambertson”: usually DC

circulating beam ($B=0$)





Septum: pulsed, but slower than the kicker



 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 

Slow Extraction (not important for colliders)

- Sometimes fixed target experiments want beam delivered *slowly* (difficult)
- To do this, we generate a harmonic resonance
 - Usually sextupoles are used to create a 3rd order resonant instability



Particles will flow out of the stable region along lines in phase space into an electrostatic extraction field, which will deflect them into an extraction Lambertson

- Tune the instability so the escaping beam exactly fills the extraction gap between interceptions (3 times around for 3rd order)
 - Minimum inefficiency $\sim (\text{septum thickness})/(\text{gap size})$
 - Use electrostatic septum made of a plane of wires. Typical parameters
 - Septum thickness: .1 mm
 - Gap: 10 mm
 - Field: 80 kV

 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 13 

Standard Beam Instrumentation


- Bunch/beam intensity are measured using inductive toroids
- Beam position is typically measured with beam position monitors (BPM's), which measure the induced signal on a opposing pickups
- Longitudinal profiles can be measured by introducing a resistor to measure the induced image current on the beam pipe -> Resistive Wall Monitor (RWM)



 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 14 

Beam Instrumentation (cont'd)

- Beam profiles in beam lines can be measured using secondary emission multiwires (MW's)
- Can measure beam profiles in a circulating beam with a “flying wire scanner”, which quickly passes a wire through and measures signal vs time to get profile
- Non-destructive measurements include
 - Ionization profile monitor (IPM): drift electrons or ions generated by beam passing through residual gas
 - Synchrotron light
 - Standard in electron machines
 - Also works in LHC




Beam profiles in MiniBooNE beam line



 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade  15 

Measuring Lattice Parameters


- The fractional tune is measured by Fourier Transforming signals from the BPM's
 - Sometimes need to excite beam with a kicker
- Beta functions can be measured by exciting the beam and looking at distortions
 - Can use kicker or resonant ("AC") dipole
- Can also measure the beta functions indirectly by varying a quad and measuring the tune shift

$$\Delta\nu = \frac{1}{4\pi} \frac{\beta}{f}$$


 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade  16 

Understanding Cross Sections


- The formalism of cross sections was derived for Rutherford scattering, in which a scattered solid angle was mapped to an incident cross sectional area
- It can be generalized to represent the probability of any sort of particle interaction



 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 17 

Thin target approximation

- If the total probability that a particle will interact is small, then the probability of a particular interaction for one incident particle, will be given by



$$\begin{aligned}
 R &= \sigma \times (\text{number of particles per cross-sectional area}) \\
 &= \sigma \rho_n t
 \end{aligned}$$

Target thickness [L]
 Target number density [L^{-3}]

 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 18 

Luminosity

The relationship of the beam to the rate of observed physics processes is given by the "Luminosity"

$$\text{Rate} \rightarrow R = L\sigma$$

Rate
 "Luminosity"
 Cross-section ("physics")

Standard unit for Luminosity is $\text{cm}^{-2}\text{s}^{-1}$
 Standard unit of cross section is "barn" = 10^{-24} cm^2
 Integrated luminosity is usually in barn^{-1} , where

$$\begin{aligned}
 \text{b}^{-1} &= (1 \text{ sec}) \times (10^{24} \text{ cm}^{-2}\text{s}^{-1}) \\
 \text{nb}^{-1} &= 10^9 \text{ b}^{-1}, \text{ fb}^{-1} = 10^{15} \text{ b}^{-1}, \text{ etc}
 \end{aligned}$$

For (thin) fixed target:

$$R = N\rho_n t \sigma \Rightarrow L = N\rho_n t$$


Incident rate
 Target number density
 Target thickness

Example: MiniBooNe primary target:
 $L \approx 10^{37} \text{ cm}^{-2}\text{s}^{-1}$

 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 19 

Colliding Beam Luminosity

Circulating beams typically “bunched” (number of interactions)



$$= \left(\frac{N_1}{A} \right) N_2 \sigma$$

Cross-sectional area of beam

Total Luminosity:

$$L = \left(\frac{N_1 N_2}{A} \right) r_b = \left(\frac{N_1 N_2}{A} \right) n \frac{c}{C}$$

crossing rate Circumference of machine Number of bunches

 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 20 

Luminosity of Colliding Beams

- For equally intense Gaussian beams

$$L = f \frac{N_b^2}{4\pi\sigma^2} R$$



Collision frequency Particles in a bunch Geometrical factor:
- crossing angle
- hourglass effect

- Using $\sigma^2 = \frac{\beta^* \epsilon_N}{\beta \gamma} \approx \frac{\beta^* \epsilon_N}{\gamma}$ we have

$$L = f_{rev} \frac{1}{4\pi} n_b N_b^2 \frac{\gamma}{\beta^* \epsilon_N} R$$

Revolution frequency Number of bunches Particles in bunch Transverse size (RMS) prop. to energy Normalized emittance Betatron function at collision point →
want a small β^* !

Record e+e- Luminosity (KEK-B): $2.11 \times 10^{34} \text{ cm}^{-2}\text{s}^{-1}$
 Record p-pBar Luminosity (Tevatron): $4.06 \times 10^{32} \text{ cm}^{-2}\text{s}^{-1}$
 Record Hadronic Luminosity (LHC): $2.06 \times 10^{34} \text{ cm}^{-2}\text{s}^{-1}$



Orbit correction

- Generally, beam lines or synchrotrons will have beam position monitors (BPM's) and correction dipoles (trims)

- We would like to use the trims to cancel out the effect of beamline imperfections, ie

$$\cancel{\Delta x_i} = \sum A_{ij} \theta_j$$

Cancel displacement at BPM i due to imperfections Setting of trim j

- Can express this as a matrix and invert to solve with standard techniques
 - If $n=m$, can just invert
 - If $n>m$, can minimize RMS

$$\begin{pmatrix} \Delta x_0 \\ \Delta x_1 \\ \vdots \\ \Delta x_n \end{pmatrix} = \begin{pmatrix} A_{00} & A_{01} & \cdots & A_{0m} \\ A_{10} & A_{11} & \cdots & A_{1m} \\ \vdots & \vdots & \ddots & \vdots \\ A_{n0} & A_{n1} & \cdots & A_{nm} \end{pmatrix} \begin{pmatrix} \theta_0 \\ \theta_1 \\ \vdots \\ \theta_m \end{pmatrix}$$

Example: First Beam through LHC (Sept. 10, 2008)

- General procedure
 - Proceed one octant at a time, closing collimators at the next point.


Beam 1 direction

- Measure the deviations from an ideal orbit, and calculate corrections
- Might need to iterate a few times

 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade  25 

Beam Collimation and Machine Protection

- As beams get more intense, machine protection becomes very important
 - Full LHC energy ~ 150 sticks of dynamite!
- Beam halo is generally cleaned up through multi-stage collimation



Without beam cleaning (collimators):
Quasi immediate **quench of superconducting magnets** (for higher intensities) and stop of physics.
Required **very good cleaning efficiency**

R. Assmann

 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade  26 


Secondary Beams

- When a proton beam strikes a target, the energy of the beam goes into particle production. Charged particles include (in ~descending order of population)
 - π^\pm : Most of the energy
 - K^\pm : Charged particles containing a Strange quark
 - p : ordinary protons
 - e^\pm : These mostly come from neutral pions that immediately decay to two photons.
 - Antiprotons:
 - Other strange "hyperons"
- When an electron beam strikes a target, it makes mostly photons and e^\pm
 - Positron production targets can be very efficient.
- Generally, we design secondary beam lines to maximize acceptance of the species of beam we're looking for.



Special Case: Neutrino Beams

- Electron neutrinos are generally produced in nuclear reactors. High energy particle beams are used to produce primarily muon neutrinos in the reactions




- Select correct neutrino species by focusing correct pion species





Neutrino Horns

- Neutrino horns work by producing an coaxial current so the correct sign pions are focused in *both* planes.



- This is the to decay





 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 

Antiproton Beams

- Antiprotons are produced in very small numbers in proton collisions.
- In order to be useful, these must be captured and “cooled” (i.e. have their area in phase space reduced).
- Although high energy proton-antiproton colliders are a thing of the past (homework problem), anti-protons are still of great interest at low energy:
 - CERN LEAR facility
 - FAIR Facility in Germany.

 USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 

Highest Intensity Antiproton Source: Fermilab (decommissioned)

- 120 GeV protons strike a **target**, producing many things, including antiprotons.
- a **Lithium lens** focuses these particles (a bit)
- a bend magnet selects the negative particles around 8 GeV. Everything but antiprotons decays away.
- The antiproton ring consists of 2 parts
 - the Debuncher
 - the Accumulator.

USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 33

Antiproton Source – debunching

Particles enter with a *narrow* time spread and *broad* energy spread.

High (low) energy pbars take more (less) to go around...

...and the RF is phased so they are decelerated (accelerated), resulting in a *narrow* energy spread and *broad* time spread.

At this point, the pBars are transferred to the accumulator, where they are “stacked”

USPAS Fundamentals, June 4-15, 2018 E. Prebys, Accelerator Fundamentals: Tricks of the Trade 34

Stochastic cooling of antiprotons

- Positrons will naturally “cool” (approach a small equilibrium emittance) via synchrotron radiation.
- Antiprotons must rely on active cooling to be useful in colliders.
- Principle: consider a single particle which is off orbit. We can detect its deviation at one point, and correct it at another:
- But wait! If we apply this technique to an ensemble of particles, won’t it just act on the centroid of the distribution? Yes, but...
- Stochastic cooling relies on “mixing”, the fact that particles of different momenta will slip in time and the sampled combinations will change.
- Statistically*, the mean displacement will be dominated by the high amplitude particles and over time the distribution will cool.
- Simon Van der Meer won the Nobel Prize for this.