

INDEX

Numbers

- 0 W resistors, 96–97
- 1 dB compression point (P_{1dB}), 73
- 3D modeling, CAD tools with support
 - for, 104–105, 140, 155
- 90-degree turns, 119–120
- 100 percent electrical tests, 258, 266
- 360-degree shielding, 48

A

- accelerated stress testing (aka highly accelerated life testing [HALT]; burn-in), 273–274
- acrylic conformal coating, 255
- active components
 - advertised vs. actual performance, 65–66
 - batteries, 77–79
 - diodes, 76–77
 - microcontrollers, 70–71
 - oscillators and crystals, 66–67
 - performance of, 65–66
 - power supplies, 67–69
 - RF components, 72–74
 - transistors, 74–76
- active pads (plugged vias), 133
- active parts, 23
- activity dips, 66
- Adafruit, 66, 197
- ADCs, 67, 109, 166
- AdvancedPCB, 144, 240, 302
- affirming the consequent fallacy, 292
- Agans, David, 286
- air compressors, 215, 247, 257
- alkaline batteries, 79
- alpha ionizers, 257
- Altium, 91, 141
- AMC connectors, 50, 52
- America Invents Act, 203
- American National Standards Institute (ANSI), 84
- American Society of Mechanical Engineers (ASME), 84
- amplifiers, 72–74
 - ensuring performance in, 101
 - gain in, 72–73
 - oscillation in, 101
 - testing, 279
- Amscope, 213
- analogies, using in demos, 297
- analog oscilloscopes, 221
- analog spectrum analyzers, 222
- antistatic bags, 217, 231
- antistatic floor mats and carpet, 211
- antistatic wrap, 24
- Aoyagi, 302
- approval marks, 263–264
- APROE, 305
- aqueous (water-soluble) flux, 244
- archival ink, 203
- Arduino, 145, 199–200
- arrays, 20, 178–179
- Arrow, 230
- articulated-arm microscopes, 213
- AS9100C/D certification, 235
- ASME (American Society of Mechanical Engineers), 84
- assemblers, 228, 241
- assembly. *See also* soldering
 - cost reduction in, 182–183
 - design for, 152–159
 - cables and connectors, 157–159
 - enclosures, 156–157
 - fiducials, 153–154
 - markings to aid assembly, 154–155
 - soldering considerations, 155–156
 - fabrication notes, 310
 - prototypes, 195–196
 - system integration, 258–259

- assembly (*continued*)
 - tips for, 251–258
 - cleaning and storage, 256–257
 - conformal coatings and potting materials, 254–256
 - documentation, 252–253
 - inspection and testing, 257–258
 - tools, 253–254
 - workings of, 241
- assembly panels, 149
- assumptions, questioning, 196
- atomic requirement, 5
- audience, giving demos to
 - connecting with, 297
 - knowing, 295–296
 - tips for, 298–299
- automated test equipment (ATE), 15.
 - See also* testing
- automotive-rated components, 18
- autorouters, 140
- avalanche breakdown (shoot through), 283

B

- backdrilled vias, 131–132
- back pressure, 94
- backups for demos, 298
- bad-board markers, 112
- baking out, 25, 257
- ball grid array (BGA) components and packages, 20, 88, 134, 266
- banana jacks, 221
- Bantam Tools Desktop PCB Milling Machine, 194, 239
- batch-mode design rule checks, 141
- bathtub curve, 262
- batteries
 - alkaline, 79
 - certification of, 266
 - choosing, 77
 - lead acid, 79
 - lithium, 78–79, 266
 - primary and secondary, 77
 - in schematic design, 93–94
- bed-of-nails jigs, 111, 160, 178, 268
- “BGA Crosstalk” (Johnson), 20
- bills of materials (BOMs), 21, 95, 182, 230–231
- bit flipping, 60
- black pad problem, 163
- bladeRF, 201
- blind vias, 131–132, 135, 179–180
- BNC connectors, 49, 221
- board preheaters, 212
- Bogatin, Eric, 99
- BOMs (bills of materials), 21, 95, 182, 230–231
- breadboards, 198–199
- breakaway tabs (mouse bites), 151
- breakout, preventing when drilling, 133
- breakout boards, 197–198
- BRIDG, 305
- bring-up process, 267–268
- Brooks, Douglas, 117
- Building Electro-Optical Systems* (Hobbs), 198
- buried vias, 131–132, 179
- burn-in testing (aka highly accelerated life testing [HALT]; accelerated stress testing), 273–274
- bus factor, 202–203
- buying parts, 230–232

C

- cables, 44–45. *See also* connectors
 - coaxial, 47, 49
 - design for assembly, 157–159
 - EMC and, 171
 - environmentally rated, 50
 - flat flex, 46
 - impedance-controlled, 49
 - interference and noise, 47–48
 - RF, 48–50, 222
 - safety considerations, 50–51
 - shielded, 48
 - for testing, 278–279
 - VNAs and, 224
- Cain, Jeffrey, 35
- can shields, 172–173
- capacitance vs. frequency, 33–35
- capacitors, 27–28. *See also* multilayer
 - ceramic capacitors
 - AC line filter, 170
 - aluminum electrolytic, 28, 31
 - applications for by type, 28
 - bypass, 99–100, 108, 167, 172

- ceramic, 28–31
 - C0G, 29
 - NP0, 29
- common values, 36–37
- controlled-ESR, 34–35
- decoupling, 18, 28, 99
- derating, 29–30
- electric double-layer, 32
- electrolytic caps, 28, 31
- fail-safe, 37–38
- feedthrough, 55
- film, 28, 31–32
- flexible termination, 38
- GJM, 35
- high-frequency signals, 35
- for ICs, 99
- insertion loss, 35
- low-ESR, 33–34
- parasitic inductance, 35–36
- polarized, 88–89
- polymer aluminum electrolytic, 31
- shunt, 66
- supercapacitors, 32
- tantalum, 32–33, 37
 - fail-open, 37
 - fused, 37
 - three-terminal, 55
- cap lamination, 124
- card edge connectors, 45
- cause and effect in troubleshooting, 289–291
- CE (Conformité Européenne), 15, 263
- center drill hits, 133
- certifications, 234–237
- charged-device model, 274–275
- chassis ground, 56–57
- cheating, 194
- China
 - manufacturing in, 12–13, 232–233
 - procuring parts from, 12–13, 22
- chip fabrication companies, 305
- chip-on-board method, 183
- circuit dots, 253
- CircuitHub, 182, 231–232, 302
- circuit mills, 11, 130, 156, 194, 239
- circuit protection, 55–62, 93
 - filters for EMI, 55–57
 - fuses for overcurrent events, 60–62
 - galvanic isolation, 62
 - overvoltage events, 57–59
 - reverse bias protection, 62
 - silicon-controlled rectifier latch-up, 59–60
- circuit tape, 253
- cleaning process, 256–257
- clearance distance, 112
- climax of demos, 297
- clock buffers, 98
- CMS. *See* contract manufacturers
- coaxial cables, 47, 49
- coexistence, 117
- Cognition IP, 304
- COGS (cost of goods sold), 175, 182
- comments in parts orders, 231
- communicating effectively in demos, 297
- “Comparison of Multilayer Ceramic and Tantalum Capacitors” (Cain), 35
- comparisons in demos, 299
- complete requirement, 5
- component-less programming headers, 178
- component prefixes, 84–85
- components. *See also* active components; passive components
 - choosing, 18–21
 - distributors, 305
 - purchasing, 21–26
 - determining quantity, 25–26
 - distribution of parts, 23–25
 - selecting distributors, 21–23
 - storing, 215–216
 - testers, 219
- compressed-time testing, 273
- concise requirement, 5
- condensing humidity testing, 275
- conformal coatings, 254–256
- Conformité Européenne (CE), 15, 263
- connector position assurance (CPA), 46
- connectors, 44–45
 - AMC, 50, 52
 - BNC, 49, 221
 - card edge, 45
 - crimped, 52–54
 - design for assembly, 157–159
 - edge-mount, 46

- connectors (*continued*)
 - EMC and, 171
 - IPAX, 52
 - IPEX, 52
 - IPX, 52
 - keyed, 46
 - MCX, 51
 - MHF, 52
 - MMCX, 51
 - Murata Microwave Coaxial, 160
 - naming confusion, 51–52
 - reducing costs, 178
 - requirements for, 45–47
 - RF, 160, 253
 - RP-SMA, 51
 - safety considerations, 50–51
 - in schematics, 88, 94
 - SMA, 46, 49, 51
 - through-hole, 162
 - U.FL, 51–52
 - UMCC, 52
- consistent requirement, 5
- containing fields, 167
- contaminant-related failures, 283
- contract manufacturers (CMs), 228
 - finding and working with, 232–233
 - list of, 302–303
 - prototyping, 14–15
 - respecting, 234
 - standards and certifications, 234–237
- Conway's Law, 189
- coplanar waveguide (CPW)
 - transmission lines, 129–130
- copper
 - fabrication notes, 309
 - thieving, 148
 - weights and thickness, 125, 128
- copper “coins,” 137
- copper-filled microvias, 131
- copper tape, 253–254
- core substrate, 123
- correct requirement, 5
- cost engineering, 175–183
 - in assembly, 182–183
 - in layout, 179–181
 - overall strategy for, 175–177
 - in schematics, 177–179
- cost of goods sold (COGS), 175, 182
- counterfeit parts, 22
- coupled line couplers, 160
- courtyard, 155
- CPA (connector position assurance), 46
- CPW (coplanar waveguide)
 - transmission lines, 129–130
- C rating, 77
- creepage distance, 112
- crimped connectors, 52–54
- Crimptools website, 53
- crosstalk
 - BGA components, 20
 - feedback resistors, 108
 - fields between PCB layers, 106, 172
 - grouping parts by function, 104
 - high-speed design, 117
 - series termination, 114
 - stripline transmission lines, 130
 - twisted pairs, 48
- crystal oscillators, 66–67, 98, 179
- current-sense resistors, 38–39, 96
- cut tape, 23–24
 - storing, 216
- cylindrical cells, 78

D

- DACs, 67
- Data Conversion Handbook, The* (Analog Devices), 67
- datasheets
 - consulting latest, 92
 - contents of, 18
- DC/DC converters, 67–69
- DCL, 306
- debouncing, 94–95
- debugging, 95–97, 286
- Debugging* (Agans), 286
- declaration of conformity (DOC), 264
- delays, anticipating, 12–13
- demo equipment, 218
- demos, giving, 295–299
 - backups for, 298
 - knowing audience, 295–296
 - storytelling, 296–297
 - tips for, 298–299
- depanelization, 149, 151

- derating
 - capacitors, 29–30
 - connector current, 45–46
 - inductors, 41
 - microcontrollers, 71
 - resistors, 39
 - de-risking designs, 11–12
 - design for excellence (DFx)
 - design for assembly, 152–159
 - cables and connectors, 157–159
 - enclosures, 156–157
 - fiducials, 153–154
 - markings to aid assembly, 154–155
 - soldering considerations, 155–156
 - design for fabrication, 143–152
 - copper thieving, 148
 - fabricator constraints, 144–145
 - panelization, 149–152
 - PCB markings, 145–148
 - design for reliability, 161–163
 - design for test, 159–160
 - design rule checks (DRCs), 141
 - design services companies, 305
 - design validation testing (DVT), 15
 - Developing Safety-Critical Software* (Rierson), 5
 - development boards
 - damaging, 201
 - for microcontrollers, 70
 - in prototyping, 195
 - in schematic design, 94
 - DFR (reliability, design for), 161–163
 - DFx. *See* design for excellence
 - diagonal cutters, 225
 - differential diagnosis, 287
 - differential pairs, 168–170
 - ENIG plating, 118
 - naming conventions, 91
 - twisting wires together, 48
 - DigiKey, 21–22, 24, 216, 230–231, 305
 - digital lines, terminating, 114
 - diodes, 76–77
 - ESD, 57, 179
 - flyback, 58, 93
 - marking polarity of, 146
 - Schottky, 76
 - steering, 57
 - transient voltage suppressor, 58
 - Zener, 76–77
 - discharge rate, 77
 - dispenser regulator, 215
 - dissipation factor (loss tangent), 122
 - distributed length, 47–48
 - distribution of parts, 23–25
 - distributors, selecting, 21–23
 - DOC (declaration of conformity), 264
 - documentation
 - for assembly, 252–253
 - for troubleshooting, 286
 - Dodd, Tim, 188–189
 - Dodd-Frank Conflict Minerals Statement, 236
 - DOD-STD-100 standard, 234
 - DPS adjustable power supply modules, 219
 - drain-to-source resistance, 75–76
 - DRCs (design rule checks), 141
 - drilled buried vias, 132
 - drill files, 229
 - Drip Capital, 304
 - drivers, 75
 - dropped parts, 25–26
 - dry boxes, 25, 256
 - DVT (design validation testing), 15
- ## E
- Economics of Software Quality, The* (Jones), 7
 - EDA software, 84–85, 90–92, 140
 - edge-mount connectors, 46
 - Einstein, Albert, 293
 - Elecfans, 19
 - electrical overstress (EOS), 283
 - electrical rule checks (ERCs), 85, 92, 228
 - electroless nickel, electroless
 - palladium, immersion gold (ENEPIG) plating, 163
 - electroless nickel/immersion gold (ENIG) plating, 117–118, 162–163
 - electromagnetic compatibility (EMC), 264–266
 - application note design discrepancies, 94
 - capacitors for ICs, 99
 - connectors and cables, 45

- electromagnetic compatibility (*continued*)
 - ferrite beads, 100
 - field probes, 285
 - filters, 55–56
 - ground planes, 107–108
 - prototyping platform boards, 199
 - switched-mode power supplies, 42
 - electromagnetic emissions, 264
 - reducing, 165–168
 - electromagnetic immunity, 165, 264
 - electromagnetic interference (EMI)
 - application note design
 - discrepancies, 94
 - capacitors for ICs, 99
 - connectors and cables, 45, 47, 171
 - copper tape, 253–254
 - ferrite beads, 100
 - field probes, 223, 285
 - filters, 55–57
 - galvanic isolation, 62
 - ground planes, 107, 110
 - high-speed design, 113–114, 120
 - PCB layer count, 180
 - physical isolation, 170
 - prototyping platform boards, 199
 - reducing electromagnetic emissions,
 - 167–168
 - shielding, 172
 - silicon oscillators, 67
 - switched-mode power supplies, 42
 - voltage conversion, 69
 - electromagnetic susceptibility, 264
 - electronics failure, causes of, 282–283
 - electrostatic discharge (ESD)
 - alpha ionizers, 257
 - bags, 24, 257
 - chassis ground, 56
 - diodes, 57, 179
 - dry boxes, 25, 256
 - load switches, 98, 179
 - mats, 211
 - models, 57
 - overvoltage events, 57–59
 - resistors, 38
 - SCR latch-up, 59
 - testing, 274–275
 - E-Make, 303
 - EMC. *See* electromagnetic compatibility
 - EMI. *See* electromagnetic interference
 - enclosures, 156–157
 - end of life (EOL), 16
 - parts marked as, 23
 - testing and, 262–263
 - ENEPIG (electroless nickel, electroless palladium, immersion gold)
 - plating, 163
 - engineering models, 15, 251, 265
 - engineering validation testing (EVT), 15
 - ENIG (electroless nickel/immersion gold) plating, 117–118, 162–163
 - Enzyme, 304
 - EOS (electrical overstress), 283
 - epoxy conformal coating, 255
 - equivalent series inductance (ESL), 31, 35
 - equivalent series resistance (ESR), 31,
 - 33–35, 43–44
 - ERCs (electrical rule checks), 85, 92, 228
 - errors in layout design, 140–142.
 - See also* troubleshooting
 - DRC checks, 141
 - footprint mistakes, 88, 141–142
 - escape routing (fan-out), 20
 - ESD. *See* electrostatic discharge
 - E series, 36–37
 - Estonian Center for Standardization
 - and Accreditation, 263
 - etching
 - under-etching, 126–127, 238
 - microstrip, 130
 - over-etching, 238
 - PCB fabrication, 237–238
 - etiology, 288
 - Eureka, 203
 - Eurocircuits, 240
 - eutectic mix, 245
 - evaluation boards, 66, 195, 197–198
 - Evermuch, 302
 - EVT (engineering validation testing), 15
 - expected lifetime, 262, 273
- ## F
- fabrication, 227–259 . *See also* fabricators
 - buying parts, 230–232
 - contract manufacturers, 232–237
 - respecting, 234
 - standards and certifications, 234–237

- design for, 143–152
 - copper thieving, 148
 - fabricator constraints, 144–145
 - panelization, 149–152
 - PCB markings, 145–148
- etching, 237–238
- milling, 239, 310
- notes, 307–310
- preparing for, 228–230
- quotes for, 228
- fabricators, 228
 - constraints, 144–145
 - hiring, 239–240
- failure mode, 18, 78, 288
- failure points, 273–274
- fan-out (escape routing), 20
- fans, 138, 213–214, 251
 - sinks, 138
- Fast Circuit Boards* (Morrison), 107
- fast edges, 40, 45, 167–168, 171
- fastener sets, 217
- feature creep, 6, 8
- Federal Communications Commission (FCC), 15, 165–166, 264–266
- feedback, successful designs and, 8–10, 104–105, 189, 191
- feedback resistors, 108
- ferrite beads, 42–44, 168
 - current effects, 44
 - ensuring performance using, 99–100
 - power ratings vs. signal ratings, 43–44
 - temperature effects, 44
- FFCs (flat flex connectors and cables), 46, 158–159
- fiber weave effect, 169–170
- Fictiv, 234, 303
- fiducials, 153–154
- field application engineers, 19
- FieldFox, 222
- field probes, 130, 223, 285
- Findchips, 21
- fingers as troubleshooting tools, 284
- finishes, 117–118, 162–163
- fires, 77–78, 205, 210
- firmware
 - cost engineering, 176, 178, 181
 - EMC testing, 265
 - error detection and response, 168
 - installed by manufacturer, 231–232
 - troubleshooting, 285
- first shots, 15
- Fitzpatrick, Rob, 8
- flammables cabinets, 210–211
- flat cells, 78
- flat flex connectors and cables (FFCs), 46, 158–159
- flat sheets, 91
- flexing PCBs, 38, 108, 152, 289
- Flexport, 304
- Floship, 306
- Flowspace, 304
- Fluke multimeters, 219
- flux, 42, 243–245. *See also* soldering
- flyback diodes, 58, 93
- Focus Manufacturing, 303
- foil lamination, 123
- footprint mistakes, 88, 141–142
- Ford, Henry, 8
- formatting of schematics, 90–92
- Fourier decomposition, 168
- FR-4 substrates, 121–122
 - electromagnetic waves in, 113
 - fabricators using, 240
 - reflow on, 249
 - in stackups, 125
- FreeDFM, 144
- frequency response plots, 43
- frequency vs. capacitance, 33–35
- fudging in demos, 298
- fulfillment companies, 306
- Fulfillrite, 306
- fume extractors, 210, 213, 251
- furniture for labs, 211
- fuses
 - fast-blow, 60
 - holders, 61
 - melting point of, 61
 - for overcurrent events, 60–62
 - resettable, 61
 - slow-blow, 60–61
 - troubleshooting, 292
- Fusion PCB, 302

G

- gain
 - advertised vs. actual performance, 65, 72
 - amplifiers, 72–73
- galvanic isolation, 62, 166
- GaN FETs, 75
- gap pads, 139
- gas discharge tubes (GDTs), 59
- gas gauges, 77
- gate capacitance, 74
- gate charge curves, 75
- Gener8, 303
- general-purpose input/output (GPIO) pins
 - cost reduction, 177
 - driver ICs, 75
 - firmware to check for presence of, 181
 - LEDs, 76, 96
 - logic levels, 92
 - oscillators, 179
 - Raspberry Pi, 200–201
 - special function assignments, 92
- Gerber files, 73, 140, 144, 229–230
- gerbv, 140, 230
- GNU Radio, 202
- Google Docs, 203
- Gorilla Circuits, 240, 302
- GrabCad, 301
- Graham, Paul, 11
- graphite pads, 138–139
- grid printing technique, 247–248
- ground planes
 - current flow, 107
 - electromagnetic emissions, 166–167
 - in layout design, 108
 - separating analog and digital, 109–110
- ground vias, 108, 115, 117, 169
- Guidelines for Oscillator Design on STM8AF/AL/S and STM32 MCUs/MPUs* (ST Microelectronics), 66

H

- HackRF, 201
- Hakko, 212
- half digits in multimeter displays, 219
- handheld spectrum analyzers, 222

- handheld VNAs, 223
- hardware
 - speeding up development, 193–197
 - troubleshooting, 285
- Hardware Attached on Top (HATs) for Raspberry Pi, 200
- HASL (hot-air solder leveling), 163
- hazardous materials, 7
- headers in fabrication notes, 307
- heat pipes, 139
- heat sinks, 39, 98, 138–139
- helium gas, 67
- hero's journey, 296–297
- high-density interconnect (HDI) PCBs, 20, 179, 200
- high-frequency signals, 35, 171, 253
- highly accelerated life testing (HALT;
aka accelerated stress testing;
burn-in), 273–274
- highly integrated chips, 196
- high-performance fabricators, 240
- high-power resistors, 39
- high-speed design, 112–121
 - impedance matching, 113–115
 - problems to avoid, 117–119
 - signal measurement, 115–117
 - turns in traces, 119–121
- high-tolerance parts, 41, 178, 258
- Hill, Austin Bradford, 290
- Hirose, 51–52
- Hobbs, Philip C., 198
- hot-air irons, 212–213, 248
- hot-air rework stations, 212, 248–249
- hot-air solder leveling (HASL), 163
- hot-bar soldering (thermodes), 45, 178
- HP, 222–223
- Huang, Andrew “bunny,” 268–269
- human-body model, 274
- humidity testing, 275–278

I

- P_t (melting point), 61
- IEC standards, 51, 112
 - IEC 60320, 7
 - IEC 60529, 278
 - IEC 60721-3, 270
 - IEC 61000-4-2, 58
- immunity testing, 265–266

- impedance
 - fabrication notes, 309
 - impedance-controlled cables, 49
 - matching in high-speed design, 113–115
- implementation-free requirement, 5
- ImportGenius, 304
- inductance
 - equivalent series, 31, 35
 - parasitic, 35–36, 106
- inductors, 41–42
 - high-frequency applications, 42
 - placing, 108
 - in switched-mode power supplies, 42
- industrial design, 4, 192, 234
- infrared reflow ovens, 249–250
- ingress protection (IP) certification, 277
- inherited hardware and components, 18–19
- insertion loss, 72
 - capacitors, 35
 - connectors and cables, 160, 279
 - filters, 56
 - finishes, 117–118
 - substrates, 123
- inspection microscopes, 213
- inspections, 161, 257–258
- Instrumental, 269
- integrated circuit derating, 71
- intellectual property (IP) protection, 193
- interference, 47–48, 263. *See also*
 - electromagnetic interference
- International Traffic in Arms Regulations (ITAR), 236
- interviewing users, 8–9
- inventory management software, 217
- investors, 232, 299
- iPad Pro, 203
- IPC standards, 84, 123, 234–235, 252, 276
- irons, soldering, 212–213, 242–243, 248
- ISO standards, 235, 241
- ITAR (International Traffic in Arms Regulations), 236
- iteration time, 11, 193–194

J

- JBC, 212
- JEDEC, 142, 236, 249, 257

- jellybean components, 27.
 - See also* passive components
- Jet Propulsion Lab, 262
- JLCPCB, 240
- Johanson, 35
- Johnson, Howard, 20
- Jones, Capers, 7
- jumpers, 41, 177, 198–199, 267
- JunYi Metal and Plastic, 303

K

- Kapton, 247, 253
- Keysight ADS, 114, 160, 217–220, 222–223
- Keystone, 111, 177
- k-factor, 73
- knockouts, 152
- Koch's postulates, 288
- Kyocera, 177

L

- labeling
 - conventions for, 84–89
 - PCBs, 145–146
- lab notebooks, 202–208
 - content to include, 203–208
 - maintaining, 202–203
 - options for, 203
 - page example, 206–207
 - for troubleshooting, 291
- labs, 209–226
 - furniture, 211
 - safety, 209–210
 - small hand tools, 224–225
 - soldering equipment, 212–213
 - storage options, 215–217
 - test equipment, 217–224
 - logic analyzers, 221
 - multimeters, 219–220
 - oscilloscopes, 220–221
 - power supplies, 219
 - spectrum analyzers, 222–223
 - test leads, 221–222
 - vector network analyzers, 223–224
- lamination cycle, 131–132
- laser-drilled vias, 132–133
- layers in stackup design, 121

- layout design, 103
 - common gotchas, 140–142
 - cost reduction in, 179–181
 - creepage and clearance
 - requirements, 112
 - high-speed design, 112–121
 - impedance matching, 113–115
 - problems to avoid, 117–119
 - signal measurement, 115–117
 - turns in traces, 119–121
 - keys to success in, 103–105
 - PCB physics, 106–107
 - stackup design, 121–135
 - example, 134–135
 - layers, 121
 - substrates, 121–125
 - traces, 125–130
 - vias, 130–134
 - testing, 110–112
 - thermal management, 135–140
 - tips for, 108–110
- layout designers, 194–195
- LDOs. *See* low drop-out regulators
- lead
 - contamination, 251
 - exposure, 210
 - lead acid batteries, 79
 - lead solder, 245
 - lead-free requirements, 7
 - lead-free solder, 245
- LEDs, 76, 96
- Leuchtturm1917, 203
- light-curable materials (LCMs), 256
- lightning strikes, 59
- LimeSDR, 201
- LineCalc, 168, 171
- line cards, 22
- line items, 177
- link budgets, 93
- Linux, 200
- liquid ingress numbers, 277
- lithium batteries, 78–79, 266
- load switches, 98, 179
- Loctite UF 3810, 20
- logic analyzers, 221
- logic levels, 40, 92
- looks-like prototypes, 14, 191, 195

- loops and electromagnetic
 - emissions, 166
- loss tangent (dissipation factor), 122
- low-dropout regulators (LDOs)
 - ESR requirement, 35
 - in power supplies, 69
 - in schematic design, 93–94
- low-temperature solder pastes, 245
- LPKF mills, 194, 239
- LTspice, 68, 100
- lumped length, 47–48

M

- machine model, 274
- MacroFab, 302
- Manhattan-style routing, 119
- Mantis microscopes, 213
- manufacturing process, 13–16
 - automated test equipment, 15
 - design validation testing, 15
 - engineering validation testing, 15
 - looks-like and works-like prototypes, 14
 - mass production, 16
 - product development life cycle, 13–14
 - production validation testing, 15–16
 - support, 16
 - tooling, 15
- mapping pins, 88
- markings, 145–148, 154–155
- mass production, 16
- materials, 7
 - fabrication notes, 308
 - suppliers, 304
- maximum ratings, 98–99
- McMaster-Carr, 304
- mean time between failure (MTBF), 273
- mean time to failure (MTTF), 273
- measuring signals in high-speed design, 119–121
- mechanical engineers, 183
- mechanical fasteners, 26
- mechanical wear, 283
- medical device approval, 266
- medical model for troubleshooting, 287–293
 - cause and effect, 289–291
 - narrative-based, 291

- scientific, 292–293
- signs, symptoms, etiology, 288–289
- melting point (T_m), 61
- Memfault, 301
- Mentor Graphics, 141
- Merifix, 268
- metal-core PCBs (MCPCBs), 137
- metal–oxide–semiconductor field-effect transistors (MOSFETs), 74–75
- Metcal, 212
- Microchip, 231
- MicroConnex, 303
- microcontrollers, 70–71
- microdrills, 224
- microscopes, 213
- microstrip transmission lines, 129–130
- microvias, 131
- milling, 239, 310
- Millman, Matt, 54
- MIL-PRF standards, 236
- mil-spec, 18
- mindset for prototyping, 188–190
- Mini-Circuits, 201
- minimum annular ring size, 132–133
- minimum viable product (MVP), 190–193
- MLCCs. *See* multilayer ceramic capacitors
- MLO Crossover jumpers, 177
- Model Solution, 305
- modules, 195, 197–198
- moisture sensitivity level (MSL), 24–25
- Moleskine, 203
- Molex, 53
- Mom Test, The* (Fitzpatrick), 8–9
- MOSFETs (metal–oxide–semiconductor field-effect transistors), 74–75
- mouse bites (breakaway tabs), 151
- Mouser, 24, 230, 305
- MSP430 chips, 60, 199
- MTBF (mean time between failure), 273
- MTTF (mean time to failure), 273
- multilayer ceramic capacitors (MLCCs), 28–31
 - cracking, 37
 - floating-electrode, 37
 - open-mode, 37
 - placing, 151

- multimeters, 219–220
- multipole EMI filters, 55–56
- Murata, 35
- Musk, Elon, 188–189
- MVP (minimum viable product), 190–193

N

- NanoVNA, 223
- narrative-based troubleshooting, 291
- National, 203
- near-field probes, 223
- necessary requirement, 5
- needle probes, 225
- nets, naming, 91–92
- Newark/Farnell, 230
- no-clean flux, 244
- noncondensing humidity testing, 275
- nose as troubleshooting tool, 284
- Notion, 203
- not recommended for new designs (NRND), 23
- Nvidia Jetson, 201
- NXP, 201

O

- obsolete parts, 23
- Octopart, 21, 182, 301
- OEMsTrade, 21
- Omnifixo, 214–215
- online-mode design rule checks, 141
- organic solderability preserve (OSP), 163
- organization, conventions for, 84–89
- oscillation in amplifiers, 101
- oscillators, 66–67
 - crystal, 66–67, 98, 179
 - reducing cost of, 179
 - silicon, 67
 - using resistor to reduce Q of, 100
- oscilloscopes, 220–221
- OSH Park, 239–240, 302
- OSH Stencils, 302
- outdoor wireless routers, 290–291
- overcurrent protection controllers, 61–62
- over-etching in PCBs, 238
- overnight shipping, 194

overvoltage clamps, 61–62

overvoltage events, 57–59

P

P_{1dB} (1 dB compression point), 73

packaging of components, 19–21

pads, 133, 138–139, 309

testing, 160

panelization, 149–152, 180

paperwork, resources for, 304

parallelizing development process, 189

parasitic capacitance, 106

parasitic inductance, 35–36, 106

parts. *See* active components;

components; passive components

parylene conformal coating, 255

passive components, 27–63

capacitors, 27–38

aluminum electrolytic, 28, 31

capacitance vs. frequency, 33–35

common values, 36–37

fail-safe, 37–38

film, 28, 31–32

high-frequency signals, 35

MLCCs, 28–31

parasitic inductance, 35–36

supercapacitors, 32

tantalum, 32–33, 37

circuit protection, 55–62

filters for EMI, 55–56

fuses for overcurrent events, 60–62

galvanic isolation, 62

overvoltage events, 57–59

reverse bias protection, 62

silicon-controlled rectifier latch-up, 59–60

connectors and cables, 44–54

connector requirements, 45–47

crimped connectors, 52–54

interference and noise, 47–48

naming confusion, 51–52

RF connectors and cables, 48–50

safety considerations, 50–51

ferrite beads, 42–44

inductors, 41–42

resistors, 38–41

common values, 40–41

current-sense, 39

ESD damage, 38

high-power, 39

temperature effects, 38–39

tolerance, 38

as voltage dividers, 39–40

sizing, 19

paste-in-hole technique, 247

PCB Arts, 250

PCBs (printed circuit boards)

design engineers, 194–195

fabrication, 237–240

etching, 237–238

fabricators, 105, 239–240, 302

milling, 239

preparing for, 228–230

flexing, 38, 108, 152, 289

functionality tests, 266–269

board bring-up, 267–268

test fixtures, 268–269

homemade, 237

layer count, 180

markings, 145–148

physics, 106–107

substrates, 180

pcbshopper, 228

PCBWay, 240

PDN (power distribution network)

design, 35

perforated tabs, 152

permittivity of materials, 47–48

petri dishes, 217

philosophy of testing, 261–262

pick-and-place machines, 24, 153

pi networks, 115

pins

crimping, 52–53

exposed, 21

GPIO, 92, 201

marking, 154

pogo, 268

“power good,” 69

in schematics, 86–88

soldering, 156

subsymbols for, 85

unused, 94

Pirsig, Robert, 202

pitch of BGAs, 20

PlatformIO, 71

- plugged vias (active pads), 133
- pogo pins, 268
- polarity, 93, 95
- polarized capacitor symbols, 88
- polyimide tape, 253
- polymer ESD devices, 57
- Pomona leads, 221
- popcorning, 256
- positive temperature coefficient (PTC)
 - resettable fuses, 61
- potting materials, 139, 254–256
- power budgets, 93
- power consumption, measuring, 96
- power dissipation, 98
- power distribution network (PDN)
 - design, 35
- “power good” pins, 69
- power planes, 171–172
- PowerPoint presentations, 252
- power ratings vs. signal ratings, 43–44
- power supplies, 67–69, 219
 - choosing, 67
 - low-dropout regulators, 69
 - thermal shutdown, 69
 - voltage conversion, 67–69
- power supply rejection ratio (PSRR), 69
- prepreg (pre-impregnated)
 - material, 123
- prescan tests, 264
- price breaks for volume, 176
- primary batteries, 77
- Principles of Power Integrity for PDN Design, Simplified* (Bogatin and Smith), 99
- printed circuit boards. *See* PCBs
- probes
 - field, 130, 223, 285
 - near-field, 223
 - needle, 225
- processing in fabrication notes, 308
- process value, 123
- procuring parts, 21–26
 - determining quantity, 25–26
 - distribution of parts, 23–25
 - selecting distributors, 21–23
- product development life cycle, 13–14
- production validation testing (PVT), 15–16
- product life cycle, 7

- product risk, 189
- promoters in troubleshooting, 289
- propagation time, 112
- Protolabs, 303
- prototyping, 187–208
 - maintaining lab notebook, 202–208
 - content to include, 203–208
 - notebook options, 203
 - mindset, 188–190
 - minimum viable product, 190–193
 - platforms, 199–201
 - speeding up hardware development, 193–197
 - tools, 11–12, 197–202
- PSRR (power supply rejection ratio), 69
- PTC (positive temperature coefficient)
 - resettable fuses, 61
- pull-up resistors, 92–93
- “pulse withstanding” resistors, 39
- purpose-built tools, 195
- PVT (production validation testing), 15–16

Q

- quad-flat no-leads (QFN), 21, 156
- Quality Crimping Handbook* (Molex), 53
- quality factor (Q), 29
- quantity of parts to purchase, 25–26
- questions in demos, 299
- quotes for fabrication, 228

R

- race conditions, 94
- radiation-hardened (rad-hard)
 - chips, 60
- Radicand, 305
- radio frequency components.
 - See* RF components
- raking, 243
- Raspberry Pi, 200–201
- rate of production, 12
- ratings, 18
- REACH, 236
- README files, 229
- reels, 216
- refining prototype, 192
- reflow, 247–251
- reflow ovens, 249–250

- regulatory requirements for
 - electromagnetic compatibility and immunity, 165–173
- connectors, 171
- differential pairs, 168–170
- power planes, 171–172
- reducing electromagnetic emissions, 166–168
- shielding, 172–173
- signal integrity, 170–171
- regulatory testing, 263–266
 - approval marks, 263–264
 - battery certification, 266
 - electromagnetic compatibility, 264–266
 - medical device approval, 266
- relative permittivity, 122–123
- “Relentlessly Resourceful” (Graham), 11
- reliability
 - design for, 161–163
 - in prototyping, 193
- Reliability Prediction of Electronic Equipment*, US military handbook MIL-HDBK-217F, 30
- reMarkable, 203
- repairability, 7
- requirements, 4–9
 - achieving, 7–8
 - avoiding feature creep, 8
 - changing, 9
 - commonly overlooked, 6–7
 - talking to users, 8–9
 - writing, 5–6
- reset, checking for parts held in, 284
- resistors, 38–41
 - common values, 40–41
 - current-sense, 38–39, 96
 - derating, 39
 - ESD damage, 38
 - feedback, 108
 - high-power, 39
 - network to divert RF signal to connector, 116
 - pull-up, 92–93
 - “pulse withstanding,” 39
 - reducing Q of oscillators with, 100
 - standard values, 40
 - temperature effects, 38–39
 - tolerance, 38
 - as voltage dividers, 39–40
 - 0W for debugging, 96–97
- resonant frequency, 66–67
- resource recommendations, 301–306
 - chip fabrication, 305
 - component distributors, 305
 - contract manufacturers, 302–303
 - design services, 305
 - fulfillment, 306
 - materials, 304
 - paperwork, 304
 - part fabrication, 303–304
 - PCB fabrication and assembly, 302
 - shipping and logistics, 304–305
 - tools, 301–302
- restriction of hazardous substances (RoHS), 7, 236
- reverse bias protection, 62, 93
- reverse voltage, 76
- review checklist, 92–95
- rework, 11
- RF (radio frequency) components
 - amplifiers, 72–74
 - choosing, 72
 - connectors and cables, 48–50
 - frequency-dependent parameters, 72
 - layer transitions, 110
 - prototyping tools, 201–202
 - substrates, 122
- RF Explorer, 222
- RFMW, 21–22, 230, 305
- RG-223 cables, 49
- rheology, 246
- Richardson RFPD, 230, 305
- Rierson, Leanna, 5
- right-angle turns, 119–120
- Right the First Time* (Ritchey), 117
- rigid coaxial cables, 49
- Rigol, 220
- rise time, 112–113
- rising edge electrical length, 48
- risk
 - product and technical, 189
 - reducing, 11–12
- Ritchey, Lee, 117

- Rocketbook, 203
- Rogers, 122, 194
- Rohde & Schwarz, 217, 222
- RoHS (restriction of hazardous substances), 7, 236
- rosin flux, 243
- RTL-SDR, 201, 222
- Rubber Captain, 303
- Rush Order, 306
- RX, labeling clearly, 95
- Ryder Industries, 302

S

- safety
 - connectors and cables, 50–51
 - lab, 209–210
 - soldering, 251
- Saleae logic analyzers, 221
- sales engineers, 19
- Sanmina, 302
- schedules, 11–13
- schematic design
 - conventions, 83–92
 - formatting, 90–92
 - labeling and organization, 84–89
 - supplemental information, 89–90
 - cost reduction in, 177–179
 - debugging, 95–97
 - development boards in, 94
 - ensuring performance, 97–101
 - amplifiers, 101
 - capacitors for ICs, 99
 - factors and tips for, 97–98
 - ferrite beads, 99–100
 - review checklist, 92–95
 - sheet sizes for, 91
- Schottky diodes, 76
- Schox Patent Attorneys, 304
- Scientific Notebook Company, 203
- scientific troubleshooting, 292–293
- SCR (silicon-controlled rectifier)
 - latch-up, 59–60
- screwdrivers, 225
- Sculpteo, 303
- SDR (software-defined radio), 201–202
- secondary batteries, 77
- Seeed Studio Fusion, 240
- selective wave solder machines, 247

- self-resonant frequency (SRF), 33
- selling prototypes, 191
- semi-rigid coax, 49
- series-shunt EMI filters, 56
- SEUs (single-event upsets), 59–60
- Shapeways, 303
- shielding, 172–173
 - for Arduino, 200
 - cables, 48
 - inductors, 42
 - vias, 167–168
- ShipBob, 305
- shipping and logistics, companies for, 304–305
- Shipwire, 306
- shoot through (avalanche breakdown), 283
- shortcuts, taking, 194
- shunt-series EMI filters, 56
- side-wettable QFNs, 21, 156
- SiFive, 305
- Sigmatron, 240
- signal filters, 170
- signal integrity, 170–171
- signal measurement in high-speed design, 115–117
- signs in medical model of troubleshooting, 288
- silent failure, 278
- silicon-controlled rectifier (SCR)
 - latch-up, 59–60
- silicone conformal coating, 255
- SiliconExpert, 21
- silicon oscillators, 67
- silkscreening
 - design for test, 159
 - fabrication notes, 310
 - markings, 145–148, 154–155
 - resolution, 145
- Simple Global, 306
- simplicity in troubleshooting, 196
- single-event upsets (SEUs), 59–60
- single-pole EMI filters, 55
- SkyWater, 305
- Small Batch Assembly, 302
- small hand tools, 224–225
- Smith, Larry, 99
- SMPS. *See* switched-mode power supplies

- SMT (surface-mount) components, 23–24, 153–154, 177
- SN100C, 245
- SnapMagic, 141–142, 302
- soft starts, 98
- software-defined radio (SDR), 201–202
- soldering, 242–248
 - design for assembly, 155–156
 - flux, 243–245
 - hot-bar, 45, 178
 - irons, 212–213, 242–243
 - microscopes, 213
 - reflow, 247–251
 - safety, 251
 - solder alloys, 245
 - solder mask
 - fabrication notes, 309
 - lack of, 156
 - removing, 108–109
 - solder paste, 246
 - dispensers, 215
 - presentations, 248
 - wave, 246–247
- solid particle ingress numbers, 277
- Sourcify, 305
- space, electronics in, 59–60
- SpaceX, 188
- SparkFun, 66, 197
- spark gaps, 58
- specialized distributors, 21–22
- Specialty Coating Systems, 303
- specifications, 4
 - writing, 9–10
- spectrum analyzers, 222–223
- speed
 - paying for, 11
 - speeding up hardware development, 193–197
- splitting high-speed signal traces, 113
- SRF (self-resonant frequency), 33
- stability factor, 73
- stacked microvias, 131
- stackup design, 121–135
 - example of, 134–135
 - layers, 121
 - substrates, 121–125
 - traces, 125–130
 - vias, 130–134
- staggered microvias, 131
- standards
 - for contract manufacturers, 234–237
 - for testing, 270
- Star Rapid, 303
- state of devices, mapping, 98
- stealth panelization, 152
- steering diodes, 57
- stitching vias, 167
- STM32 chips, 199
- storage
 - in labs, 215–217
 - of lithium batteries, 79
 - of PCBs, 256–257
- Storage Shelf Life and Reforming Procedures for Aluminum Electrolytic Fixed Capacitors* (US military), 31
- storytelling for demos, 296–297
- stripline transmission lines, 129–130
- StrongD Model Technology, 303
- substituting parts, 177
- substrates in stackup design, 121–125
- Summit Interconnect, 240
- supercapacitors, 32
- supplemental information in
 - schematics, 89–90
- supply voltage, checking, 92
- support for customers, 16
- surface-mount (SMT) components, 23–24, 153–154, 177
- surge suppression ICs, 61–62
- sustainability, 7
- switched-mode power supplies (SMPS)
 - in inductors, 42
 - routing under, 109
 - for voltage conversion, 67–68
- symptoms in medical model of
 - troubleshooting, 288–289
- syndromes, 289
- system integration, 258–259
- system-on-modules, 201

T

- T962 reflow ovens, 250
- tabs, 151–152
- TagConnect, 178
- Tankya, 303

- tape, 23–24, 216, 253–254
- TAP Plastics, 304
- teams collaborating, 190
- technical risk, 189
- technicians, 194
- Tektronix, 217, 220, 222
- Tek wiki, 218
- T EMI filters, 56
- temperature coefficient of Dk (TCDk), 123
- temperature coefficient of resistance (TCR), 38
- temperature effects
 - ferrite beads, 44
 - resistors, 38–39
- tenting vias, 133
- terminating digital lines, 114
- test coupons, 111–112
- testing, 257–258
 - accelerated stress, 273–274
 - amplifiers, 279
 - avoiding problems with, 278–279
 - design for, 159–160
 - designing tests, 269–278
 - electrostatic discharge, 274–275
 - failure point, 273–274
 - humidity, 275–278
 - equipment for, 217–224
 - logic analyzers, 221
 - multimeters, 219–220
 - oscilloscopes, 220–221
 - power supplies, 219
 - spectrum analyzers, 222–223
 - test leads, 221–222
 - vector network analyzers, 223–224
 - fixtures, 268–269
 - labs, 264
 - layout designs, 110–112
 - leads, 221–222
 - pads, 160
 - PCB functionality testing, 266–269
 - board bring-up, 267–268
 - test fixtures, 268–269
 - philosophy of, 261–262
 - points, 96, 110–111
 - regulatory, 263–266
 - approval marks, 263–264
 - battery certification, 266
 - electromagnetic compatibility, 264–266
 - medical device approval, 266
 - stack, 112
- thermal cameras, 267, 284
- thermal degradation, 283
- thermal epoxy, 138
- thermal imagers, 225
- thermally conductive resin, 139
- thermal management, 135–140
- thermal noise, 39
- thermal paste, 138
- thermal relief, 137
- thermal shutdown, 69
- thermal vias, 135–137
- thermodes (hot bars), 178
- thickness of stackups, 125
- third hand, 214
- through-hole components, 23, 131, 162
- time studies, 252
- tin whiskers, 161–162
- tip cleaners, 242–243
- toaster ovens, 250
- tombstoning, 137–138
- tooling holes, 152
- tools, 15
 - for assembly, 253–254
 - companies for, 301–302
 - for crimping, 53–54
 - purpose-built, 195
 - small hand tools, 224–225
- torque wrenches, 253
- Toyota Production System, 289
- traceable requirement, 5
- traces
 - powering analog circuitry, 110
 - in stackup design, 125–130
 - turns in high-speed design, 119–121
- trace weights, 110
- trace widths, 110
- transient voltage suppressor (TVS)
 - diodes, 58
- transistors, 74–76
- transmission lines, 95, 129–130
- travel sheets, 252–253
- Trio Labs, 303

- troubleshooting
 - documentation, 286, 291
 - getting to root cause of problems, 282–286
 - causes of electronics failure, 282–283
 - tips for, 283–286
 - medical model, 287–293
 - cause and effect, 289–291
 - narrative-based, 291
 - scientific, 292–293
 - signs, symptoms, and etiology, 288–289
 - simplicity in, 196
- turns in traces, 119–121
- turn time, 194
- tweezers, 224
- twisted pairs, 48
- TX, labeling clearly, 95

U

- UART, 97
- UltraLibrarian, 141
- UN38.3 certification, 266
- unambiguous requirement, 5
- under-etching in PCBs, 126–127, 238
- underfill, 20
- Underwriters Laboratories (UL), 236, 264–265
- unique parts, 177
- units in PCB layout, 140
- universal finish, 163
- Universal Serial Radio Peripheral (USRP), 201
- Upverter, 302
- urethane conformal coating, 255
- USB spectrum analyzers, 222
- USB VNAs, 223
- used equipment, 218
- users
 - defining and discovering, 9
 - feedback from, 8–10, 104–105, 189, 191
 - interviewing, 8–9
 - support for, 155
- USRP (Universal Serial Radio Peripheral), 201

V

- vapor-phase reflow, 250
- vector network analyzers (VNAs), 223–224
- verifiable requirement, 5–6
- V-grooving, 150–151
- viable requirement, 6
- via fences, 167
- vias
 - backdrilled, 131–132
 - blind, 131–132, 135, 179–180
 - buried, 131–132, 179
 - copper-filled microvias, 131
 - drilled buried, 132
 - fabrication notes, 310
 - ground, 108, 115, 117, 169
 - laser-drilled, 132–133
 - microvias, 131
 - plugged, 133
 - shielding, 167–168
 - in stackup design, 130–134
 - staggered microvias, 131
 - stitching, 167
 - tenting, 133
 - thermal, 135–137
 - vias-in-pad, 133–134
- ViewMate, 230
- VNAs (vector network analyzers), 223–224
- voltage
 - capacitance vs., 29–30
 - conversion in power supplies, 67–69
 - resistors as voltage dividers, 39–40
 - ripple, 68
 - spikes, 58
- Voodoo Manufacturing, 304

W

- Wago lever nuts, 197
- warranty plans, 262–263
- water-soluble (aqueous) flux, 244
- wavelengths, calculating for medium, 113
- wave soldering, 246–247
 - pallets, 247
- WEBENCH, 68
- Weller, 212
- windowing technique, 247–248

wires in schematics, 91
wire strippers, 225
works-like prototypes, 14, 191
Worthington Assembly, 303

X

X-Microwave, 201
Xometry, 304

Z

Zen and the Art of Motorcycle Maintenance
(Pirsig), 202
Zener diodes, 76–77
zigzag routing method, 170