1. Program Version

```
5001,25.08,1,40, 3, 1,'January 93      '
[  6, 10]  25.08  Program Edition
[ 12, 12]  1      No of Headers (ONE always)
[ 14, 15]  40     No of Lines in Header
[ 17, 18]   3     Lines per Station Id
[ 20, 21]   1     Lines per Drop
[ 24, 39]  Jan... Program Comment
```

2. Primary 'Files'

```
5002,'25SI    ','8002-XXX','9000-XXX'
[  7, 14]  25SI     SI for metric, US for english units
[ 18, 25]  8002-XXX Trailer SN
[ 29, 36]  9000-XXX Processor SN
```

3. Secondary 'Files'

```
5003,'JOHN    ','STANDARD'
[  7, 14]  JOHN     First eight characters of operator name
[ 18, 25]  STANDARD First eight characters of Test Setup name
```

4. Units & History option

```
5010,0,0,0,0,0,0,0,3,0,0,0,0,0,0,1,0,0,0,0,0,1,'MDB'
[  6,  6]  0    Temperature       0:C  1:F
[  8,  8]  0    Spare
[ 10, 10]  0    Weight(Mass)      0:kg 1:lb
[ 12, 12]  0    Spare
[ 14, 14]  0    Deflection        0:mu 1:mil
[ 16, 16]  0    Distance          0:mm 1:in
[ 18, 18]  0    Spare
[ 20, 20]  3    Location          2:m 3:km 5:feet 6:yards 7:ml 9:ml.feet
[ 22, 22]  0    Geographic angle  1:deg 2:Deg'Min 3:Deg'Min'Sec
[ 24, 24]  0    Force             0:kN  1:lbf
[ 26, 26]  0    Pressure          0:kPa 1:psi
[ 28, 28]  0    Heavy Pressure    0:MPa 1:ksi
[ 30, 30]  0    Spare
[ 32, 32]  0    Spare
[ 34, 34]  1    Angle             0:Rad 1:Deg 2:Deg.Min
[ 36, 36]  0    Spare
[ 38, 38]  0    Spare
[ 40, 40]  0    Spare
[ 42, 42]  0    Spare
[ 44, 44]  0    Spare
[ 46, 46]  1    History Mode, 1=BINARY
[ 49, 51]  MDB  Histories stored in database
```

5. Date and Time

```
5011,0,1,1991,06,05,14,07,0,'Non',000
[  6,  6]  0        Date
[  8,  8]  1        Time
[ 10, 19]  1991,06,05 Date as follows...
[ 10, 13]  1991     Year
[ 15, 16]  06       Month
[ 18, 19]  05       Day
[ 21, 25]  20,06    Time as follows...
[ 21, 22]  14       Hour
[ 24, 25]  06       Minute
[ 27, 27]  0        NA
[ 30, 32]  Non      NA
[ 35, 37]  000      NA
```

6. Load Cell

```
5200,'XX1      ',2,1.000,89.00,  0.02,  7.129
[  7, 14]  XX1       Load Cell File
[ 17, 17]  2         Type
[ 19, 23]  1.000     Relative Gain
[ 25, 29]  89.00     Absolute Gain
[ 31, 36]    0.02    Unbalanced Zero
[ 38, 44]    7.130   Shunt Value
```

7. Center SD

```
5201,'0231     ',4,1.000,1.000
[  7, 14]  0231      SD 1 (File)
[ 17, 17]  4         Type
[ 19, 23]  1.000     Relative Gain
[ 25, 29]  1.000     Absolute Gain
```

Lines 8..24 hold SD 2 to 18 similar to Line 7.

25. Plate Radius and X-Positions

```
5020,   150,     0,   200,   300,   ......
[  6, 11]     150   Radius of Plate
[ 13, 18]       0   X 1
[ 20, 25]     200   X 2
[ 27, 32]     300   X 3
    .
    .
[132,137]           X18
```

26. Diameter of Plate and Y-Positions

```
5021,   300,     0,     0,     0,   ......
[  6, 11]     300   Diameter of Plate
[ 13, 18]       0   Y 1
[ 20, 25]       0   Y 2
[ 27, 32]       0   Y 3
    .
    .
[132,137]           Y18
```

27. 'Other' Physicals

```
5022,0, 200, 201,   45,   97,  195,  386,'L123456789
[  6,  6]  0        Plate Type: 0=Standard  1=Split Plate
[  8, 11]     0     NA
[ 13, 16]     0     NA
[ 18, 22]     45    Height ONE
[ 24, 28]     97    Height TWO
[ 30, 34]    195    Height THREE
[ 36, 40]    386    Height FOUR
[ 43, ..] L123…  Active channels
```

28. Station and Lane Information

```
5023,1,4,2,  23.800,  31.200,  31.200,   0.200,   0.200,1,1
[  6,  6]  1        NA
[  8,  8]  3        NA
[ 10, 10]  0        NA
[ 12, 19]    23.800 Min Station
[ 21, 28]    31.200 Max Station
[ 30, 37]    31.200 Previous Station
[ 39, 46]     0.200 Station Step
[ 48, 55]     0.000 NA
[ 57, 57]  1        NA
[ 59, 59]  1        NA
```

29. Test Setup Options

```
5024,0,1,1,1,1,1,      0, 0.0,      0, 0.0,0,0,0, 120
[  6,  6]  0       Station Prompt
[  8,  8]  1       Temperature Prompt(s)
[ 10, 10]  1       Condition Prompt
[ 12, 12]  1       Reject Prompt
[ 14, 14]  1       Decrease Check
[ 16, 16]  1       Roll Off Check
[ 18, 23]        0 Pressure Variation
[ 25, 28]    0.0   Pressure Variation %
[ 30, 35]        0 Deflection Variation
[ 37, 40]    0.0   Deflection Variation %
[ 42, 42]  0       Temperatures "Keep"
[ 44, 44]  0       Smoothing
[ 46, 46]  0       NA
[ 48, 51]     60   Cut off (Hz)
```

30. No of Sequences, Drops total

```
5029,        4,       12,      120,      683
[  6, 13]          4 Sequences stored
[ 15, 22]         12 Drops stored
[ 24, 31]        120 Sequences
[ 33, 40]        683 Drops
```

31. Operator Name

```
5030,'John                                  '
[  7, 38]  John
```

32. Roadway Id

```
5031,'273.1864VV  KARSTENSGADE
[  7, 66]        Roadway Name
```

33. Subsection Id

```
5032,'test1
[  7, 66]        Subsection Id
```

Lines 34-35-36 presents the layout of 'Station Information'.

34. Station Id

```
5301,0,1,3,3,  31.500,1,1,        3,1991,06,05,20,07,2,"J0  "
[  6,  6]  0         NA
[  8,  8]  1         NA
[ 10, 10]  3         NA
[ 12, 12]  3         Location unit
[ 14, 21]     31.500 Station
[ 23, 23]  1         NA
[ 25, 25]  1         NA
[ 27, 34]          3 Lane
[ 36, 45]  19910605  Date
[ 36, 39]  1991      Year
[ 41, 42]  06        Month
[ 44, 45]  05        Day
[ 47, 51]  20,06     Time
[ 47, 48]  20        Hour
[ 50, 51]  06        Minute
[ 53, 53]  2        NA
[ 56, 59]  0000      NA
```

35. Comments

```
5302,0,1,8,0,0,0,0,0,'Closin" this file NOW !!
[  6,  6]  0 NA
[  8,  8]  1 NA
```

```
[ 10, 10]  8 NA
[ 12, 12]  0 Level of Cracking
[ 14, 14]  0 NA
[ 16, 16]  0 NA
[ 18, 18]  0 NA
[ 20, 20]  0 NA
[ 23, 82]  Closin" this file NOW !!
```

36. Temperatures

```
5303,0, 24.0, 27.0, 25.0
[  6,  6]  0     Temperature: 0='C  1='F
[  8, 12]   24.0 Asphalt
[ 14, 18]   15.0 Surface
[ 20, 24]   14.0 Air
```

Lines 37..40 are not used.

---------- END of HEADER ----------

TEST data are stored chronologically from line 41 and up in groups of:
'Station Information' as lines 34,35,36 above and
one or more lines of Load and Deflection PEAK READINGS.
Remarks and optional GPS information.

Load and Deflection PEAK READINGS:

```
    1,   574,   434,   396,   375,   337,  .....
    2,  1194,   907,   828,   776,   712,  .....
    3,  1677,  1283,  1155,  1095,  1001,  .....

[  1,  4]       1   Sequence Step No is 'Line ID Number'
[  6, 11]     574   Peak Load (kPa)
[ 13, 18]     434   Center Deflection
[ 20, 25]     396   SD2 Deflection
[ 27, 32]     375   SD3     -
    .
[132,137]     ---   SD18 Deflection
```

The width of these lines is ruled by the number of deflectors used.

Remarks:

```
7651,  23.846,'Railroad crossing'
 [  1,..4].   7651 to 7658 for Remarks 1 to 8
 [  6, 13]    23.800 Station
 [.16,.??]    Remark text
```

GPS Navigation Results:

```
5280,0,400743,+90.0000000,+180.0000000,999.9
[  6,  6] 0: No Failure
            1: Too few satellites
            2: DOPs too large
            3: Position STD too large
            4: Velocity STD too large
            5: Too many iterations for velocity
            6: Too many iterations for position
            7: 3 sat startup failed
            8: Initial Acq.
            9: Timeout
[  8, 13] 000000       (UTC time, seconds into the week)
[ 15, 25]  +90.0000000 Latitude (degrees, real)
[ 27, 38] +180.0000000 Longitude (degrees, real)
[ 40, 44]  999.9       Height (meters, always)
```