



PURN SANKET ELECTROLS




## Thermocouple Sensors




**HK-Spring Loaded**

"J"  "K"



**HK-Bolt In - L Bend**

"J"  "K"




**HK- Clamp Pencil - L Bend**



**HK-Spring Loaded - L Bend**

"J"  "K"




**HK-Bolt In**

"J"  "K"



**HK-Washer**




**HK-Holder Rotating**

"J"  "K"



**HK-Nozzle**

"J"  "K"




**HK- Lugs**

"J"  "K"



**HK-Spring Rotating**

"J"  "K"



**HK-Nozzle Long Tip**

"J"  "K"



**HK- Push In**

"J"  "K"




**HK- Spring Adjustable**

"J"  "K"



**HK- LBF Nozzle**

"J"  "K"



**HK- Straight Pencil**

"J"  "K"

## Special Thermocouple Sensors




"J"  "K"

**HK-Thermowell Bolt In**



"J"  "K"

**HK-Air Sensor**



"J"  "K"

**HK-Clamp On**



"J"  "K"

**HK-Head Sensor**



"R"  "S"

**HK-PT/PT/RH-High Temp**



"J"  "K"

**HK-Bare Junction**



"J"  "K"

**HK-Bolt In - MI Sensor**



"J"  "K"


**HK-MI Sensor**



"J"  "K"

**HK-QRT**

## RTD Sensor




Simplex  Duplex

**HK-Straight Pencil**



**HK-Bolt In-Duplex**




**HK-Bolt In-Simplex**



Simplex  Duplex

**HK-Head Sensor-Bolt In**



Simplex  Duplex

**HK-Head Sensor-Sanitary**




Simplex  Duplex

**HK-Spring Loaded**




## Thermocouple & RTD Probes



"J"  "K"  Pt-100

**HK-Hand Held Leaf Probe**




"J"  "K"  Pt-100

**HK-Hand Held Roller Probe**




"J"  "K"  Pt-100

**HK-Hand Held Air Probe**



"J"  "K"  Pt-100

**HK-Hand Held Needle Probe**



"J"  "K"  Pt-100

**HK-Hand Held Immersion Probe**




"J"  "K"  Pt-100

**HK-Hand Held Coated Immersion Probe**




"J"  "K"  Pt-100

**HK-Hand Held Prick Probe**



"J"  "K"  Pt-100

**HK-Hand Held Bow Surface Probe**



"J"  "K"  Pt-100

**HK-Hand Held Spring Surface Probe**



"J"  "K"  Pt-100

**HK-Hand Held Bead Probe**

## Single Level Switch



SPST  SPDT

HK-HFS-B



SPST  SPDT

HK-HFS-HB



SPST  SPDT

HK-HFS-C




SPST  SPDT

HK-HFS-PP



SPST  SPDT

HK-VFS-L-SS



SPST  SPDT

HK-HFS-F



SPST  SPDT

HK-MVFS-SS



SPST  SPDT

HK-MVFS-PP

## Multi Level Switch & Controller



**HK-VFS-2L-1F**



**HK-VFS-L-2L-1F**



**HK-VFS-2L-2F-Adj**



**HK-VFS-4L-4F**



**HK-Liquid Level Controller**

Power	230VAC
Input	2 S/W points
Output	10A 230VAC Relay



**HK-Conductivity Level Switch**

## Level Indication & Switching



**Side Arm + Float S/W**



**Top Mount**



**Magnetic Coupled**

## Thermocouple Sensors



**HK-LED 22.5**



**HK-LED 16**




**HK-NL-6F**

■ R ■ Y ■ G ■ B

■ R ■ Y ■ G ■ B

■ R ■ Y ■ G



**HK-NL-41 (C)**

■ R ■ Y ■ G



**HK-NL-41 (CH)**

■ R ■ Y ■ G



**HK-NL-30**

■ R ■ Y ■ G



**HK-NL-22**

■ R ■ Y ■ G



**HK-29 (D)**

■ R ■ Y ■ G



**HK-28**

■ R ■ Y ■ G



**HK-PL-40**

■ R ■ Y ■ G



**HK-BA9S**

■ R ■ G



**HK-NL-40**

■ R ■ Y ■ G



**HK-Toggle**




**HK-Rocker-4C**



**HK-FH**



## Ball Valve




## Solid State Relay




**Configuration Available**

- DC to AC Switching
- AC to AC Switching
- DC to DC Switching



### HK-Ball Valve

### HK-SSR & Heat Sink



## PURN SANKET ELECTROLS

### Office Address

# 311, Tapo Commercial Complex,  
Ram Mandir Road, Goregaon (West),  
Mumbai - 400104

PURN SANKET ELECTROLS

## CONTACT US

**Phone:** +91 22 4016 9611

**Mobile:** +91 9833 554 159 / +91 9820 027 701  
+91 9320 014 167

**Email:** sanketcontrols@gmail.com

**Website:** www.sanketelectrols.com