
Little and Big Endian Mystery

What are these?



Suppose integer is stored as 4 bytes (For those who are using DOS based compilers such as C++ 3.0, integer is 2 bytes) then a variable x with value 0x01234567 will be stored as following.



Memory representation of integer ox01234567 inside Big and little endian machines

How to see memory representation of multibyte data types on your machine?

Here is a sample C code that shows the byte representation of int, float and pointer.

```
#include <stdio.h>
/* function to show bytes in memory, from location start to start+n*/
void show_mem_rep(char *start, int n)
    int i;
    for (i = 0; i < n; i++)
         printf(" %.2x", start[i]);
    printf("\n");
```



}

Run on IDE

When above program is run on little endian machine, gives "67 45 23 01" as output, while if it is run on endian machine, gives "01 23 45 67" as output.

Is there a quick way to determine endianness of your machine?

There are n no. of ways for determining endianness of your machine. Here is one quick way of doing the same.

```
#include <stdio.h>
int main()
{
    unsigned int i = 1;
    char *c = (char*)&i;
    if (*c)
        printf("Little endian");
    else
        printf("Big endian");
    getchar();
    return 0;
}
```

Run on IDE

In the above program, a character pointer c is pointing to an integer i. Since size of character is 1 byte when the character pointer is de-referenced it will contain only first byte of integer. If machine is little endian then *c will be 1 (because last byte is stored first) and if machine is big endian then *c will be 0.

Does endianness matter for programmers?

Most of the times compiler takes care of endianness, however, endianness becomes an issue in following cases.

It matters in network programming: Suppose you write integers to file on a little endian machine and you transfer this file to a big endian machine. Unless there is little andian to big endian transformation, big endian machine will read the file in reverse order. You can find such a practical example here.

Standard byte order for networks is big endian, also known as network byte order. Before transferring data on network, data is first converted to network byte order (big endian).

Sometimes it matters when you are using type casting, below program is an example.

Learn more

Video tools that work as hard as you do. Collaborate and share securely.

Run on IDE

In the above program, a char array is typecasted to an unsigned short integer type. When I run above program on little endian machine, I get 1 as output, while if I run it on a big endian machine I get 256. To make programs endianness independent, above programming style should be avoided.

What are bi-endians?

Bi-endian processors can run in both modes little and big endian.

What are the examples of little, big endian and bi-endian machines?

Intel based processors are little endians. ARM processors were little endians. Current generation ARM processors are bi-endian.

Motorola 68K processors are big endians. PowerPC (by Motorola) and SPARK (by Sun) processors were big endian. Current version of these processors are bi-endians.

Does endianness effects file formats?

File formats which have 1 byte as a basic unit are independent of endianness e..g., ASCII files. Other file formats use some fixed endianness format e.g, JPEG files are stored in big endian format.

Which one is better — little endian or big endian

The term little and big endian came from Gulliver's Travels by Jonathan Swift. Two groups could not agree by which end a egg should be opened -a-the little or the big. Just like the egg issue, there is no technological reason to choose one byte ordering convention over the other, hence the arguments degenerate into bickering about sociopolitical issues. As long as one of the conventions is selected and adhered to consistently, the choice is arbitrary.







Buying 1 BHK ma

1.92 lakhs + PRE EMI Rs.10,900 pm (Nothing more till possession)

iotning more till possessior

GATE CS Corner Company Wise Coding Practice

1

Articles Bit Magic Big Endian Endianness Little Endian

Login to Improve this Article

Please write to us at contribute@geeksforgeeks.org to report any issue with the above content.

Recommended Posts:

Write an Efficient C Program to Reverse Bits of a Number

Count set bits in an integer

Check for Integer Overflow

Understanding "extern" keyword in C

Count number of bits to be flipped to convert A to B

rcp Command in Linux with examples

od command in Linux with example

help Command in Linux with examples

Things one should know before choosing Computer Science as their major

free Command in Linux with examples



Writing code in comment? Please use ide.geeksforgeeks.org, generate link and share the link here.

Load Comments

Share this post!

@geeksforgeeks, Some rights reserved



About Us!

Careers!

Privacy Policy











