Projects 7 and 15

GOAL:

Create a diagram style monitoring screen showing a schematic representation of the entire system and displaying process values on the diagram where they originate.

SUMMARY:

Now we're going to flex our HMI muscles a little bit. First, we're going to create our schematic. And then, we're going to put in our displays / indicators. That's the easy part.

We also want to show which output devices are energized and which are deenergized. Yep – animations, boys and girls… animations. We also want to show basic system status information here.

So this screen is going to be incredibly useful. It'll be a diagram of the system as well as a real-time monitor showing things coming on, shutting off, water flow changing directions and etc. It's going to be the hallmark of our HMI!

TAG USAGE:

B3:4/5	BACKWASH_PENDING	Backwash Cycle Pending
B3:4/6	BACKWASH_RUNNING	Backwash Running
F8:3	DIFF_PRES	Differential Pressure
B3:0/0	FS1	Flow Switch FS-1
F8:2	LT1_SV	Level Transmitter LT-1 (0-100 %) Scaled Value
B3:0/7	P1	Pump P-1 Bit
F8:0	PT1_SV	Pressure Transmitter PT-1 (0-20 psi) Scaled Value
F8:1	PT2_SV	Pressure Transmitter PT-2 (0-20 psi) Scaled Value
B3:0/1	SV1	Solenoid Valve SV-1 Bit
B3:0/2	SV2	Solenoid Valve SV-2 Bit
B3:0/3	SV3	Solenoid Valve SV-3 Bit
B3:0/4	SV4	Solenoid Valve SV-4 Bit
B3:0/5	SV5	Solenoid Valve SV-5 Bit
B3:0/6	SV6	Solenoid Valve SV-6 Bit
B3:3/8	SYS_RUNNING	System Running