# Projects 9 and 17

**GOAL:**

Create a trending screen which will enable the Operator to monitor process values as they change over time.

**SUMMARY:**

Are you up on all the latest trends? Well now, your HMI is going to be too!

We want to make a screen that has a graph (or graphs) which show our float values changing which updates automatically in real time.

Our monitoring screen is great, but it really only shows the Operator a running snapshot of the system – "This is what it looks like right now." But what is the pattern? Is pressure creeping up or down over time? Does a backwash reduce differential pressure to the same amount each time, or is it drifting up still?

Many such questions require a little real time monitoring in order to answer. And this is going to be the screen where all that happens....

**TAG USAGE:**

| | | |
|---|---|---|
| F8:3 | DIFF_PRES | Differential Pressure |
| F8:2 | LT1_SV | Level Transmitter LT-1 (0-100 %) Scaled Value |
| F8:0 | PT1_SV | Pressure Transmitter PT-1 (0-20 psi) Scaled Value |
| F8:1 | PT2_SV | Pressure Transmitter PT-2 (0-20 psi) Scaled Value |