# Projects 8 and 16

**GOAL:**

Implement alarms into our HMI to include a robust system of notifications as well as a screen showing the alarm history and offering appropriate controls.

**SUMMARY:**

Very rare is the system which is considered complete without alarms!

So today, we're going to be setting up our alarms in the HMI so that whatever the Operator is doing, and no matter what screen he's on, if there's an alarm, he'll know about it.

And once the alarm has been tripped, we want him to have the opportunity to either silence the alarm or reset it.

And wouldn't it also be beneficial to have a history of what alarms the system has encountered and when? Well, I agree – it totally would. So let's create a screen and make it happen!

**TAG USAGE:**

| | | |
|---|---|---|
| B3:3/9 | ALARM_RESET | Alarm Reset |
| B3:3/10 | ALARM_SILENCE | Alarm Silence |
| B3:4/14 | LEVEL_HH_ALARM | Storage Tank HH Notification Bit |
| B3:4/12 | LEVEL_LL_ALARM | Storage Tank LL Notification Bit |
| B3:4/10 | LOW_FLOW_ALARM | Low Flow Notification Bit |
| B3:4/8 | PRES_HH_ALARM | High Pressure Notification Bit |